

Preproduction model shown

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Ford dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

United States

Ford Customer Relationship Center
1-800-392-3673 (FORD)
(TDD for the hearing impaired:
1-800-232-5952)

fordowner.com



@FordService


Canada

Ford Customer Relationship Centre
1-800-565-3673 (FORD)

ford.ca



@FordServiceCA




QUICK REFERENCE GUIDE

2015 FOCUS

Preproduction model shown



COMMONLY USED SYNC® VOICE COMMANDS

Press the voice control  on the steering wheel, and then say:

Basic Commands

- What can I say?
- List of commands
- Main menu
- Previous
- Next
- Go back
- Exit
- Help
- Pair my phone

Phone

- Phone list of commands
- Dial
- Call <name> on cell/at home/at work
- Call voicemail
- Do not disturb <On/Off>
- Listen to text messages (phone-dependent feature)



Climate**

- Climate control list of commands
- Climate temperature



Navigation**

- Navigation list of commands
- Destination street address <number, name, city>
- Destination home
- Navigation voice <On/Off>
- Navigation voice volume <increase/decrease>
- Repeat instruction
- Show <map/north-up/heading-up/3-D>
- Travel Link list of commands
- Traffic
- Weather
- Movie listings
- Fuel prices
- Sports <headlines/scores/schedule>



Entertainment

- Audio list of commands: You can also get detailed lists of commands for radio, USB, Bluetooth® audio, SiriusXM and SD card*
- Radio
 - <On/Off>
 - FM <87.9-107.9>
 - FM preset <#>
- CD
 - Play track <1-512>
 - Shuffle <On/Off>
- USB
 - Play song <name>
 - Play album <name>
- SiriusXM
 - <Channel name>
 - Preset <#>



LEARN MORE ABOUT YOUR NEW VEHICLE

Scan the country-appropriate QR code with your smartphone (make sure you have a scanner app installed) and you can access even more information about your vehicle.



fordowner.com



ford.ca

TABLE OF CONTENTS

4 – 5	INSTRUMENT PANEL
6 – 7	SYNC
8 – 10	SYNC WITH MYFORD TOUCH
11	CONVENIENCE
12 – 14	FUNCTION
15 – 17	COMFORT
18 – 19	ESSENTIAL INFORMATION

*if equipped
**available only with MyFord Touch

Some services may not be available in your area. Refer to your Owner's Manual, visit the website or call the toll-free number for more information.

For U.S. customers: visit SyncMyRide.com or call **1-800-392-3673** (select Option 1 or 2 for language, then Option 3).

For Canadian customers: visit SyncMyRide.ca or call **1-800-565-3673** (select Option 1 or 2 for language, then Option 3).

WARNING

Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.

INSTRUMENT PANEL



Preproduction model shown

1 Trunk*/Liftgate* Release

2 Cruise Control*


To Set Your Cruise Control Speed

- Press the **ON** control and release.
- Accelerate to the desired speed.
- Press the **SET +** control and release, then take your foot off the accelerator.

After you set your speed, you can press **SET +** or **SET -** to adjust your cruise speed. To disable, tap the brake, press the clutch pedal or press the **CAN** (Cancel) control.

Note: Using the clutch pedal to cancel a set speed may cause the engine speed to increase briefly.

*if equipped



Preproduction model shown

3 Information Display

Provides information about various systems on your vehicle. Use the left, 5-way controls, located on the steering wheel, to choose and confirm settings and messages. Refer to the *Information Displays* chapter of your *Owner's Manual* for more information.

4 Service Engine Soon Light

Lights briefly when you switch the ignition on. If it remains on or blinks after you start the engine, the On-Board Diagnostics (OBD-II) system detects a problem. Drive in a moderate fashion and contact your authorized dealer as soon as possible.

5 Wiper Controls

Use the rotary control on the lever to adjust the wipe intervals. Pull the lever toward you to spray and wash the windshield. Press the button at the end of the lever to turn the rear wiper* on, off or change to intermittent wipe.

6 Steering Wheel Controls*

Use the right-hand, 5-way controls to adjust the following features:

Press **VOL +** or **-** to increase or decrease volume levels.

Press the right arrow **▶▶** to hear the next saved radio station, CD track or MP3 choice. Press the left arrow **◀◀** to hear the previous selection.

Press **Ⓜ** to access voice recognition.

Press **☎** to answer a call.

Press **⏏** to exit phone mode or end a call.



7 Push Button Start*

Allows you to start your vehicle by pressing the **START STOP** button while fully pressing down on the brake (automatic transmission) or clutch and brake (manual transmission) pedal(s). Press the button again to switch the engine off.

Note: Your intelligent access transmitter must be inside the vehicle for keyless starting to work.

8 Tilt/Telescope Steering Column

Unlock the steering wheel by pulling the lever down. Adjust the wheel to the desired position. Push the lever back up to lock the steering wheel in place.

9 Hazard Warning Flashers

*if equipped

Getting Started with Your SYNC System

SYNC is a hands-free, voice recognition system used for entertainment, information and communication. SYNC. Say the Word.

Before You Get Started

1. Set up your owner account at SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada). Register by following the on-screen instructions. After registering, you can see what available services you are eligible for.
2. SYNC uses a wireless connection called **Bluetooth**® to communicate with your phone. Turn **Bluetooth** mode on in your phone's menu options. This lets your phone find SYNC. If you need more details on setting up your phone with SYNC, visit SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada), or your phone manufacturer's website.

Pairing Your Phone with SYNC

In order to use many of the features of SYNC, you must first pair and connect your phone with SYNC.

To Pair Your Phone for the First Time

1. Make sure that your vehicle is in park (P) or neutral (N) with the parking brake applied (for vehicles with manual transmissions only) and you switch your ignition and radio on.
2. Press the phone button. When the display indicates no phone is paired, press **OK**.
3. When **Find SYNC** appears in the display, press **OK**.
4. Put your phone into **Bluetooth** discovery mode. See your phone's user guide, if necessary.
5. When prompted on your phone's display, enter the six-digit PIN provided by SYNC in the radio display.

The System May Prompt You to

- Set your phone as primary or favorite (the primary phone receives messages and voicemail).
- Download your phone book (required to use the full set of voice commands).
- Turn on 911 Assist®.

Tips

- Make sure you accept the request from SYNC to access your phone.
- To pair subsequent phones, please refer to *Pairing Subsequent Phones* in the SYNC chapter of your *Owner's Manual*.
- If you experience pairing problems, try performing a clean pairing by deleting your device from SYNC, deleting the SYNC connection from your phone, and then repeating the *Pairing Your Phone with SYNC* process.

Preproduction model shown

*if equipped



Why Do You Need a SYNC Owner Account?

A SYNC owner account is required to receive the latest software updates that add new places, directions and information; and if you have questions, you'll get free customer support.

Note: Your SYNC system may offer advanced features such as AppLink™. Some services may not be available in your area. Visit the website or call the toll-free number for more information. See the inside front cover of this guide for details.

Using Your Phone with SYNC

Note: You must download your phone book to make phone calls with voice commands by name.

Making a Phone Call

Use SYNC to make a phone call to anyone in your phone book by pressing the voice control **Ⓜ**. When prompted, give a voice command.

For example, you could say **"Call Jake Smith at home"**. SYNC repeats the command back to you and dials the number.

Note: You can also make phone calls by pressing the voice button **Ⓜ**. When prompted, give the voice command **"Dial"**, then say the phone number.



Answering Incoming Calls

Whenever you have an incoming call, the display shows the name and number of the person calling. Press the phone button **Ⓜ** to answer an incoming call. You can hang up at any time by pressing the phone button **Ⓜ**.

Do Not Disturb Mode

This feature blocks incoming calls and text messages, and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command **"Do not disturb on"** to enable and **"Do not disturb off"** to disable.

Using SYNC to Access Digital Media

Plug in your USB media devices such as phones and MP3 players, and use SYNC to play all of your favorite music.


Note: SYNC indexes your music. The more music that is stored on your device, the longer it takes SYNC to index.

Using Voice Commands to Play Music

1. Plug your media player into your USB port.
2. Press the voice control **Ⓜ**. When prompted, say **"USB"**, and then follow-up with a voice command.

SYNC® WITH MYFORD TOUCH®*

A REVOLUTIONARY WAY TO CONNECT WITH YOUR VEHICLE.




Getting Started, Understanding SYNC with MyFord Touch

Use the four-corner, four-color touchscreen to explore and interact with your vehicle. The touchscreen works the same way traditional controls, knobs and buttons do. Press the various corners on your touchscreen to personalize the many features and settings of your vehicle all in one place. The system provides easy interaction with your cellular phone, multimedia entertainment, climate controls and navigation system*.

*if equipped

General Tips

- Press the home icon  at any time to return to your home screen.
- For additional support, refer to your *Owner's Manual*, visit the website or call the toll-free number. See the inside front cover of this guide for details.

Before You Get Started

- Pair your phone with SYNC before using MyFord Touch. See the *Getting Started with Your SYNC System* section for instructions on how to do this.
- Make sure to insert your navigation SD card* into the media port or your navigation features cannot work.



Get in Touch Using Your Four-corner Touchscreen

Phone, Navigation*, Climate and Entertainment are the four main operations of SYNC® with MyFord Touch®. Each feature has its own corner represented by its own color.

Phone

Voice-control your phone for hands-free calling with your phone securely put away. With SYNC, you won't even need to know the phone number. Just say the name of the person you want from your contacts.

Your Phone Connects You with Many Other Features

- Automatically connect with a 911 operator in the event of an accident (if set to **ON** prior to the incident).
- Transfer calls seamlessly from SYNC to phone as you get in or out of your vehicle.

Refer to the *MyFord Touch* chapter of your *Owner's Manual* for complete details.

Navigation*



Get started with your navigation system by pressing the upper-right, green corner.

The available voice-activated navigation system includes:


- SiriusXM Traffic™
- SiriusXM Travel Link™
- GPS (Global Positioning System) technology
- 3-D mapping
- Turn-by-turn navigation

Some features require activation. Refer to the *MyFord Touch* chapter of your *Owner's Manual* for complete details.

Set a Destination



Set a destination through your touchscreen by using a street address, a city center, a place on the map or a point of interest (POI). The easiest way, however, is by voice.

1. Press the voice control  . When prompted, say **"Destination street address"**.
2. The system asks you to say the full address and then displays an example on-screen.
3. You can then speak the address naturally, such as: **"One two three Main Street, Anytown"**.

You can also choose from up to three different types of routes:

- **Fastest:** Uses the fastest moving roads possible.
- **Shortest:** Uses the shortest distance possible.
- **Eco (EcoRoute):** Uses the most fuel efficient route.

Tips

- Save your favorite locations by touching **"Save to Favorites"**.
- Change your map views from Heading Up, North Up or 3-D.

*if equipped



Climate

SYNC with MyFord Touch controls the temperature, airflow direction and fan speed for you and your front passenger.

To use voice commands to operate the climate controls, say a voice command like **“Climate temperature 72 degrees”** and MyFord Touch makes that adjustment.

Set Your Temperature

- Touch the lower-right, blue corner on the touchscreen.
- Set your exact, desired temperature using the + or – buttons.



Entertainment

No matter how you store your music, SYNC makes it yours to enjoy when you're behind the wheel. Press the lower-left, red corner of the touchscreen. From here, you can easily go between AM, FM, SiriusXM and other media sources. Use your touchscreen or the audio controls on your steering wheel to interact with your digital media.

Bring in Your Own Music

Gain access to any audio source by voice and even control how each operates, like changing radio stations, CD tracks or music on one of the following devices:

- USB
- Bluetooth® streaming
- SD card*
- Audio in

For additional support, refer to your *Owner's Manual*, visit the website or call the toll-free number. See the inside front cover of this guide for details.



*if equipped

CONVENIENCE

Intelligent Access*


Note: Your intelligent access transmitter must be within 3 feet (1 meter) of your vehicle.

To unlock a front door: Pull the front exterior door handle.

To lock all of the doors: Press and hold the door handle lock sensor.

To unlock and open the trunk* or liftgate*: Press the exterior trunk release button near the license plate.

The intelligent access transmitter also contains a mechanical key blade, that you can use to unlock the driver door, if necessary.





Preproduction model shown

Remote Start*

Remote start allows you to start the engine from outside your vehicle using your transmitter.

To Start

1. Press  and then press  twice within three seconds.
2. Once inside, press the brake while pressing the **START STOP** button.

MyKey®

Allows you to program speed restrictions, limited volume levels, safety belt reminders and more. For complete information, refer to the *MyKey* chapter in your *Owner's Manual*.



*if equipped

Rear View Camera

Provides a video image of the area behind the vehicle in the display in the center of the instrument panel. The image automatically appears when the vehicle is in reverse (R) and uses green, yellow and red guides to alert you of your proximity to objects.



PowerShift Six-speed Automatic Transmission*

We designed this transmission for fun-to-drive performance and exceptional fuel efficiency, by using the advantages of a manual transmission with the convenience of an automatic transmission.

You may notice the following characteristics of this technology:

- Although the gears shift automatically, the shifting feel and sound experienced from the PowerShift transmission are similar to those of a manual transmission, which is normal.
- The PowerShift transmission continuously makes electronic adjustments to optimize shift quality. During the initial break-in period, you may feel slight vibrations when accelerating your vehicle from low speeds.



See the *Transmission* chapter of your *Owner's Manual* for more details.

Integrated Blind Spot Mirrors

Designed to assist you by increasing the visibility along the side of your vehicle.


- The integrated convex mirror is within the upper outboard corner of the exterior mirrors.
- When an approaching vehicle moves toward you, the reflection appears first in the main mirror, and then in the blind spot mirror.



Active Park Assist*



The active park assist system can detect an available parallel parking space and automatically steer the vehicle into that space (hands-free). The system instructs the driver with visual and audible instructions with regard to braking, accelerating and shifting gears in order to safely park the vehicle.

- To initiate active park assist, press the  button located on the center console.
- To stop the parking procedure, grab the steering wheel or press the control again. For complete information, refer to the *Parking Aids* chapter in your *Owner's Manual*.

Note: The driver is always responsible for controlling the vehicle, supervising the system and intervening, if required.

Autolamps*

The headlamps turn on and off automatically in low light situations or during inclement weather. They remain on for a period of time after you switch the ignition off. You can adjust the time delay through the information display controls.



Preproduction model shown

Towing Your Focus

Towing your Focus behind an RV or any other vehicle may be limited. Refer to *Towing the Vehicle on Four Wheels* in the *Towing* chapter of your *Owner's Manual*.

Headlamp Exit Delay

After you switch the ignition off, you can switch the headlamps on by pulling the direction indicator lever toward you. A short tone sounds. The headlamps turn off automatically after three minutes with any door open or 30 seconds after you close the last door. You can cancel this feature by pulling the direction indicator toward you again or switching the ignition on.

*if equipped

*if equipped

Ambient Lighting*

The ambient lighting system lights the interior with a choice of several colors. The ambient lighting control is in the overhead console. Rotate the control knob to switch the feature on and adjust the desired brightness. Press the palette button to cycle through your color choices.

Ambient lighting switches on when:

- You switch the ignition on.
- You switch the headlamps on.

Traction Control

The traction control system helps avoid drive wheel spin and loss of traction.

If your vehicle begins to slide, the system applies the brakes to individual wheels and, when needed, reduces engine power at the same time. If the wheels spin when accelerating on slippery or loose surfaces, the system reduces engine power in order to increase traction.

In certain situations (for example, stuck in snow or mud), turning the traction control off may be beneficial as this allows the wheels to spin with full engine power. You can switch this feature off in the information display.

Interior Lamps

The lamps turn on when you open any door, press a remote control button or press the overhead control.

Press  to switch off the door illumination function when you open any door.

Press  again to switch the door illumination function back on.

Press  to switch the overhead lamps on and off.



**if equipped*



AdvanceTrac® Stability Control System

The system helps you keep control of your vehicle when on a slippery surface. The electronic stability control portion of the system helps avoid skids and lateral slides, while the traction control system helps avoid drive wheel spin and loss of traction.

Preproduction model shown



Tilting Head Restraints*



You can adjust your vehicle's front-row head restraints.

To raise: Pull up on the head restraint.

To lower: Press the head restraint down while pressing and holding the guide sleeve adjust and release button.

To tilt the head restraint: Gently pull the top of the head restraint forward.

To return it to its upright position: Tilt it forward once more and release.

Note: Do not attempt to force the head restraint backward after tilting it. Instead, continue tilting it forward until the head restraint releases to the upright position.

Front-Seat Adjusters


Height/Recline Adjustment



Adjust the height of the driver seat by lifting the lever.

Adjust the angle of the seatback by lifting the control.

Heated Front Seats*

Press the heated front seat  control on the instrument panel or use the touchscreen.

Dual Zone Temperature Control*

You can operate the temperature with one control, called single zone, or two, called dual zone where both driver and front passenger can select independent temperatures using their own rotary dials.

To operate the dual zone: Use the rotary control on the passenger's side. Single zone automatically shuts off. You can now adjust the driver's side and passenger's side temperatures independently.

To return back to single zone: Press and hold the **AUTO** button for 2–4 seconds. The passenger's temperature switches to the driver's temperature setting.



**if equipped*

Auxiliary Power Points

The power points are on the center console or in the center console, depending on your vehicle style. You can use the power point to power your smaller electrical devices that require up to 180 watts. Run the vehicle for full-capacity use of the power point.

To prevent the battery from discharging:

- Do not use the power point longer than necessary when the vehicle is not running.
- Do not leave devices plugged in overnight or when the vehicle is parked for extended periods.



Rear Window Buffeting

You may hear a pulsing noise when just one of the windows is open. Lower an opposite window slightly to reduce this noise.

- Press the control to open the window.
- Lift the control to close the window.

Folding the Rear Seats

Your rear seatback can fold down for more versatile cargo storage and transport. Your vehicle may have split seatbacks* that must be folded individually.

To lower the seatback(s), do the following:

- Remove the outboard head restraint(s).
- Press the unlock buttons located on the top outboard sides of each seatback.
- Push the seatback forward.

Note: Make sure you stow the safety belt in the belt stowage clip to prevent it from getting caught in the seat latch.

- In vehicles with split-folding seatbacks, you can flip the seat cushions forward before folding the seatback for additional cargo space.
- When raising the seatback(s), make sure you hear the seat latch into place and that no red portion is visible on the release button on both sides.



**if equipped*

Moonroof*

The control is in the overhead console and includes a one-touch open and close feature. To stop the motion during a one-touch operation, press the control a second time.

- Press and release the rear of the control to open the moonroof. The moonroof stops short of the fully opened position. This position helps to reduce wind noise.
- Press and release the control again to fully open the moonroof.
- Press and release the front of the control to close the moonroof.



Preproduction model shown



Trunk*/Liftgate* Release

To open the trunk or liftgate from the inside of your vehicle, press the button located on the instrument panel, near the headlamp switch.

With your vehicle unlocked, you can open the trunk or liftgate from the outside by pressing the release button located under the handle and above the license plate.

With your vehicle locked and the intelligent access transmitter* within 3 feet (1 meter) of the trunk or liftgate, press the release button located above the license plate to open it.

You can also use the keyless remote.



**if equipped*

Tire Pressure Monitoring System

Your vehicle displays a low tire pressure warning light (⚠) in your instrument cluster when one or more of your tires are significantly under-inflated. If this happens, stop and check your tires as soon as possible, then inflate them to the proper pressure. Refer to the Inflating Your Tires section in the *Wheels and Tires* chapter of your *Owner's Manual* for more information.

Preproduction model shown



Fuel Tank Capacity/Fuel Info

Your vehicle has a 12.4 gallon (46.9L) fuel tank capacity.

If your vehicle has a yellow ring around the fuel inlet, you have a flex fuel vehicle and can use either regular unleaded fuel, E85 ethanol fuel or any mixture of the two.

Some tips to keep in mind with an E85 vehicle:

- It is best not to alternate repeatedly between gasoline and E85. If you do switch fuels, it is recommended that you add as much fuel as possible, at least half a tank.
- Do not add less than 5 gallons (18.9L) when refueling.
- You should drive the vehicle immediately after refueling for at least 5 miles (8 km) to allow the vehicle to adapt to the change in ethanol concentration.
- If you exclusively use E85 fuel, we recommend to fill the fuel tank with regular unleaded gasoline at each scheduled oil change.
- Non-flex fuel vehicles use only UNLEADED fuel with a minimum octane rating of 87. **Do not use fuel (E20-E85) ethanol (E85), diesel fuel, fuel-methanol, leaded fuel or any other fuel because it could damage or impair the emission control system.**

Location of Spare Tire and Tools

Your spare tire and tools are under the carpeted floor panel in the rear of your vehicle.

- The spare tire is designed for emergency use only. You should replace it as soon as possible.
- For complete details on changing your tire, refer to the *Changing a Road Wheel* section in the *Wheels and Tires* chapter of your *Owner's Manual*.



Easy Fuel® System



To use, put your vehicle into park (P) and switch the ignition off. Open the fuel-filler door. Insert the nozzle. Begin fueling. Wait 5–10 seconds between the time the refueling nozzle is shut off until you remove the nozzle from the vehicle to allow residual fuel in the nozzle to drain into the tank. When using a portable fuel container, slowly insert the fuel funnel (located in the spare tire compartment) and pour the fuel into the funnel.

Note: Do not use aftermarket funnels as they do not work with the Easy Fuel system and may cause damage. Properly clean the funnel after each use.



Front and Rear Sensing Systems*

Each system sounds an audible warning tone if there is an obstacle near the vehicle's front or rear bumpers.

- As the vehicle moves closer to the obstacle, the rate of the warning tone increases in frequency.
- The front sensors automatically activate when the vehicle is in drive (D) and detect objects up to 28 inches (70 cm) away.
- The reverse sensors activate automatically when the vehicle is in reverse (R), and detect objects up to 71 inches (180 cm) away.
- See the *Parking Aids* chapter in your *Owner's Manual* for complete information on your vehicle's sensing systems.

Note: Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your *Owner's Manual* for safety information, more details and limitations.

SelectShift Automatic® Transmission*



Gives you the ability to manually change gears, if you like. To use, move the gearshift lever from drive (D) to sport (S). Press the + or – thumb toggle on the side of your gearshift lever or pull the + or – paddles on your steering wheel to upshift or downshift.

Roadside Assistance

Your new Ford vehicle comes with the assurance and support of 24-hour emergency roadside assistance.

To receive roadside assistance in the United States, call 1-800-241-3673. In Canada, call 1-800-665-2006.