

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual, which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Ford dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

WARNING

Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.

United States Ford Customer Relationship Center

1-800-392-3673 (FORD)
(TDD for the hearing impaired:
1-800-232-5952)

owner.ford.com



Canada Ford Customer Relationship Centre

1-800-565-3673 (FORD)
(TDD for the hearing impaired:
1-888-658-6805)

ford.ca



Learn More About Your New Vehicle

Scan the country-appropriate QR code with your smartphone (make sure you have a scanner app installed) and you can access even more information about your vehicle.




owner.ford.com (U.S.)



ford.ca (Canada)

JE8119G217 AA



Ford

FIESTA




Quick Reference Guide 2018

Go Further



commonly used voice commands

SYNC® Say the Word.

Press the voice button  on the right side of your steering wheel and then say:

Audio

- AM <530-1710>
- FM <87.9-107.9>
- *Bluetooth* Audio
- USB
- SiriusXM <0-233>³
- <Sirius channel name>³
- Help

Apps

- List mobile apps
- Find mobile apps
- <App name>
- <App name> help

Basic Commands

- Main menu
- Go back¹
- Cancel
- List of commands¹
- Next page¹
- Previous page¹
- Help

Phone

- Phone list of commands
- Pair phone
- Call <name> <on cell/
at home/at work>
- Dial <number>
- Listen to message

Navigation^{1,2}

- Navigation list of commands
- Destination
 <home/previous destination>
- Find
 <an address/POL/intersection>
- Show <route>
- Where am I?
- SiriusXM Traffic and Travel Link³
 list of commands
 - » Show
 <traffic/weather map/
 5-day forecast/fuel prices>
 - » Help

¹ only available with SYNC 3

² if equipped

³ *SiriusXM may not be available
in all markets. Activation and a
subscription are required.*

Some services may not be available in your area. Refer to your **Owner's Manual**, visit the website or call the toll-free number for more information.

For U.S. customers: Visit owner.ford.com or call 1-800-392-3673 (select Option 1 or 2 for language, then Option 3).

For Canadian customers: Visit syncmyride.ca or call 1-800-565-3673 (select Option 1 or 2 for language, then Option 3).

table of contents

4–5 *instrument panel*

6–8 *SYNC*

9–11 *SYNC 3*

12 *comfort*






13 *convenience*

14–16 *function*

17–19 *essential information*




1. Media Steering Wheel Controls*

-  Press **+** to increase or **-** to decrease volume levels.
-  Press to access voice recognition.
-  Press to access phone mode or to answer a call.
-  Press to exit phone mode or end a call.
-  Press to tune the radio to the previous or next stored preset or play the previous or next track.

2. Trip Computer

Press the button on the end of the left-hand steering wheel lever to scroll through the trip computer displays. These displays include odometer and fuel information. Refer to the **Information Displays** chapter of your **Owner's Manual** for more information.

3. Service Engine Soon

 Normally, the service engine soon light stays on until you switch the engine on. It turns off if no malfunctions are present. If the light remains on or blinks after you start the engine, the On-Board Diagnostics (OBD-II) system detects a problem. Drive in a moderate fashion and contact your authorized dealer as soon as possible.

4. Keyless Starting*

Allows you to start your vehicle by pressing the **START STOP** button when fully pressing down on the clutch pedal (manual transmission) or the brake pedal (automatic transmission). Press the control again to switch the engine off.

Note: Your intelligent access transmitter* must be inside the vehicle for the ignition to start.

instrument panel



5. Windshield Wipers

Pull the lever down for a single wipe. Raise the lever upward for intermittent, normal or high-speed wipe. Adjust the intermittent wipe interval using the rotary control on the lever. To spray and wash the windshield, press the end of the wiper lever in. To operate the rear wiper, pull the lever toward you. To wash the rear window, pull the lever toward you.

6. Cruise Control*

To Set a Cruise Control Speed

- a. Press and release **ON**.
- b. Drive to the desired speed.
- c. Press and release **SET+**, then take your foot off the accelerator. The indicator displays in the instrument cluster confirming you have set the speed correctly.

After you set your speed, you can change it in 1 mph (2 km/h) increments by pressing **SET+** or **SET-**. To disable, press the **OFF** control.


7. Tilt and Telescope Steering Column

Unlock the steering wheel by pulling the lever down. Adjust the wheel to the desired position. Push the lever back up to lock the steering wheel into place.

8. SYNC® 3* Touchscreen*

Displays information about audio, mobile apps, settings, phone and navigation*. To operate the touchscreen, you can simply touch the item or option that you want to select. The button highlights when you select it. Refer to the **SYNC 3** chapter in your **Owner's Manual** for more information.

9. Lock and Unlock Button

Press the  button located near your audio system to lock and unlock all the doors. When you lock the doors, the button lights.

GETTING STARTED WITH SYNC

SYNC is an in-vehicle communications system that works with your *Bluetooth* wireless technology-enabled phone and portable media player.

Support

The SYNC support team is available to help you with any questions you cannot answer on your own.

In the United States, call **1-800-392-3673**.

In Canada, call **1-800-565-3673**.

Driving Restrictions

For your safety, certain features are speed-dependent and restricted when your vehicle is traveling over 3 mph (5 km/h).

SYNC Owner Account

A SYNC owner account is essential for keeping up with the latest software downloads available for SYNC. It also provides you access to customer support for any questions you may have.

Pairing Your Phone with SYNC

In order to use the many features of SYNC, you must first pair your phone with SYNC.

To Pair Your Phone for the First Time

1. Make sure that your vehicle is in park (P) and switch your ignition and radio on.
2. Press the **PHONE** button. When the audio display indicates there is no paired phone, select the option to add.
3. When a message to begin pairing appears in the audio display, search for SYNC on your phone to start the pairing process.
4. When prompted on your phone's display, confirm that the PIN provided by SYNC matches the PIN displayed on your phone. Your phone is now paired and the display indicates that the pairing was successful. If you are prompted to enter a PIN on your device, enter the PIN displayed on the screen. The display indicates when the pairing is successful.

Note: The system may prompt you to set your phone as the primary or favorite (the phone SYNC automatically tries to connect with first upon vehicle start-up) and to download your phone book.


Tips

- Make sure you accept the request from SYNC to access your phone.
- To pair subsequent phones, please refer to the **SYNC** chapter of your **Owner's Manual**.
- If you experience pairing problems, try deleting your device from SYNC, deleting SYNC from your device and trying again.

Using Your Phone with SYNC

Note: You must download your phone book to make phone calls with voice commands by name.

Making a Phone Call

Use SYNC to make a phone call to anyone in your phone book by pressing the voice button  and when prompted, say any of the following voice commands:

"Call <name>"



"Call <name> at work or home"

"Call <name> on mobile or cell"

For example, you could say, **"Call Jake Smith at home"**. SYNC repeats the command back to you and dials the number.

Note: You can also make phone calls by giving the voice command **"Dial"**, then verbally say the phone number.

Answering Incoming Calls

Whenever you have an incoming call, the name and number of the person calling appear in your display. Press the phone button  to answer an incoming call. You can hang up at any time by pressing and holding the phone button .

Using the display, you can choose from privacy mode (listen and talk through your phone) or open mode (listen and talk through your vehicle's speakers and microphone).



SYNC AppLink®: Voice Access to Your Mobile Apps

The available SYNC AppLink* allows you voice access to select mobile apps that you already have or can download to your Android™ or iPhone®.

Using SYNC AppLink

1. Make sure that you have an active account online for the app you want and make sure you set it up the way you like it. Some apps work automatically with no setup.
2. Download or update to the latest mobile app through your smartphone's marketplace.
3. Switch the ignition on.
4. Pair the phone to your vehicle. If you already paired your phone to the vehicle, it connects to SYNC automatically when you enter the vehicle.
5. If you are an iPhone owner, you must also connect the Apple®-provided USB cable and start the app you want to use on your phone through SYNC. Android can connect wirelessly using SYNC AppLink.
6. Now you are ready to voice-access the app by pressing the voice button and saying, "**Mobile Apps**", and then the name of the app you want.



SYNC® 3*

Using SYNC 3

The SYNC 3 system allows you to interact with a variety of features using the touchscreen and voice commands. By integrating with your *Bluetooth* wireless technology-enabled phone, the touchscreen provides easy interaction with audio, multimedia, navigation*, and your phone's SYNC compatible apps.



Pairing Your Phone with SYNC 3

Pair your *Bluetooth*-enabled phone with the system before using the functions in hands-free mode.

1. Select **Add Phone**.
2. Follow the on-screen instructions.
3. A prompt alerts you to search for the system on your phone.
4. Select your vehicle's make and model as it displays on your phone.
5. Confirm that the six-digit number appearing on your phone matches the six-digit number on the touchscreen.
6. The touchscreen indicates when the pairing is successful.
7. Your phone may prompt you to give the system permission to access information. To check your phone's compatibility, visit owner.ford.com.

Phone

After pairing your phone, you can access more phone-dependent features:

- **Recent call lists.**
- **Contacts:** Sort alphabetically and choose a specific letter to begin viewing your entries.
- **Phone settings:** Pair another phone, and set ring tones and alerts.
- **Text messages.**
- **Do not disturb:** Send all calls to your voicemail, and all ring tones and alerts are set to silent mode.

Note: Refer to the **SYNC 3** chapter in your **Owner's Manual**, owner.ford.com (U.S.) or syncmyride.ca (Canada) for details.

Smartphone Connectivity

SYNC 3 allows you to use Apple CarPlay and Android Auto to access your phone over a USB connection.

When you use Apple CarPlay or Android Auto, you can:

- Make calls.
- Send and receive messages.
- Listen to music.
- Use your phone's voice assistant.

For more information, refer to the **SYNC 3** chapter in your **Owner's Manual** for details.

Navigation*

Press the **Navigation*** icon to set your destination. Select one of two ways to find your destination:

- Destination mode lets you key in a specific address or use a variety of search methods to locate where you want to go.
- Map mode shows advanced viewing of 2D city maps, 3D landmarks and 3D city models (when available).

Refer to the **SYNC 3** chapter in your **Owner's Manual** for complete details.

Set a Destination

Press **Destination** on your touchscreen and then press **Search**. Enter a street address, intersection, city or a Point Of Interest (POI).

After you choose your destination, press **Start**. The system uses a variety of screens and visible prompts to guide you to your destination.

During your route, you can press the maneuver arrow icon on the map if you want the system to repeat the previous route guidance instructions.

The navigation map shows your estimated time of arrival, remaining travel time or the distance to your destination.

Navigation Menu

While you are on your route, you can change your touchscreen view. Touch **Menu** and then select **Screen View** to select from these options:

- Full Map.
- Highway Exit Info displays on the right side of the touchscreen. View POI icons (restaurants, ATMs, etc.) as they pertain to each exit. You can select a POI as a waypoint, if you wish.
- Turn List shows all of the available turns on your current route.



Settings

Touch the **Settings** icon to customize information within your vehicle. Adjust the clock, display, some vehicle features and sound settings.

Audio

No matter how you store your music, SYNC makes it yours to enjoy when you are behind the wheel. Just press the **Audio** icon on the touchscreen. From here, you can easily go between AM, FM, SiriusXM and other media sources.

Set Your Radio Presets

- Tune to the station and then press and hold one of the preset buttons. The audio mutes briefly while the system saves the station, and then the audio returns.
- Two preset banks are available for AM, while there are three banks for FM and three banks for SiriusXM*. To access additional presets, tap the preset button. The indicator on the preset button shows which bank of presets you are currently viewing.



Using SYNC 3 to Access Digital Media

Play all of your favorite music from phones, flash drives and other devices.

Plug your device into a USB port, select **Sources** and then choose **USB**. Wait for the system to finish indexing your music to begin listening.

You can use the **Shuffle** function to create random playlists.

Refer to the **SYNC 3** chapter in your **Owner's Manual**, visit the website or call the toll-free number for more information.

comfort



Moonroof*

Your moonroof controls are on the overhead console.

To open, press and release the rear of the **SLIDE** control. The sliding shade automatically opens, if closed, while the moonroof opens.


To close, press and hold the front of the **SLIDE** control. Close the sunshade manually.




To vent the moonroof, press and hold the rear of the **TILT** control.

To close from a venting position, press and hold the front of the **TILT** control.

Heated Seats*

Press  once for seat heating. The light on the control illuminates.

Press  again to switch off the seat heater. The light on the control turns off.



convenience

Passive Key*

Locking buttons are located on each of the front doors.

Locking your vehicle





For central locking and to arm the alarm, press a locking button once. When you lock your vehicle, the direction indicators will flash to confirm your vehicle has locked and the alarm is armed.

Unlocking your vehicle

Press a locking button once. When you unlock your vehicle, the direction indicators will flash to confirm your vehicle has unlocked and the alarm has disarmed.

Note: A valid passive key must be located within the detection range of that door.

Integrated Keyhead Transmitter and Intelligent Access Remote Entry Icons*


- Press  once to lock all doors. Press again within three seconds to confirm all doors are locked.
- Press  once to unlock the driver door. Press again within three seconds to unlock all of the doors.
- Press  twice within three seconds to open the luggage compartment or liftgate.
- **Car finder:** Press  twice within three seconds to locate your vehicle. The horn sounds and the direction indicators flash.

MyKey®*

MyKey allows you to program certain driving restrictions in order to promote good driving habits. You can program settings such as speed restrictions and limited volume levels. For complete information, refer to the **MyKey** chapter in your **Owner's Manual**.

Autolamps*

When you switch autolamps  on, your headlamps turn on and off automatically in low-light situations or when the wipers turn on.



Front Seat Adjusters


Lift the controls to adjust your seat position.

Recline Adjustment

Pull the control to adjust the angle of the seatback.

Height Adjustment

Lift the control to adjust the seat cushion height.

**Folding Rear Seatback with Adjustable Head Restraints**


You can fold down the rear seatbacks for more cargo space. To do this, make sure the adjustable rear head restraints are in the lowest position. Press and hold the release buttons on the seatback and push the seatback forward. When raising the seatback(s), make sure you hear the seat latch into place. Pull down on the seatback to make sure it is latched.

Automatic Climate Control*

Automatically control the temperature, fan speed and airflow direction to reach and maintain your selected temperature.

Press the **AUTO** button to switch the automatic system on and off. Press **OFF** to switch off the climate system.

**Ambient Lighting***

Lights the interior with a choice of several colors. The ambient lighting control is in the center stack, under the climate controls. Press and release the  button to cycle through your color choices.

The ambient lighting will switch on when you switch the ignition on.

**Hill Start Assist***

The system makes it easier to pull away when you park your vehicle on a slope without using the parking brake. When active, this feature allows your vehicle to remain stationary on a slope for up to two to three seconds after you release the brake pedal. This short period gives you time to move your foot to the accelerator and pull away. This feature activates automatically if the sensors detect that the vehicle is on a slope. This feature works with both manual and automatic transmissions.

**Sport Mode and Manual Shifting***

This transmission gives you the ability to manually change gears if you would like.

To Use

- Move the gearshift lever from drive (D) to sport (S).
- Activate SelectShift using the thumb toggle located on the side of your gearshift lever to make manual shifts.
- Press the (+) button to upshift. Press the (–) button to downshift.

**USB Ports**

The USB port allows you to plug in media playing devices, memory sticks and charge devices (if supported).

Rear View Camera

This system provides a video image of the area behind the vehicle. Switch on the ignition and shift into reverse (R), and the display appears in the touchscreen.

The system uses green, yellow and red guides to alert you of your proximity to objects. The camera is on the liftgate (near the handle) or on the trunk near the license plate bracket.

**Heated Exterior Mirrors***

The outside mirrors have heating elements that defrost or de-mist the mirror glass. The feature turns on automatically when you switch on the rear defrost.

**Rear Parking Aid**

The system sounds an audible warning tone if there is an obstacle near your vehicle's rear bumper. As the vehicle moves closer to the obstacle, the rate of the warning tone increases in frequency. The rear sensors are active only when the transmission is in reverse (R), your vehicle is moving at 3 mph (5 km/h) or less, and objects are detected up to 72 inches (183 centimeters) away, with decreased coverage at the outer corners of the bumper. See the **Parking Aids** chapter in your **Owner's Manual** for complete information on your vehicle's sensing systems.

Note: *Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your **Owner's Manual** for safety information, more details and limitations.*

essential information


Rear Window Buffeting

You may hear a pulsing noise when just one of the windows is open. Lower the opposite window slightly to reduce this noise. Press the control to open the window. Lift the control to close the window.

Luggage Compartment Opening and Closing

Press the button located in the top of the liftgate pull cup handle to unlatch the liftgate, and then pull on the outside handle.

Use the Remote to Unlatch the Luggage Compartment

Press the  button twice within three seconds.



essential information



Towing Your Vehicle

Towing your vehicle behind an RV or any other vehicle may be limited. Refer to the **Towing the Vehicle on Four Wheels** section in the **Towing** chapter of your **Owner's Manual**.

Refueling

- To open the fuel filler door, press the center rear edge of the fuel filler door and then release or pull the rear of the fuel filler door to open it. Fully open the fuel tank filler door.

- Insert the fuel pump nozzle up to the first notch on the nozzle. Keep it resting on the cover of the fuel tank filler pipe opening.
- Hold the fuel pump nozzle in a level position when refueling. Holding the fuel nozzle in a raised position can affect the flow of fuel and shut off the fuel nozzle before the fuel tank is full.
- Wait at least 10 seconds, then slightly raise the fuel pump nozzle and then slowly remove it. Fully close the fuel filler door.



Note: When adding fuel from a portable container, do not use aftermarket funnels as they do not work with the capless fuel system and may cause damage. Properly clean the funnel after each use.

Fuel Tank Capacity and Fuel Info

Your vehicle has a 12.4 gallon (47 liter) fuel tank capacity. We recommend regular unleaded gasoline with a pump (R+M)/2 octane rating of 87. **Do not use E85 fuels because your vehicle was not designed to run on fuels with more than 15% ethanol.**

Location of Spare Tire and Tools

Your spare tire and tools are beneath the carpeted floor panel in the rear of your vehicle.

- The spare tire is designed for emergency use only and should be replaced as soon as possible.
- For complete details on changing your tire, see the **Wheels and Tires** chapter in your **Owner's Manual**.

Tire Pressure Monitoring System*

Your vehicle displays a low tire pressure warning light (!) in your instrument cluster when one or more of your tires are under-inflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the **Wheels and Tires** chapter of your **Owner's Manual** for more information.

Roadside Assistance

Your new Ford vehicle comes with the assurance and support of 24-hour emergency roadside assistance. To receive roadside assistance in the United States, call **1-800-241-3673**. In Canada, call **1-800-665-2006**.

