



United States
Ford Customer Relationship Center

1-800-392-3673 (FORD)
(TDD for the hearing impaired:
1-800-232-5952)

fordowner.com

Canada
Ford Customer Relationship Centre

1-800-565-3673 (FORD)

ford.ca



Follow us on Twitter:
@FordServiceCA

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Ford dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

**learn more about
your vehicle**

To put QR tags to work for you, use your mobile phone's browser or app store link to download a QR tag reader. Scan the QR tag and see your vehicle's features come to life through animation and video.

WARNING

Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.



FORDOWNER.COM



FORD.CA



QUICK REFERENCE GUIDE 2015



FM5J19G217 HA
August 2014
First Printing
Quick Reference Guide
C-MAX Energi
Litho in U.S.A.



energy saving tips

HELP MAXIMIZE YOUR FUEL ECONOMY BY UTILIZING THESE FEW TIPS

- 1. Use smooth acceleration and braking.**
According to the United States Department of Energy, aggressive driving can lower your gas mileage by up to 33 percent at highway speeds and 5 percent in the city.

2. Carry the bare essentials.
The Department of Energy estimates that an extra 100 pounds (45 kilograms) in your vehicle could reduce your fuel economy by up to 2 percent.

3. Seasonal fuel makes a difference.
Winter fuel contains slightly less energy than summer fuel, so the fuel blend you fill up with can impact your efficiency.
- 4. Idling burns fuel, too.**
You can burn up to half a gallon (1.9 liters) of fuel per hour while idling. Minimize your morning warm-up and parking lot waits to get the most out of filling your tank.

5. Avoid extreme temperatures.
Find a shady or sheltered spot to help keep your lithium-ion battery operating efficiently, and minimize the amount of energy required to heat or cool your cabin.

6. Use accessories wisely.
Heat and air conditioning reduce your vehicle's electric range and can prompt the gasoline engine to operate. Use energy from your home outlet or
- charging station by taking advantage of the preconditioning feature and setting your GO Times in advance. When you precondition your vehicle, you can reduce the amount of heating or air conditioning you need at the start of your drive. See page 3 for more SmartGauge details.

7. Check your tires.
Proper tire inflation can help you improve your fuel economy by up to 3.3 percent, according to the Department of Energy, while under-inflation could lower your fuel economy by 0.3 percent for every 1 psi drop in pressure of all four tires. Check your vehicle's door sticker for recommended cold tire inflation pressure.

C-MAX Energi smart start

SMARTGAUGE® WITH ECOGUIDE

Use your 5-way steering wheel controls to scroll through your menu choices. Select the following screens from the Display/Trip and Fuel Economy menus to help improve your fuel efficiency:

- Engage:** Provides gas and electric power-split information, plus instant and average fuel economy.
- Empower:** Provides a power demand gauge with an engine on and off threshold, plus instant and average fuel economy.
- MyView:** Lets you choose your preferred information to create your own custom display.
- Energy Use:** Helps you achieve your initial electric range estimate. Use the climate power gauge to see how much power you are losing to your climate control use.
- Efficiency Leaves:** Shows your short-term fuel economy. The more leaves you have, the more efficiently you are driving!
- Fuel History:** Tracks your fuel economy over time and helps you try to improve your average.
- Coach:** Rates the efficiency of your recent acceleration efficiency, braking and cruising behavior. The more blue you see, the better you are driving!



energy saving tips	2
C-MAX Energi smart start	3–4
unique C-MAX Energi features	5
instrument panel	6–7
SYNC with MyFord Touch	8–12
parking aids	13
convenience	14
C-MAX Energi power management	15
comfort	16
function	17
essential information	18–19

C-MAX Energi smart start (continued)

PLUG-IN POWER

- » C-MAX Energi comes equipped with a 120-volt convenience cord, located in the floor compartment behind the driver's seat. This cord allows you to charge the battery using a standard, 120-volt, grounded, three-pronged household outlet. See your *Owner's Manual* for more details.
- » For faster charge times, the available 240-volt charging station provides a full charge in approximately 2.5 hours. See your *Dealer* for more information.

CHARGE PORT DOOR AND LIGHT RING

The charge port is between the front left-side door and wheel well. To open, use your thumb to press in and release the indentation on the charge port door. To close, use your thumb to press and hold the indentation until the door rotates and closes.



TO CHARGE C-MAX ENERGI

1. Put your vehicle in park (P) and switch off the ignition.
2. Open the charge port door.
3. Plug the charging coupler into the vehicle's charge port, making sure the button clicks to latch into the port. Plug the three-prong electrical plug into a standard, 120-volt outlet. Unlock the padlock* and insert the straight end through the hole in the black button on the coupler. Lock the padlock.

4. The charge port light ring flashes twice, and then pulses slowly when charging.
5. When charging is complete, the light ring turns off. Unlock the padlock* and remove it. Then press the coupler button and remove the coupler from the charge port.

CHOOSE YOUR C-MAX ENERGI MODE

Your vehicle contains driver-selectable **Electric Vehicle (EV) modes** controlled through the EV button on the center of the instrument panel, below the climate controls.



Choose to drive in electric-only mode for city driving, saving your plug-in power for later or let the system adjust your power mode to suit the current driving conditions.

- » **Auto EV:** automatically selects high-voltage battery power during the drive, staying in electric mode when possible and running the engine when needed. After the plug-in power depletes, this mode is the only one available.
- » **EV Now:** puts your vehicle into an all-electric power experience, after you charge your vehicle using plug-in power.
- » **EV Later:** provides gasoline-hybrid driving power, and saves most of the high-voltage battery plug-in power for future use when the driver is ready to switch to **Auto EV** or **EV Now** modes.

To make the most of your C-MAX Energi and the electric vehicle lifestyle, please visit www.PlugintoFord.com.

unique C-MAX Energi features

THE BRAKE COACH



Appears after the vehicle has come to a stop. It coaches you to maximize the amount of energy returned through the regenerative braking system. The percentage displayed indicates the regenerative braking efficiency.

EV+ MODE

Learns your frequent destinations after two to four weeks of use, allowing for more EV driving as you approach them. For example, when nearing your home, it should be easier to stay in electric mode.

See the *Information Displays* chapter of your *Owner's Manual* for more details.



ECO CRUISE CONTROL

Saves vehicle energy by slowing down acceleration compared to standard cruise control. Your vehicle may relax its acceleration temporarily when going uphill. You can switch this feature on and off in the Driver Assist section of the Settings menu.

EFFICIENCY LEAVES



The right vehicle information display provides a visual representation of your driving behavior. The leaves grow as driving habits and efficiency improve.


THE BATTERY GAUGE

During Plug-in Power Mode, a full battery fill represents the total amount of energy you can get from an external charge (plugging your vehicle in).

It is normal for your electric range estimate to vary from charge to charge due to changes in average energy usage. Driving style, drive route, extreme temperatures and use of heat and air conditioning affect your energy usage.

SILENT KEY START



When starting your vehicle, you may not hear your engine because your hybrid-electric vehicle includes silent key start. This fuel-saving feature allows your vehicle to be ready to drive without requiring your gas engine to be running. Look for the 'ready to drive' indicator light  in your instrument display. When the light displays, you successfully started your vehicle and it is ready to drive.

instrument panel

1 CRUISE CONTROL

To Set a Cruise Control Speed

- Press the **ON** button and release.
- Accelerate to the desired speed.
- Press the **SET+** and release, then take your foot off the accelerator.

After setting your speed, you can press **SET+** or **SET-** to adjust cruise speed. To disable, press the **OFF** button, tap the brake pedal or pull the **CAN** control toward you.

2 LEFT VEHICLE INFO DISPLAY

Provides specific information about various systems on your vehicle. Use the left-hand, 5-way controls to use SmartGauge®, customize views, and choose and confirm settings and messages. Refer to the *Information Displays* chapter of your *Owner's Manual* for more information.

3 TILT AND TELESCOPE STEERING COLUMN

Unlock the steering wheel by pulling the lever down. Adjust the steering wheel to your desired position. Push the lever up to lock the steering wheel in place.



4 RIGHT VEHICLE INFO DISPLAY

Access information about Entertainment, Phone, Navigation* or the *animated EcoGuide and efficiency leaves* by using the right-hand, 5-way controls. Scroll through the menu, highlight selections and make adjustments. Press **OK** to confirm your choices. Refer to the *MyFord Touch®* chapter in your *Owner's Manual* for more information.

5 STEERING WHEEL MEDIA CONTROLS

Volume: Press to increase or to decrease volume levels. Press to access the next or previous radio station, CD track or preset satellite radio channel*.

Pull to access voice recognition.

Press to access phone mode or to answer a call.

Press to confirm your selection.

6 PUSH BUTTON START

While transmitters remain in your pocket, purse or back pack, you can still start your vehicle. With your vehicle in park (P) and you pressing the brake pedal, press the **START STOP** button. Press the button again to switch off the vehicle.

NOTE Your intelligent access transmitter must be inside the vehicle for the ignition to start.

7 DOOR LOCK INDICATOR LIGHT

Lights after you lock all of the doors, and does not light when a door remains open or unlocked. The central door locks are on both driver and front-passenger doors, and on your keyless remote.

8 FUEL BUTTON

Press to open the fuel door. It may take up to 15 seconds to open.

9 EV MODE BUTTON

*if equipped

SYNC® with MyFord Touch®

A REVOLUTIONARY WAY TO CONNECT WITH YOUR VEHICLE.



GETTING STARTED, UNDERSTANDING SYNC WITH MYFORD TOUCH

Use the four-corner, four-color touchscreen to explore and interact with your vehicle. The screen works the same way as traditional controls, knobs and buttons do. Press the various corners on your touchscreen firmly and accurately to personalize the many features and settings of your vehicle. The system provides easy interaction with your cellular phone, multimedia entertainment, climate controls and navigation system*.

Before You Get Started

- » Pair your phone to SYNC before using MyFord Touch (see the *Getting Started with Your SYNC System* section for instructions on how to do this).
- » If you have the navigation SD card*, make sure to insert it into the media port or your navigation cannot work.

EV Info

Press the “road and leaf” icon to access the Power Flow and Charge Settings screens.

- » The Power Flow screen shows you where your vehicle power is coming from and where it is being used.
- » The Charge Settings screen lets you schedule GO Times and cabin conditioning, select charging preferences, view charge status and more.



CREATE YOUR ACCOUNT

1. Set up your owner account at **SyncMyRide.com** (U.S.) or **SyncMyRide.ca** (Canada). Register by following the on-screen instructions. After registering, you can learn about the services available to you.
2. SYNC uses a wireless connection called **Bluetooth®** to communicate with your phone. Switch on **Bluetooth** mode in your phone's menu options. This lets your phone find SYNC. If you need more details on setting up your phone with SYNC, visit **SyncMyRide.com** (U.S.) or **SyncMyRide.ca** (Canada), or your phone manufacturer's website.

WHY DO YOU NEED A SYNC OWNER ACCOUNT?

A SYNC owner account allows you to receive the latest software updates that add new places, directions and information. When you have questions, you get free customer support. Some services may not be available in your area. Create your account by visiting the website or calling the toll-free number for more information.

For U.S. customers: visit **SyncMyRide.com** or call **1-800-392-3673** (select Option 1 or 2 for language, then Option 3).

For Canadian customers: visit **SyncMyRide.ca** or call **1-800-565-3673** (select Option 1 or 2 for language, then Option 3).

PAIRING YOUR PHONE WITH SYNC

In order to use many of the features of SYNC, you must first pair and connect your phone with SYNC. Make sure your vehicle is in park (P) and you switch on your ignition and radio, then:

1. Touch **Add Phone** in the upper left corner of your touchscreen. **Find SYNC** appears on the screen and instructs you to begin the pairing process from your device.
2. Make sure that **Bluetooth** is set to **ON** and your cellular phone is in the proper mode. See your phone's manual if necessary. Select SYNC and a six-digit PIN appears on your device.
3. If you are prompted to enter a PIN on your device, it does not support Secure Simple Pairing. To pair, enter the PIN displayed on the touchscreen. Skip the next step.

4. When prompted on your phone's display, confirm that the PIN provided by SYNC matches the PIN displayed on your cellular phone.

5. The display indicates when the pairing is successful.

NOTE The System May Prompt You to

- » Set your phone as the *primary* or *favorite* (the primary phone receives messages and voicemail).
- » Download your phone book (required to use the full set of voice commands).
- » Switch on 911 Assist®.

TIPS

- » Make sure you accept the request from SYNC to access your phone.
- » To pair subsequent phones, please refer to *Pairing Subsequent Phones* in the SYNC chapter of your *Owner's Manual*.
- » If you experience pairing problems, try performing a clean pairing by deleting your services from SYNC, deleting the SYNC connection from your phone, and then repeating the process.

SYNC® with MyFord Touch® (continued)

GET IN TOUCH USING YOUR FOUR-CORNER TOUCHSCREEN

Phone, Navigation, Climate and Entertainment are the four main features of SYNC with MyFord Touch. Each feature has its own corner represented by its own color.



PHONE

Voice-control your phone for hands-free calling with your phone securely put away. With SYNC, you won't even need to know the phone number. Just say the name of the person you want from your contacts.

Your Phone Connects You with Other Features


- » Connect directly to a 911 Operator in the event of an accident (feature must be set to ON prior to an incident).
- » Transfer calls seamlessly from SYNC to phone as you get in or out of your vehicle.

Refer to the SYNC chapter of your *Owner's Manual* for complete details.


USING YOUR PHONE WITH SYNC

NOTE You must download your phone book to make phone calls with voice commands by name. Remember to say the contact name exactly as you listed it in your phone book.



Making a Phone Call

Use SYNC to make a phone call to anyone in your phone book by pulling the voice control  and when prompted, give a voice command.

For example, you could say **"Call Jake Smith at home"**. SYNC repeats the command back to you and dials the number.

NOTE You can make phone calls by pulling the voice control  and when prompted, give the voice command **"Dial"** again to initiate the call.

Answering Incoming Calls


Whenever you have an incoming call, the name and number of the person calling appears in the display. Press the  button to answer an incoming call. You can hang up at any time by pressing and holding the  button.

Do Not Disturb Mode

This feature blocks incoming calls and text messages, and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command **"Do not disturb on"** to enable and **"Do not disturb off"** to disable.



NAVIGATION*



Get started with your navigation system by pressing the upper-right, green corner. The available voice-activated navigation system includes:

- » SiriusXM Traffic™
- » SiriusXM Travel Link™
- » GPS (Global Positioning System) technology
- » 3-D mapping
- » Turn-by-turn navigation


Some features require activation. Refer to the *MyFord Touch* chapter of your *Owner's Manual* for complete details.

TIPS

- » Save your favorite locations by touching **Save to Favorites**.
- » Change your map views from Direction Headed, North Up or 3-D.

Set a Destination

Set a destination on your touchscreen by using a street address, a city center, a place on the map or a point of interest (POI). The easiest way, however, is by voice.

1. Pull the voice control  .
When prompted, say **"Destination street address"**.
2. The system asks you to say the full address and then displays an example on-screen.
3. You can then speak the address naturally, such as: **"One two three Main Street, Anytown"**.

You can also use the touchscreen to enter a destination and narrow your choices by city or street as you type.

You can choose from up to three different types of routes:

- » **Fastest:** Uses the fastest moving roads possible.
- » **Shortest:** Uses the shortest distance possible.
- » **Eco (EcoRoute):** Uses the most fuel-efficient route.



CLIMATE

SYNC with MyFord Touch controls the temperature, airflow direction, fan speed, and activates other climate features like heated front seats for you and your passenger. To use voice commands to operate climate, say a voice command like **"Climate temperature 72 degrees"** and MyFord Touch makes that adjustment.

Set Your Temperature

- » Touch the lower-right, blue Climate corner on the touchscreen.
- » Set your exact, desired temperature by using the **+** or **-** buttons.



*if equipped

SYNC® with MyFord Touch® (continued)



ENTERTAINMENT



No matter how you store your music, SYNC makes it yours to enjoy when you are behind the wheel. Just press the lower-left, red corner of the touchscreen. From here, you can easily go between AM, FM, SiriusXM and other media sources.

Set Your Radio Presets

- » Touch the Entertainment corner on the touchscreen.
- » Touch **FM**.
- » Touch **Direct Tune**.
- » Enter the desired station and touch **Enter**.
- » Touch **Presets** and then touch and hold one of the memory preset buttons to save it. The sound mutes briefly and returns once the system saves the station.


Bring in Your Own Music

Gain access to any audio source by voice and even control how each operates, like changing radio stations, CD tracks or music on one of the following devices:


- » USB
- » Bluetooth® streaming
- » SD card*
- » A/V in

USING SYNC TO ACCESS DIGITAL MEDIA

Plug in your USB media devices, such as phones and MP3 players, and use SYNC to play all of your favorite music.



Using Voice Commands to Play Music

1. Plug your media player into your USB port.
2. Pull the voice control . When prompted, say “**USB**” and then a voice command.

Refer to the *MyFord Touch* chapter in your *Owner's Manual*, visit the website or call the toll-free number for more information. See the *Why Do You Need a SYNC Owner Account?* page in this guide for more details.



parking aids

FORWARD* AND REVERSE* SENSING SYSTEMS

Sounds an audible warning tone if there is an obstacle near the vehicle's front or rear bumpers. As the vehicle moves closer to the obstacle, the rate of the warning tone increases in frequency.

NOTE The driver is always responsible for controlling the vehicle, supervising the system and intervening if required. Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your *Owner's Manual* for safety information, more details and limitations.



REAR VIEW CAMERA

Provides a visual display of the area behind the vehicle. The display automatically appears in the touchscreen when the vehicle is in reverse (R) and uses colored guides to alert you of your proximity to objects.

ACTIVE PARK ASSIST*



Can detect an available parallel parking space and automatically steer the vehicle into that space (hands-free). The system instructs the driver with visual and audible instructions with regard to braking, accelerating and shifting gears in order to safely park the vehicle.

- » To start active park assist, press the button located in the instrument panel below the audio system.
- » To stop the parking procedure, grab the steering wheel or press the control again. For complete information, refer to the *Parking Aids* chapter of your *Owner's Manual*.

convenience

INTELLIGENT ACCESS*

NOTE Your intelligent access transmitter must be within 3 feet (1 meter) of the vehicle for intelligent access to function properly.



To lock or unlock the vehicle, touch the inside of the front exterior door handle. To unlock and open the liftgate, press the luggage compartment button. The intelligent access transmitter also contains a mechanical key blade that you can use to unlock the driver's door, if necessary.

REMOTE START

To remote start your vehicle, press the buttons within three seconds of each other:

1. Press the lock button to lock all the doors.
2. Press the remote start button twice. The exterior lamps flash twice.

NOTE When starting with an integrated keyhead transmitter, switch the ignition on before driving. When starting with an intelligent access transmitter, press the **START STOP** button on the instrument panel once while applying the brake pedal before driving. For complete information, refer to the *Remote Control* chapter in your *Owner's Manual*.

MYKEY®

MyKey allows you to program certain driving restrictions in order to promote good driving habits. You can program things like: speed restrictions, limited volume levels and safety belt reminders. For complete information, refer to the *MyKey* chapter in your *Owner's Manual*.

110-VOLT AC POWER POINT*



The power point is on the rear of the center console. You can use it to power smaller electrical devices that require up to 150 watts. This feature is available to use when you switch on your ignition and the battery voltage is above 11 volts. When the indicator light is on, the power point is working and ready to use.

120-VOLT CONVENIENCE CORD AND CARGO STORAGE

Your vehicle includes two under-floor storage compartments that are in front of the rear seats. The compartment behind the driver seat contains the plug-in charge cord. You can use the compartment behind the passenger seat to store items discretely. Secure the lids so items stay in place while you drive.



C-MAX Energi power management

SMART POWER-SPLIT ARCHITECTURE

City Driving: In stop and go driving and at low speeds, the electric motor provides the necessary power. The gas engine kicks in only to recharge the battery or when you need more power.

Accelerating: Step on the accelerator pedal and get all the responsiveness of a traditional gasoline engine.

Cruising or Highway Driving: With greater power demands at highway speeds, your vehicle uses the gasoline engine more frequently than while driving at city traffic speeds. This is normal.

Braking: For added efficiency, the energy normally created during braking recycles to the battery.

Stopped: To save energy, the gasoline engine shuts off and the electric motor stops drawing current.



MYFORD® MOBILE APP FOR SMARTPHONES


The downloadable MyFord Mobile app lets you know the status of your charge and upcoming charge schedules at any time, from anywhere.

Use the App to

- » See your charge status.
- » Set charging schedules when utility rates are low with the Value Charging feature.
- » Set your cabin temperature when setting a GO Time either remotely or through your touchscreen to precondition your cabin when the vehicle remains plugged in.

NOTE Extreme outside temperatures or using a standard outlet with 120V charging may reduce cabin conditioning effectiveness. For maximum efficiency, use a 240V outlet.

Register your smartphone: visit www.MyFordmobile.com to download your free app.



comfort



DUAL ZONE TEMPERATURE CONTROL

With dual controls, you have the flexibility to operate the temperature with one control, called single zone, or two, where both driver and front passenger can select independent temperatures using their own rotary dials.

To operate the dual zone temperature control: Use the rotary control on the passenger side. Single zone temperature control automatically turns off.

To return back to single zone: Press and hold the **AUTO** button. The passenger side temperature automatically turns to the driver side temperature setting.

HEATED SEATS*



The front heated seat controls are on the center console near the gearshift lever. Rotate the dial to select your preferred heat mode.



TO FOLD THE REAR SEATBACK


1. Fold the outboard head restraints and lower the center head restraint.
2. Pull the lever up to fold the seatback forward.

To unfold the seatback, simply pull up on the seatback to raise it to the upright position.





function

MANUAL LIFTGATE

To open the liftgate manually from outside of your vehicle, press the control located in the top of the liftgate pull cup handle. This unlatches the liftgate. Then, pull on the outside handle. You can also use the transmitter to unlock your liftgate. Press  twice within three seconds. Use the molded handle inside the liftgate to help with closing.

POWER LIFTGATE*

You can open the power liftgate from the instrument panel by pressing , or with your transmitter by pressing  twice within three seconds. If the vehicle is running, the liftgate operates only with the transmission in park (P). Three warning tones sound once as the liftgate begins to power close. Five short tones indicate a problem with the open or close request, caused when:


- » The ignition is on and the transmission is not in park (P).
- » The battery voltage is below the minimum operation voltage.
- » The vehicle speed is at or above 3 mph (5 km/h).



HANDS-FREE POWER LIFTGATE*

To open your liftgate hands-free while you are at the liftgate: Move your foot under and away from the rear bumper, using a single kicking motion. Do not move your foot sideways or the sensors may not detect the motion. The liftgate power opens or closes.

NOTE Your intelligent access transmitter must be within 3 feet (1 meter) of the liftgate for the feature to work. The liftgate may not power open or close under specific conditions. Refer to the *Locks* chapter in your *Owner's Manual* for more information.





essential information

FUEL TANK CAPACITY AND FUEL INFO


C-MAX Energi has a 14.0 gallon (53L) fuel tank capacity, in addition to its high-voltage battery system.

Use only “Regular” UNLEADED fuel with an octane rating of 87 or higher, with no more than 15% ethanol. Do not use ethanol (E20-E85) (E85), diesel, fuel-methanol, leaded fuel or any other fuel because it could damage or impair the emission control system.

REFUELING



Your vehicle features a locking fuel door and an auto-sealing feature that locks the fuel tank refueling valve.

1. Put your vehicle into park (P) and switch off the ignition.
2. Press the button  located on the center console. Pressing this button unlocks the fuel tank refueling valve, allowing the fuel filler door to open so you can insert the fuel filler nozzle into the fuel inlet.
3. Wait up to 15 seconds before opening the fuel filler door. During this time, a **Fuel Door Opening** message appears in the Information display.
4. When the door opens, a **Fuel Door Open** message appears in the information display, indicating that the vehicle is ready for refuelling. The vehicle remains ready to refuel for approximately 20 minutes. If you need more than 20 minutes, you need to press the refueling button again. You may experience the fuel pump shutting off if the refuel button is not pressed again.



5. Open the fuel filler door.
6. Slowly insert the fuel filler nozzle fully into the fuel system, and leave the nozzle fully inserted until you are done pumping.

Hold the handle higher during insertion for easier access.

7. After you are done pumping fuel, slowly remove the fuel filler nozzle. Allow approximately 5–10 seconds after pumping fuel before removing the fuel filler nozzle. This allows residual fuel to drain back into the fuel tank and not spill onto the vehicle.

NOTE When refilling with a portable container, use only the funnel that comes with your vehicle. Do not use aftermarket funnels as they do not work with the Easy Fuel® system and may cause damage. You can purchase extra funnels from your authorized dealer.

FUEL FRESHNESS MODE

This feature helps keep the fuel system functional and the fuel in your tank fresh.

If you operate your vehicle mainly in plug-in power mode using electricity from plugging in without refueling, the gasoline in your tank eventually becomes old. Old fuel can damage the engine and fuel system.

To prevent the fuel from becoming old, your vehicle automatically enters fuel freshness mode. In fuel freshness mode, your vehicle operates in hybrid mode, causing the gasoline engine to run in order to consume the fuel in the fuel tank.

NOTE If you do not add new fuel during an 18-month period, fuel freshness mode consumes fuel until about 1 gallon (3.8 liters) remains in the tank.

During Fuel Freshness Mode

- » The information display screen indicates that fuel freshness mode is active.
- » The vehicle runs only in hybrid mode. **EV Now** is not available.
- » Most of the plug-in power stores until fuel freshness mode is complete.

NOTE **EV Now** resumes if less than 1 gallon (3.8 liters) of fuel is left in the tank.

NOTE In most cases, when the fuel level is below 1/4 tank, refueling the vehicle ends fuel freshness mode and **EV Now** becomes available. Refueling after consuming a full tank in fuel freshness mode also ends the mode.


NOTE We recommend that you use a fuel stabilizer if your vehicle consumes less than a full tank of fuel during an 18-month period.

LOW ENGINE USE MODE

The feature automatically keeps the engine oil quality in good condition when you drive the vehicle with limited engine use. When you start the vehicle in **Low Engine Use** mode, a message appears in the information display.

When the vehicle is in **Low Engine Use** mode, the vehicle runs the engine as necessary. That means if you select the **EV Now** mode when the vehicle is in the **Low Engine Use** mode, **EV Now** mode suspends for as long as you are in **Low Engine Use** mode. You can suspend the **Low Engine Use** mode by getting regular oil changes and resetting the oil life monitoring system.

TIRE PRESSURE MONITORING SYSTEM

Your vehicle shows a low tire pressure warning light  in your information display when one or more of your tires are significantly under-inflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the *Inflating Your Tires* section in the *Wheels and Tires* chapter of your *Owner's Manual* for more information.

TIRE MOBILITY KIT

C-MAX Energi includes a tire mobility kit that is under the front passenger seat. It consists of an air compressor to reinflate the tire and a sealing compound in a canister that seals most punctures caused by nails or similar objects. Refer to the *Wheels and Tires* chapter of your *Owner's Manual* for more details.



ROADSIDE ASSISTANCE

Your new Ford vehicle comes with the assurance and support of 24-hour emergency roadside assistance. To receive roadside assistance in the United States, call **1-800-241-3673**. In Canada, call **1-800-665-2006**.

TOWING YOUR VEHICLE

Towing your vehicle behind an RV or any other vehicle may be limited. Refer to *Towing the Vehicle on Four Wheels* in the *Towing* chapter of your *Owner's Manual*.