

Table of contents

Introduction	4
Congratulations	4
Safety and environment protection	4
Symbol glossary	8
Vehicle inspection guide	8
Instrumentation	20
Warning and control lights	20
Gauges	25
Climate controls	29
Heater only	29
Manual heating and air conditioning	30
Entertainment systems	32
AM/FM stereo	32
AM/FM stereo cassette	34
AM/FM stereo cassette with CD	37
AM/FM stereo with CD	41
Lights	47
Headlamps	47
Turn signal control	48
Interior lamps	49
Bulb replacement	49
Driver controls	52
Windshield wiper/washer control	52
Steering wheel adjustment	53
Power windows	55
Mirrors	56
Speed control	58

Table of contents

Locks and security	62
Keys	62
Locks	62
Anti-theft system	62
Seating and safety restraints	66
Seating	66
Safety restraints	71
Child restraints	80
Driving	88
Starting	88
Vehicle loading	94
Brakes	95
Air suspension	114
Transmission operation	117
Roadside emergencies	136
Hazard flasher switch	137
Fuses and relays	137
Jump starting	143
Wrecker towing	146
Customer assistance	150
The dispute settlement board	152
Utilizing the mediation/arbitration	155
Getting assistance outside the U.S. and Canada	156
Ordering additional owner's literature	157
Reporting safety defects (U.S. only)	158
Cleaning	159
Cleaning your vehicle	159
Repairing paint chips	159
Underbody preservation	162

Table of contents

Maintenance and specifications	163
Hood	170
Engine oil	171
Battery	180
Air filter(s)	188
Fuel information	190
Lubricant specifications	212
Refill capacities	223
General maintenance information	229
Index	265

All rights reserved. Reproduction by any means, electronic or mechanical including photocopying, recording or by any information storage and retrieval system or translation in whole or part is not permitted without written authorization from Ford Motor Company. Ford may change the contents without notice and without incurring obligation.

Copyright © 2002 Ford Motor Company

Introduction

CALIFORNIA Proposition 65 Warning



WARNING: Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

CONGRATULATIONS

Congratulations on acquiring your new vehicle. Please take the time to get well acquainted with your vehicle by reading this handbook. The more you know and understand about your vehicle the greater the safety and pleasure you will derive from driving it.

Additional owner information is given in separate publications.

This Owner's Guide describes every option and model variant available and therefore some of the items covered may not apply to your particular vehicle. Furthermore, due to printing cycles it may describe options before they are generally available.

Remember to pass on the Owner's Guide when reselling the vehicle. It is an integral part of the vehicle.

SAFETY AND ENVIRONMENT PROTECTION



Warning symbols in this guide

How can you reduce the risk of personal injury and prevent possible damage to others, your vehicle and its equipment? In this guide, answers to such questions are contained in comments highlighted by the warning triangle symbol. These comments should be read and observed.



Warning symbols on your vehicle

When you see this symbol, it is imperative that you consult the relevant section of this guide before touching or attempting adjustment of any kind.



Introduction

Protecting the environment

We must all play our part in protecting the environment. Correct vehicle usage and the authorized disposal of waste cleaning and lubrication materials are significant steps towards this aim. Information in this respect is highlighted in this guide with the tree symbol.



SPECIAL NOTICES

Emission warranty

The New Vehicle Limited Warranty includes Bumper-to-Bumper Coverage, Safety Restraint Coverage, Corrosion Coverage, and 6.0L Power Stroke Diesel Engine Coverage. In addition, your vehicle is eligible for Emissions Defect and Emissions Performance Warranties. For a detailed description of what is covered and what is not covered, refer to the *Warranty Guide* that is provided to you along with your Owner's Guide.

Special instructions

For your added safety, your vehicle is fitted with sophisticated electronic controls.



By operating other electronic equipment (e.g. mobile telephone without exterior aerial) electromagnetic fields can occur which can cause malfunctions of the vehicle electronics. Therefore you should observe the instructions of the equipment manufacturers

Introduction

These are some of the symbols you may see on your vehicle.

Safety Alert		See Owner's Guide	
Fasten Safety Belt		Air Bag-Front	
Air Bag-Side		Child Seat	
Child Seat Installation Warning		Child Seat Lower Anchor	
Child Seat Tether Anchor		Brake System	
Anti-Lock Brake System		Brake Fluid - Non-Petroleum Based	
Traction Control		AdvanceTrac	
Master Lighting Switch		Hazard Warning Flasher	
Fog Lamps-Front		Fuse Compartment	
Fuel Pump Reset		Windshield Wash/Wipe	
Windshield Defrost/Demist		Rear Window Defrost/Demist	
Power Windows Front/Rear		Power Window Lockout	

Introduction

Child Safety Door
Lock/Unlock



Interior Luggage
Compartment Release
Symbol



Panic Alarm



Engine Oil



Engine Coolant



Engine Coolant
Temperature



Do Not Open When Hot



Battery



Avoid Smoking, Flames,
or Sparks



Battery Acid



Explosive Gas



Fan Warning



Power Steering Fluid



Maintain Correct Fluid
Level



Emission System



Engine Air Filter



Passenger Compartment
Air Filter



Jack



Check fuel cap



Low tire warning



Vehicle inspection guide

FEDERAL HIGHWAY ADMINISTRATION REGULATION

Regulations such as those issued by the Federal Highway Administration or issued pursuant to the Occupational Safety and Health Act (OSHA), and/or state and local laws and regulations may require additional equipment for the way you intend to use the vehicle. It is the responsibility of the registered owner to determine the applicability of such laws and regulations to your intended use for the vehicle, and to arrange for the installation of required equipment. Your dealer has information about the availability of equipment which may be ordered for your vehicle.

ENTERING, EXITING AND/OR CLIMBING ON THIS VEHICLE

You must be careful and deliberate to minimize the possibility of personal injury from a slip and fall when entering, exiting and/or climbing on this vehicle. Always use the steps and assist handles before climbing. Do not skip any steps or assist handles. Use three point contact at all times with at least two feet and one hand or two hands and one foot firmly placed during all phases of entering, exiting and/or climbing. Always keep your shoe soles and hands clean. Keep the steps and assist handles free of snow, ice, oil, grease, substances or debris. Be sure to use extra care in bad weather. Avoid wearing thick gloves. Always perform trailer hook-up while standing on the ground.



Do not carry items while entering, exiting, and/or climbing. Make sure you keep a firm grip. Always FACE the VEHICLE STEP and HANDLE SYSTEM while climbing up and down. Do not climb behind the cab unless you have three point contact with a step and handle system at all times.

To be sure your vehicle is ready to operate, conduct a pre-trip inspection at the beginning of each work period. Follow the steps listed in this section to assure a proper vehicle inspection procedure. The pages in this section may be produced locally and used on a regular basis.

Note: Always make sure the parking brake is applied before starting the engine.

Vehicle inspection guide

Engine compartment (with engine stopped)	
Engine oil level:	Use the engine oil dipstick to verify that the engine oil level is between the FULL and ADD marks.
Engine coolant level:	Look through the plastic reservoir and make sure the fluid is within the minimum and maximum fluid level range as marked on the reservoir. Do not remove pressure cap until the coolant has cooled.
Power steering fluid:	Verify that the fluid level is between the full and refill marks.
Brake fluid (master cylinder):	Remove the master cylinder caps and inspect the fluid level. The full mark is at the bottom of the opening of the port ring.
Hydraulic clutch fluid:	Check for adequate amount of hydraulic clutch fluid. Fluid level should be at the step of the reservoir; refer to <i>Clutch fluid/linkage adjustments</i> in the <i>Maintenance and specifications</i> chapter.
Fan, alternator, water pump/drive belt:	Press belt to test that it is snug. Check for frays, cracks, loose fibers or visible signs of wear. If it deflects more than 1.25 cm–2 cm (1/2–3/4 inch), slippage is probably excessive.
Air compressor:	Check belts (if equipped). Same for water pump.
Refrigerant compressor:	Check belts (if equipped). Same for water pump.
Any leaks:	Check for signs of fluid puddles, dripping fluid on the ground under the engine or the underside of the engine.
HVAC air inlet:	Check for debris, leaves, etc. that may have collected on the HVAC air inlet grille or inside the exterior module as this may cause reduced system performance.

Vehicle inspection guide

Engine compartment (with engine stopped)

HVAC fresh air filter (if equipped):	Periodically check the HVAC fresh air filter for cleanliness.
---	---



Exercise great caution when working on vehicle equipped with an automatic fan clutch. The fan starts in motion only after the engine coolant reaches a predetermined temperature or the refrigerant pressure (if equipped with air conditioning) reaches a predetermined setting. The fan will start at these point with no advance warning. Never reach near, or permit objects to protrude into, the fan blade radius while the engine is running as this could result in vehicle damage, personal injury or death.

Engine starting (with parking brake applied)

Safety/Emergency equipment:	Prior to entering the cab, verify that the vehicle is equipped with spare electrical fuses (if used), three red reflective triangles, a properly charged and rated fire extinguisher and wheel chocks. Walk around the vehicle and check that all steps and grab handles, inside and out as well as behind, are tight and clean. Use extreme caution and a three-point stance at all times. Check door latches for positive closing, latching and locking.
Clutch/Gearshift:	Depress the clutch (if equipped with a manual transmission) and verify the transmission is in neutral before turning on the starter. Keep the pedal depressed until the engine reaches idling speed.
Oil pressure builds:	Make sure engine oil pressure is building to normal operating range.

Vehicle inspection guide

Engine starting (with parking brake applied)	
Air chime sounds (if equipped with air compressor):	The low air pressure warning chime should sound immediately after the engine starts but before the compressor has built up some pressure. The low air pressure warning chime should stop when the air pressure reaches 483 kPa (70 psi) (or more). Let the air pressure build to governed cut-out pressure, which should occur between 793–896 kPa (115–130 psi).
Accelerator:	Depress the accelerator and verify that it operates smoothly without any binding or irregular feel. Remove your foot from the pedal and make sure the engine returns to idle speed immediately.
Ammeter/Voltmeter:	Check the gauge to see if the alternator is charging.
Steering linkage free play:	Check for excessive free play in the steering linkages. The steering wheel should have less than 5 cm (2 inches) of free play at rim of steering wheel.
Hydraulic brake check:	Pump the brake pedal three times, then apply firm pressure to the pedal and hold it for five seconds. The pedal should not move; if it does, there may be a leak or another problem. Do not drive the vehicle until the problem is fixed.
Parking brake:	Check that the parking brake will hold the vehicle by gently trying to pull forward with the parking brake applied.

Vehicle inspection guide

Engine starting (with parking brake applied)	
Air brake check:	Check the air brakes in the following manner (Chock the wheels, if necessary. Push in the parking brake and on tractors, also push in the tractor protection valve knob):
	1. Check the air compressor or governor cut-out pressure (approximately 305 kPa [120 psi]).
	2. Cut-off the engine and turn the key back to ON, without starting the engine.
	3. Without the brake pedal applied, note the air pressure drop for one minute. It should be less than 5 kPa (2 psi) for single vehicle and 8 kPa (3 psi) for combination vehicles.
	4. Depress and hold the brake pedal with 621 kPa (90 psi) or more and make sure there is no more than a 8 kPa (3 psi) per minute leak. For combination vehicles, no more than 10 kPa (4 psi) per minute.
	5. Step on and off the brake pedal and check for the warning light and chime to activate between 163-193 kPa (64-76 psi).
	6. Step on and off the brake pedal and make sure the tractor protection and parking brake knobs pop out between 138-310 kPa (20-45 psi)
	7. Restart the engine, shift to a lower gear and gently pull against the service and parking brakes separately to make sure they hold.

Vehicle inspection guide

Engine starting (with parking brake applied)	
Automatic transmission fluid:	With the engine idling (at normal operating temperature) and the parking brake applied, check the automatic transmission fluid. If fluid needs to be added, place the transmission in the appropriate gear as specified in the transmission operator's manual and refer to <i>Transmission fluid</i> in the <i>Maintenance and specifications</i> chapter.
Front of vehicle	
Lights:	Make sure all lights illuminate and are clean. Make sure headlights function on both high and low beams. Make sure reflectors are clean and unbroken and of proper color (red on rear, amber elsewhere). Make sure the running lights are also clean and unbroken. Rear running lights must be checked separately from signal, flasher and brake lights.
Steering gear:	Look for: missing or loose fasteners, power steering fluid leaks and damage to power steering hoses.
Steering linkage:	Make sure connecting links, arms and rods are not worn or cracked; joints, sockets and boot seals are not worn or loose and that there are no loose or missing cotter keys, nuts or bolts.
Tow hooks:	Front and rear tow hooks should be inspected for damage or loose mounting. This is particularly important on vehicles where tow hooks are frequently used.

Vehicle inspection guide

Front suspension	
Spring:	Check for missing, broken or shifted leaves or leaves that are in contact, or nearly contacting a tire, rim, brake drum, frame or body components.
Spring mount:	Check/Inspect spring hangers, bolts, bushings, axle mounting bolts and nuts for cracks, breaks, wear, damage, tightness and correct component quality.
Shock absorber:	Check for cracks, leaks and missing or broken bolts or bushings.

Note: Never apply grease to spring pads.



Do not operate the vehicle if any suspension conditions listed in the *Front suspension* chart are evident. Loss of steering or suspension could result in property damage, personal injury or death.

Front brakes	
Hoses:	Checked for cracked, worn or frayed hoses. Make sure all couplings are secured.
Chambers:	Make sure brake chambers are not cracked or dented and that they are securely mounted.
Slack adjuster:	Check for broken, loose or missing parts; the angle between the push rod and adjuster arm should be approximately 90 degrees when the brakes are applied. When pulled by hand, the push rod should not move more than approximately 2.5 cm (one inch).
Drum:	Make sure there are no cracks, dents or holes and no loose or missing bolts. Make sure brake linings are not worn or dangerously thin or contaminated by lubricant.

Vehicle inspection guide

Front wheels	
Rims:	Check for damaged or bent rims. Rims should not have welding repairs and no rust trails that indicate it is loose on the wheel.
Lug nuts:	Make sure all lug nuts are present and not loose (look for rust trails around the lug nuts). There should be no cracks radiating from the lug bolt holes or distortion of the bolt holes.
Hub oil seal:	Check wheel hub oil seal for leaks, and if sight glass if present, check to see that the oil level is adequate.
Oil-lubricated front wheel bearing:	If the hubcap has a transparent window, check for proper lubrication level. If the hubcap does not have a transparent window, remove the rubber fill-plug and check for proper level.



If a wheel must be changed, obtain expert tire service help. Mounting and un-mounting of tires should only be performed by a qualified technician using necessary safety procedures and equipment, otherwise the result could be property damage, personal injury or death.

Driver/Fuel area	
Fuel tank:	Make sure the fuel tank and caps are secure. Make sure there is no damage to the tank.
Leaks:	Check for any leaks from the fuel tanks.
Underbody of vehicle (rear of tractor)	
Driveshaft:	Make sure that the driveshaft is not bent or cracked. Ensure all driveshaft couplings are secure.
Exhaust system:	Make sure the outside visible parts are securely mounted. Make sure there are no cracks, holes or severe dents.

Vehicle inspection guide

Underbody of vehicle (rear of tractor)

Frame:	Check for cracks or bends in longitudinal frame members. Make sure there are no loose, cracked, bent, broken or missing crossmembers or crossmember fasteners.
---------------	--



Maintain adequate clearance between all parts of the exhaust system and all hoses, wires and lines for engine cooling, brake system, fuel system, power steering system and electrical system, Heat damage to hoses, wires or lines may cause vehicle malfunction that could result in property damage, personal injury or death.

Truck/Tractor

Air/Electric lines:	Make sure that air hoses are not cut, cracked, chafed or worn (steel braid should not show through). Listen for audible air leaks, Make sure air and electrical lines are not tangled, crimped or pinched or being dragged against any truck/tractor parts. Electrical line insulation should not be cut, cracked, chafed or worn. None of the air or electrical line should be spliced or taped. Check for corrosion on pins and in electrical sockets to ensure continuity and reduced heat build-up potential.
Deck plate:	Make sure deck plate is clean, securely bolted to the tractor frame and clear of loose objects.
Lights, reflectors:	Make sure reflectors are clean and none are missing or broken. Check for proper color (red on rear, amber elsewhere). All running lights should be clean, not broken and proper color. All running lights must be check separately from signal, flasher and brake lights.

Vehicle inspection guide

Tractor - coupling system	
Mounting bolts:	Check for loose or missing mounting brackets, clamps, bolts or nuts. Both fifth wheel and slide mounting must be solidly attached.
Platform:	Check for cracks or breaks in the platform structure.
Safety latch:	Make sure safety latch is engaged.
Release arm:	Make sure safety latch is in the engaged position and that any safety latch is in place.
Kingpin/Apron:	Make sure kingpin is not bent or worn. Also make sure that the apron lies flat on the fifth wheel skid plate and that the visible part of the apron is not bent, worn, cracked or broken.
Rear springs	
Springs:	Check for broken or shifted leaves or leaves that are in contact, or nearly contacting a tire, rim, brake drum, frame or body components. Check for missing or broken leaves in the leaf spring.
Spring mounts:	Check for cracked or broken spring hangers, broken, missing or loose bolts, missing or damaged bushings, broken, loose or missing axle mounting parts.
Torsion, shocks:	Make sure torsion arm is not cracked, broken or missing. Check the shock absorber for cracks or leaks; there should be no missing or broken mounting bolts or worn bushings.
Rear brakes	
Hoses:	Checked for cracked, worn or frayed hoses. Make sure all couplings are secured.
Chambers:	Make sure brake chambers are not cracked or dented and that they are securely mounted.

Vehicle inspection guide

Rear brakes	
Slack adjuster:	Check for broken, loose or missing parts; the angle between the push rod and adjuster arm should be approximately 90 degrees when the brakes are applied. When pulled by hand, the push rod should not move more than approximately 2.5 cm (one inch).
Drum:	Make sure there are no cracks, dents or holes and no loose or missing bolts. Make sure brake linings are not worn or dangerously thin or contaminated by lubricant.
Rear wheels	
Spacers:	Make sure dual wheels are evenly separated and that tires are not touching one another.
Rims:	Check for damaged or bent rims. Rims should not have welding repairs and no rust trails that indicate it is loose on the wheel.
Lug nuts:	Make sure all lug nuts are present and not loose (look for rust trails around the lug nuts). There should be no cracks radiating from the lug bolt holes or distortion of the bolt holes.
Rear of vehicle	
Signal/Brake lights:	Make sure both brake lights illuminate when the brake pedal is applied. Also, make sure each signal flashes. Make sure that four-way flashers work properly.
Lights, reflectors:	Make sure all lights illuminate and are clean. Make sure headlights function on both high and low beams. Make sure reflectors are clean and unbroken and of proper color (red on rear, amber elsewhere). Make sure the running lights are also clean and unbroken. Rear running lights must be checked separately from signal, flasher and brake lights.

Vehicle inspection guide

TRAILER

If you are operating a tractor with a trailer attached, an inspection of the trailer similar to that of the tractor should be done. Such an inspection should follow trailer manufacturer recommendation and should include at a minimum: general condition, landing gear, doors, sides, light, reflectors, suspension, brakes, tires and wheels.

TRANSMISSION

If your vehicle is equipped with an automatic transmission, have a qualified technician regularly check the transmission's neutral start switch.




If the unit starts in gear and/or the neutral start switch is defective, the vehicle may inadvertently move which could result in property damage, personal injury or death.

Check the transmission fluid level and shift linkage for proper operation.

Instrumentation

WARNING LIGHTS AND CHIMES



Warning lights and gauges can alert you to a vehicle condition that may become serious enough to cause expensive repairs. A warning light may illuminate when a problem exists with one of your vehicle's functions. Many lights will illuminate when you start your vehicle to make sure the bulb works. If any light remains on after starting the vehicle, have the respective system inspected immediately.

Service engine soon: If this light illuminates while driving, it is a possible indication that one of the engine's emission control systems has failed.

SERVICE
ENGINE
SOON

Check suspension (if equipped): Illuminates when there is a fault in the electronic subsystem of the air suspension.

CK
SUSP

Stop engine (if equipped): This light is used in conjunction with the electronic engine control.

STOP
ENGINE

Refer to the Engine Operator's Manual for specific information regarding this feature.

If the engine shuts down, it can be restarted and operated for 30 seconds at a time or until the problem is corrected. Refer to *Engine shutdown system* in the *Driving* chapter.

Drivers of electronically controlled engines should know the extent of warning engine shutdown system before operating the vehicle. This information can be obtained from your dealer.

Instrumentation

Brake reserve system warning (if equipped): Illuminates to indicate normal Hydromax booster reserve system activation when the engine is OFF and the service brake pedal is applied.



This light may also illuminate momentarily if the engine is running and the driver turns the steering wheel fully in one direction while braking.


If the light remains on while the engine is running, this indicates inadequate hydraulic booster pressure or reserve pump system failure. Stop the vehicle safely as soon as possible and seek service immediately.

Brake system warning light: To confirm the brake system warning light is functional, it will momentarily illuminate when the ignition is turned to the ON position when the engine is not running, or in a position between ON and START, or by applying the parking brake when the ignition is turned to the ON position. If the brake system warning light does not illuminate at this time, seek service immediately from your dealership. Illumination after releasing the parking brake indicates low brake fluid level and the brake system should be inspected immediately by your servicing dealership.



 Driving a vehicle with the brake system warning light on is dangerous. A significant decrease in braking performance may occur. It will take you longer to stop the vehicle. Have the vehicle checked by your dealer immediately.


Anti-lock brake system: If the ABS light stays illuminated or continues to flash, a malfunction has been detected, have the system serviced immediately. Normal braking is still functional unless the brake warning light also is illuminated.



Instrumentation

Trailer ABS brake system (if equipped):

Illuminates briefly when the engine is powered-up and only when a PLC trailer or a PLC diagnostic tool is connected. If the light remains on after the vehicle is started, continues to flash or fails to illuminate, have the system serviced immediately.



Parking brake warning (Hydraulic brakes only):

Momentarily illuminates when the ignition is turned to the ON position and the engine is off. Also illuminates when the parking brake is engaged. If the brake warning lamp does not illuminate at these times, seek service immediately.



Safety belt: Reminds you to fasten your safety belt. A chime will also sound to remind you to fasten your safety belt.



Check trans (Allison automatic transmission):

The lamp will illuminate for several seconds after the ignition is turned to the ON position. Illumination of this light indicates that a problem has been detected and shifting may be restricted. Depending upon the severity of the problem, the read-out digit on the shifter display may be blank. Operation may continue in order to reach service assistance. The ECU may not respond to shift selector requests, since operating limitations are being placed on the transmission, i.e. upshifts and downshifts may be restricted. Direction changes will not occur.



Refer to the Transmission Operator's Manual for more information.

Instrumentation

Range inhibit: Illuminates when the transmission is not engaged in the selected gear. The warning light will go off when the gearshift lever is adjusted in to the appropriate gear.

Refer to the Transmission Operator's Manual for more information.

**RANGE
INHIBIT**

Charging system: Illuminates when the battery is not charging properly.



Wait to start: Indicates the air intake heater is in operation and special starting procedures are required. Refer to the *Driving* chapter.

**WAIT
TO
START**



If equipped with an air intake heater, DO NOT use ether or any other starting fluids. The use of starting fluids (ether) in an engine equipped with an air intake heater could result in damage and/or personal injury.

Water in fuel (if equipped):

During refueling it is possible for water-contaminated diesel fuel to be pumped into your fuel tank. Your vehicle fuel system is equipped with

a fuel filter/water separator to remove water from the fuel. The indicator light illuminates when the fuel filter/water separator has a significant quantity of water, or when the ignition key is switched to the START position. If the light illuminates when the engine is running, stop the vehicle as soon as safely possible, shut off the engine and drain the filter bowl. Allowing water to stay in the system could result in extensive damage to, or failure of, the fuel injection system.

To drain the fuel filter/water separator (refer to *Maintenance and Specifications* chapter for procedure). Rotate the valve at the bottom of the filter assembly allowing water to drain from the system. Close the valve upon completion.

**WATER
IN
FUEL**



Do not drain water separator while engine is running. Fuel may ignite if separator is drained while engine is running or vehicle is moving.

Instrumentation

Traction control (if equipped):



Illuminates when the traction control system is turned off.

Differential lock (if equipped):

Illuminates when the main differential is locked (engaged).

**DIFF
LOCK**

Turn signal:

Illuminates when the left or right turn signal or the hazard lights are turned on. If the indicators stay on or flash faster, check for a burned out bulb.



High beams: Illuminates when the high beam headlamps are turned on.




Key-in-ignition warning chime: Sounds when the key is left in the ignition in the OFF/LOCK or ACC position and the driver's door is opened.


Headlamps on warning chime: Sounds when the headlamps or parking lamps are on, the ignition is off (and the key is not in the ignition) and the driver's door is opened.

Instrumentation


Odometer: Registers the total kilometers (miles) of the vehicle.




Trip odometer: Registers the kilometers (miles) of individual journeys. To reset, depress the control.



Tachometer: Indicates the engine speed in revolutions per minute. Driving with your tachometer pointer continuously at the top of the scale may damage the engine.




Battery voltage gauge: Indicates the battery voltage when the ignition is in the ON position. If the pointer moves and stays outside the normal operating range (as indicated by arrows), have the vehicle's electrical system checked as soon as possible.



Instrumentation


Engine oil pressure gauge:

Indicates engine oil pressure. The needle should stay in the normal operating range (between “L” and “H”). If the needle falls below the normal range, stop the vehicle, turn off the engine and check the engine oil level. Add oil if needed. If the oil level is correct, have your vehicle checked at your dealership or by a qualified technician.




Air filter restriction gauge:

Measures the vacuum inside the air cleaner. The more the air cleaner is restricted (dirty, clogged), the higher the vacuum reading. Change the air filter when the gauge reads 25 inches. After installation of the new filter element, reset the gauge to 0.




Fuel gauge: Indicates approximately how much fuel is left in the fuel tank (when the ignition is in the ON position).



Instrumentation

Air pressure gauge and warning buzzer (if equipped): Indicates the amount of air pressure in the brake system (green=primary, red=secondary) in pounds per square inch. When the pressure is too low for normal brake operation (less than 414 kPa [60 psi]) and the ignition is turned to ON:



- a warning buzzer sounds
- the warning light illuminates

All vehicles have a dual-pointer air pressure gauge to indicate the pressure in both brake circuits.

Vehicles equipped with rear air suspension also have a dual-pointer air pressure gauge.



Do not drive the vehicle when the low air pressure buzzer is sounding or the warning light is lit. These warnings indicate there is not enough air pressure for the brake or suspension system to operate properly.

Climate controls

HEATER ONLY SYSTEM

1. **Fan speed adjustment:** Controls the volume of air circulated in the vehicle.



2. **Air flow selections:** Controls the direction of the airflow in the vehicle. See the following for a brief description on each control.

 : Distributes outside air through the instrument panel vents.

O (OFF): Outside air is shut out and the fan will not operate.

 : Distributes outside air through the instrument panel vents and the floor vents.

 : Distributes outside air through the floor vents.

 : Distributes outside air through the windshield defroster vents and floor vents.

 : Distributes outside air through the windshield defroster vents.

3. **Temperature selection:** Controls the temperature of the airflow in the vehicle.

OPERATING TIPS

- To reduce fog build up on the windshield during humid weather, place the air flow selector in the  position.
- To reduce humidity build up inside the vehicle during cold or warm weather, do not drive with the air flow selector in the OFF position.
- Under normal weather conditions, do not leave the air flow selector in OFF when the vehicle is parked. This allows the vehicle to “breathe” using the outside air inlet vents.
- Do not put objects under the front seats that will interfere with the air flow to the back seats.
- Remove any snow, ice or leaves from the air intake area at the base of the windshield.

To aid in side window defogging/demisting in cold weather:

1. Select 
2. Set the temperature control to full heat
3. Set the fan speed to HI
4. Direct the outer instrument panel vents towards the side windows

Climate controls

To increase airflow to the outer instrument panel vents, close the vents located in the middle of the instrument panel.



Do not place objects on top of the instrument panel as these objects may become projectiles in a collision or sudden stop.

MANUAL HEATING AND AIR CONDITIONING SYSTEM



1. **Fan speed adjustment:** Controls the volume of air circulated in the vehicle.

2. **Temperature selection:** Controls the temperature of the airflow in the vehicle.

3. **Air flow selections:** Controls the direction of the airflow in the vehicle. See the following for a brief description on each control.

MAX A/C (if equipped): Uses recirculated air to cool the vehicle. Air flows from the instrument panel vents only.

A/C (if equipped): Uses outside air to cool the vehicle. Air flows from the instrument panel vents only.

: Distributes outside air through the instrument panel vents.

O (OFF): Outside air is shut out and the fan will not operate.

: Distributes outside air through the instrument panel vents and the floor vents.

: Distributes outside air through the floor vents.

: Distributes outside air through the windshield defroster vents and floor vents.

: Distributes outside air through the windshield defroster vents.

OPERATING TIPS

- To reduce fog build up on the windshield during humid weather, place the air flow selector in the position.
- To reduce humidity build up inside the vehicle: do not drive with the air flow selector in the OFF or MAX A/C position.
- Under normal weather conditions, do not leave the air flow selector in MAX A/C or OFF when the vehicle is parked. This allows the vehicle to “breathe” using the outside air inlet vents.

Climate controls

- Do not put objects under the front seats that will interfere with the airflow to the back seats.
- Remove any snow, ice or leaves from the air intake area at the base of the windshield.

To aid in side window defogging/demisting in cold weather:

1. Select 
2. Select A/C
3. Modulate the temperature control to maintain comfort.
4. Set the fan speed to HI
5. Direct the outer instrument panel vents towards the side windows


To increase airflow to the outer instrument panel vents, close the vents located in the middle of the instrument panel.



Do not place objects on top of the instrument panel as these objects may become projectiles in a collision or sudden stop.

Entertainment systems

AM/FM STEREO (IF EQUIPPED)



1. **Seek:** Press ◀ / ▶ to find the next strong station down/up the frequency band.



2. **Tune:** Press ◀ / ▶ to manually change radio frequency down/up.



3. **AM/FM:** Press to choose a frequency band in radio mode.




4. **Memory preset buttons:** To set a station: Select frequency band AM/FM; tune to a station, press and hold a preset button until sound returns.




Entertainment systems

5. **Power/volume:** Press to turn ON/OFF; turn to increase or decrease volume levels.



6. **Tone:** Press TONE until the desired level — Bass, Treble, Fade appears on the display. Turn the volume control to raise/lower the levels, or to move the audio sound from the right to left or the front to back (if equipped).




7. **CLK (Clock):** To set the hour, press and hold CLK until CLOCK SET appears in the display. Press SEEK to decrease ◀ or increase ▶ the hours.



To set the minute, press and hold CLK until CLOCK set appears in the display. Press TUNE to decrease ◀ or increase ▶ the minutes.

Entertainment systems

AM/FM STEREO CASSETTE (IF EQUIPPED)



1. **Balance:** Press to shift sound to the left/right speakers.



2. **Fade:** Press to shift sound to the rear/front speakers.



3. **CLK:** To set the hour, press and hold CLK. Then press SEEK to decrease ◀ or increase ▶ the hours.



To set the minute, press and hold CLK and press TUNE to decrease ◀ or increase ▶ the minutes.

Entertainment systems

4. **Tape AMS:** In tape mode, press and hold to activate Automatic Music Search (allows you to quickly locate the beginning of the tape selection being played or to skip to the next selection). Then, press REW (for the beginning of the current selection) or FF (to advance to the next selection). The tape MUST have a blank section of at least four seconds duration between programs.



5. **Side 1-2:** Press to change tape direction.



6. **REW (rewind):** Press to rewind the tape.



FF (fast forward): Press to advance the tape.



7. **Memory preset buttons:** To set a station: Select frequency band AM/FM1/FM2; tune to a station, press and hold a preset button until sound returns.



8. **Dolby® noise reduction:** Works in tape mode only. Reduces tape noise and hiss; press to activate/deactivate.

9. **Scan:** Press SCAN to hear a brief sampling of all listenable radio stations or all tape selections. Press again to stop.



10. **Tune:** Works in radio mode only. Press TUNE ◀/▶ to change frequency down/up




11. **Seek:** Press and release ◀/▶ for previous/next strong station, selection or track.




Entertainment systems

12. **Power/volume:** Press to turn ON/OFF; turn to increase or decrease volume levels.



13. **AM/FM:** Press to choose a frequency band in radio mode.



14. **Bass:** Press ▼ / ▲ to decrease/increase the bass output.



15. **Treble:** Press ▼ / ▲ to decrease/increase the treble output.




16. **EJ (Eject):** Press to eject a tape.




17. **Cassette door:** Insert a cassette into the cassette door.

Entertainment systems

PREMIUM AM/FM STEREO/CASSETTE/SINGLE CD (IF EQUIPPED)




1. **Power/volume:** Press to turn ON/OFF; turn to increase/decrease volume.



2. **Scan:** Press to hear a brief sampling of all listenable stations, tape selections or CD tracks. Press again to stop.




3. **CD Door:** Insert a CD with the label side up.




Entertainment systems

4. **Cassette door:** Insert the cassette with the opening to the right.



5. **Eject:** Press to eject the cassette/CD. The radio will resume playing.



6. **Tape:** Press to start tape play. Press to stop tape during rewind/fast forward.



CD: Press to start CD play. With the dual media audio, press CD to toggle between single CD and CD changer play (if equipped).



7. **Mute:** Press to MUTE playing media; press again return to playing media.



8. **Auto:** Press to set first six strongest stations (if available) into AM, FM1 or FM2 memory buttons; press again to return to normal stations.




9. **Clock:** Press and hold to set the clock. Press the ◀ SEEK to decrease hours or SEEK ▶ to increase hours. Press the ◀ TUNE to decrease minutes or TUNE ▶ to increase minutes. If your vehicle has a stand alone clock this control will not function.




Entertainment systems


10. **Balance:** Press BAL; then press SEL ◀/▶ to shift sound to the left/right speakers.



Fade: Press FADE; then press SEL ◀/▶ to shift sound to the rear/front speakers.



11. **Memory preset buttons:** To set a station: Select frequency band AM/FM, tune to a station, press and hold a preset button until sound returns.



12. **Shuffle (CD):** Press to play tracks in random order.



13. **Compression (CD):** Press to bring soft and loud passages together for a more consistent listening level.



14. **Dolby® noise reduction:** Works in tape mode only. Reduces tape noise and hiss; press to activate/deactivate.



15. **Side 1-2:** Works in tape mode only. Press to play reverse side of the tape.



16. **Fast Forward (FF):** Press for a slow advance, press and hold for a fast advance.



17. **Rewind (REW):** Press for a slow rewind, press and hold for a fast rewind.




Entertainment systems


18. **Select (SEL):** Use with Bass, Treble, Balance and Fade controls.




19. **Bass:** Press BASS; then press SEL ◀ / ▶ to decrease/increase the bass output.




Treble: Press TREB; then press SEL ◀ / ▶ to decrease/increase the treble output.



20. **Tune:** Works in radio mode only. Press TUNE ◀ / ▶ to change frequency down/up.



21. **Seek:** Press and release SEEK ◀ / ▶ for previous/next strong station, selection or track.




22. **AM/FM:** Press to select AM/FM1/FM2 frequency band.



Entertainment systems

PREMIUM IN-DASH SIX CD SOUND SYSTEM (IF EQUIPPED)



1. **Seek:** Press and release SEEK ◀ / ▶ for previous/next strong station, selection or track.



2. **Rewind:** In CD mode, press until desired selection is reached.



Fast forward: In CD mode, press until desired selection is reached.



3. **COMP** (Compression): The compression feature operates in CD mode and brings soft and loud CD passages together for a more consistent listening level. Press the COMP control until COMP ON is displayed.

DSP (Digital Signal Processing): Press to enter DSP mode – allows you to engage/disengage DSP status, and choose signal modes of JAZZ CLUB, HALL, CHURCH, STADIUM. You may also change the occupancy mode to optimize sound for ALL SEATS, DRIVER SEAT or REAR SEAT.

Entertainment systems


4. **Mute:** Press to MUTE playing media; press again return to playing media




5. **Eject:** Press to eject a CD. Press and hold to eject all loaded discs.




6. **Bass:** Press BASS; then press SEL ◀/▶ to decrease/increase the bass output.




Treble: Press TREB; then press SEL ◀/▶ to decrease/increase the treble output.




7. **Select:** Use with Bass, Treble, Balance and Fade controls to adjust levels.



8. **Balance:** Press BAL; then press SEL ◀/▶ to shift sound to the left/right speakers.




Fade: Press FADE; then press SEL ◀/▶ to shift sound to the rear/front speakers.



Entertainment systems

9. **Menu:** Press MENU and SEL to access clock mode, RDS on/off, Traffic announcement mode and Program type mode. On Audiophile audios, press MENU to access the compression feature. Press SEL to turn the feature ON or OFF.



Traffic: Allows you to hear traffic broadcasts. With the feature ON, press SEEK or SCAN to find a station broadcasting a traffic report (if it is broadcasting RDS data). *Traffic information is not available in most U.S. markets.*

FIND Program type: Allows you to search RDS-equipped stations for a certain category of music format: Classic, Country, Info, Jazz, Oldies, R&B, Religious, Rock, Soft, Top 40.

Show TYPE: Displays the station's call letters and format.

Compression: Brings soft and loud CD passages together for a more consistent listening level.

Setting the clock: Press MENU until SELECT HOUR or SELECT MINUTE is displayed. Use SEL to manually increase (▲) or decrease (▼) the hours/minutes. Press MENU again to disengage clock mode.

10. **Memory presets:** To set a station: Select frequency band AM/FM; tune to a station, press and hold a preset button until sound returns.



11. **CD:** Press to select CD mode.



12. **AM/FM:** Press to select AM/FM frequency band.



Autostore: Allows you to set the strongest local radio stations without losing your original manually set preset stations for AM/FM1/FM2. Press and momentarily hold AM/FM. AUTOSTORE will flash on the display. When the six strongest stations are filled, the station stored in preset 1 will begin playing. If there are less than six strong stations, the system will store the last one in the remaining presets. Press again to disengage.

Entertainment systems

13. **Power/volume:** Press to turn ON/OFF; turn to increase or decrease volume levels.



Automatic Volume Control (if equipped): Changes the volume automatically and slightly with vehicle speed to compensate for road and wind noise. The recommended level is 1–3. Level 0 turns the speed sensitive volume off and level 7 is the maximum setting. Press and hold the volume control for five seconds. Then, press the SEL control to increase or decrease volume levels. The selected level will appear in the display.

14. **Load:** Press to load a CD. Press and hold to load up to six discs.



15. **Shuffle:** Press to play tracks in random order.



16. **Scan:** Press for a brief sampling of radio stations or CD tracks. Press again to stop.



17. **Disc tune:** Radio: Press ◀ or ▶ to manually tune down or up the radio frequency band.



CD: Press ◀ to select the previous track or ▶ to select the next track on the CD.

RADIO FREQUENCIES

AM and FM frequencies are established by the Federal Communications Commission (FCC) and the Canadian Radio and Telecommunications Commission (CRTC). Those frequencies are:

AM - 530, 540–1700, 1710 kHz

FM- 87.7, 87.9–107.7, 107.9 MHz

Entertainment systems

RADIO RECEPTION FACTORS

There are three factors that can effect radio reception:

- Distance/strength: The further you travel from an FM station, the weaker the signal and the weaker the reception.
- Terrain: Hills, mountains, tall buildings, power lines, electric fences, traffic lights and thunderstorms can interfere with your reception.
- Station overload: When you pass a broadcast tower, a stronger signal may overtake a weaker one and play while the weak station frequency is displayed.

CASSETTE/PLAYER CARE

Do:

- Use only cassettes that are 90 minutes long or less.
- Tighten very loose tapes by inserting a finger or pencil into the hole and turning the hub.
- Remove loose labels before inserting tapes.
- Allow tapes which have been subjected to extreme heat, humidity or cold to reach a moderate temperature before playing.
- Clean the cassette player head with a cassette cleaning cartridge after 10–12 hours of play to maintain good sound/operation.

Don't:

- Expose tapes to direct sunlight, extreme humidity, heat or cold.
- Leave tapes in the cassette player for a long time when not being played.

CD/CD PLAYER CARE

Do:

- Handle discs by their edges only. Never touch the playing surface.
- Inspect discs before playing. Clean only with an approved CD cleaner and wipe from the center out.

Don't:

- Expose discs to direct sunlight or heat sources for extended periods of time.
- Insert more than one disc into each slot of the CD changer magazine.
- Clean using a circular motion.

Entertainment systems

CD units are designed to play commercially pressed 12 cm (4.75 in) audio compact discs only. Due to technical incompatibility, certain recordable and re-recordable compact discs may not function correctly when used in Ford CD players. Irregular shaped CDs, CDs with a scratch protection film attached, and CDs with homemade paper (adhesive) labels should not be inserted into the CD player. The label may peel and cause the CD to become jammed. It is recommended that homemade CDs be identified with permanent felt tip marker rather than adhesive labels. Ball point pens may damage CDs. Please contact your dealer for further information.


AUDIO SYSTEM WARRANTY AND SERVICE

Refer to the *Warranty Guide* for audio system warranty information. If service is necessary, see your dealer or qualified technician.

Lights


HEADLAMP CONTROL ☀

- Turns the lamps off.
- P☀ Turns on the parking lamps, instrument panel lamps, license plate lamps and tail lamps.
- ☀ Turns the headlamps on.




High beams ☸

Push the lever toward the instrument panel to activate. Pull the lever towards you to deactivate.



Flash-to-pass

Pull toward you slightly to activate and release to deactivate.



Daytime Running Lamps (DRL) (if equipped)

Turns the headlamps on with a reduced output.

To activate:

- the ignition must be in the ON position and
- the headlamp control is in the OFF, parking lamp or autolamp position.

Lights


 Always remember to turn on your headlamps at dusk or during inclement weather. The Daytime Running Lamp (DRL) system does not activate with your tail lamps and generally may not provide adequate lighting during these conditions. Failure to activate your headlamps under these conditions may result in a collision.

PANEL DIMMER CONTROL

Use to adjust the brightness of the instrument panel and all applicable switches in the vehicle during headlamp and parklamp operation.

Move the control to the full upright position, past detent, to turn on the interior lamps.

Move the control to the full down position, past detent, to prevent the interior lights from illuminating when the doors are opened.




AIMING THE HEADLAMPS

The headlamps on your vehicle are properly aimed at the assembly plant. If your vehicle has been in an accident the alignment of your headlamps should be checked by a qualified service technician.

TURN SIGNAL CONTROL

- Push down to activate the left turn signal.
- Push up to activate the right turn signal.




Lights

INTERIOR LAMPS

Map lamps (if equipped)

To turn on the map lamps, press the control next to each lamp.



EXTERIOR BULBS

Checking operation of lamps, safety equipment and warning signals

It is a good safety practice to check operation of headlamps, parking lamps, turn signals, clearance and marker lamps, instrument panel and control lamps each day.

Using the right bulbs


Function	Number of bulbs	Trade number
Headlamps	2	4652
Front turn signal lamps	2	1157
Front sidemarker/Park lamps	2 (amber)	194
Brake/Tail/Stop/Rear turn signal/License lamps	4	2057
Back-up lamps	2	1156
Front clearance and identification lamps	5	168
Dome lamp	1	105
To replace all instrument panel lights - see your dealer		

Lights

Replacing headlamp bulbs

To remove the headlamp bulbs:


1. Make sure headlamp switch is in OFF position.
2. Remove four screws and move the parking lamp assembly away from the headlamp bulb.



3. Remove four screws and the retaining bracket from the headlamp bulb.

4. Pull headlamp bulb out of the housing, disconnect the electrical connector and remove the headlamp bulb.

5. To complete installation, follow the removal procedure in reverse order.




Replacing front parking lamp/turn signal/side marker bulbs

To remove the parking lamp/turn signal bulbs:

1. Make sure the headlamp control is in the OFF position.

Lights


2. Remove four screws from the lamp assembly.
3. Carefully lower lamp assembly and pull the bulb socket straight out of the lamp assembly.
4. Carefully pull the bulb straight out of the socket and push in the new bulb.
5. To complete installation, follow the removal procedure in reverse order.



Replacing front clearance and identification lamp bulbs

To change the cab marker bulbs:


1. Make sure the headlamp switch is in the OFF position and then remove the screw and lens from the lamp assembly.
2. Carefully pull the bulb straight out of the socket and push in the new bulb.
3. Install lens on lamp assembly with screw.



Replacing brake/tail/rear turn signal/back-up/license plate lamp bulbs

The brake/tail/rear turn signal/back-up/license plate lamp bulbs are located in the same portion of the tail lamp assembly. Follow the same steps to replace any of these bulbs:

1. Make sure the headlamp switch is in the OFF position and then remove the four screws and the lamp lens from lamp assembly.
2. Carefully pull the bulb straight out of the socket and push in the new bulb.
3. Install the lens on the lamp assembly with the four screws.




Driver controls

WINDSHIELD WIPER/WASHER CONTROLS

Rotate the windshield wiper control to the desired interval, low or high speed position.

The bars of varying length are for intermittent wipers. When in this position rotate the control upward for fast intervals and downward for slow intervals.

Push the control on the end of the stalk to activate washer. Push and hold for a longer wash cycle. The washer will automatically shut off after ten seconds of continuous use.



Windshield wiper blades

Check the wiper blades for wear at least twice a year or when they seem less effective. Substances such as tree sap and some hot wax treatments used by commercial car washes reduce the effectiveness of wiper blades.

Checking the wiper blades


If the wiper blades do not wipe properly, clean both the windshield and wiper blades using undiluted windshield wiper solution or a mild detergent. Rinse thoroughly with clean water. To avoid damaging the blades, do not use fuel, kerosene, paint thinner or other solvents.

Driver controls

Changing the wiper blades


To replace the wiper blades:

1. Pull the wiper arm away from the windshield and lock into the service position.
2. Turn the blade at an angle from the wiper arm. Push the lock pin manually to release the blade and pull the wiper blade down toward the windshield to remove it from the arm.
3. Attach the new wiper to the wiper arm and press it into place until a click is heard.



TILT STEERING

Pull the tilt steering control toward you to move the steering wheel up or down. Hold the control while adjusting the wheel to the desired position, then release the control to lock the steering wheel in position.



Driver controls




Never adjust the steering wheel when the vehicle is moving.

AUXILIARY POWER POINT 12V

Power points are designed for accessory plugs only. Do not hang any type of accessory or accessory bracket from the plug. Improper use of the power point can cause damage not covered by your warranty.

The auxiliary power point is located on the instrument panel.



Do not plug optional electrical accessories into the cigarette lighter. Use the power point.

CELL PHONE USE

The use of Mobile Communications Equipment has become increasingly important in the conduct of business and personal affairs. However, drivers must not compromise their own or others' safety when using such equipment. Mobile Communications can enhance personal safety and security when appropriately used, particularly in emergency situations. Safety must be paramount when using mobile communications equipment to avoid negating these benefits.

Mobile Communication Equipment includes, but is not limited to cellular phones, pagers, portable email devices, in vehicle communications systems, telematics devices and portable two-way radios.




A driver's first responsibility is the safe operation of the vehicle. The most important thing you can do to prevent a crash is to avoid distractions and pay attention to the road. Wait until it is safe to operate Mobile Communications Equipment.

Driver controls


POWER WINDOWS (IF EQUIPPED)

Press and hold the rocker switches to open and close windows.

- Press the top portion of the rocker switch to close.




- Press the bottom portion of the rocker switch to open.



One touch down

- Press AUTO completely down and release quickly. The driver's window will open fully. Depress again to stop window operation.




Driver controls

Window lock (if equipped)

The window lock feature allows only the driver to operate the power windows.


To lock out all the window controls except for the driver's press the left side of the control. Press the right side to restore the window controls.



MIRRORS

With the doors closed and the seat adjusted for proper comfort, move the mirrors to maximize rear viewing area by adjusting the western mirrors left or right as required.

Adjust the auxiliary convex mirrors. Convex mirrors are a ball-stud design for precise adjustment to maximize viewing area.




Power side view mirrors (if equipped)

The ignition can be in any position to adjust the power side view mirrors.


To adjust your mirrors:

1. Select L to adjust the left mirror or R to adjust the right mirror.



Driver controls

2. Move the control in the direction you wish to tilt the mirror.




3. Return to the center position to lock mirrors in place.

4. Adjust spotter mirrors (if equipped) manually.

Fold-away mirrors

The mirrors can be manually folded forward or backwards for narrow spaces like driving through an automatic car wash or backing out of a garage with the trailer tow mirror.



The telescoping feature (if equipped) allows the mirror to extend approximately 76 mm (3 inches). This feature is especially useful to the driver when towing a trailer.

Heated outside mirrors (if equipped)

Both main mirrors are heated automatically to remove ice, mist and fog. The mirrors are automatically activated when the vehicle is started.

Note: The mirrors may be **hot** to the touch but will not burn. This is a normal condition.

Driver controls

The mirror heating elements are designed to operate regardless of the geographic location of the vehicle. There is no switch to turn on, or other operator involvement required other than to start the vehicle.

The spotter mirror, below the main mirror, is not heated and must be adjusted manually.


Do not remove ice from the mirrors with a scraper or attempt to readjust the mirror glass if it is frozen in place. These actions could cause damage to the glass and mirrors.

SPEED CONTROL

To turn speed control on

Press CRUISE RPM. If the vehicle is moving, speed control will be enabled; if the vehicle is stationary, engine RPM can be controlled.

 Do not use the speed control in heavy traffic or on roads that are winding, slippery, or unpaved.




To turn speed control off

- Press OFF or
- Turn off the vehicle ignition.

Once speed control is switched off, the previously programmed engine RPM will be erased.


 Do not use the speed control in heavy traffic or on roads that are winding, slippery, or unpaved.



Driver controls

To set a speed

Press SET +. If the vehicle is moving, this will set the vehicle speed. If the vehicle is stationary, this will set the vehicle idle RPM.



If you drive up or down a steep hill, your vehicle speed may vary momentarily slower or faster than the set speed. This is normal.

Speed control cannot reduce the vehicle speed if it increases above the set speed on a downhill. If your vehicle speed is faster than the set speed while driving on a downhill, you may want to shift to the next lower gear or apply the brakes to reduce your vehicle speed.


If the vehicle speed falls below 48 km/h (30 mph) or engine RPM falls below 1,000 RPM, your speed control will disengage. This is normal. Pressing RESUME - will re-engage it.



Do not use the speed control in heavy traffic or on roads that are winding, slippery, or unpaved.

To set a higher set speed

Press and hold SET +. If the vehicle is moving, this will increase vehicle speed; if the vehicle is stationary, this will increase engine RPM. Release the control when the desired vehicle speed/engine RPM is reached.




Press and release SET + to operate the tap-up function. Each press will increase the set speed by 1.6 km/h (1 mph) or engine RPM in idle mode.

Driver controls

To set a lower set speed


Press and hold RESUME -. If the vehicle is moving, this will decrease vehicle speed by 1.6 km/h (1 mph) increments; if the vehicle is stationary, this will decrease engine RPM. Release the control when the desired vehicle speed/engine RPM is reached.



Press and release RESUME - to operate the tap-down function. Each press will decrease the set speed by 1.6 km/h (1 mph) or engine RPM in idle mode.


To disengage speed control

- Depress the brake pedal or



- Depress the clutch pedal (if equipped).

Disengaging the speed control will not erase the previously programmed set speed or engine RPM.




Driver controls

Pressing OFF will erase the previously programmed engine RPM.



To return to a previously set speed

Press RESUME -. For RESUME - to operate, the vehicle speed must be above 48 km/h (30 mph) or engine speed must be above 1,000 RPM.



Locks and security


KEYS

The key operates all locks on your vehicle. In case of loss, replacement keys are available from your dealer.

You should always carry a second key with you in a safe place in case you require it in an emergency.

POWER DOOR LOCKS (IF EQUIPPED)

Press U to unlock all doors and L to lock all doors.



REMOTE ENTRY SYSTEM (IF EQUIPPED)

This device complies with part 15 of the FCC rules and with RS-210 of Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The remote entry system allows you to lock or unlock all vehicle doors without a key.

The remote entry features only operate with the ignition in the LOCK position.


If there is any potential remote keyless entry problem with your vehicle, ensure **ALL remote entry transmitters** are brought to the dealership, to aid in troubleshooting.

Locks and security

Unlocking the doors

Press this control to unlock the driver's door. The interior lamps will illuminate.

Press the control a second time within five seconds to unlock all doors.




Locking the doors

Press this control to lock all doors.

To confirm all doors are closed and locked, press the control a second time within five seconds. The doors will lock again, the horn will chirp and the lamps will flash.


If any of the doors are ajar, the horn will make two quick chirps, reminding you to properly close all doors.



Sounding a panic alarm

Press both controls to activate the alarm. The horn will sound and the lights will flash.

To deactivate the alarm, press both controls again or turn the ignition to ACC or ON.



Locks and security

Replacing the battery

The remote transmitter is powered by one coin type three-volt lithium battery CR2032 or equivalent. Typical operating range will allow you to be up to 10 meters (33 feet) away from your vehicle. A decrease in operating range can be caused by the following factors:


- Weather conditions
- Nearby radio towers
- Structures around the vehicle
- Other vehicles parked next to the vehicle

To replace the battery:

1. Twist a thin coin between the two halves of the transmitter near the key ring. **DO NOT TAKE THE FRONT PART OF THE TRANSMITTER APART.**

2. Place the positive (+) side of new battery in the same orientation. Refer to the diagram inside the transmitter unit.

3. Snap the two halves back together.




Replacement of the battery will **not** cause the remote transmitter to become deprogrammed from your vehicle. The remote transmitter should operate normally after battery replacement.

Replacing lost transmitters

If a remote transmitter has been lost and you would like to remove it from the vehicle's memory, or you would like to purchase additional remote transmitters and have them programmed to your vehicle:

- Take **all** your vehicle's transmitters to your dealer for programming, or
- Perform the programming procedure yourself




Locks and security

Programming remote transmitters

It is necessary to have **all** (maximum of four — original and/or new) of your remote transmitters available prior to beginning this procedure.

To program the transmitters yourself:

- Place the key in the ignition and turn from 2 (LOCK) to 3 (OFF) and cycle between 3 (OFF) and 4 (ON) eight times in rapid succession (within 10 seconds) with the eighth turn ending in the 4 (ON) position. The doors will lock/unlock to confirm that programming mode has been entered.
- Within 20 seconds, program a remote transmitter by pressing any button on a transmitter. The doors will lock/unlock to confirm that the remote transmitter has been programmed. (If more than 20 seconds pass before pressing a remote transmitter button, the programming mode will exit and the procedure will have to be repeated.)
- Repeat the previous step to program additional remote transmitters. The doors will lock/unlock to confirm that each remote transmitter has been programmed.
- When you have completed programming the remote transmitters, turn the ignition to 3 (OFF) or wait 20 seconds. Again the doors will lock/unlock to confirm programming has been completed.



Illuminated entry

The illuminated entry system will turn on the interior lights when the remote transmitter unlock control is pressed.

The illuminated entry system will turn off the interior lights if the ignition is turned to the ON position, or if the remote transmitter lock control is pressed, or after 25 seconds of illumination.

The inside lights will not turn off if:

- they have been turned on with the dimmer control, or
- any door is open.

The battery save feature will turn off the interior lights 45 minutes after the last door is closed, even if the dimmer control is on.

Seating and safety restraints

SEATING

Notes:




Reclining the seatback can cause an occupant to slide under the seat's safety belt, resulting in severe personal injuries in the event of a collision.




Do not pile cargo higher than the seatbacks to reduce the risk of injury in a collision or sudden stop.

Recline seat (if equipped)

Move handle to the left to move seat forward or backward.




Rotate control to adjust seatback.




Seating and safety restraints

Easy-Aire seat (if equipped)


Move handle to the left to move seat forward or backward.



Rotate control to adjust seatback.




Pump handle to raise seat height.
Push handle full down to lower.
Always adjust the seat height **before** fastening seatbelt.




Seating and safety restraints

Air-Ride seat (if equipped)

Push up on the switch to raise the seat height.




Press down on the switch to lower the seat height.




Always adjust the seat height **before** fastening seatbelt.

Press up on the switch to increase the firmness of the seatback.




Press down on the switch to reduce the firmness of the seatback.



Seating and safety restraints


40/20/40 split bench seat (if equipped)

- Lift the track release bar to move the seat forward or backward. Ensure the seat is related into place.
- Pull the handle on the side of the seat up to recline the seat.
- Push down the lever located at the bottom of the seatback to quickly fold the seatback forward.




Adjusting the front power seat (if equipped)

The control is located on the outboard side of the seat cushion. Press to raise or lower the front portion of the seat cushion.




Press to raise or lower the rear portion of the seat cushion.



Seating and safety restraints


Press the control to move the seat forward, backward, up or down.



Heated seats (if equipped)

To operate the heated seats:

- Push control to activate.
- Push again to deactivate.




REAR FLIP-UP SEAT (IF EQUIPPED)

Flipping-up the seat

The rear seatback has a split 60/40 seat. Each seat cushion can be flipped-up into the seatback position.

1. Pull the control to release the seat cushion.
2. Rotate the seat cushion up until it locks into the vertical storage position.



Seating and safety restraints

Returning the seat to horizontal position



Always latch the vehicle seat to the floor, whether the seat is occupied or empty. If not latched, the seat may cause injury during a sudden stop.



Make sure the safety belts are accessible and not trapped behind the seat when the seat is returned to its horizontal position.

1. Pull the control on the side of the seat to release the seat cushion from its storage position.
2. Push the seat cushion down until it locks into the horizontal position.

SAFETY RESTRAINTS

Safety restraints precautions



Always drive and ride with your seatback upright and the lap belt snug and low across the hips.



To reduce the risk of injury, make sure children sit where they can be properly restrained.



All occupants of the vehicle, including the driver, should always properly wear their safety belts.



Never let a passenger hold a child on his or her lap while the vehicle is moving. The passenger cannot protect the child from injury in a collision.



It is extremely dangerous to ride in a cargo area, inside or outside of a vehicle. In a collision, people riding in these areas are more likely to be seriously injured or killed. Do not allow people to ride in any area of your vehicle that is not equipped with seats and safety belts. Be sure everyone in your vehicle is in a seat and using a safety belt properly.

Seating and safety restraints




In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a safety belt.




Each seating position in your vehicle has a specific safety belt assembly which is made up of one buckle and one tongue that are designed to be used as a pair. 1) Use the shoulder belt on the outside shoulder only. Never wear the shoulder belt under the arm. 2) Never swing the safety belt around your neck over the inside shoulder. 3) Never use a single belt for more than one person.

Combination lap and shoulder belts

1. Insert the belt tongue into the proper buckle (the buckle closest to the direction the tongue is coming from) until you hear a snap and feel it latch. Make sure the tongue is securely fastened in the buckle.



2. To unfasten, push the release button and remove the tongue from the buckle.



The front and rear outboard safety restraints in the vehicle are combination lap and shoulder belts. The front and rear seat passenger outboard safety belts have vehicle sensitive emergency locking retractors.

Seating and safety restraints


Vehicle sensitive retractor

The vehicle sensitive retractor allows free shoulder belt length adjustment to your movements and locks in response to vehicle movement. For example, if the driver brakes suddenly or turns a corner sharply, or the vehicle receives an impact of approximately 8 km/h (5 mph) or more, the combination safety belts will lock to help reduce forward movement of the driver and passengers.

Front safety belt height adjustment


SuperCab and CrewCab vehicle has safety belt height adjustments for the driver and front passenger. Adjust the height of the shoulder belt so the belt rests across the middle of your shoulder.

- 4-door SuperCab



Seating and safety restraints

- 4-door CrewCab



To lower the shoulder belt height, push the button and slide the height adjuster down. To raise the height of the shoulder belt, slide the height adjuster up. Pull down on the height adjuster to make sure it is locked in place.

 Position the safety belt height adjusters so that the belt rests across the middle of your shoulder. Failure to adjust the safety belt properly could reduce the effectiveness of the seat belt and increase the risk of injury in a collision.


Lap belts

The front center and rear center lap belts do not adjust automatically.


 The lap belt should fit snugly and as low as possible around the hips, not across the waist.

Seating and safety restraints

Insert the tongue into the correct buckle (the buckle closest to the direction the tongue is coming from). To lengthen the belt, turn the tongue at a right angle to the belt and pull across your lap until it reaches the buckle. To tighten the belt, pull the loose end of the belt through the tongue until it fits snugly across the hips.



Shorten and fasten the belt when not in use.



Safety belt warning light and indicator chime

The safety belt warning light illuminates in the instrument cluster and a chime sounds to remind the occupants to fasten their safety belts.

Conditions of operation

If...	Then...
The driver's safety belt is not buckled before the ignition switch is turned to the ON position...	The safety belt warning light illuminates 1-2 minutes and the warning chime sounds 4-8 seconds.
The driver's safety belt is buckled while the indicator light is illuminated and the warning chime is sounding...	The safety belt warning light and warning chime turn off.
The driver's safety belt is buckled before the ignition switch is turned to the ON position...	The safety belt warning light and indicator chime remain off.

Seating and safety restraints

BeltMinder

The BeltMinder feature is a supplemental warning to the safety belt warning function. This feature provides additional reminders to the driver that the driver's safety belt is unbuckled by intermittently sounding a chime and illuminating the safety belt warning lamp in the instrument cluster.

If...	Then...
The driver's safety belt is not buckled before the vehicle has reached at least 5 km/h (3 mph) and 1-2 minutes have elapsed since the ignition switch has been turned to ON...	The BeltMinder feature is activated - the safety belt warning light illuminates and the warning chime sounds for 6 seconds every 30 seconds, repeating for approximately 5 minutes or until safety belt is buckled.
The driver's safety belt is buckled while the safety belt indicator light is illuminated and the safety belt warning chime is sounding...	The BeltMinder feature will not activate.
The driver's safety belt is buckled before the ignition switch is turned to the ON position...	The BeltMinder feature will not activate.

The following are reasons most often given for not wearing safety belts: (All statistics based on U.S. data)

Reasons given...	Consider...
"Crashes are rare events"	36700 crashes occur every day. The more we drive, the more we are exposed to "rare" events, even for good drivers. <i>1 in 4 of us will be seriously injured in a crash during our lifetime.</i>
"I'm not going far"	3 of 4 fatal crashes occur within 25 miles of home.

Seating and safety restraints

Reasons given...	Consider...
"Belts are uncomfortable"	We design our safety belts to enhance comfort. If you are uncomfortable - try different positions for the safety belt upper anchorage and seatback which should be as upright as possible; this can improve comfort.
"I was in a hurry"	Prime time for an accident. BeltMinder reminds us to take a few seconds to buckle up.
"Seat belts don't work"	Safety belts , when used properly, reduce risk of death to front seat occupants by 45% in cars , and by 60% in light trucks .
"Traffic is light"	Nearly 1 of 2 deaths occur in single-vehicle crashes , many when no other vehicles are around.
"Belts wrinkle my clothes"	Possibly, but a serious crash can do much more than wrinkle your clothes, particularly if you are unbelted.
"The people I'm with don't wear belts"	Set the example, teen deaths occur 4 times more often in vehicles with TWO or MORE people. Children and younger brothers/sisters imitate behavior they see.
"I have an air bag"	Air bags offer greater protection when used with safety belts. Frontal airbags are not designed to inflate in rear and side crashes or rollovers.
"I'd rather be thrown clear"	Not a good idea. People who are ejected are 40 times more likely to DIE . Safety belts help prevent ejection, WE CAN'T "PICK OUR CRASH".

Seating and safety restraints



Do not sit on top of a buckled safety belt to avoid the Belt Minder chime. Sitting on the safety belt will increase the risk of injury in an accident. To disable (one-time) or deactivate the Belt Minder feature please follow the directions stated below.

One-time disable

Any time the safety belt is buckled and then unbuckled during an ignition ON cycle, BeltMinder will be disabled for that ignition cycle only.

Deactivating/Activating the BeltMinder feature

Read steps 1 - 9 thoroughly before proceeding with the deactivation/activation programming procedure.

The BeltMinder feature can be deactivated/activated by performing the following procedure:

Before following the procedure, make sure that:

- The parking brake is set.
- The gearshift is in P (Park) (automatic transmission) or the neutral position (manual transmission).
- The ignition switch is in the OFF position.
- All vehicle doors are closed.
- The driver's safety belt is unbuckled.
- The parklamps/headlamps are in OFF position (If vehicle is equipped with Autolamps, this will not affect the procedure).



To reduce the risk of injury, do not deactivate/activate the Belt Minder feature while driving the vehicle.

BeltMinder activation and deactivation procedure

1. Turn the ignition switch to the RUN (or ON) position. (DO NOT START THE ENGINE.)
2. Wait until the safety belt warning light turns off. (Approximately 1–2 minutes.)
 - Steps 3–5 must be completed within 60 seconds or the procedure will have to be repeated.
3. Buckle then unbuckle the safety belt three times, ending with the safety belt unbuckled. This can be done before or during BeltMinder warning activation.

Seating and safety restraints

4. Turn on the parklamps/headlamps, turn off the parklamps/headlamps.
5. Buckle then unbuckle the safety belt three times, ending with the safety belt unbuckled.
 - After step 5 the safety belt warning light will be turned on for three seconds.
6. Within seven seconds of the safety belt warning light turning off, buckle then unbuckle the safety belt.
 - This will disable BeltMinder if it is currently enabled, or enable BeltMinder if it is currently disabled.
7. Confirmation of disabling BeltMinder is provided by the safety belt warning light flashing four times per second for three seconds.
8. Confirmation of enabling BeltMinder is provided by:
 - The safety belt warning light flashing four times per second for three seconds.
 - Followed by three seconds with the safety belt warning light off.
 - Once again, the safety belt warning light will flash four times per second for three seconds.
9. After receiving confirmation, the deactivation/activation procedure is complete.

Safety belt extension assembly

If the safety belt is too short when fully extended, there is a 20 cm (8 inch) safety belt extension assembly that can be added (part number 611C22). This assembly can be obtained from your dealer at no cost.

Use only extensions manufactured by the same supplier as the safety belt. Manufacturer identification is located at the end of the webbing on the label. Also, use the safety belt extension only if the safety belt is too short for you when fully extended.



Do not use extensions to change the fit of the shoulder belt across the torso.

Safety belt maintenance

Inspect the safety belt systems periodically to make sure they work properly and are not damaged. Inspect the safety belts to make sure there are no nicks, tears or cuts. Replace if necessary. All safety belt assemblies, including retractors, buckles, front seat belt buckle

Seating and safety restraints

assemblies, buckle support assemblies (slide bar-if equipped), shoulder belt height adjusters (if equipped), shoulder belt guide on seatback (if equipped), child safety seat tether anchors, and attaching hardware, should be inspected after a collision.



Ford Motor Company recommends that all safety belt assemblies used in vehicles involved in a collision be inspected for proper function and replaced, if necessary. Safety belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.



Failure to inspect and if necessary replace the safety belt assembly under the above conditions could result in severe personal injuries in the event of a collision.

Refer to *Interior* in the *Cleaning* chapter.

SAFETY RESTRAINTS FOR CHILDREN

Important child restraint precautions

You are required by law to use safety restraints for children in the U.S. and Canada. If small children (generally children who are four years old or younger and who weigh 18 kg [40 lbs] or less) ride in your vehicle, you must put them in safety seats made especially for children. Check your local and state or provincial laws for specific requirements regarding the safety of children in your vehicle. When possible, always place children under age 12 in the rear seat of your vehicle. Accident statistics suggest that children are safer when properly restrained in the rear seating positions than in the front seating position.



Never let a passenger hold a child on his or her lap while the vehicle is moving. The passenger cannot protect the child from injury in a collision.

Always follow the instructions and warnings that come with any infant or child restraint you might use.

Children and safety belts

If the child is the proper size, restrain the child in a safety seat.

Children who are too large for child safety seats (as specified by your child safety seat manufacturer) should always wear safety belts.

Seating and safety restraints

Follow all the important safety restraint precautions that apply to adult passengers in your vehicle.

If the shoulder belt portion of a combination lap and shoulder belt can be positioned so it does not cross or rest in front of the child's face or neck, the child should wear the lap and shoulder belt. Moving the child closer to the center of the vehicle may help provide a good shoulder belt fit.



Do not leave children, unreliable adults, or pets unattended in your vehicle.



Safety belts and seats can become hot in a vehicle that has been closed up in sunny weather; they could burn a small child. Check seat covers and buckles before you place a child anywhere near them.

Child booster seats

Children outgrow a typical convertible or toddler seat when they weigh 40 pounds and are around 4 years of age. Although the lap/shoulder belt will provide some protection, these children are still too small for lap/shoulder belts to fit properly, which could increase the risk of serious injury.

To improve the fit of both the lap and shoulder belt on children who have outgrown child safety seats, Ford Motor Company recommends use of a belt-positioning booster.

Booster seats position a child so that safety belts fit better. They lift the child up so that the lap belt rests low across the hips and the knees bend comfortably. Booster seats also make the shoulder belt fit better and more comfortably for growing children.


When children should use booster seats

Children need to use booster seats from the time they outgrow the toddler seat until they are big enough for the vehicle seat and lap/shoulder belt to fit properly. Generally this is when they weigh about 80 lbs (about 8 to 12 years old).

Seating and safety restraints

Booster seats should be used until you can answer YES to ALL of these questions:

- Can the child sit all the way back against the vehicle seat back with knees bent comfortably at the edge of the seat without slouching?



- Does the lap belt rest low across the hips?
- Is the shoulder belt centered on the shoulder and chest?
- Can the child stay seated like this for the whole trip?

Types of booster seats

There are two types of belt-positioning booster seats:

- Those that are backless.

If your backless booster seat has a removable shield, remove the shield and use the lap/shoulder belt. If a seating position has a low seat back and no head restraint, a backless booster seat may place your child's head (top of ear level) above the top of the seat. In this case, move the backless booster to another seating position with a higher seat back and lap/shoulder belts.



- Those with a high back.

If, with a backless booster seat, you cannot find a seating position that adequately supports your child's head, a high back booster seat would be a better choice.



Both can be used in any vehicle in a seating position equipped with lap/shoulder belts if your child is over 40 lbs.

Seating and safety restraints

The shoulder belt should cross the chest, resting snugly on the center of the shoulder. The lap belt should rest low and snug across the hips, never up high across the stomach.

If the booster seat slides on the vehicle seat, placing a rubberized mesh sold as shelf or carpet liner under the booster seat may improve this condition.

The importance of shoulder belts

Using a booster without a shoulder belt increases the risk of a child's head hitting a hard surface in a collision. For this reason, you should never use a booster seat with a lap belt only. It is best to use a booster seat with lap/shoulder belts in the back seat- the safest place for children to ride.



Follow all instructions provided by the manufacturer of the booster seat.



Never put the shoulder belt under a child's arm or behind the back because it eliminates the protection for the upper part of the body and may increase the risk of injury or death in a collision.



Never use pillows, books, or towels to boost a child. They can slide around and increase the likelihood of injury or death in a collision.

SAFETY SEATS FOR CHILDREN



Child and infant or child safety seats


Use a safety seat that is recommended for the size and weight of the child. Carefully follow all of the manufacturer's instructions with the

Seating and safety restraints

safety seat you put in your vehicle. If you do not install and use the safety seat properly, the child may be injured in a sudden stop or collision.

When installing a child safety seat:

- Use the correct safety belt buckle for that seating position.
- Insert the belt tongue into the proper buckle until you hear a snap and feel it latch. Make sure the tongue is securely fastened in the buckle.
- Keep the buckle release button pointing up and away from the safety seat, with the tongue between the child seat and the release button, to prevent accidental unbuckling.



- Place seat back in upright position.

Ford recommends the use of a child safety seat having a top tether strap. Install the child safety seat in a seating position which is capable of providing a tether anchorage. For more information on top tether straps, refer to *Attaching safety seats with tether straps*.




Carefully follow all of the manufacturer's instructions included with the safety seat you put in your vehicle. If you do not install and use the safety seat properly, the child may be injured in a sudden stop or collision.

Seating and safety restraints


Installing child safety seats with combination lap and shoulder belts

1. Position the child safety seat in a seat with a combination lap and shoulder belt.




Children under 12 are safer when properly restrained in the rear seat, to the extent this is possible.

2. While holding the shoulder and lap belt portions together, route the tongue through the child seat according to the child seat manufacturer's instructions. Be sure the belt webbing is not twisted.




Seating and safety restraints

3. Buckle the seat belt. Push down on the childseat and pull on the shoulder portion of the belt to snug the lap belt. Hold the lap and shoulder belts next to the tongue and unbuckle the belt.



4. Install a locking clip over both lap and shoulder belt portions next to the sliding tongue. Rebuckle the belt. Obtain the locking clip kit (part number FO3Z-5461248-A) at no charge from an authorized Ford or Lincoln-Mercury dealer.



5. Before placing the child in the seat, forcibly tilt the seat forward and back to make sure the seat is securely held in place. To check this, grab the seat at the belt path and attempt to move it side to side and forward and back. There should be no more than one inch of movement for proper installation.

6. If the child seat is not tight enough, unbuckle the seat belt, move the tongue and locking clip to shorten the lap portion and push down hard on the childseat while you rebuckle the belt.

7. Check to make sure the child seat is properly secured before each use.

Seating and safety restraints

Attaching safety seats with tether straps

Most forward-facing child safety seats include a tether strap which goes over the back of the set and hooks to an anchoring point. Tether straps are available as an accessory for many older safety seats. Contact the manufacturer of your child safety seat for information about ordering a tether strap.

Tether anchorage hardware

A tethered seat can be installed in the front seat. Put the tether strap over the seatback and attach it to an anchor bracket.

An anchor bracket can be installed to the inside of the back panel of your vehicle.

The anchor bracket must be installed using the instructions provided with the tether anchorage hardware kit.

Tether anchorage hardware kits (part number 613D74) including instructions, may be obtained at no charge from any Ford or Lincoln/Mercury dealer.

If you have a Super Cab or Crew Cab, Ford recommends you attach tether safety seats in the rear seating position (if possible) with the tether strap attached to the tether anchorage bracket as shown in the instructions provided with the tether anchor kit.



Tighten the anchor according to specifications. Otherwise, the safety seat may not be properly secured and the child may be injured in a sudden stop or collision.

Driving

STARTING PROCEDURES

Operating precautions

- Always shift to a lower gear at high altitudes to prevent engine smoking.
- Avoid extended and unnecessary idling.



Diesel engine vapors are combustible. Do not operate the engine in an enclosed area. These vapors can be sucked through the air intake system and cause an explosion which may result in severe bodily injury and extensive property damage.

Starting the engine

1. Ensure headlamps and all accessories are turned off, the parking brake is applied and the transmission is in the neutral position (or P [Park] for Allison 2400 transmissions).

If your vehicle is equipped with an air intake heater, the heater will activate in cooler weather. If the *Wait to start* light illuminates, **do not** crank the engine until the light goes off.

**WAIT
TO
START**



If equipped with an air intake heater, DO NOT use ether or any other starting fluids. The use of starting fluids (ether) in an engine equipped with an air intake heater could cause an explosion and result in property damage and/or personal injury.


2. Do not depress the accelerator during starting the engine.
3. Start the engine.

If the engine does not start after 30 seconds of cranking, allow two minutes for the starter to cool before trying again. Excessive cranking may damage the starter.

After the engine starts:

- On some engines, the *Wait to start* light should illuminate after the engine starts. Allow the engine to idle about three minutes or until the engine coolant temperature gauge begins to rise. Maintain idle speed until the *Wait to start* light cycles off to indicate the air intake heater has shut off (approximately six minutes). Operating the engine at higher speeds will reduce the effectiveness of the air inlet heater.
- Do not increase engine speed until the oil pressure gauge indicates normal pressure.
- Ensure engine oil pressure is indicated on the gauge within 15 seconds after starting.
- Idle the engine for three to five minutes before operating with a full load.
- Try to limit engine idle to 10 minutes. Excessive idling reduces fuel economy.
- When starting a cold engine, increase the engine speed (RPM) slowly to make sure adequate lubrication is available to the bearings.

**WAIT
TO
START**



Restarting after running out of fuel

The fuel system may need to be purged of air, refer to *Running out of fuel* in the *Maintenance and specifications* chapter.

Cold weather operation



Do not use volatile starting aids such as ether, propane or gasoline in the engine air intake system. Glow plugs may ignite vapors which can cause engine damage or personal injury.

In order to operate the engine in temperatures of 0°C (32°F) or lower, read the following instructions:

- Make sure that the batteries are of sufficient size and are fully charged. Check other electrical components to make sure they're in optimum condition.
- Use a permanent-type engine coolant solution to protect the engine against damage from freezing.

Driving

- If your vehicle is equipped with a water-fuel separator, drain it daily. Fill the fuel tank at the end of daily operation to prevent condensation in the fuel system.
- Make sure you use proper cold weather engine oil and that it is at its proper level.
- At temperatures of -20°C (-4°F) or below, it is recommended that you use a crankcase-mounted coolant heater to improve cold engine starting.
- If operating in arctic temperatures of -29°C (-20°F) or lower, consult your truck dealer for information about special cold weather equipment and precautions.

Note: Idling in cold weather will not heat the engine to its normal operating temperature. Long periods of idling in cold weather can cause a buildup of heavy deposits of carbon and rust on valve stems causing them to stick which, in turn, can cause valvetrain damage.

The following cold weather idling guidelines must be followed:

- Avoid idling the engine for more than 10 minutes at a time.
- Use a minimum of 45 Cetane Diesel fuel or use Cetane Index improvers from a reputable manufacturer.
- Maintain a minimum idle of 1250 RPM by using the hand throttle. Always make sure that the parking brake is applied and the transmission is in neutral before applying the hand throttle.
- Maintain the engine cooling system properly.
- Do not shut the engine down after an extensive idling period (10 minutes or more). Drive the vehicle under load for several miles at normal operating temperatures to burn off any accumulated carbon and varnish.
- Consider using an engine block heater, approved winter fronts and/or radiator shutters where conditions warrant.

Winter fronts

The use of winter fronts, or other air-restrictive devices mounted in front of the radiator on vehicles with chassis-mounted charge air coolers, are not recommended unless extremely cold weather conditions exist. Air flow restriction can cause high exhaust temperatures, power loss, excessive fan usage and a reduction in fuel economy. If you insist on using a winter front, the device should have a permanent opening of at least 774 sq. cm (120 sq in.) directly in line with the fan hub.

Hot weather operation

- Keep the engine cooling system filled with a clean, permanent coolant solution to protect against damage from overheating.
- Fill the fuel tank at the end of daily operation to prevent condensation in the fuel system.
- Keep external surfaces of the engine, radiator, charge air cooler, A/C condenser and accessories clean to avoid dirt build-up.

Above normal coolant temperatures could be experienced while driving in a transmission gear ratio which lugs the engine. To correct this problem, engine speed should be increased by downshifting in to the next lower gear to increase engine RPM.

Starting a turbocharged engine with the vehicle on a steep grade

When starting a naturally aspirated Diesel engine when the loaded vehicle is on a grade, the engine RPM will start to fall slightly when the clutch is engaged, but quickly recovers as the vehicle begins moving.

Turbocharged Diesel engines act differently; once the clutch is engaged, the engine RPM will fall significantly. When the engine RPM first falls, do not disengage the clutch and try to increase engine RPM as this may damage driveline components. After the initial drop in engine RPM, the engine will recover by itself and accelerate in a normal manner.

Engine shutdown

Allow the engine to idle for three to five minutes before shutting it down. The larger the engine, the greater the need for this idling period.

Engine automatic shutdown warning light or chime

Your vehicle may be equipped with an automatic shutdown feature that stops the engine in the event of high coolant temperature, low engine oil pressure or low engine coolant level. A warning light in the instrument cluster and a warning chime will indicate high engine coolant temperature or low engine oil pressure. If the temperature and/or pressure becomes too high or too low, the engine will automatically shut down.

Driving

Vehicles are equipped with an override feature that allows the operator to restart the engine so the vehicle can be moved; the engine should not be operated any longer than necessary. A decal located in front of the operator provides instructions on how the override should be operated.



Do not attempt to use this restarting feature to drive the vehicle very far as serious engine damage could result.



In the event of engine shutdown, make sure the vehicle is safely off the road and the problem is remedied prior to returning to the road. Failure to remove the vehicle from the road could result in an accident, causing serious injury or death.

GENERAL OPERATING INSTRUCTIONS

- Start the vehicle in motion by using the highest gear gear speed in the transmission that will let the engine easily start the load without slipping the clutch.
- Accelerate smoothly and evenly; rapid acceleration increases fuel consumption without increasing engine performance.
- When approaching a hill, depress the accelerator smoothly to start the incline at full power, then shift down as needed to maintain vehicle speed.
- When going down a hill, or long steep grades, prevent over-speeding of the engine. The engine governor has no control over engine speed when it is being pushed by a loaded vehicle.
- Operate in a gear that will permit an engine speed not in excess of the maximum governed speed or high-idle RPM (no load).



All vehicles have blind spots. To reduce the risk of severe injury or property damage, never move your vehicle to the side or rear or change lanes without being sure your way is clear on both sides and to your rear.

Driving

Backing up



To reduce the risk of the possibility of personal injury while backing the vehicle, always be sure your vehicle's path is clear.

Before backing your vehicle, be sure you can do so safely. If anything behind the cab limits your view, do not rely on mirrors alone to assure that your intended path is clear. If other people are in the vicinity, have someone standing well behind your vehicle and outside of your intended path (visible through an exterior mirror) guide you as you back up.

Although OSHA or some governmental regulations may require the use of an electrical or mechanical back-up alarm to warn bystanders, such an alarm does not assure that the intended path is clear.

If an electrical back-up alarm is installed, it should be connected to the back-up lamp circuit.

Parking your vehicle

Always use the parking brake. When parking on a grade, block the wheels and turn the front wheels to one side.



When parking your vehicle, do not leave the transmission in gear; if the key is in the ON position and the vehicle rolls, then engine could start. Failure to follow these instructions could result in an unattended vehicle moving, possibly causing personal injury or property damage.

Driving through water

If driving through deep or standing water is unavoidable, proceed very slowly especially if the depth is not known. Never drive through water that is higher than the bottom of the hubs (for trucks) or the bottom of the wheel rims (for cars). Traction or brake capability may be limited and your vehicle may stall. Water may also enter your engine's air intake and severely damage your engine.

Once through the water, always dry the brakes by moving your vehicle slowly while applying light pressure on the brake pedal. Wet brakes do not stop the vehicle as quickly as dry brakes. **Driving through deep water where the transmission vent tube is submerged may allow water into the transmission and cause internal transmission damage.**

Driving

Maximum vehicle loading

Every vehicle manufactured by Ford Motor Company is supplied with information on the Vehicle Rating Decal listing the maximum loading for the vehicle (GVWR), and its axle systems (GAWR) at the tire to ground interface.

A product of FORD MOTOR COMPANY					
MFD. BY BLUE DIAMOND TRUCK, S. de R.L. de C.V.					
FRONT			REAR		
G	A	LB	G	A	LB
V	W	12000	W	12000	12000
R	R	5443	R	5443	5443
15876	11RX22.5-14	TIRES	11RX22.5-14	TIRES	11RX22.5-14
22.5X8.25	RIMS	22.5X8.25	RIMS	22.5X8.25	RIMS
AT 724 KPA/105	PSI COLD	AT 724 KPA/105	PSI COLD	AT 724 KPA/105	PSI COLD DUAL
WB: 260	Model: F750	ASSEMBLED IN MEXICO			
VIN 3FRXF75L0V285893			MFD ON 01-MAY-2002		
					
Ext. Pnt: XX		Int. Trim: XX		Axle: XX	
Tran: X					

- U.S.

A product of FORD MOTOR COMPANY					
Incomplete Vehicle Manufactured By (Véhicule incomplet fabriqué par)					
BLUE DIAMOND TRUCK, S. de R.L. de C.V.					
FRONT			REAR		
G	A	LB	G	A	LB
V	W	12000	V	W	12000
R	R	5443	R	R	5443
15876	11RX22.5-14	TIRES	11RX22.5-14	TIRES	11RX22.5-14
22.5X8.25	RIMS	22.5X8.25	RIMS	22.5X8.25	RIMS
AT 724 KPA/105	PSI COLD	AT 724 KPA/105	PSI COLD	AT 724 KPA/105	PSI COLD DUAL
WB: 230	Model: F750 4X2	ASSEMBLED IN MEXICO			
VIN 3FRXF75L0V285893			MFD ON 01-MAY-2002		
					
Ext. Pnt: XX		Int. Trim: XX		Axle: XX	
Tran: X					

- Canada

Driving

Under no circumstances should your vehicle be loaded in excess of the GVWR or GAWR. It is the operator's responsibility to assure that neither the axle capacities, spring capacities, tire capacities nor the vehicle rated GVWR is exceeded. For tire capacities, refer to *Maintenance and specifications* chapter.

Unloaded or lightly loaded vehicles

The braking system has been designed to safely stop your vehicle when fully loaded to its GVWR.



When operating empty or lightly loaded, sudden or hard braking may induce wheel lockup with loss of vehicle control and the possibility of accident and serious injury, especially on wet or slippery road surfaces.

HYDRAULIC BRAKES (IF EQUIPPED)

Your service brakes are self-adjusting. Refer to the *General Maintenance Information* for scheduled maintenance.

Occasional brake noise is normal and often does not indicate a performance concern with the vehicle's brake system. In normal operation, automotive brake systems may emit occasional or intermittent squeal or groan noises when the brakes are applied. Such noises are usually heard during the first few brake applications in the morning; however, they may be heard at any time while braking and can be aggravated by environmental conditions such as cold, heat, moisture, road dust, salt or mud. If a "metal-to-metal," "continuous grinding" or "continuous squeal" sound is present while braking, the brake linings may be worn-out and should be inspected by a qualified service technician.



If you are driving down a long or steep hill, shift to a lower gear. Do not apply your brakes continuously, as they may overheat and become less effective.

IF BRAKES DO NOT GRIP WELL

- If you have been driving through deep water, gently apply the brakes several times while the vehicle is moving slowly.
- Let the brakes cool if you have been using them excessively, as in mountain driving or after several fast, high speed stops.
- Check brake adjustment.
- Check brake linings for excessive wear.

Driving

Hydraulic brake booster system (Hydromax)

The Hydromax systems receive fluid pressure from the power steering pump to provide power assist during braking.

The Hydromax booster receives backup pressure from the reserve system electric pump whenever the fluid in the power steering system is not flowing. When the engine is OFF, the pump will turn on if the brake pedal is applied, or if the ignition is turned to the ON position.

The sound of the pump operating may be heard by the driver, but this is a normal characteristic of the system.

The reserve system provides reduced braking power, so the vehicle should be operated under these conditions with caution, and only to seek service repair and remove the vehicle from the roadway.

For Hydromax, under normal operating conditions noise of the fluid flowing through the booster may be heard whenever the brake is applied. This condition is normal. Vehicle service is not required.

If braking performance or pedal response becomes very poor, even when the pedal is strongly applied, this may indicate the presence of air in the hydraulic system or fluid leakage. Stop the vehicle safely as soon as possible and seek service immediately.

If the red BRAKE warning lamp in the instrument cluster remains illuminated after engine start up, this indicates a system failure in the master cylinder of the brake system. Stop the vehicle safely as soon as possible and seek service immediately.




If the yellow BRAKE RESERVE (E-motor) warning light remains on while the engine is running, this indicates inadequate hydraulic booster pressure or reserve pump system failure. Stop the vehicle safely as soon as possible and seek service immediately.



Parking brake

Apply the parking brake whenever the vehicle is parked. To set the parking brake, pull handle up until it snaps into the locked position.

When the parking brake is out of adjustment, seek service immediately.



The parking BRAKE warning lamp in the instrument cluster illuminates and remains illuminated (when the ignition is turned ON) until the parking brake is released.




 Do not use the gearshift selector in place of the parking brake. Always set the parking brake fully AND make sure the gearshift selector is in R (Reverse) for vehicles equipped with manual transmission, P (Park) **(if equipped)** or N (Neutral) for vehicles with automatic transmission. Use of wheel chocks is also recommended in hilly or off-road usage.

 Unexpected and possible sudden vehicle movement may occur if these precautions are not taken.

Driving

The parking brake is not recommended to stop a moving vehicle. However, if the normal brakes fail, the parking brake can be used to stop your vehicle in an emergency. Since the parking brake only applies retardation to the rear wheels, the vehicle's stopping distance will increase greatly and the handling of your vehicle will be adversely affected.

Push the palm release lever on the parking brake handle and push down as far as possible to release the brake. Driving with the parking brake on will cause the brakes to wear out quickly and reduce fuel economy.



Burnish procedure

For optimal performance of a new parking brake system/new linings perform the following procedure:

1. While driving the vehicle at 16 km/h (10 mph) apply the parking brake (with applicable force to set to approximately 18 kg [40 lbs]). Allow the vehicle to come to a complete stop.
2. Release the parking brake, drive 16.8 km (1.5 miles) to cool the brakes.
3. Repeat steps 1 through 2 ten times.

AIR BRAKES (IF EQUIPPED)


Foot service brakes

Air brakes are operated by a standard dash-mounted foot pedal.

All standard equipment brakes are designed to be self-adjusting. Automatic adjustment, when required, occurs whenever the brakes are applied and released during forward or reverse operation.

Know the required stopping distances for all driving conditions that may be encountered. For longer brake lining life, take full advantage of engine braking power when coming to a stop.

Before descending a long or steep hill, shift to a lower gear and avoid continuous application of the brakes.



Do not drive with your foot resting on the brake pedal. This will result in abnormally high brake temperatures, excessive lining wear and increased stopping distances.



Continuous application of the brakes will cause the brakes to overheat, resulting in a temporary loss of braking.

Occasional or intermittent brake squeal may result from environmental conditions such as cold, hot, wet, snow, salt, mud, etc. This condition will not affect braking effectiveness. The brakes should be checked only if squeal occurs continuously with every application.

If brakes do not grip well


- If you have been driving through deep water, gently apply the brakes several times while the vehicle is moving slowly.
- Let the brakes cool if you have been using them excessively, as in mountain driving or after several fast, high speed stops.
- Check brake adjustment.
- Check brake linings for excessive wear.
- Check system air pressure.

Driving

Air brake reservoir draining

 Failure to drain air brake reservoirs can result in a reduction or loss of braking ability due to fluid accumulation in the reservoir and/or possible freeze-up during cold weather.

Drain all the air brake reservoirs daily, completely to 0 kPa/psi, by opening the draincock at the ends of the tanks (where accessible). Pull-chains are used when the drains are undercab or otherwise inaccessible). Close draincock after complete draining. Air tanks equipped with automatic moisture ejector valves may also be drained manually as required to maintain a dry air system. Contact your dealer if you are unsure of the air reservoir locations or the draining procedure.



Air brakes


After starting the engine, give the air compressor time to build up the air pressure to 414 kPa (60 psi) before moving the vehicle.

 Do not drive or continue to drive if the low air pressure buzzer is sounding or the brake warning light is lit. These warnings indicate that air pressure is not to normal operating level. Continued use of the vehicle could result in loss of braking ability.

 Avoid repeated light application of the brake pedal. This will deplete air pressure faster and could result in loss of braking capability.

Driving

Periodically check the air pressure gauge while driving. Pressure should range between approximately 724 to 930 kPa (105-135 psi). The air compressor governor cut-in and cut-out pressure settings are preset at the factory and are not adjustable.



BRAKE
(!)

When air pressure is insufficient (below 414 kPa [60 psi]), a warning light illuminates and a buzzer sounds when the ignition is in the ON position.

This condition may be caused by excessive brake applications depleting the system air pressure. If this condition occurs, stop driving the vehicle until the compressor has fully recharged the air system.



Do not move the vehicle in this condition because the brake system may be inoperative.

Select a gear ratio to help slow your vehicle before descending grades. Supplement with brakes as required to safely slow the vehicle and avoid overspeeding the engine.

Air chamber stroke indication


Air chamber push rods have orange stroke indicator stripes that alert the operator when the braking system requires adjustment or repair. The orange stripe is painted on the air chamber push rod at the slack adjuster readjustment stroke dimension.

Air brake inspection and adjustment should be performed by a qualified service technician in accordance with the instructions in the service manual.

Driving

Cam brakes - automatic slack adjusters

Standard air brakes (cam) are equipped with automatic brake adjusters. Automatic adjustment occurs during brake applications. Inspect brakes for proper adjustment at the intervals listed in the vehicle Service Maintenance Guide.



Emergency air brake

All vehicles are equipped with a dual brake system. In the unlikely event of a failure of one system, the second system will function for emergency stopping. These systems are all controlled by the brake pedal in the same manner as for normal stops.



Do not continue to operate the vehicle with a failure of one of the systems. Take the vehicle to your dealer for service immediately.

Parking brake



Do not use the gearshift selector in place of the parking brake. Always set the parking brake fully AND make sure the gearshift selector is in R (Reverse) for vehicles equipped with manual transmission or N (Neutral) for vehicles with automatic transmission.



Unexpected and possible sudden vehicle movement may occur if these precautions are not taken.

If the service brakes should fail to operate while the vehicle is in motion, you can make an emergency stop with the parking brake. The stopping distance, however, will be much greater than normal. Repairs should be made immediately to an inoperative air brake system circuit.

Parking brake control (knob)

Pull the yellow parking brake knob out to apply the parking brake. Push the knob in to release the parking brake.

 This control is used for parking only. Do not leave the vehicle unattended after setting the parking brake without placing the transmission in R (Reverse) for manual transmission or N (Neutral) for automatic transmission. Use of wheel chocks is also recommended in hilly or off-road usage.



Parking brake control (lever)

To engage the parking brake, depress the brake pedal, squeeze the parking brake handle, then pull the park brake handle up.

Note: The parking brake handle should not be allowed to snap up to the released position. The operator should always maintain manual control of the handle.

To release the parking brake, place the transmission in neutral (with the engine running to ensure hydraulic park brake assist), then depress the brake pedal, squeeze the parking brake handle, then push the park brake handle down.

Note: Rapid release of the handle, or forced release of the handle can cause the parking brake cable to kink at the handle. This may result in early cable failure.

 A failed parking brake cable can result in vehicle rollaway which can cause property damage, personal injury and/or death.

Note: Should the handle not travel to the fully released position, don't force it; this condition indicates that there is an obstruction at the brake end or a restriction within the cable housing. Check for any corrosion, ice, snow or cable damage in the cable housing which may prevent full release of the parking brake shoes. Any restriction in the parking brake cable must be removed to prevent cable damage.

Driving

If the parking brake does not hold the vehicle stationary, a linkage adjustment and/or the internal park brake adjustment must be performed. These procedures should only be done by a qualified technician.

Releasing spring brake with air pressure

The air system in all vehicles with spring-actuated rear wheel parking brakes is equipped with a tank valve located on the supply or service air tank for connection to an outside air supply. The valve permits the system to be recharged with air from an outside source, releasing the spring-actuated parking brakes. The vehicle may then be towed in an emergency.

An outside air source can be used only if the protected system is in operating condition. If air pressure cannot be restored in the protected air system, the spring-actuated brakes must be released manually.

Releasing spring brake manually



Do not attempt to disassemble the parking brake chamber under any circumstances. The high spring load may cause serious injury if the chamber clamps are removed.

If air pressure is released from the spring brake chamber the power spring applies the brake and, unless air pressure can be re-established, the spring brake must be released as follows in order to move the vehicle.



Block the wheels to prevent the vehicle from moving.





Unexpected and possibly sudden vehicle movement may occur if these precautions are not taken.

Impact wrenches should not be used as they may damage the piston and prevent proper caging of the spring. Do not apply more than 68 Nm (50 lb-ft) torque to the release bolt nut.

Driving

1. Remove the stud tool and nut from the carrying pocket on the brake chamber assembly.
2. Remove the access plug from the end of the spring chamber.
3. Insert the release stud through the opening in the chamber and into the spring pressure plate.
4. Turn the release stud one-quarter turn to engage the stud tangs with the slot in the pressure plate. Keep the stud engaged and install the nut on the release stud.
5. Tighten the nut until the spring is fully caged and the brakes are released. Do not loosen or remove the release stud and nut unless the brake chamber is completely assembled and is securely clamped.




6. When the air pressure is restored, unscrew and remove the release stud and install in the carrying pocket. Install the access plug.

Exhaust brake (if equipped)

An exhaust brake is an optional auxiliary braking system that assists, but does not replace, the primary service brake system. An on-off switch on the instrument panel, in combination with the accelerator and clutch pedal switches, allows the operator to make maximum use of the exhaust brake in the following conditions:


- off-highway driving
- mountain driving
- heavy traffic
- high speed highway driving

It is not available with automatic transmissions.



Driving


The exhaust brake is a butterfly type valve mounted in the exhaust pipe. When the operator's foot is not on the accelerator pedal and the exhaust brake switch is in the ON position, an air cylinder shuts the butterfly valve, restricting the flow of exhaust gases and retarding the engine. This retarding action is carried through the engine and drivetrain, slowing the vehicle and reducing the need for frequent service brake applications.



Exhaust brakes are not intended for use as the primary braking system during vehicle operation.

Operation

Push the rocker switch up to turn the exhaust brake on. The switch will illuminate in the ON position. Push the switch down to turn the brake off.



Starting engine

Before starting the engine, make sure that the exhaust brake switch is in the OFF position. Do not turn the exhaust brake on until the engine has reached normal operating temperatures.

Driving downhill

While approaching a steep grade, make sure that the exhaust brake switch is in the ON position. The exhaust brake actuates as soon as you remove your foot from the accelerator pedal. While going down the grade, use a low enough gear to descend safely with a minimum application of the service brakes. As a general guideline, use the same gear as you would to ascend the hill.

Before descending a hill or steep grade always select the proper gear. If the transmission is taken out of gear while descending it is possible that you will not be able to select another gear because of maximum RPM being governed.

Driving

Make sure the engine speed does not exceed the maximum allowable engine RPM. Exceeding the maximum allowable engine RPM will result in damage to the engine. Apply the service brakes to reduce the engine RPM or make a slower descent by using a lower gear.



The exhaust brake is not recommended for use on slippery or low traction road surfaces. Under these conditions a loss of vehicle control could occur.

Exhaust brake operating characteristics

When you remove your feet from both the accelerator and clutch pedals and the exhaust brake switch is in the ON position, the exhaust brake is activated. The following conditions should exist if the brake is operating properly:

- A slight change in the sound of the engine when the exhaust brake is activated.
- Exhaust smoke appears normal.
- Engine temperature remains in the normal operating range.
- Road speed usually decreases when the exhaust brake is applied during a descent, except when the vehicle is carrying a heavy load or the grade is extremely steep. In these instances, you may need to apply the service brakes occasionally.
- During a descent, the tachometer usually shows a drop in RPM depending on the grade and the vehicle load.
- Do not expect a retarding effect similar to sudden hard application of the service brakes. The exhaust brake retards the vehicle with a smooth braking effect.
- Depending on the grade and vehicle load, you may or may not feel the retarding force acting against your body when the brake is applied. The brake's retarding force is actually preventing the vehicle from going much faster.


Make sure the exhaust brake is turned off before shutting off the engine.

Note: Installing an exhaust or auxiliary brake should never allow the engine to exceed maximum governed speeds under any conditions.

Driving

Trailer brake hand control

The hand control, located on the right-hand side of the instrument panel, is used to apply the trailer service brakes which are independent of the tractor service brakes.



The hand control should never be used to apply the brakes when the tractor and trailer are parked unattended. Air may leak from the system and the vehicle could possibly move, resulting in possible property damage, personal injury or death.

The hand control operates a valve that provides gradual control of air pressure applied; when the valve is only partially applied, the trailer brakes can be overridden by pressing fully on the brake pedal.

To apply the trailer brakes using the hand control, move the lever downward. The further the lever is pushed downward, the greater the air pressure is applied to the brakes. The lever will remain in place until manually moved.

To release the trailer brakes, move the lever upward completely.

Trailer air supply and parking brake modular controls




The trailer air supply valve delivers air to the trailer supply and will automatically pop out, shutting off the trailer supply if pressure is decreased to approximately 249 kPa (35 psi).




The parking brake controls the spring brakes on the tractor. When the knob is pulled out it causes the trailer supply valve to pop out, applying both the tractor and trailer parking brakes. The trailer brakes may be independently released by pushing only the trailer air supply valve in.

Initial charge




With the air system completely discharged, both knobs (1 and 2) will be out. When the air pressure reaches 483 kPa (70 psi) the trailer air supply (1 – red knob) may be pushed in and should stay in charging the trailer air system and releasing the trailer brakes.



The parking brake (2–yellow knob) can now be pushed in and supply air to the tractor spring brakes, releasing them.


Driving

Normal driving position




With both knobs pushed in, air is then supplied to both trailer and tractor spring brakes, and all brakes are released.

System park




With both knobs pushed in (normal driving position), the parking brakes for both the tractor and trailer can be applied by pulling the parking brake knob (2) out, exhausting air from the tractor spring brakes, simultaneously causing the trailer air supply valve to pop out, applying the trailer brakes.

Trailer charge



If both knobs are out, and you want to recharge the trailer while leaving the tractor spring brakes applied, the trailer air supply (1) can be pushed in to recharge the trailer air supply line. This mode may also be used to park a combination vehicle with tractor spring brakes.


Automatic application



If both knobs are pushed in and the brake system air pressure is reduced to approximately 249 kPa (35 psi), the trailer air supply (1) knob will automatically pop out applying the emergency or parking brakes on the trailer. If the trailer air supply (1) knob is manually held in and the air pressure is reduced to approximately 207 kPa (30 psi), a tripper piston within the valve will move, exhausting the trailer air supply, applying the trailer brakes. Further reduction of air pressure, while holding the trailer air supply knob in, will cause the parking brake knob to pop out at 172 kPa (25 psi).

Driving

Actuation of trailer park (emergency) or tractor bobtail position



To actuate the trailer brakes only, pull out the trailer air supply knob (1). The trailer brakes are now applied whether emergency or spring brakes are used on the trailer.


This mode is also used when the tractor is used during bobtail operation.

ANTI-LOCK BRAKE SYSTEM (ABS)

Four-wheel anti-lock brake system (ABS)

A noise from the hydraulic pump motor and pulsation in the pedal may be observed during ABS braking events. Pedal pulsation coupled with noise while braking under panic conditions or on loose gravel, bumps, wet or snowy roads is normal and indicates proper functioning of the vehicle's ABS. If the vehicle has continuous vibration or shudder in the steering wheel while braking, the vehicle should be inspected by a qualified service technician.

The ABS operates by detecting the onset of wheel lockup during brake applications and compensating for this tendency. The wheels are prevented from locking even when the brakes are firmly applied. The accompanying illustration depicts the advantage of an ABS equipped vehicle (on bottom) to a non-ABS equipped vehicle (on top) during hard braking with loss of front braking traction.



ABS warning lamp

The  warning lamp in the instrument cluster momentarily illuminates when the ignition is turned on and the engine is off. If the light does not

illuminate momentarily at start up, remains on after the vehicle reaches 10 to 15 km/h (5 to 10 mph), or continues to flash, the ABS needs to be serviced.

With the ABS light on, the anti-lock brake system is disabled and normal braking is still effective unless the brake warning light also remains illuminated. (If your parking brake warning lamp illuminates, have your vehicle serviced immediately).

Using ABS

- In an emergency or when maximum efficiency from the ABS is required, apply continuous full force on the brake. The ABS will be activated immediately, thus allowing you to retain full steering control of your vehicle and, providing there is sufficient space, will enable you to avoid obstacles and bring the vehicle to a controlled stop.
- The ABS does not decrease the time necessary to apply the brakes or always reduce stopping distance. Always leave enough room between your vehicle and the vehicle in front of you to stop.
- We recommend that you familiarize yourself with this braking technique. However, avoid taking any unnecessary risks.

TRACTION CONTROL™

Your vehicle may be equipped with a Traction Control™ system. This system helps you maintain the stability and steerability of your vehicle, especially on slippery road surfaces such as snow- or ice-covered roads and gravel roads, by reducing engine power and/or selectively applying the rear brakes. The system will allow your vehicle to make better use of available traction in these conditions.

Note: The traction control system will not apply the brakes when the vehicle speed is above 40 km/h (25 mph).

During Traction Control™ operation, the traction control light in the instrument cluster will flash and the engine will not “rev-up” when you push further on the accelerator. This



is normal system behavior and should be no reason for concern. If the traction control light does not flash or stays illuminated, the system is not functioning.

When the Traction Control™ switch, located on the instrument panel, is in the off position, the traction control light will be illuminated.

Driving

If you should become stuck in snow or ice or on a very slippery road surface, try switching the Traction Control[™] system off. This may allow excess wheel spin to “dig” the vehicle out and enable a successful “rocking” maneuver.




Aggressive driving in any road conditions can cause you to lose control of your vehicle increasing the risk of severe personal injury or property damage. The occurrence of a Traction Control[™] event is an indication that at least some of the tires have exceeded their ability to grip the road; this may lead to an increased risk of loss of vehicle control, vehicle rollover, personal injury and death. If you experience a severe road event, SLOW DOWN.

AIR SUSPENSION (IF EQUIPPED)

Note: The vehicle must not be operated without air in the suspension springs. Operating the vehicle without air in the air suspension springs will damage the suspension, degrade ride performance and may cause property damage.

The suspension system that automatically adjusts to different loads to maintain a constant frame height. The system allows for ease of vehicle loading and provides improved vehicle ride and increased driver comfort.

The system is controlled by a switch located on the instrument panel. The switch will operate only when the ignition is in the ACC (Accessory) or IGNITION positions and the air tanks have sufficient pressure to fill the air springs. When the ignition is turned off, the suspension will remain in whatever state it was last set.



Note: The suspension will dump air when the ignition is in the ACC or IGNITION position, but will only fill when the ignition is in the IGNITION position.

When the lower portion of the switch is pressed and the vehicle speed is below 8 km/h (5 mph), air supplied to the air spring is exhausted, lowering the frame for loading. Pressing the upper portion of the switch causes air to fill the air springs so the vehicle will regain normal ride height.

Tractor-trailer connections

 To reduce the risk of personal injury, use extreme caution when making brake and light connections. Inclement weather and accumulated road contamination deposits on handhold and stepping surfaces require extra care to avoid slip and falls. Provide adequate lighting of working areas.

 Do not climb on the back of the tractor unless it has been provided with a deck plate and handholds. Use a three-point stance when climbing up and down from a deck plate. Do not jump from the vehicle. Whenever possible, make all connections while standing on the ground.

Connecting and disconnecting a trailer with air suspension

When connecting to a trailer:

- Press the lower portion of the switch and air will exhaust from the air suspension system.
- After making the connection to the trailer, press the upper portion of the switch, then raise the landing gear.

When disconnecting the trailer:

- Lower the landing gear, then press the lower portion of the switch.
- Disconnect the brake hoses, trailer-side and rear light connectors, then pull the release lever on the fifth wheel.

The upper portion of the switch must be pressed before operating with a trailer or operating in the bobtail mode.

Suspension conversions

It is not recommended, or approved, that suspension conversions be performed. However, it is understood that, on occasion, aftermarket add-on suspensions are installed by others on the truck chassis which allow operator control for weight transfer from other axles (i.e., air lift axles).

 When operating a loaded vehicle, the driver must keep all adjustable axles on the ground at all times, supporting their share of the vehicle's load. Failure to do so can overload other axles, tires, wheels, springs, steering components, brakes and frames, resulting in early component failure, loss of vehicle control, possible property damage and personal injury.

Driving

FIFTH WHEEL OPERATION



Failure to follow the fifth wheel manufacturer's instructions for hooking and unhooking as well as sliding the fifth wheel could result in an accident, personal injury or death.



When the tractor and trailer are parked unattended, the trailer brake hand control should never be used to apply the brake, since air may leak from the system, allowing vehicle movement, resulting in possible property damage, personal injury or death.

Hook-up

1. Fifth wheel jaws must be fully opened.
2. Tilt the fifth wheel back to prevent body damage when the tractor is backed under a trailer.
3. Block the trailer wheels and be sure the trailer spring brakes are adjusted and applied. Never chase a trailer.
4. Make sure the brake hoses and light cords are clear of the fifth wheel.
5. Back the trailer squarely under the tractor, engaging the fifth wheel jaws on the kingpin. Always back-up slowly, making sure the trailer is neither too high nor too low. Avoid backing under the trailer from an angle.
6. Connect the service and emergency brake hoses and trailer light connector. Refer to *Tractor-trailer connection* in this chapter, adhering to the warning and using the three-point stance while connecting and disconnecting the trailer.
7. Inspect the jaws of the fifth wheel to be sure they have fully closed on the trailer kingpin and the trailer plate is resting securely on the fifth wheel.
8. Be sure the coupler release lever is in the locked position.
9. Charge the trailer brake system. Set the trailer brakes, either with the hand valve or tractor protection valve. Pull against the trailer for an additional check of proper hook-up. Do not pull hard enough to damage or strain the equipment.
10. Set the tractor parking brakes and fully raise the trailer landing gear. Refer to *Brakes* in this chapter for proper operation of the parking brake and trailer brakes.

Driving

11. Check the operation of all trailer lights and correct and lights that may be faulty.

Un-hook

1. Try to keep the tractor and trailer in a straight line.
2. Apply the parking brakes.
3. Lower the trailer landing gear, making sure it is on solid, level ground. The weight of the trailer is to be on the landing gear.
4. Block the trailer wheels.
5. Disconnect the brake hoses and light cords. Be sure hoses and cords are clear.
6. Pull coupler release lever to disengage the fifth wheel jaws.
7. Release the tractor parking brakes.
8. Pull out from the trailer slowly, allowing the landing gear to take the load gradually.

AUTOMATIC TRANSMISSION OPERATION (IF EQUIPPED)

Main transmission, auxiliary transmission, transfer case and power take-off (PTO) control shift patterns can be found on a placard or decal on the driver's visor door, on the instrument panel or on the shift control itself.

The main transmission control is used to select the various gear ratios or speeds of the transmission. Selecting D (Direct Drive), does not change the transmission gear ratio, but is used where the gear ratios in the main transmission are adequate to handle the vehicle operation.



Hold the brake pedal down while you move the gearshift lever between positions. If you don't hold the brake pedal down, your vehicle may move unexpectedly and cause property damage, personal injury or death.

Allison 2000 automatic transmission

This transmission is available with a column-mounted gearshift lever. The gear positions are displayed on the RNDL in the instrument cluster.

Allison 2400 automatic transmission with park pawl feature

Note: For Allison automatic transmission-equipped vehicles, also refer to the separate Allison Transmission Operator's Manual.

Driving

The Allison 2400 automatic transmission features a park pawl which, by grounding the output shaft, prevents the driveline from moving. If the vehicle is stationary, selecting P (Park) places the transmission in neutral and engages the park pawl. **Always use the parking brake.**

Note: If the transmission is shifted into P (Park) while the vehicle is in motion (2 km/h [1 mph] or higher), the park pawl mechanism will ratchet, and not hold the vehicle.



Always fully set the parking brake. Do not use the gearshift lever instead of the parking brake.



To avoid sudden, unwanted vehicle movement and possible personal injury or death, always bring the vehicle to a complete stop and put the transmission gearshift lever in P (Park) [Allison 2400], PB (Park Brake) [Auto-Apply Park Brake] or N (Neutral). (If equipped with the Allison 2400, slowly lift your foot off the brake pedal to engage the park pawl.) Fully apply the parking brake. (If equipped with the Allison 2400, do not rely only on the P (Park) position of the transmission.) (For the Auto-Apply Park Brake, make sure the PB (Park-Brake) selection has applied the parking brake and that it is held properly.) Turn off the engine if you're leaving the vehicle. **NEVER LEAVE THE VEHICLE UNATTENDED WITH THE ENGINE RUNNING.**

Releasing the parking brake - vehicle equipped with Allison 2400 automatic transmission

Perform the appropriate following procedure to release the parking brake:

Manual parking brake

1. Start the engine, then place your foot firmly on the brake pedal.
2. Push and hold the shift selector button while moving the gearshift lever to the desired position.
3. Push manual parking brake lever down to release it, then release the brake pedal.

Air-operated parking brake

1. Start the engine, then place your foot firmly on the brake pedal.
2. Push and hold the shift selector button while moving the gearshift lever to the desired position.
3. Push the parking brake knob in to release the air-operated parking brake, then release the brake pedal.

Optional P (Park) or PB (Park-Brake) position

1. Start the engine, then place your foot firmly on the brake pedal.
2. Push and hold the shift selector button and move the gearshift lever from P (Park) or PB (Park-Brake) to the desired position.
3. Push parking brake knob in to release the parking brake or, for PB (Park-Brake)-equipped vehicles, verify the knob is pushed in. Release the brake pedal.

Allison MD (Medium Duty) electronic World Transmission (WT)

Two modes are available for the Allison MD-WT: Performance and Economy. Performance mode will give you the best all-around transmission operation; Economy provides operation at lower engine RPM while maintaining adequate performance. The transmission will automatically default to Performance mode when you start the engine. Pressing MODE on the shifter will activate the Economy mode; this will also illuminate the Mode ON lamp.

If the engine speed is above idle when a gear is selected using the shifter, the vehicle will not move. To move the vehicle, the shifter must be moved to re-select a gear after the engine speed returns to idle.

Note: For more information regarding the Allison MD-WT, refer to the separate Allison MD-WT Operator's Manual.

Torque lock

If your vehicle is parked on an incline and P (Park) is not properly engaged (The parking brake is not applied before the transmission is shifted into P [Park]), the weight of the vehicle may generate an excessive amount of torque of the park pawl. In this situation, it may be difficult to shift the transmission out of P (Park). To drive the vehicle out of the torque lock, push the vehicle uphill a small amount to relieve the pressure on the park pawl and permit the shift out of P (Park), then depress the brake pedal. Hold the brake pedal down while shifting out of P (Park), then release the parking brake.


Park lock position

The transmission gearshift is equipped with a P (Park) position interlock. To shift from P (Park), the key must be in the ON position and the brake pedal depressed before the gearshift lever can be moved.

Driving

Allison MD (Medium Duty) push-button shifter

To shift the transmission into R (Reverse) or D (Drive), depress the brake pedal, then press R or D, then release the brake pedal. To select a lower range when in D (Drive), press the down-arrow button. To select a higher range when in D (Drive), press the up-arrow button. To place the transmission in N (Neutral), press N.



Automatic transmission operating temperatures

- Allison 2000/2400 – The sump/fluid reservoir temperatures should not exceed 120°C (250°F). The converter temperature should not exceed 144°C (300°F).
- Allison MD (with retarder) - Converter temperature should not exceed 158°C (330°F).

Your vehicle may be equipped with a warning light or gauge that will indicate high transmission fluid temperatures.

Power take-off (PTO) operation with an Allison automatic transmission (except MD applications and vehicles equipped with a Caterpillar 3126E engine)

The power take-off can be operated while the vehicle is standing or moving.

To engage the PTO, apply the brakes and shift to any gear other than N (Neutral) - this stops the rotation of the PTO drive gear in the transmission - then engage the PTO.

If engagement is prevented by the gear teeth not meshing properly, release the brakes and allow the vehicle to creep slightly - or shift the selector to N (Neutral) and then back in gear. The PTO should never be engaged by clashing the gear teeth. This may damage the PTO unit and the transmission PTO drive gear teeth. This could result in further damage to the transmission and PTO.

PTO operation with vehicle stationary

To operate the power take-off, stop the vehicle, idle the engine and set the parking brake. Make sure the gear selector is in any forward drive range, then engage the PTO. After the PTO is engaged for stationary

Driving

vehicle operation, move the range selector to N (Neutral). Increase the engine speed until the desired power take-off operation speed is obtained. To disengage the PTO after operation with the vehicle standing, release the throttle, allow the drive equipment to come to a stop, and then disengage the PTO.



When the PTO is operated with the vehicle stationary, the transmission must be placed in N (Neutral) with the parking brake set. If the transmission is not in N (Neutral) and is equipped with a remote throttle control, an increase in engine speed can overpower the parking brake and cause the vehicle to move, possibly resulting in personal and/or property damage.

PTO operation while vehicle is moving

After the PTO is engaged for driven vehicle operation, shift to the desired range and drive the vehicle. The speed of the PTO, during this period of operation, will always maintain direct relation to vehicle speed. PTO speed will decrease in relation to vehicle (transmission output) speed as shifts to a higher gear occur. When operating the PTO while the vehicle is moving, the PTO may be disengaged whenever it is no longer required. When there is no load on the PTO gear, it can be pulled out of engagement.

Power take-off (PTO) operation on vehicles equipped with a Caterpillar 3126E engine

If your vehicle is equipped with a Caterpillar 3126E engine, the PTO will only operate if the vehicle is in Neutral. This feature can be overridden by a special service tool; see your dealer or service representative for more information.

Power take-off (PTO) operation with an Allison automatic transmission (MD applications)

The PTO drive gear is engine driven and provides direct engine power. The PTO can be operated when the vehicle is either stationary or moving.

The PTO gear is in constant mesh with the drive gear in the torque converter housing. A friction clutch or constant drive is used to transmit power to the PTO.

Driving

CLUTCH

Properly maintain the clutch to prolong its life. Do not ride or slip the clutch as this will cause unnecessary heat and wear.

Clutch precautions

Maintain specified clutch adjustment; regularly inspect the clutch control linkage for tightness.

When adjustment of the clutch is necessary, it is very important that the work be performed properly or early clutch failure may result and a costly clutch overhaul may become necessary. Clutch work should only be performed by a qualified technician.

Engaging the clutch

- **Always start in the proper gear.** An empty vehicle can start in a higher gear than a fully loaded vehicle. Starting in too high a gear can cause clutch slippage and excessive heat and wear on the clutch. A gear that will start the vehicle moving at idle speed is the correct gear. If the engine has to be revved to get the vehicle going, the gear selection is too high.
- **Do not shift until the vehicle has reached the proper speed.** Upshifting before the vehicle has reached the proper speed can cause clutch slippage and excessive heat and wear on the clutch.
- **Never hold a vehicle on a grade with the clutch.** This will cause the clutch to slip and can actually burn up the clutch.
- **Never coast with the clutch disengaged.** The high RPM (sometimes over 10,000), can actually burst the facing material of the clutch.
- **Never engage the clutch while coasting.** Re-engaging the clutch after coasting may not only cause a great shock to the clutch, but the whole drivetrain. Internal engine damage and/or clutch and flywheel failure can result from this.

If your vehicle's transmission is equipped with a ceramic clutch, you must start the vehicle moving in first gear and engage the clutch before pressing the accelerator at idle. Also, don't try to slip the clutch by raising engine RPM and riding or feathering the clutch pedal since the vehicle will experience erratic engagement. Erratic engagement can cause the engine stalling and potential serious damage to the vehicle's driveline components.

Clutch brake (vehicles equipped with a non-synchronized transmission) - Vehicle stationary

A clutch brake is used to stop the transmission input shaft rotation so that the initial 1 (First) or R (Reverse) gear selection can be accomplished when the vehicle is stationary and the engine is running at idle speed. Clutch brake application occurs in the last 25 mm (one inch) of clutch pedal travel.

When using the clutch brake, fully depress the clutch pedal and shift the transmission into 1 (First) or R (Reverse). If the transmission won't go into one of these gears, slowly release the clutch pedal while applying light pressure on the transmission shift lever until it shifts into gear.

Note: After engagement of 1 (First) gear, **do not** use the clutch brake for upshifting or downshifting. If you do, clutch brake life will shorten and gear selection shift efforts may increase.

Double-clutch procedures - vehicles equipped with a non-synchronized transmission

In order to properly upshift or downshift, perform the following steps:

1. Depress the clutch pedal to disengage the clutch.
2. Shift the transmission in to neutral.
3. Release the clutch pedal.

If upshifting, wait until the engine speed matches the transmission speed of the gear you are selecting.

If downshifting, accelerate the engine until the engine speed matches the input speed of the gear you are selecting. Depress the clutch pedal immediately and shift into the desired gear, then release the clutch pedal.


MANUAL TRANSMISSION OPERATION (IF EQUIPPED)

Continued use of a damaged or worn clutch, prolonged clutch slippage or downshifting at excessive speeds can result in a failure of the engine, transmission or clutch components.

To avoid premature clutch wear and failure, do not drive with your foot resting on the clutch pedal or use it to hold the vehicle at a standstill on an upgrade as when waiting for a traffic light.

Driving

Manual transmission shift patterns are displayed on either the shift lever knob or the sun visor.



Study this information carefully before you drive the vehicle even though you may be familiar with similar units. Do not attempt to drive the vehicle without knowing the exact shift pattern of the transmission. Consult your authorized dealer if any questions exist as to the shifting instructions posted in your vehicle.



Do not coast the vehicle with the clutch pedal depressed or with the transmission in neutral. This practice could result in loss of vehicle control.

Always use a gear ratio low enough to allow the engine to operate above the minimum engine operation speed range. Do not lug the engine. When more power is required, shift to a lower gear and accelerate the engine near the governed speed.

Driving hints

The following driving hints are provided as a brief, general guide in operating the different manual transmissions used in your vehicle.

- Always use the lowest gear to start the vehicle.
- Do not slam or jerk the gearshift lever into gear.
- When shifting into 1 (First) or R (Reverse) with vehicle standing still, quickly release and depress the clutch pedal (if necessary to complete gear engagement).

Shifting with a synchronized transmission


With the clutch pedal depressed, use 2 (Second) gear synchronizer to stop the clutch disc rotation; this allows smooth engagement of 1 (First) or R (Reverse). To complete the gear engagement, it may be necessary to apply light pressure to the gearshift lever during initial engagement of the clutch. It takes a second or two to match gear speeds; steady pressure on the gearshift lever will help the synchronizer perform its job more quickly. If the gearshift lever is forced into position, this action defeats the purpose of the synchronizer by causing gear clash.

Shifting with a non-synchronized transmission

Refer to *Clutch brake* and *Double clutch procedures* in the *Clutch* section of this chapter.

Operating the Eaton FS-4205A and FS-5205A 5-speed transmissions

The 5-speed transmission is equipped with five forward gears and one reverse. The 2nd, 3rd, 4th and 5th gears are synchronized. The shift pattern is embossed on the gear shift knob.



Do not shift the transmission into R (Reverse) while the vehicle is moving as this could damage the transmission.

To go forward


With the engine idling, depress the clutch pedal and shift into 1 (First). Engage the clutch while pressing the accelerator to start forward. Operate the clutch and upshift as required by driving conditions.

To go backward

Reverse is obtained by putting the gearshift lever in R (Reverse) and engaging the clutch while pressing lightly on the accelerator.

Operating the Eaton FS-5406A, FS-5406N, FS-6406A and FS-6406N 6-speed transmissions

These 6-speed transmissions are equipped with six forward gears and one reverse. All the forward gears are synchronized. The shift pattern is embossed on the gear shift knob.



Do not shift the transmission into 1 (First) or R (Reverse) while the vehicle is moving as this could damage the transmission.

Driving

To go forward


With the engine idling, depress the clutch pedal and shift into 1 (First). Engage the clutch while pressing the accelerator to start forward. Operate the clutch and upshift as required by driving conditions.

To go backward

Reverse is obtained by putting the gearshift lever in R (Reverse) and engaging the clutch while pressing lightly on the accelerator.

Operating the Spicer ES56-7B and ES066-7B 7-speed transmissions

These 7-speed transmissions are equipped with seven forward gears and one reverse. The 2nd, 3rd, 4th, 5th, 6th and 7th gears are synchronized. The shift pattern is embossed on the gear shift knob.



Do not shift the transmission into 1 (First) or R (Reverse) while the vehicle is moving as this could damage the transmission.

To go forward


With the engine idling, depress the clutch pedal and shift into 1 (First). Engage the clutch while pressing the accelerator to start forward. Operate the clutch and upshift as required by driving conditions.

To go backward

Reverse is obtained by putting the gearshift lever in R (Reverse) and engaging the clutch while pressing lightly on the accelerator.


Removing key from ignition

- Turn the ignition key to OFF.
- Push the release lever forward and rotate the key towards you to remove it.



Operating the Eaton 8908LL 10-speed transmission

These transmissions have five forward speeds in the LO range, and four forward speeds in the HI range. These transmissions employ a Deep Reduction Valve and control to allow for a LO-LO gear operation for adverse conditions. Study the instruction plate on the sun visor thoroughly and learn the shift pattern of your transmission.




To go forward


With the engine idling, depress the clutch pedal and move the gearshift lever to the neutral position.

Driving

Place the range selector in the LO range and the Deep Reduction Button in the OUT/REARWARD position or,



place the Deep Reduction in the IN/FORWARD position if you want to start in LO-LO under adverse conditions.




To start forward, place the gearshift lever in LO gear and disengage the clutch while slightly depressing the accelerator. Operate the clutch and upshift through the shift pattern (up to 4th) as required by driving conditions. To shift into the HI range from 4th gear (LO range), place the range control button in the HI range, then shift to 5th gear. Upshift through 8th. When downshifting, shift 8-7-6-5, depress the range control button to LO, then move the gearshift lever to 4-3-2-1-LO as necessary. Never move the gearshift lever to the LO position when the transmission is in the HI range.

Use LO-LO only for adverse conditions by changing the Deep Reduction Button to the IN/FORWARD position, while the range selector is in the LO range and the gearshift lever is in the LO position. Do not pre-select Deep Reduction.

Driving


To upshift from LO-LO to LO in the same gearshift lever position, move the Deep Reduction Button to the OUT/REARWARD position and immediately release the accelerator, depress the clutch pedal once to break torque, and re-engage clutch.



The transmission will shift from Deep Reduction to low range when synchronous is reached, then accelerate.

To go backward


Reverse is obtained by putting the gearshift lever in R (Reverse) and the range control button in LO or HI (Deep Reduction Button should be in the OUT/REARWARD position).



Driving


Removing key from ignition

- Turn the ignition key to OFF.
- Push the release lever forward and rotate the key towards you to remove it.



Operating the Eaton 9210B 10-speed transmissions

These transmission have five forward speeds in both the LO and HI ranges, and two reverse speeds. Study the instruction plate on the sun visor and learn the shift pattern of your transmission.




To go forward

With the engine idling, depress the clutch pedal and push the range control button to the LO range position. Shift into the LO gear position and engage the clutch while pressing on the accelerator to start forward. Operate the clutch and upshift through the pattern as required by driving conditions. To shift into the HI range from the LO range, place the range control in the HI range position, then shift into 6th gear. When downshifting from HI to LO, place the range control into the LO range, then downshift from 6th gear to 5th gear (below 1,500 engine RPM).

To go backward

Reverse is obtained by putting the gearshift lever in R (Reverse) and the range control button in LO or HI.



Power-take off operation (PTO) with a manual transmission

Transmission-mounted power take-off units are available for local installation on your vehicle. See your Body Builder's Layout Book for restrictions on use and installation of power take-off units.

To engage the PTO unit, stop the vehicle and place the transmission control in neutral. Depress the clutch and allow the gears to stop rotating, then engage the PTO unit. The PTO can also be selected with the transmission in gear as long as the clutch is depressed.

When operating the PTO unit with the vehicle stationary, first set the parking brake (chock the wheels if the vehicle is on a hill or other unlevel surface).

REAR AXLE INFORMATION

Axle operating temperature normally will not exceed 38°C (100°F). If the operating temperature exceeds 110°C (230°F), the rate of axle lubrication oxidation will increase and shorten the life of the lubricant and seals, requiring axle lubrication changes to become more frequent to preserve the axle. Extreme Pressure (EP) lubricants should not be run consistently above 110°C (230°F).

Gross axle weight

Your truck has gross axle weight, gross vehicle weight and gross combination weight ratings. Do not exceed these ratings.



Exceeding these ratings by overloading can cause component failure resulting in property damage, personal injury or death.

Driving

Rear axles with locking or limited-slip differentials

If your vehicle is equipped with a locking or limited-slip differential, note the following:

- Power will be transmitted to the opposite wheel should one of the wheels begin to slip.
- Both wheels must be raised free of the ground should it be necessary to operate one wheel with the vehicle stationary.



If both wheels are not raised free of the ground, the one wheel that is not raised may pull the vehicle off its support, possibly resulting in personal injury

Driver-controlled differential lock

To prevent the vehicle from moving when servicing the wheels, tires or brakes, turn the engine off and raise all drive wheels of the locker differential axle. Axles equipped with NoSPIN Detroit Locker differentials deliver power to both wheels even when only one wheel is on the ground.



Failure to raise all drive wheels with this type of differential could cause the vehicle to move unexpectedly, resulting in property damage, personal injury or death.

Care should be taken to avoid sudden accelerations when both drive wheels are on a slippery surface.



Sudden accelerations on slippery surfaces could cause the wheels to spin, the vehicle to turn sideways on a crowned road surface or in a turn, possibly resulting in loss of vehicle control and personal injury.

Some Dana/Spicer drive axles have a driver-controlled differential lock. The differential lock can lock or unlock the differential when the vehicle is moving or stopped. When extra traction is required, the differential lock will provide full power to both axles.

The differential can be locked or unlocked when the vehicle is moving at a constant speed of less than 40 km/h (25 mph) and while the wheels are not slipping. If the differential is locked and vehicle speed exceeds 40 km/h (25 mph), the differential will automatically unlock. Also, the differential must not be locked when the vehicle is traveling down steep grades and traction is minimal.

Driving

When the differential is locked, the vehicle's turning radius will increase (vehicle will "under-steer")

Axle conversions

It is not recommended, or approved, for axle conversions to be performed. However, it is understood that, on occasion, aftermarket add-on axles are installed by others on the truck chassis which allow operator control for weight transfer from other axles (i.e., air lift axles).



When operating a loaded vehicle, the driver must keep all adjustable axles on the ground at all times, supporting their share of the vehicle's load. Failure to do so can overload other axles, tires, wheels, springs, steering components, brakes and frames, resulting in early component failure, loss of vehicle control, possible property damage and personal injury.

TWO-SPEED REAR AXLE

A two-speed rear axle allows the driver to select a LO range for greater pulling power and a HI range for greater road speed and fuel economy. These ranges can also be used to provide additional steps between transmission shifts when driving on steep grades and/or fuel economy may be factors.

Note: Do not shift between ranges when the speed control is on.



Never shift a two-speed axle when descending a steep grade as this may cause loss of vehicle control and result in personal injury.

Axle shifting

Manual transmissions:

- **To downshift**, select the next lower gear, release and depress the accelerator pedal rapidly, or while holding the accelerator pedal down, release and engage the clutch rapidly. **Note:** The clutch method is recommended when driving at slower speeds.
- **To upshift**, keep the accelerator pedal down, select the next higher gear, release the accelerator and pause until the axle upshifts. **Note:** De-clutch for smoother axle upshifts when driving at slower speeds.

Driving

Automatic transmissions:

- Use LO range for when you drive a fully loaded vehicle on a severe grade or in congested traffic. To activate LO range, press the upper portion of the switch.
- Use HI range for all normal driving conditions with a lightly loaded or partially loaded vehicle. To activate HI range, press the lower portion of the switch.



Note: You cannot split-shift with an automatic transmission. Also, downshifting above 64 km/h (40 mph) may result in transmission or axle damage.

Shifting the axle from LO to HI range - vehicle stopped

Place the transmission in N (Neutral), then press the lower part of the switch.

Shifting the axle from LO to HI range - vehicle moving

Accelerate to approximately 56 km/h (35 mph), press the lower part of the switch while the transmission is in N (Neutral), then release and apply the accelerator.

Shifting the axle from HI to LO range - vehicle stopped

Place the transmission in N (Neutral), then press the upper part of the switch.

Note: Do not shift the axle to LO range with the vehicle in motion.

Split-shifting (combined axle and transmission shift - manual transmissions only)

Split-shift sequence											
Ratio combination	1	2	3	4	5	6	7	8	9	10	11
Transmission gear	1st	1st	2nd	2nd	3rd	3rd	4th	4th	5th	6th	6th
Axle range	LO	HI	LO	HI	LO	HI	LO	HI	LO	LO	HI

Driving

To downshift the axle to a slower ratio and shift the transmission, shift the transmission and move the control switch to the lower ratio before the clutch is re-engaged.

To upshift the axle and shift the transmission, move the control switch to a faster ratio and make the transmission shift in the usual manner.

Ratio extender use

Low End

A two-speed axle can be used as a ratio-extender when split shifting is not necessary. For low end use, just shift the axle into the LO to start out, and shift to HI when the extra torque is no longer needed.

Transmission (5-speed)	1st	1st	2nd	3rd	4th	5th	6th
Two-speed Axle	Axle Low	Axle High					

High End

To use the two-speed axle as a high end ratio-extender, stay in the LO range for normal upshifts and only shift the axle to HI on the freeway for greater road speed.

Transmission (5-speed)	1st	2nd	3rd	4th	5th	6th Speed
Two-Speed Axle	Low for Gradeability					Axle High

Roadside emergencies

GETTING ROADSIDE ASSISTANCE

To fully assist you should you have a vehicle concern, Ford offers a complimentary roadside assistance program. This program is separate from the New Vehicle Limited Warranty and is not applicable to vehicles sold in Canada. The service is available:

- 24-hours, seven days a week
- for the New Vehicle Limited Warranty period (U.S.) of two years (unlimited miles)

Roadside assistance will cover:

- jump-starts.
- lock-out assistance.
- towing to the nearest Ford Motor Company dealership, or towing to your selling dealership if within 56 km (35 miles). Even non-warranty related tows, like accidents or getting stuck in the mud or snow, are covered (some exclusions apply, such as impound towing or repossession).

Using roadside assistance

Complete the roadside assistance identification card and place it in your wallet for quick reference. This card is found in the Owner Guide portfolio in the glove compartment.

To receive roadside assistance in the United States, call 1-800-241-3673.


If you need to arrange roadside assistance for yourself, Ford will reimburse a reasonable amount. To obtain information about reimbursement, call 1-800-241-3673.

Roadside emergencies

HAZARD FLASHER

The hazard flasher control is located on the steering column, just behind the steering wheel. The hazard flashers will operate when the ignition is off.

Push in the flasher control and all front and rear direction signals will flash. Press the flasher control again to turn them off. Use it when your vehicle is disabled and is creating a safety hazard for other motorists.



Note: With extended use, the flasher may run down your battery.


FUSING

If electrical components in the vehicle are not working, a fuse may have blown. Blown fuses are identified by a broken wire within the fuse. Check the appropriate fuses before replacing any electrical components.

Note: Always replace a fuse with one that has the specified amperage rating. Using a fuse with a higher amperage rating can cause severe wire damage and could start a fire.

Roadside emergencies

Fuse block - battery junction box



Fuse/Relay Location	Fuse Amp Rating	Fuse Description
F1	15A*	Main light switch
F2	—	Not used
F3	—	Not used
F4	15A*	Washer pump relay, Washer pump motor
F5	15A*	Exhaust brake (Caterpillar engine)
F6	—	Not used
F7	15A*	Stoplamp switches
F8	25A*	Fuel heater relay (Caterpillar engine)
F9	—	Not used
F10	15A*	Heated drain valve
F11	—	Not used
F12	—	Not used

Roadside emergencies

Fuse/Relay Location	Fuse Amp Rating	Fuse Description
F13	—	Not used
F14	—	Not used
F15	7.5A*	Body builder - trailer adapter stoplamps
F16	5A*	WABCO hydraulic ABS
F17	—	Not used
F18	10A*	Fuel transfer pump
F19	—	Not used
F20	10A*	Engine ECM power relay (Navistar V8 engine)
F21	10A*	Control for Hydro-max motor
F22	10A*	V8 engine IDM2 logic power
F23	—	Not used
F24	—	Not used
F101	30A**	Air ABS relay, Hydraulic modulator relay
F102	20A**	Ignition switch to customer access
F103	50A**	Ignition switch, Central Junction Box (CJB) fuses 8, 9, 10, 11, 19, 20, 23, 24, 25, 29, 30, 31
F104	20A**	Power point
F105	20A**	Door lock switches
F106	30A**	Main light switch, Multifunction switch, CJB fuses 16, 26 and 28, Headlamps, DRL relays
F107	50A**	CJB fuses 1, 2, 3, 4, 12, 13, 14, 15
F108	—	Not used
F109	40A**	Power window relay
F110	30A**	Motorized seat - driver's side
F111	30A**	Park lamps relay, Park lamps
F112	40A**	Blower motor relay, Blower motor
F113	30A**	Heated seats
F114	25A**	Hydraulic ABS ECU power
F115	40A**	Ignition switch, CJB fuse 21
F116	30A**	Turn relays and back-up lamp relay


Roadside emergencies

Fuse/Relay Location	Fuse Amp Rating	Fuse Description
F117	20A**	Stoplamp relay (Caterpillar engine)
F118	30A**	Motorized seat - passenger's side
F119/F120	60A**	Air brake, Trailer tow fuse block
F121/F122	60A**	Air brake, Trailer tow fuse block, Hydraulic brake, ABS
R1-201	—	Washer pump relay
R2-202	—	Wiper speed relay
R3-203	—	Wiper run-park relay
R4-204	—	Crank inhibit relay (Navistar V8 engine)
R5-207	—	Drain valve heater relay
R6-205	—	RH stop/turn relay
R7-206	—	LH stop/turn relay
R8-208	—	Back-up lamps relay
R9-209	—	ECM ISO relay (Navistar V8 engine) or Stoplamp relay (Caterpillar engine)
FIR1-301	—	Fuel heater, Fuel heater-fuel transfer pump
FIR2-302	—	Park lamp relay
FIR3-303	—	Blower motor relay
FIR4-304	—	Air ABS relay, Hydraulic modulator relay

* Mini fuse **Maxi fuse

Roadside emergencies

Fuse block - central junction box



Fuse/Relay Location	Fuse Amp Rating	Fuse Description
1	20A	Horn relay
2	15A	Hazard flasher
3	20A	Cigar lighter
4	10A	Diagnostics
5	15A	Blend door actuator, Back-up lamps, DRL signal, Heated seats
6	—	Horn switch
7	—	Not used
8	5A	Radio, GEM ACC
9	5A	Headlamp switch LED, Window switch LED and relay
10	15A	Heated and lighted mirrors

Roadside emergencies

Fuse/Relay Location	Fuse Amp Rating	Fuse Description
11	30A	Wiper motor, Washer pump relay
12	10A	Spare
13	20A	Cluster, Radio
14	10A	Interior lamp relay
15	10A	Interior lamp relay
16	15A	Headlamp high beam, High beam indicator
17	—	Not used
18	5A	Headlamp switch interior lighting
19	15A	Engine control (all engines), Accelerator pedal (Navistar V8 engine)
20	15A	Starting system
21	10A	DRL resistor
22	15A	Speed control feed (Navistar V8 engine), Air solenoid, Fuel transfer pump
23	10A	Hazard flasher (Run)
24	15A	ABS, Air dryer, Vacuum pump, Fuel heater relay
25	10A	Function selector switch
26	10A	RH headlamp low beam
27	—	Not used
28	10A	LH headlamp low beam
29	10A	Cluster warning lamps, Gauges GEM, Hydraulic brake ABS
30	—	Not used
31	15A	Allison transmission or ABS event
Relay 1	1/2 ISO	Interior lamp relay
Relay 2	1/2 ISO	Not used
Relay 3	Full ISO	Horn relay
Relay 4	Full ISO	One-touch window down relay
Relay 5	Full ISO	Not used

Roadside emergencies

JUMP STARTING YOUR VEHICLE



The gases around the battery can explode if exposed to flames, sparks, or lit cigarettes. An explosion could result in injury or vehicle damage.



Batteries contain sulfuric acid which can burn skin, eyes and clothing, if contacted.


Do not attempt to push-start your vehicle. Automatic transmissions do not have push-start capability; also, the catalytic converter may become damaged.

Jump starting your vehicle



The gases around the battery can explode if exposed to flames, sparks, or lit cigarettes. An explosion could result in injury or vehicle damage.


Connecting the jumper cables




1. Connect the positive (+) booster cable to the positive (+) terminal of the discharged battery.

Note: In the illustrations, *lightning bolts* are used to designate the assisting (boosting) battery.


Roadside emergencies



2. Connect the other end of the positive (+) cable to the positive (+) terminal of the assisting battery.



3. Connect the negative (-) cable to the negative (-) terminal of the assisting battery.



4. Make the final connection of the negative (-) cable to an exposed metal part of the stalled vehicle's engine, away from the battery and the carburetor/fuel injection system. **Do not** use fuel lines, engine rocker covers or the intake manifold as *grounding* points.



Do not connect the end of the second cable to the negative (-) terminal of the battery to be jumped. A spark may cause an explosion of the gases that surround the battery.


5. Ensure that the cables are clear of fan blades, belts, moving parts of both engines, or any fuel delivery system parts.

Roadside emergencies

Jump starting

1. Start the engine of the booster vehicle and run the engine at moderately increased speed.
2. Start the engine of the disabled vehicle.
3. Once the disabled vehicle has been started, run both engines for an additional three minutes before disconnecting the jumper cables.


Removing the jumper cables



Remove the jumper cables in the reverse order that they were connected.


1. Remove the jumper cable from the *ground* metal surface.

Note: In the illustrations, *lightning bolts* are used to designate the assisting (boosting) battery.




2. Remove the jumper cable on the negative (-) connection of the booster vehicle's battery.

Roadside emergencies



3. Remove the jumper cable from the positive (+) terminal of the booster vehicle's battery.



4. Remove the jumper cable from the positive (+) terminal of the disabled vehicle's battery.

After the disabled vehicle has been started and the jumper cables removed, allow it to idle for several minutes so the engine computer can *relearn* its idle conditions.

WRECKER TOWING INSTRUCTIONS

Before moving the towed vehicle, check for adequate road clearance of vehicle components. It is recommended the towed vehicle be unloaded prior to being towed to reduce any abnormal load to the vehicle components resulting from the towing procedures. Before towing, be sure to fully release the parking brake. The spring-actuated type parking brake can be reset by recharging the air system with at least 441 kPa (64 psi) of air. If the brake system will not retain air pressure, then the spring brakes must be released manually. Refer to *Parking brake* in the *Driving* chapter

Note: For towing, make sure the vehicle is securely connected to the tow vehicle and the tow vehicle parking brakes are applied before releasing the disabled vehicle's spring brakes.

Roadside emergencies



To reduce the risk of personal injury or property damage when manually releasing the spring brakes, be sure to block the wheels so the vehicle cannot move once the brakes are released.

Towing the vehicle with the front wheels suspended

When it is necessary to tow a vehicle with the front wheels suspended, extra precautions must be taken to avoid transmission or differential damage. Proceed as follows:

- Remove the axle shafts from the axle assembly to prevent the wheels from driving the differential and the transmission.
- The wheel hub ends must be covered to prevent loss of axle lubricant and entrance of other contaminants. If the axle shafts are not removed, removal of the propeller shafts is required.

Note: To avoid transmission damage, vehicles should not be towed even a short distance without suspending rear wheels or removing the axle shaft or propeller shaft.


Note: In the event the chassis is equipped with a tandem axle and the vehicle is to be towed from the front, the forward rear axle may be raised to clear the road surface and secured to the frame by chains or U-bolts, allowing only the rear rear axle to contact the road surface. Axle shafts must be removed from the rear rear axle assembly. The wheel hub ends must be covered to prevent loss of axle lubricant and entrance of contaminants. Use extreme care in securing the chains or U-bolts to avoid possible damage to the brake lines, hoses or other components.

Towing vehicles equipped with a driver-controlled differential lock

Note: If the vehicle must be towed to a service facility with the drive axle wheels on the ground, it is necessary to remove the axle shafts before the vehicle is towed.

Roadside emergencies

1. Shift collar in the locked position
2. Actuator assembly and shift fork
3. Axle shaft
4. Interference between the shift collar and housing
5. Shift collar in the unlocked position
6. Outer splines - axle shaft to collar
7. Shift collar and differential case splines
8. Inner splines - axle shaft to side gear
9. Side gear
10. Differential (plain) case half



Removing axle shafts before towing

1. Shift the main differential to the unlocked (disengaged) position. The differential lock light will turn off.
2. Remove the capscrews and washers or stud nuts and washers from flanges of both axle shafts.
3. Loosen the tapered dowels in the flanges of both axle shafts by holding a 1½ inch diameter brass drift or hammer against the axle shaft center and hitting it with a five or six pound hammer. **Note:** Do not use a chisel or wedge to loosen the axle shafts and dowels. Use of a chisel or wedge can damage the hub, axle shafts and oil seals.
4. Remove the tapered dowels and both axle shafts from the axle assembly.
5. Assemble a cover over openings of both wheel ends to prevent loss of lubricant and keep dirt away from the wheel bearing cavities.

Note: One of the axle shafts has two sets of splines. One set to engage with the differential side gear and one set to engage with the shift collar for the differential lock. It may be necessary to rotate the shaft slightly to align the gear spline teeth with the shift collar teeth in order to remove the axle shaft.

Roadside emergencies

Installing the axle shafts

1. Remove the covers from the wheel ends
2. Shift the differential lock to the unlocked position (disengaged) position.
3. Install the axle shafts
 - Place the gaskets on the wheel hub studs.
 - Push the right-hand axle shaft and gasket in to the wheel end and housing until the shaft stops against the differential shift collar.
 - Push down and in on the axle shaft flange and rotate the shaft until the splines of the shaft and shift collar are engaged.
 - Push the axle shaft further into the housing until the shaft stops against the differential side gear.
 - Push down on the axle shaft flange and rotate the shaft until the splines of the shaft and side gear are engaged.
 - Push the axle shaft completely into the housing until the axle shaft flange and the gasket are flush against the wheel hub.
 - Install the left-hand axle shaft and gasket into the wheel end.
4. If tapered dowels are required, install them at each stud and into the flange of the axle shaft. Use a punch or drift and hammer, if needed.
5. Install the fasteners and tighten to correct torque value. Refer to the Service Manual section.

Towing the vehicle with the rear wheels suspended

Note: To avoid damage to the cab roof or air deflector when towing the vehicle backward (rear wheels suspended) the air deflector must be removed.

Whenever possible, it is preferable to tow a disabled vehicle from the rear by raising the rear of the chassis. When towing a vehicle with the rear of the chassis suspended the front wheels must be locked in the straight-ahead position.

Vehicles equipped with a manual-shift transmission must have at least one (1) pint of transmission fluid drained from the case. This will prevent the transmission fluid from entering the clutch housing and fluid saturating the clutch discs. Make sure that the transmission fluid is replaced before the vehicle is returned to service.

Customer assistance

GETTING THE SERVICES YOU NEED

At home

Ford Motor Company and Ford of Canada have authorized dealerships to service your vehicle. It is preferred that you return to the authorized dealer where your vehicle was purchased when warranty repairs are needed. However, you may also take your vehicle to another Ford Motor Company or Ford of Canada dealership authorized for warranty repairs. Certain warranty repairs require special training though, so not all dealers are authorized to perform all warranty repairs. That means that depending on the warranty repair needed, the vehicle may need to be taken to another dealer. If a particular dealership cannot assist you, then contact the Customer Relationship Center.

If you have questions or concerns, or are unsatisfied with the service you are receiving, follow these steps:

1. Contact your Sales Representative or Service Advisor at your selling/servicing dealership.
2. If your inquiry or concern remains unresolved, contact the Sales Manager or Service Manager at the dealership.
3. If the inquiry or concern cannot be resolved at the dealership level, please contact the Ford Customer Relationship Center.

Away from home

If you own a Ford or Mercury vehicle and are away from home when your vehicle needs service, or if you need more help than the dealership could provide, after following the steps described above, contact the Ford Customer Relationship Center to find an authorized dealership to help you.

In the United States:

Ford Motor Company
Customer Relationship Center
16800 Executive Plaza Drive
P.O. Box 6248
Dearborn, Michigan 48121
1-800-392-3673 (FORD)
(TDD for the hearing impaired: 1-800-232-5952)
www.ford.com

Customer assistance

In Canada:
Customer Relationship Centre
Ford Motor Company of Canada, Limited
P.O. Box 2000
Oakville, Ontario L6J 5E4
1-800-565-3673 (FORD)
www.ford.ca

If you own a Lincoln vehicle and are away from home when your vehicle needs service, or if you need more help than the dealership could provide, after following the steps described above, contact the Ford Customer Relationship Center to find an authorized dealership to help you.

In the United States:
Ford Motor Company
Customer Relationship Center
16800 Executive Plaza Drive
P.O. Box 6248
Dearborn, Michigan 48121
1-800-521-4140
(TDD for the hearing impaired: 1-800-232-5952)
www.ford.com

In Canada:
Customer Relationship Centre
Ford Motor Company of Canada, Limited
P.O. Box 2000
Oakville, Ontario L6J 5E4
1-800-565-3673 (FORD)
www.ford.ca

In order to help you service your Ford or Lincoln Mercury vehicle, please have the following information available when contacting a Customer Relationship Center:

- Your telephone number (home and business)
- The name of the dealer and the city where the dealership is located
- The year and make of your vehicle
- The date of vehicle purchase
- The current odometer reading
- The vehicle identification number (VIN)

If you still have a complaint involving a warranty dispute, you may wish to contact the Dispute Settlement Board (U.S.).

Customer assistance

In some states (in the U.S.) you must directly notify Ford in writing before pursuing remedies under your state's warranty laws. Ford is also allowed a final repair attempt in some states.

In the United States, a warranty dispute must be submitted to the Dispute Settlement Board before taking action under the Magnuson-Moss Warranty Act, or to the extent allowed by state law, before pursuing replacement or repurchase remedies provided by certain state laws. This dispute handling procedure is not required prior to enforcing state created rights or other rights which are independent of the Magnuson-Moss Warranty Act or state replacement or repurchase laws.

THE DISPUTE SETTLEMENT BOARD (U.S. ONLY)

The Dispute Settlement Board is:

- an independent, third-party arbitration program for warranty disputes.
- available free to owners and lessees of qualifying Ford Motor Company vehicles.

The Dispute Settlement Board may not be available in all states. Ford Motor Company reserves the right to change eligibility limitations, modify procedures and/or to discontinue this service without notice and without incurring obligations per applicable state law.

What kinds of cases does the Board review?

Unresolved warranty repair concerns or vehicle performance concerns as on Ford and Lincoln Mercury cars and Ford and Lincoln Mercury light trucks which are within the terms of any applicable written new vehicle warranty are eligible for review, except those involving:

- a non-Ford product
- a non-Ford dealership
- sales disputes between customer and dealer except those associated with warranty repairs or concerns with the vehicle's performance as designed
- a request for reimbursement of consequential expenses unless a service or product concern is being reviewed
- items not covered by the New Vehicle Limited Warranty (including maintenance and wear items)
- alleged personal injury/property damage claims
- cases currently in litigation

Customer assistance

- vehicles not used primarily for family, personal or household purposes (except in states where the Dispute Settlement Board is required to review commercial vehicles)
- vehicles with non-U.S. warranties

Concerns are ineligible for review if the New Vehicle Limited Warranty has expired at receipt of your application and, in certain states eligibility is dependent upon the customer's possession of the vehicle.

Eligibility may differ according to state law. For example, see the unique brochures for California, West Virginia, Georgia and Wisconsin purchasers/lessees.

Board membership

The Board consists of:

- Three consumer representatives
- A Ford or Lincoln Mercury dealership representative

Consumer candidates for Board membership are recruited and trained by an independent consulting firm. The dealership Board member is chosen from Ford and Lincoln Mercury dealership management, recognized for their business leadership qualities.

What the Board needs

To have your case reviewed you must complete the application in the DSB brochure and mail it to the address provided on the application form. Some states will require you to use certified mail, with return receipt requested.

Your application is reviewed and, if it is determined to be eligible, you will receive an acknowledgment indicating:

- The file number assigned to your application.
- The toll-free phone number of the DSB's independent administrator.

Your dealership and a Ford Motor Company representative will then be asked to submit statements.

To properly review your case, the Board needs the following information:

- Legible copies of all documents and maintenance or repair orders relevant to the case.
- The year, make, model, and Vehicle Identification Number (VIN) listed on your vehicle ownership license.
- The date of repair(s) and mileage at the time of occurrence(s).

Customer assistance

- The current mileage.
- The name of the dealer(s) who sold or serviced the vehicle.
- A brief description of your unresolved concern.
- A brief summary of the action taken by the dealer(s) and Ford Motor Company.
- The names (if known) of all the people you contacted at the dealership(s).
- A description of the action you expect to resolve your concern.

You will receive a letter of explanation if your application does not qualify for Board review.

Oral presentations

If you would like to make an oral presentation, indicate YES to question 6 on the application. While it is your right to make an oral presentation before the Board, this is not a requirement and the Board will decide the case whether or not an oral presentation is made. An oral presentation may be requested by the Board as well.

Making a decision

Board members review all available information related to each complaint, including oral presentations, and arrive at a fair and impartial decision. Board review may be terminated at any time by either party.

Every effort is made to decide the case within 40 days of the date that all requested information is received by the Board. Since the Board generally meets once a month, it may take longer for the Board to consider some cases.

After a case is reviewed, the Board mails you a decision letter and a form on which to accept or reject the Board's decision. The decisions of the Board are binding on Ford (and, in some cases, on the dealer) but not on consumers who are free to pursue other remedies available to them under state or federal law.

Customer assistance

To request a DSB Brochure/Application

For a brochure/application, speak to your dealer or write/call to the Board at the following address/phone number:

Dispute Settlement Board
P.O. Box 5120
Southfield, MI 48086-5120
1-800-428-3718

You may also contact the North American Customer Relationship Center at 1-800-392-3673 (Ford), TDD for the hearing impaired: 1-800-232-5952 or by writing to the Center at the following address:

Ford Motor Company
Customer Relationship Center
16800 Executive Plaza Drive
P.O. Box 6248
Dearborn, Michigan 48121

UTILIZING THE MEDIATION/ARBITRATION PROGRAM (CANADA ONLY)

In those cases where you continue to feel that the efforts by Ford and the dealer to resolve a factory-related vehicle service concern have been unsatisfactory, Ford of Canada participates in an impartial third party mediation/arbitration program administered by the Canadian Motor Vehicle Arbitration Plan (CAMVAP).

The CAMVAP program is a straight-forward and relatively speedy alternative to resolve a disagreement when all other efforts to produce a settlement have failed. This procedure is without cost to you and is designed to eliminate the need for lengthy and expensive legal proceedings.

In the CAMVAP program, impartial third-party arbitrators conduct hearings at mutually convenient times and places in an informal environment. These impartial arbitrators review the positions of the parties, make decisions and, when appropriate, render awards to resolve disputes. CAMVAP decisions are fast, fair, and final; the arbitrator's award is binding both to you and Ford of Canada.

CAMVAP services are available in all territories and provinces. For more information, without charge or obligation, call your CAMVAP Provincial Administrator directly at 1-800-207-0685.

Customer assistance

GETTING ASSISTANCE OUTSIDE THE U.S AND CANADA

Before exporting your vehicle to a foreign country, contact the appropriate foreign embassy or consulate. These officials can inform you of local vehicle registration regulations and where to find unleaded fuel.

If you cannot find unleaded fuel or can only get fuel with an anti-knock index lower than is recommended for your vehicle, contact a district or owner relations/customer relationship office.

The use of leaded fuel in your vehicle without proper conversion may damage the effectiveness of your emission control system and may cause engine knocking or serious engine damage. Ford Motor Company/Ford of Canada is not responsible for any damage caused by use of improper fuel.

In the United States, using leaded fuel may also result in difficulty importing your vehicle back into the U.S.

If your vehicle must be serviced while you are traveling or living in Central or South America, the Caribbean, or the Middle East, contact the nearest Ford dealership. If the dealership cannot help you, write or call:

FORD MOTOR COMPANY
WORLDWIDE DIRECT MARKET OPERATIONS
1555 Fairlane Drive
Fairlane Business Park #3
Allen Park, Michigan 48101
U.S.A.
Telephone: (313) 594-4857
FAX: (313) 390-0804

If you are in another foreign country, contact the nearest Ford dealership. If the dealership employees cannot help you, they can direct you to the nearest Ford affiliate office.

If you buy your vehicle in North America and then relocate outside of the U.S. or Canada, register your vehicle identification number (VIN) and new address with Ford Motor Company Worldwide Direct Market Operations.

Customer assistance

ORDERING ADDITIONAL OWNER'S LITERATURE

To order the publications in this portfolio, contact Helm, Incorporated at:

HELM, INCORPORATED

P.O. Box 07150

Detroit, Michigan 48207

Or call:

For a free publication catalog, order toll free: 1-800-782-4356

Monday-Friday 8:00 a.m. - 6:00 p.m. EST

Helm, Incorporated can also be reached by their website:

www.helminc.com.

(Items in this catalog may be purchased by credit card, check or money order.)

Obtaining a French owner's guide

French Owner's Guides can be obtained from your dealer or by writing to Ford Motor Company of Canada, Limited, Service Publications, P.O. Box 1580, Station B, Mississauga, Ontario L4Y 4G3.

IN CALIFORNIA (U.S. ONLY)

California Civil Code Section 1793.2(d) requires that, if a manufacturer or its representative is unable to repair a motor vehicle to conform to the vehicle's applicable express warranty after a reasonable number of attempts, the manufacturer shall be required to either replace the vehicle with one substantially identical or repurchase the vehicle and reimburse the buyer in an amount equal to the actual price paid or payable by the consumer (less a reasonable allowance for consumer use). The consumer has the right to choose whether to receive a refund or replacement vehicle.

California Civil Code Section 1793.22(b) presumes that the manufacturer has had a reasonable number of attempts to conform the vehicle to its applicable express warranties if, within the first 18 months of ownership of a new vehicle or the first 29,000 km (18,000 miles), whichever occurs first:

1. Two or more repair attempts are made on the same nonconformity likely to cause death or serious bodily injury OR
2. Four or more repair attempts are made on the same nonconformity (a defect or condition that substantially impairs the use, value or safety of the vehicle) OR

Customer assistance

3. The vehicle is out of service for repair of nonconformities for a total of more than 30 calendar days (not necessarily all at one time)

In the case of 1 or 2 above, the consumer must also notify the manufacturer of the need for the repair of the nonconformity at the following address:

Ford Motor Company
16800 Executive Plaza Drive
Mail Drop 3NE-B
Dearborn, MI 48126

REPORTING SAFETY DEFECTS (U.S. ONLY)

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you

Ford Motor Company

should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Ford Motor Company.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Ford Motor Company.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 (or 366-0123 in the Washington D.C. area) or write to:

NHTSA
U.S. Department of Transportation
Washington, D.C. 20590

You can also obtain other information about motor vehicle safety from the Hotline.

WASHING THE EXTERIOR

Wash your vehicle regularly with cool or lukewarm water and a neutral Ph shampoo, such as Motorcraft Detail Wash (ZC-3-A), which is available from your dealer.

- Never use strong household detergents or soap, such as dish washing or laundry liquid. These products can discolor and spot painted surfaces.
- Never wash a vehicle that is “hot to the touch” or during exposure to strong, direct sunlight.
- Always use a clean sponge or carwash mitt with plenty of water for best results.
- Dry the vehicle with a chamois or soft terry cloth towel in order to eliminate water spotting.
- It is especially important to wash the vehicle regularly during the winter months, as dirt and road salt are difficult to remove and cause damage to the vehicle.
- Immediately remove items such as gasoline, diesel fuel, bird droppings and insect deposits because they can cause damage to the vehicle’s paintwork and trim over time.
- Remove any exterior accessories, such as antennas, before entering a car wash.
- **Suntan lotions and insect repellents can damage any painted surface; if these substances come in contact with your vehicle, wash off as soon as possible.**

WAXING

Applying a polymer paint sealant to your vehicle every six months will assist in reducing minor scratches and paint damage.

- Wash the vehicle first.
- Do not use waxes that contain abrasives.
- Do not allow paint sealant to come in contact with any non-body (low-gloss black) colored trim, such as grained door handles, roof racks, bumpers, side moldings, mirror housings or the windshield cowl area. The paint sealant will “gray” or stain the parts over time.

PAINT CHIPS

Your dealer has touch-up paint and sprays to match your vehicle’s color. Take your color code (printed on a sticker in the driver’s door jam) to your dealer to ensure you get the correct color.

Cleaning

- Remove particles such as bird droppings, tree sap, insect deposits, tar spots, road salt and industrial fallout before repairing paint chips.
- Always read the instructions before using the products.

ALUMINUM WHEELS AND COVERS

Aluminum wheel rims or covers are coated with a clearcoat paint finish. In order to maintain their shine:

- Clean with Motorcraft Wheel and Tire Cleaner (ZC-37-A), which is available from your dealer.
- Never apply any cleaning chemical to hot or warm wheel rims or covers.
- Some automatic car washes may cause damage to the finish on your wheel rims or covers. Chemical-strength cleaners, or cleaning chemicals, in combination with brush agitation to remove brake dust and dirt, could wear away the clearcoat finish over time.
- Do not use hydrofluoric acid-based or high caustic-based wheel cleaners, steel wool, fuels or strong household detergent.
- To remove tar and grease, use Ford Extra Strength Tar and Road Oil Removal (B7A-19520-AA), available from your dealer.

ENGINE

Engines are more efficient when they are clean because grease and dirt buildup keep the engine warmer than normal. When washing:

- Take care when using a power washer to clean the engine. The high-pressure fluid could penetrate the sealed parts and cause damage.
- Do not spray a hot engine with cold water to avoid cracking the engine block or other engine components.
- Spray Motorcraft Engine Shampoo and Degreaser (ZC-20) on all parts that require cleaning and pressure rinse clean.
- Never wash or rinse the engine while it is running; water in the running engine may cause internal damage.

PLASTIC (NON-PAINTED) EXTERIOR PARTS

Use only approved products to clean plastic parts. These products are available from your dealer.

- For routine cleaning, use Motorcraft Detail Wash (ZC-3-A).
- If tar or grease spots are present, use Ford Extra Strength Tar and Road Oil Removal (B7A-19520-AA).

Cleaning

INSTRUMENT PANEL AND CLUSTER LENS

Clean the instrument panel with a damp cloth, then dry with a dry cloth.

- Avoid cleaners or polish that increase the gloss of the upper portion of the instrument panel. The dull finish in this area helps protect the driver from undesirable windshield reflection.
- Be certain to wash or wipe your hands clean if you have been in contact with certain products such as insect repellent and suntan lotion in order to avoid possible damage to the painted surfaces.

INTERIOR TRIM

- Clean the interior trim areas with a damp cloth, then dry by wiping with a dry, soft, clean cloth.
- Do not use household or glass cleaners as these may damage the finish.

INTERIOR

For fabric, carpets, cloth seats and safety belts:

- Remove dust and loose dirt with a vacuum cleaner.
- Remove light stains and soil with Ford Extra Strength Upholstery Cleaner (E8AZ-19523-AA).
- If grease or tar is present on the material, spot-clean the area first with Motorcraft Spot and Stain Remover (ZC-14).
- Never saturate the seat covers with cleaning solution.
- Do not use household cleaning products or glass cleaners, which can stain and discolor the fabric and affect the flame retardant abilities of the seat materials.



Do not use cleaning solvents, bleach or dye on the vehicle's seatbelts, as these actions may weaken the belt webbing.

LEATHER SEATS (IF EQUIPPED)

Your leather seating surfaces have a clear, protective coating over the leather.

- To clean, use a soft cloth with Motorcraft Deluxe Leather and Vinyl Cleaner (ZC-11-A). Dry the area with a soft cloth.
- To help maintain its resiliency and color, use the Motorcraft Deluxe Leather Care Kit (ZC-11-D), available from your authorized dealer.

Cleaning

- Do not use household cleaning products, alcohol solutions, solvents or cleaners intended for rubber, vinyl and plastics, or oil/petroleum-based leather conditioners. These products may cause premature wearing of the clear, protective coating.

UNDERBODY

Flush the complete underside of your vehicle frequently. Keep body and door drain holes free from packed dirt.

Maintenance and specifications

GENERAL SERVICING GUIDELINES AND PRECAUTIONS

As with any machine, care should be taken to avoid being injured when performing maintenance, repairs or system checks. Improper or incomplete service could result in the vehicle not working properly which, in turn, may result in personal injury or damage to the vehicle or equipment. It is the operator's responsibility to see that the vehicle receives proper care and maintenance. If you have any questions about performing some service, have the service done by a qualified technician.

Servicing guidelines

When servicing your vehicle, always:

- turn off the ignition unless the particular procedure call for the engine to be running.
- set the parking brake or chock the wheels.
- use support stands, not a jack, whenever you must be under a raised vehicle.
- do not smoke.
- wear safety glasses for eye protection.
- operate the engine in a well-ventilated area
- do not work on the brakes or the clutch unless the proper precautions are taken to avoid inhaling friction material dust.
- do not wear loose-fitting clothing, hanging jewelry, watches or rings.
- avoid contact with hot metal parts. Allow the hot components to cool before working with, or around them.

Quality service parts are available through your dealer. If dealer parts are not used, the owner must make sure that the parts that are being used are equivalent quality to dealer parts.



The use of inferior parts can adversely affect the quality and reliability of your vehicle which, in turn, can result in property damage, personal injury or death.

Note: To avoid damage to the vehicle's electrical components, disconnect the positive (+) and negative (-) battery cables prior to electric welding. Attach the welder ground cable as close as possible to the part being welded. If it is necessary to weld close to an electrical component, it is recommended that the electronic component be temporarily removed.

Follow the periodic lubrication procedures and regular inspection intervals as outlined. Have your dealer or service center inspect your

Maintenance and specifications

vehicle at least once a year. Remember that regular maintenance and replacement of worn components will usually prevent serious problems from developing later.



Making modifications to various parts, components and systems of the vehicle, such as brake and steering systems can adversely affect the quality, reliability and operation of your vehicle and could result in property damage, personal injury or death. Such modifications must be avoided.

The lubrication intervals present a good opportunity to inspect the vehicle. It is suggested that the various points listed herein be checked at the lubrication or other recommended intervals.



Failure to properly perform maintenance and servicing procedures could result in vehicle damage, personal injury or death.

If the owner/operator of the vehicle is a skilled technician and intends on performing the vehicle maintenance and service, he is strongly urged to purchase a service manual.



Take care when performing any maintenance, system check or service on your vehicle. Some of the materials may also be hazardous if used, serviced or handled improperly and could result in property damage, personal injury or death.

Air conditioning system checks

Have your air conditioning system checked each spring. The refrigerant charge, cleanliness of the condenser-evaporator cores and belt condition is essential to air conditioning performance.

When the air conditioning system is being used daily, remove the fresh air filter (if equipped) once each season and check for dirt, lint, etc. Replace the filter if necessary. Vehicles operating in unusually dusty conditions may require inspecting and replacing the fresh air filter more often.

Front axle - general service information

Maintaining the front axle alignment to specifications is very important and should only be performed by a qualified technician. Toe-in adjustment is particularly important with radial tires.

Maintenance and specifications

Check to make sure that the axle mounting U-bolt nuts, attaching or mounting bolts and nuts are securely tightened. Regularly check front axle for damage, binding, worn parts and adequate lubrication.

At regular intervals, or during other scheduled maintenance, (tire rotation/service, wheel bearing service, alignment, etc.) the kingpins should be checked for excessive wear. Refer to the service manual for proper procedures.

Toe-in setting - general inspection

Inspecting steer axle tires in the first 4,800–16,000 service km (3,000–10,000 service miles) will generally show if tires are wearing normally.

Rapid outside shoulder wear on both tires indicates too much toe-in. Rapid inside shoulder wear on both tires indicates too much toe-out. In P&D-type service, which includes school buses, left-to-right steer tire tread life differentials up to 40% can be observed depending on routes and other variables.

Follow the tire manufacturer's recommended cold inflation pressure for the tire size, load range (ply rating) and steer axle loading typical for their operation (each steer axle tire will equal ½ steer axle loading).

Special applications may warrant a setting based on past experience with the type of tire operating loads and conditions. Radial tires are more sensitive to toe-in setting than bias ply tires. While not insensitive to vehicle alignment, fine tuning school bus alignment to line-haul truck standards will not drastically improve tire tread life.

It is essential that correct toe-in and tire pressure be maintained for optimum tire wear.

Rear axle - general inspection

Check to make sure that the axle mounting U-bolts, attaching or mounting bolts and nuts are securely tightened. Refer to *U-bolt nut torque chart* in this chapter. Regularly check the rear axle for damaged, binding or worn parts.

NoSpin Detroit Locker positive locking differential

Vehicle equipped with this type differential have the operator's manual supplied with the vehicle. Refer to this manual for maintenance checks.

Brake system - general inspection

Your vehicle is equipped with non-asbestos brake linings. However, exposure to excessive amounts of brake material (whether asbestos or

Maintenance and specifications

non-asbestos, fiberglass, mineral wool, aramid or carbon) may be a potentially serious health hazard.



Avoid breathing brake lining fiber dust as it may be extremely hazardous to your health. Always use of respirator during brake maintenance.

Note: Persons handling brake linings should follow all precautions listed below:

1. Always wear a respirator approved by the National Institute of Occupational Studies of Health (NIOSH) or Mine Safety and Appliance (MSA) during all brake service procedures. Wear the respirator from removal of the wheels through assembly.
2. **Never** use compressed air or dry brushing to clean brake parts or assemblies.
3. Clean brake parts and assemblies in open air. During assembly, carefully place all parts on the floor to avoid getting dust in the air. Use an industrial vacuum cleaner with a HEPA filter system to clean dust from the brake drums, backing plates and other brake parts. After using the vacuum, remove any remaining dust with a rag soaked in water and wrung until nearly dry.
4. **Never** use compressed air or dry sweeping to clean the work area. Use an industrial vacuum cleaner with a HEPA filter system and rags soaked in water until wrung until nearly dry. Dispose of used rags with care to avoid getting dust in the air. Use an approved respirator when emptying vacuum cleaners and handling used rags.
5. **Worker clean-up:** Wash your hands before eating, drinking or smoking. Vacuum your work clothes after use and then launder them separately, without shaking them, to prevent fiber dust getting into the air.

Air brakes - inspection and adjustment

A regular schedule for periodic cleaning, lubrication, adjustment and inspection should be established based on the type of vehicle operation. It is difficult to predetermine an exact maintenance interval (time or mileage), since vehicles will be used in a wide variety of applications and conditions. If you are uncertain of the proper schedule and procedures for your vehicle, contact your dealer.

Periodic checking of push rod travel or brake adjustment is essential for effective braking. Push rod travel should be checked every service

Maintenance and specifications

interval to determine if adjustment is necessary. Brake chamber push rods on original equipment chambers now incorporate a stroke indicator to aid in adjustment checks; an orange paint marker near the base of the push rod. If the push rod is clean and the brakes require adjustment, the orange marker can be seen protruding from the chamber when the brakes are applied.

Slack adjusters should also be checked to ensure proper operation of the adjuster mechanism at the six-month interval. Push rod travel should be kept at a minimum without the brakes dragging.

Inspect the brake lining every maintenance interval. When brake lining or blocks are worn to within 1.6 mm (1/16 in.) of rivets, brake lining must be replaced. This inspection or adjustment should only be performed by a qualified technician and must be in accordance with instructions provided by the service manual.

Do not back off or disconnect the front brake so that they are less effective, letting the rear brakes do all the stopping of the vehicle. Do not overlook the brakes on the trailer, either. Brake condition on the trailer is just as important as the tractor. Proper brake balance on trucks and tractor-trailers is essential for effective braking.

Once a year, the entire brake system must be inspected. Check the following:

- Any rubber as it may deteriorate whenever used. Rubber brake components should be inspected by a qualified technician and replaced as necessary. Replacement intervals vary according to the severity and length of vehicle service.
- Condition of brake drums, brake chambers and slack adjusters.
- System for air leaks.
- Hose or pipes for rust, damage and deterioration.
- Operation of service and parking brakes.

Some parts such as air brake chamber diaphragm, air compressor and air cleaner should be inspected periodically and replaced if considered unserviceable.

Air brakes - air dryer

Performance of desiccant or after-cooler type air dryers is dependent on climatic conditions in which your vehicle is operating. Maintenance schedules must be established for each specific operation.

The use of an air dryer on a vehicle does not eliminate the need to periodically drain the air reservoirs.

Maintenance and specifications

Air brakes - desiccant air dryer

Inspect for moisture in the air system by opening reservoirs, drain cocks or valves and checking for presence of water. The presence of small amounts of water is due to condensation is normal and should not be considered as an indication that the dryer is not functioning properly.

The desiccant cartridge should be replaced or rebuilt when it has been determined that the desiccant is contaminated and does not have adequate water absorption capacity. The desiccant change interval may vary; it is generally recommended that the desiccant be replaced every 12 months (yearly). If experience has shown that extended or shortened life has resulted for a particular installation, then the yearly interval can be increased or decreased accordingly.

Hydraulic brakes - general inspection and adjustment

A regular schedule for periodic cleaning, lubrication, adjustment and inspection should be established based on the type of vehicle operation. It is difficult to predetermine an exact maintenance interval (time or mileage), since vehicles will be used in a wide variety of applications and conditions. If you are uncertain of the proper schedule and procedures for your vehicle, contact your dealer.

Inspect the brake lining every maintenance interval. Establish inspection intervals that provide for lining replacement before damage to the disc occurs. Excessive lining wear may expose the backing plate to the disc causing scoring of the disc faces.

This inspection should be performed by a qualified technician and must be in accordance with instructions provided by the service manual.

Note: Hydraulic brake system are power assisted. Braking capabilities will be greatly reduced without engine assist.

Hydraulic brakes - fluid level

Fluid level should be at the bottom edge of the ring on each reservoir fill port. Do not fill the master cylinder to the top of the reservoir.

Note: If brake fluid requires attention to maintain a proper master cylinder level, this is an indication of either severe operation (pad wear) or fluid system leakage. A more frequent and thorough brake inspection will be required.

Maintenance and specifications

Hydraulic brakes - fluid precautions

The Hydro-Max brake system consists of two completely separate hydraulic systems operating with two different and incompatible fluids; power steering fluid and hydraulic brake fluid. Failure to observe precautions preventing the contamination of either system with fluid from the other will result in swelling and deterioration of rubber parts leading to reduced brake performance and eventual brake failure.

To avoid fluid contamination, the following should always be observed:

1. Use only fluids specified (or equivalent) and properly identified.
2. Add fluids only to the following locations:
 - Power steering fluid to the power steering fluid pump reservoir
 - Brake fluid to the brake master cylinder

Hydraulic brakes - brake lines, hoses and fittings

Inspect these components every 6,000 km (4,000 miles).

- Check lines for kinks, dents, corrosion or rupture.
- Check hoses for abrasions, kinks, soft spots or rupture, collapse, cracks, twists or loose frame supports. When replacing a hose, be sure there is adequate clearance to the hose to avoid an abrasion to the new hose.
- Examine all connections for leaks.
- Repair or replace brake line tubes, hoses or fittings as required.

Driveline parking brake

Parking brake adjustment should only be performed by a qualified technician, and in accordance with the instructions in the service manual.



Use wheel chocks and exercise caution when inspecting under the vehicle. A vehicle roll-away could result in property damage, personal injury or death.

Maintenance and specifications

OPENING THE HOOD

The hood and fenders are held in position by a latch located on each fender.




The parking brake must be fully set before opening the hood or possible personal injury may occur.




If you must leave the engine running while checking under the hood, do not allow any loose clothing, jewelry, hair or other items to get near moving engine components or possible personal injury may occur.

To open the hood:

1. Set the parking brake, shift into N (Neutral) (automatic transmission) or 1 (First) (manual transmission) and turn the engine off.
2. Lift upward on the bottom of each latch.




3. Pull the bottom of each latch away from the fender.



Maintenance and specifications

4. Tilt the hood forward until stopped by the retaining cables.



To lower the hood:

1. Push the hood rearward at the top center of the hood above the grille until closed.
2. Engage the latch on each fender.
3. Push down on the bottom of each latch until locked.



To reduce the risk of the possibility of personal injury, never stand beneath the hood when it is being raised or lowered.

ENGINE OIL

Checking engine oil level—Cummins B and Caterpillar 3126 B engines

Refer to the appropriate engine operator's manual for information on the engine oil.

Checking engine oil level—6.0L Power Stroke engine


Refer to the general maintenance information section for the appropriate intervals for checking the engine oil.

Check the engine oil level consistently and accurately. The following procedure is recommended:

1. Start the engine and let it run until it reaches normal operating temperature (the engine coolant temperature gauge indicator will be near the center of the normal area between H and C).

Maintenance and specifications

2. Park the vehicle on level ground.
3. Set the parking brake and shift into N (Neutral) (automatic transmission) or 1 (First) (manual transmission).
4. Turn off the engine and wait a few minutes for the oil to drain completely into the oil pan.
5. Open the hood. Protect yourself from engine heat.
6. Locate and carefully remove the engine oil level indicator (dipstick).



7. Wipe the indicator clean. Insert the indicator fully, then remove it again.
 - If the oil level is **between FULL and OPERATING RANGE**, the oil level is acceptable. **DO NOT ADD OIL.**
 - Maintain the oil level between ADD and OPERATING RANGE on the dipstick by adding oil as required.
 - The distance from ADD to OPERATING RANGE on the dipstick represents 1.9L (2 quarts).
 - Oil levels above OPERATING RANGE may cause engine damage. Some oil must be removed from the engine by a qualified service technician.
8. Put the indicator back into the engine and ensure it is fully seated.

Engine oil and filter recommendations—Cummins B and Caterpillar 3126 B engines

Refer to the appropriate engine operator's manual for information on the engine oil.

Maintenance and specifications

Engine oil and filter recommendations—6.0L Power Stroke engine

To help achieve proper engine performance and durability, it is important that you:


- Use only engine lubricating oils and oil filters of the proper quality.
- Change the engine oil and filter **no later** than the recommended service interval. Refer to the general maintenance information section for the appropriate intervals for changing the engine oil and filter.
- Change your engine oil and filter more frequently if your vehicle operation includes extended periods of idling or low-speed operation, driving for a long time in cold temperatures or short driving distances.

Diesel engines require specially formulated oil to resist contamination. Proper quality oils also provide maximum efficiency of the crankcase ventilation system which reduces air pollution.

For normal or severe service, use Motorcraft oil or an equivalent oil conforming to Ford Specification WSS-M2C171-C or API Service categories CI-4 or CI-4/SL. If CI-4 oil is not available, CH-4 is acceptable.

Diesel engine oils with improved fuel economy properties (energy conserving) are currently available. If you use an energy conserving oil, be sure it meets Ford specification WSS-M2C171-D or API service category designation CI-4/SL and is of the proper viscosity grade for the temperature range in which you expect to operate your vehicle. Some energy conserving oils do not meet the requirements necessary for your diesel engine.

Maintenance and specifications



* Heavy duty trailer towing with ambient temperatures above 10°C (50°F) requires 15W-40 engine oil.

Using the chart, determine which SAE viscosity grade best suits the temperature range in which you expect to operate your vehicle. The use of the correct oil viscosity grade for diesel engines is important for satisfactory engine operation.

A symbol has been developed by the American Petroleum Institute (API) to help you select the proper engine oil. The symbol will be included on the oil container you purchase.

The top section of the symbol shows the API service category designation. This should be CI-4/SL.

The center section of the API symbol shows the SAE viscosity grade.



The lower section of the API symbol will state *energy conserving* if the engine oil has been proven to have fuel savings capabilities.

Use a Ford engine oil filter, part number FL-1995 or equivalent. This filter protects your engine by filtering harmful, abrasive or sludge particles.

Maintenance and specifications

ENGINE COOLING SYSTEM

Inspect cooling system daily

Note: The de-aeration tank requires air space for expansion volume. The proper fill level is identified on the reservoir; do not overfill the reservoir.



To reduce the risk of personal injury or death, use only the following procedure to remove the pressure-type cap from the radiator or expansion tank.

1. Always allow the engine to cool first.
2. Wrap a thick, heavy cloth around the cap.
3. Loosen the cap slowly, then pause a moment. This will reduce the risk of possible scalding by hot water or steam.
4. Continue to unscrew the cap and remove only after pressure in the radiator is fully released.

Note: If the coolant should get extremely low and the engine very hot, let the engine cool for approximately 15 minutes before adding coolant. After the engine has cooled, start the engine and add coolant slowly. Adding coolant to a hot engine may crack the cylinder head or crankcase. Never use only water to fill the cooling system.

Adding engine coolant - 6.0L Powerstroke

When adding coolant, make sure it is a 50/50 mixture of engine coolant and distilled water. Add the mixture to the coolant reservoir, **when the engine is cool**, until the appropriate fill level is obtained.

For vehicles with overflow coolant systems with a non-pressurized cap on the coolant recovery system, add coolant to the coolant recovery reservoir when the engine is cool. Add the proper mixture of coolant and water to the “cold full” level. For all other vehicles, which have a coolant degas system with a pressurized cap, or if it is necessary to remove the coolant pressure relief cap on the radiator of a vehicle with an overflow system, follow these steps to add engine coolant.



To reduce the risk of personal injury, make sure the engine is cool before unscrewing the coolant pressure relief cap. The cooling system is under pressure; steam and hot liquid can come out forcefully when the cap is loosened slightly.

Maintenance and specifications



Do not add engine coolant when the engine is hot. Steam and scalding liquids released from a hot cooling system can burn you badly. Also, you can be burned if you spill coolant on hot engine parts.



Do not put engine coolant in the windshield washer fluid container. If sprayed on the windshield, engine coolant could make it difficult to see through the windshield.

1. Before you begin, turn the engine off and let it cool.
2. When the engine is cool, wrap a thick cloth around the coolant pressure relief cap on the coolant reservoir (an opaque plastic bottle). Slowly turn cap counterclockwise (left) until pressure begins to release.
3. Step back while the pressure releases.
4. When you are sure that all the pressure has been released, use the cloth to turn it counterclockwise and remove the cap.
5. Fill the coolant reservoir slowly with the proper coolant mixture (see above), to within the “cold fill range” or the “cold full” level on the reservoir. If you removed the radiator cap in an overflow system, fill the radiator until the coolant is visible and radiator is almost full.
6. Replace the cap. Turn until tightly installed. (Cap must be tightly installed to prevent coolant loss.)

After any coolant has been added, check the coolant concentration see Checking Engine Coolant section). If the concentration is not 50/50 (protection to $-34^{\circ}\text{F}/-36^{\circ}\text{C}$), drain some coolant and adjust the concentration. It may take several drains and additions to obtain a 50/50 coolant concentration.

Whenever coolant has been added, the coolant level in the coolant reservoir should be checked the next few times you drive the vehicle. If necessary, add enough 50/50 concentration of engine coolant and distilled water to bring the liquid level to the proper level.

If you have to add more than 1.0 liter (1.0 quart) of engine coolant per month, have your dealer check the engine cooling system. Your cooling system may have a leak. Operating an engine with a low level of coolant can result in engine overheating and possible engine damage.

Maintenance and specifications

Extended life engine coolant

The cooling system in your vehicle is filled with yellow-colored Motorcraft Premium Gold Engine Coolant meeting Ford Specification WSS-M97B51-A1.

- **Add Motorcraft Premium Gold Engine Coolant (yellow-colored), VC-7-A (VC-7-B in Oregon).**

Note: Use of Motorcraft Cooling System Stop Leak Pellets, VC-6, may darken the color of Motorcraft Premium Gold Engine Coolant from yellow to golden tan.

- **Do not add/mix extended life coolants such as Motorcraft Speciality Orange Engine Coolant, VC-2 (U.S.) or CXC-209 (Canada), meeting Ford specification WSS-M97B44-D, with the factory-fill coolant, Motorcraft Premium Gold Coolant meeting Ford Specification WSS-M97B51-A.** Mixing Motorcraft Speciality Orange Engine Coolant or any equivalent extended life engine coolant with this factory-fill coolant can result in degraded corrosion protection.
- A large amount of water without engine coolant may be added, in case of emergency, to reach a vehicle service location. In this instance, the cooling system must be drained and refilled with a 50/50 mixture of engine coolant and distilled water as soon as possible. Water alone (without engine coolant) can cause engine damage from corrosion, overheating or freezing.
- **Do not use alcohol, methanol or brine or any engine coolants mixed with alcohol or methanol antifreeze (coolant).** Alcohol and other liquids can cause engine damage from overheating or freezing.
- **Do not add extra inhibitors or additives to the coolant.** These can be harmful and compromise the corrosion protection of the engine coolant.
- **Do not mix with recycled coolant unless from a Ford-approved recycling process (see *Use of Recycled Engine Coolant* section).**

Coolant condition inspection

Engine cooling systems should be checked twice a year to assure proper glycol/water concentrations. a 50/50 mixture is recommended and provides freeze protection in weather conditions as low as -36°C (-34°F) as well as optimum corrosion protection. For vehicle operating in extremely cold climate, a concentration of 60% ethylene glycol will

Maintenance and specifications

provide freeze protection in weather conditions as low as -51°C (-59°F). Concentrations greater than 60% glycol are not recommended.

Engine coolant capacities and part numbers

For cooling system capacities, refer to *Refill capacities* in this chapter. For coolant part numbers, refer to *Lubricant specifications* in this chapter.

Severe climates

If you drive in extremely cold climates (less than -36°C [-34°F):

- **It may be necessary to increase the coolant concentration above 50%.**
- **NEVER increase the coolant concentration above 60%.**
- **Engine coolant concentrations above 60% will decrease the overheat protection characteristics of the engine coolant and may cause engine damage.**
- **If available, refer to the chart on the coolant container to ensure the coolant concentration in your vehicle will provide adequate freeze protection at the temperatures in which you drive in the winter months.**

If you drive in extremely hot climates:

- **It is still necessary to maintain the coolant concentration above 40%.**
- **NEVER decrease the coolant concentration below 40%.**
- **Engine coolant concentrations below 40% will decrease the corrosion protection characteristics of the engine coolant and may cause engine damage.**
- **Engine coolant concentrations below 40% will decrease the freeze protection characteristics of the engine coolant and may cause engine damage.**
- **If available, refer to the chart on the coolant container to ensure the coolant concentration in your vehicle will provide adequate protection at the temperatures in which you drive.**

Vehicles driven year-round in non-extreme climates should use a 50/50 mixture of engine coolant and distilled water for optimum cooling system and engine protection.

Maintenance and specifications

Fan clutches

Your vehicle's cooling system is equipped with a viscous fan clutch.

- The fan clutch helps control cooling, increase performance, improve fuel economy and reduce noise.
- The fan clutch is controlled by bimetallic spring sensors. Do not tamper with these sensors as this may change their calibration or keep the fan clutch from operating at all.




Stay clear of the fan/fan area while the engine is running or possible personal injury may occur.

WINDSHIELD WASHER FLUID

Inspect the solution level in the washer reservoir when insufficient solution is sprayed.

Use 3.8L (4.0 quarts) of Ultra-Clear Windshield Washer Concentrate or a washer fluid that meets the Ford specification listed. Refer to *Lubricant specifications* in this chapter.

State or local regulations on volatile organic compounds may restrict the use of methanol, a common windshield washer antifreeze additive. Washer fluids containing non-methanol antifreeze agents should be used only if they provide cold weather protection without damaging the vehicle's paint finish, wiper blades or washer system.




Do not put engine coolant in the washer fluid reservoir. Engine coolant can severely reduce visibility if sprayed on the windshield.

Maintenance and specifications

BRAKE FLUID

Check and refill the Hydromax brake fluid reservoir using the following procedure. Refer to the general maintenance information section for the service interval.

1. Clean the reservoir caps before removal to prevent dirt or water from entering the reservoir.
2. Visually inspect the fluid level.
3. If necessary, add brake fluid from a clean un-opened container until the level reaches MAX. Do not fill above this line.
4. Use only a DOT 3 brake fluid certified to meet manufacturer specifications. Refer to *Lubricant specifications* in this chapter.



 Brake fluid is toxic. If brake fluid contacts the eyes, flush eyes with running water for 15 minutes. Seek medical attention if irritation persists. If taken internally, drink water and induce vomiting. Seek medical attention immediately.

 If you use a brake fluid that is not DOT 3, you will cause permanent damage to your brakes.


 Do not let the reservoir for the master cylinder run dry. This may cause the brakes to fail.

BATTERY


Your vehicle is equipped with two maintenance-free batteries which are mounted in a covered tray and located on the left frame rail. The covered battery tray, depending upon application, may also have one or two steps attached.

Maintenance and specifications

- Covered battery tray shown.
Battery tray with steps similar.
The two rubber straps on top of the cover must be pulled up and moved to the side of the battery in order to remove the lid.



- Battery tray with cover removed.



Maintenance-free batteries do not normally require adding additional water. However, for severe usage or in high temperature climates, check the battery electrolyte levels. Refer to the general maintenance information section for the service interval schedules.

**Keep the electrolyte level in each cell up to the “level indicator”.
Do not overfill the battery cells.**

If the electrolyte level in the battery is low, you can add plain tap water to the battery, as long as you do not use hard water (water with a high mineral or alkali content). If possible, however, try to only fill the battery cells with distilled water. If the battery needs water often, have the charging system checked.

Make sure the battery cover/shield is reinstalled after the battery has been cleaned or replaced.

For longer, trouble-free operation, keep the top of the batteries clean and dry. Also, make certain the battery cables are always tightly fastened to the battery terminals.

If you see any corrosion on the battery or terminals, remove the cables from the terminals and clean with a wire brush. You can neutralize the acid with a solution of baking soda and water.

Maintenance and specifications


 Batteries normally produce explosive gases which can cause personal injury. Therefore, do not allow flames, sparks or lighted substances to come near the battery. When working near the battery, always shield your face and protect your eyes. Always provide proper ventilation.

 When lifting a plastic-cased battery, excessive pressure on the end walls could cause acid to flow through the vent caps, resulting in personal injury and/or damage to the vehicle or battery. Lift the battery with a battery carrier or with your hands on opposite corners.

 Keep batteries out of reach of children. Batteries contain sulfuric acid. Avoid contact with skin, eyes or clothing. Shield your eyes when working near the battery to protect against possible splashing of acid solution. In case of acid contact with skin or eyes, flush immediately with water for a minimum of 15 minutes and get prompt medical attention. If acid is swallowed, call a physician immediately.

 Battery posts, terminals and related accessories contain lead and lead compounds. **Wash hands after handling.**

Always dispose of automotive batteries in a responsible manner. Follow your local authorized standards for disposal. Call your local authorized recycling center to find out more about recycling automotive batteries.



Alternator

Before connecting a fast-charger, booster battery or installing a new battery, make sure the ground polarities of the fast-charger, booster battery or alternator (when installing a battery) are matched to the ground polarity of the vehicle battery. Improper usage of the fast-charger, hook-up of booster battery or installation of a new battery

Maintenance and specifications

can cause damage to the electrical system or to the alternator. Do not attempt to polarize the alternator.

STEERING - GENERAL INSPECTION

- Ask your service technician to examine the steering mechanism. Only minor adjustments may be necessary.
- Check tie rod, drag link end clamp bolts and ball joints. They must be tight.
- Check for installation and spread of cotter pins and tightness of nuts at both ends of the tie rod and drag link.
- Check the pitman arm (steering arm at steering gear) mounting is tight and locked. Check system for leaks or hose chafing. Repair at once.
- Maintain proper steering gear and power steering pump lubricant levels.
- Regularly inspect steering column joint bolts and steering linkage, particularly for body-to-chassis clearance.

Note: Have any steering problems corrected at once by a qualified service technician.



Failure to maintain the steering system in proper condition can cause reduced steering ability resulting in property damage, personal injury or death.

Tightening steering column joint bolts

As a good maintenance practice, it is recommended that steering column joint bolts be checked for tightness every 96,000 km (60,000 miles) or annually, whichever occurs first. **DO NOT OVERTIGHTEN.**

Power steering

Whenever the hydraulic (power steering) system has been drained and refilled for any reason, air must be bled from the system before returning the vehicle to service. Failure to properly bleed the hydraulic system can result in degradation of power system performance.

Consult your dealer who is aware of the proper procedures for filling and bleeding the system.


POWER STEERING FLUID

Check the power steering fluid level using the following procedure. Refer to the general maintenance information section for the recommended service intervals. If adding fluid is necessary, use only MERCON® ATF.

Maintenance and specifications


1. Set the parking brake, shift into N (Neutral) (automatic transmission) or 1 (First) (manual transmission) and turn the engine off.
2. Open the hood.
3. Clean the top of the power steering fluid reservoir.
4. Remove the dipstick from the reservoir and wipe the dipstick clean.
5. Reinstall the dipstick. Remove it again and check the fluid level.

- If the fluid temperature is at approximately 20°C - 49°C (68°F - 120°F) (**fluid cool or warm to the touch**), check the COLD side of the dipstick. The fluid level should be within the FULL range



- If the fluid level is below the ADD line, add fluid in small amounts, continuously checking the level until it reaches the proper level.

- If the fluid temperature is at approximately 80°C - 110°C (176°F - 230°F) (**fluid too hot to touch**), check the HOT side of the dipstick. The fluid level should be within the FULL range.



- If the fluid level is below the ADD line, add fluid in small amounts, continuously checking the level until it reaches the proper level.

A low fluid level may indicate a leak in the power steering system. Inspect the power steering system and repair the leak. If necessary, see your dealer or a qualified service technician.

To avoid damage to the power steering system, **do not** operate the vehicle with a low power steering fluid level.

Whenever the dipstick is installed, make sure it is properly seated and tightened securely.

CLUTCH FLUID/LINKAGE ADJUSTMENTS

Clutch fluid (if equipped)


Check the clutch fluid level. Refer to the general maintenance information section for the service interval schedules.

During normal operation, the fluid level in the clutch reservoir should remain constant. If the fluid level drops, maintain the fluid level at the step in the reservoir.

Maintenance and specifications

Use only a DOT 3 brake fluid designed to meet manufacturer specifications. Refer to *Lubricant specifications* in this chapter.

1. Set the parking brake, shift into 1 (First) and turn the engine off.
2. Open the hood.
3. Clean the reservoir cap before removal to prevent dirt and water from entering the reservoir.
4. Remove cap and rubber diaphragm from reservoir.
5. Add fluid until the level reaches the step in the reservoir.
6. Reinstall rubber diaphragm and cap onto reservoir.




Clutch linkage (if equipped)

Lubricate the clutch linkage using the following procedure. Refer to the general maintenance information section for the service interval schedules.

Use a grease which meets manufacturer specifications. Refer to *Lubricant specifications* in this chapter.

1. Set the parking brake, shift into 1 (First) and turn the engine off.
2. Remove the inspection cover from the clutch housing.

- **Transmission and clutch removed for clarity.**



3. With a grease gun, lubricate the clutch release bearing (at one location) and the clutch release shaft (at two locations) using the grease fittings provided.
4. Lubricate clutch release wear pads at the two locations where they contact the clutch release bearing using a brush or similar tool.
5. Install the inspection cover onto the clutch housing.

Maintenance and specifications

TRANSMISSION FLUID



Always dispose of used automotive fluids in a responsible manner. Follow your community's standards for disposing of these types of fluids. Call your recycling center to find out about recycling automotive fluids.

Automatic transmission fluid

Refer to your Allison Automatic Transmission Operator's Manual for scheduled intervals for transmission fluid checks and changes. Your transmission does not consume fluid. However, the fluid level should be checked if the transmission is not working properly, i.e., if the transmission slips or shifts slowly or if you notice some sign of fluid leakage.

Transmission fluid level should be checked by your dealer or a qualified service technician.

If you must add transmission fluid, make sure the correct type of fluid is being used. The type of fluid used is indicated in your Allison Automatic Transmission Operator's Manual.

Use of a non-approved automatic transmission fluid may cause internal transmission component damage.

Manual transmission fluid

Refer to your general maintenance information section for transmission fluid level checks and fluid change intervals.

Your manual transmission may be filled with an optional synthetic fluid which allows the use of extended service intervals. A tag on the filler plug will identify the use of the synthetic fluid.

Use only fluid that meets manufacturer specifications (refer to *Lubricant specifications* in this chapter).

Use of a non-approved transmission fluid may cause internal transmission component damage.

Check your transmission fluid level using the following procedure:

1. Park the vehicle on level ground.
2. Set the parking brake and shift into 1 (First) and turn the engine off.
3. Clean any dirt from around the filler plug.
4. Remove the filler plug and inspect the fluid level.
5. The fluid level should be up to the bottom of the filler plug opening.
6. If necessary, add enough fluid through the filler plug opening so that the fluid level is at the bottom of the opening.

Maintenance and specifications

7. Clean and install the filler plug securely.

Drain and refill your transmission fluid using the following procedure:

1. Drain the transmission while the fluid is warm.
2. Park the vehicle on level ground.
3. Set the parking brake and shift into 1 (First) and turn the engine off.
4. Clean any dirt from around the filler and drain plugs.
5. Remove the filler and drain plugs and drain the fluid into a suitable container. Dispose all used automotive fluids in a responsible manner following your local authorized standards.
6. Clean and install the drain plug securely.
7. Add enough fluid through the filler plug opening so that the fluid level is up to the bottom of the opening.
8. Clean and install the filler plug securely.

ENGINE AND SUBSYSTEM MAINTENANCE

Note: Information in this section pertains to the 6.0L Powertsoke engine only. For information pertaining to other engines, see the respective engine operator manual.

Note: To prevent damage to the engine control module, never spray-wash it directly. Never spray any connector.

For effective emissions control and low operating cost, it is important that maintenance operations listed in this section be performed at the specified periods or mileage intervals indicated (kilometers, miles, hours, or months, whichever comes first).

Service intervals are based upon average operating conditions. Where dusty, frequent start and stop or heavily laden operations are encountered, more frequent servicing will be required.

As the vehicle (engine) owner, you are responsible for the performance of all scheduled maintenance. The required maintenance operations may be performed by the owner at a service establishment of the owner's choosing. Any replacement parts used for required maintenance services or repairs should be genuine manufacturer service parts or equivalent in quality and performance to genuine manufacturer service parts. Use of inferior parts hinders operations of the engine and emissions controls and can reduce engine life and/or jeopardize the warranty.

Receipts covering the performance of regular maintenance should be retained in the event questions arise concerning maintenance. The receipts should be transferred to each subsequent owner of the vehicle (engine).

Maintenance and specifications

Catalytic converter

If your Diesel engine is equipped with a catalytic converter, it is important to review the maintenance schedule to insure proper functioning of the catalytic converter. Also, take precautions not to damage the catalytic converter when servicing your engine or storing your vehicle.

Note: If your vehicle is equipped with a catalytic converter/muffler, **do not** blend waste oil with Diesel fuel. Operate only on low sulfur (less than 500 parts per million sulfur) Diesel fuel with a cetane value of 45 or higher.

Note: If your vehicle is equipped with a vertical exhaust pipe, it is very important to have and maintain a rain cap on the exhaust pipe to prevent water from entering the exhaust system and catalytic converter. Any water entering the catalytic converter may damage the catalyst and affect the function of the converter.

Air induction system

Once each year, perform a complete inspection of the air induction system. In areas where road salt is used, the inspection consists of disassembling the joints of each aluminum component and inspecting for salt build-up, presence of chlorine that can cause aluminum particles to flake off and enter the engine combustion chambers.

If evidence of corrosion is found (usually at the pipe connections), use a wire brush to clean the inside of the pipes and inside the rubber hoses.

If the intake pipes are pitted at the joint ends, use RTV silicone to seal the joints. Be certain that no excess material is on the inside of the pipes that can be pulled into the engine. If the service condition of the pipes, hoses or clamps is questionable, replace the defective part(s).



To reduce the risk of personal injury or death when performing maintenance to any turbocharged engine with engine air inlet piping disconnected, a turbocharger compressor air inlet protective shield should be installed over the turbocharger air inlet.


Dual element air cleaner (if equipped) - 6.0L Powerstroke

The dual element air cleaner provides a large primary (outer) filter element and small secondary (inner) filter element. The dual element should be used in dusty environments such as sump and mixer applications.

Your vehicle is equipped with an air filter restriction gauge to determine when to replace the air cleaner element. It is not possible to determine

Maintenance and specifications

the need for service by visually inspecting the air filter. When the yellow indicator on the gauge reaches the red line, the air cleaner should be replaced. Each time the air cleaner is replaced, reset the gauge by pressing the red button.



The dual element air cleaner assembly restriction indicator is located between the primary and secondary elements, in the bottom of the air cleaner housing. This arrangement allows only the primary element to be sensed by the restriction indicator or dash-mounted vacuum gauge. The restriction indicator for the secondary element is separate, and has two possible locations, depending on the element manufacturer. One type has a rectangular wing nut with a built-in indicator and the other uses an indicator located on the secondary element end cap. The secondary element is to be replaced when all the green disappears on the wing nut type or the green dot disappears from the indicator built into the element end cap. The following provides procedures for servicing the secondary element.

1. Remove the hold down nut. Remove the secondary filter element carefully and slowly, then discard the old element. **Note:** Be careful not to bump the filter while it's still in the housing; this can raise a cloud of dust that can enter the clean piping to the turbocharger.
2. Wipe the inside of the air cleaner housing with a damp cloth. Be sure to clean the gasket sealing surface. **Note:** Do not use compressed air for this cleaning! Prevent dust from entering the turbocharger inlet piping during the wiping and element replacement process.
3. Visually inspect the air cleaner housing for damage or distortion which could allow unfiltered air into the engine. Inspect to be sure that the rubber dust unloader valve at the bottom of the housing is in place and not cracked. Make corrections as required.
4. Inspect the new filter element for a damaged or non-resilient rubber gasket. Inspect the filter's body element for dents or excessive pleat

Maintenance and specifications

bunching. If any of the mentioned condition exist, obtain a new service element (consult your dealer). If the new element is not defective, install it.

5. Install the retaining nut (with seal washer, if applicable) and torque to 6.7–8.5 N.m (60–75 in. lbs.)

6. Reassemble the air cleaner end cover to the air cleaner housing, making sure that the cover seats squarely on the housing and the clamp is neither too loose nor too tight. A loose condition is the result of an element that is too short; a tight or “no clamp” condition is the result of the element being too long. Obtain an outer service element that meets quality specifications.

7. Check all clean air ducts between the air cleaner and turbocharger. All connection must be tight, without any leaks.

8. When servicing is completed, reset the air restriction gauge by pushing the reset button and releasing it. The yellow indicator will drop below the gauges window.

Note: After starting the engine, the indicator may be seen in the lower part of the gauge’s window. This is normal and should not be mistaken as a signal for element service.

Cummins B and Caterpillar engines

Refer to the respective engine operator manual for air filter replacement procedure.

FUEL INFORMATION

Important safety precautions



Do not overfill the fuel tank. The pressure in an overfilled tank may cause leakage and lead to fuel spray and fire.



The fuel system may be under pressure. If the fuel cap is venting vapor or if you hear a hissing sound, wait until it stops before completely removing the cap.



Automotive fuels can cause serious injury or death if misused or mishandled.

Maintenance and specifications

Observe the following guidelines when handling fuel:

- Extinguish all smoking materials and any open flames before fueling your vehicle.
- Always turn off the vehicle before fueling.
- Automotive fuels can be harmful or fatal if swallowed. If fuel is swallowed, call a physician immediately, even if no symptoms are immediately apparent. The toxic effects of fuel may not be visible for hours.
- Avoid inhaling fuel vapors. Inhaling too much fuel vapor of any kind can lead to eye and respiratory tract irritation. In severe cases, excessive or prolonged breathing of fuel vapor can cause serious illness and permanent injury.
- Avoid getting fuel liquid in your eyes. If fuel is splashed in the eyes, remove contact lenses (if worn), flush with water for 15 minutes and seek medical attention. Failure to seek proper medical attention could lead to permanent injury.
- Fuels can also be harmful if absorbed through the skin. If fuel is splashed on the skin and/or clothing, promptly remove contaminated clothing and wash skin thoroughly with soap and water. Repeated or prolonged skin contact with fuel liquid or vapor causes skin irritation.



If you must replace the fuel filler cap, replace it with a genuine Ford or Motorcraft part. The customer warranty may be void for any damage to the fuel tank or fuel system if a genuine Ford or Motorcraft fuel filler cap is not used.



If you do not use the proper fuel filler cap, excessive pressure or vacuum in the fuel tank may damage the fuel system or cause the fuel system to work improperly in a collision, which may result in possible personal injury.

Choosing the right fuel

At operating temperatures below 0°C (32°F), use a blend of No. 1D and No. 2D Diesel fuels, also known as winterized No. 2D.

Do not use diesel fuel blended with waste oil in engines equipped with a catalytic converter-muffler. Blending waste oil in with the fuel will plug the catalytic converter-muffler, resulting in a significant loss of engine power. Your emissions warranty will be voided if blending waste oil with diesel fuel is practiced.

Maintenance and specifications

Use low sulfur (less than 0.05% by weight) fuel as required by the EPA for emission compliance.



Do not mix diesel fuel with gasoline, gasohol or alcohol. This could cause an explosion resulting in personal injury.



Do not use starting fluid such as ether or gasoline. Such fluids can cause immediate explosive damage to the engine and possible personal injury.

Running out of fuel

Avoid running out of fuel as this will allow air to enter the fuel system, which will make restarting the vehicle difficult.

If you have run out of fuel:

- **If your vehicle is equipped with dual fuel tanks**, add at least 15–19 liters (4–5 gallons) of fuel to each tank before attempting to restart the engine.
- **If your vehicle is equipped with the Caterpillar 3126 B engine**, the fuel system must be primed before attempting to restart the engine. Refer to the engine operator's manual for instructions on priming the engine.
- **Use caution not to overheat and damage the starter** by cranking the engine for an excessive period of time. You may need to crank the engine for a longer time than normal. If the engine fails to start in 30 seconds, turn the ignition to the OFF position and wait for two minutes before cranking the engine again.
- Any remaining trapped air will self-purge from the fuel system once the engine starts running.
- The engine may run rough and produce white smoke while air is in the fuel system. This is normal and should stop after a short period of time.

Fuel and lubricant additives

It should not be necessary to add any aftermarket fuel or lubricant additives to your fuel tank if you use a properly formulated Diesel fuel that meets the ASTM D 975 industry specification. Malfunctions attributed to the use of such additives or failure to follow recommended fuel or lubricant recommendations may not be covered under your warranty.

Maintenance and specifications

Fuel filter/water separator




Do not drain water separator while engine is running. Fuel may ignite if separator is drained while engine is running or vehicle is moving.

The fuel filter/water separator removes any contaminated particles and/or water from the fuel before the fuel enters the engine.

The fuel filter/water separator should be drained as recommended in the general maintenance information section.

Draining the fuel filter/water separator - Caterpillar 3126E engine

1. With the engine off, open the drain valve located at the bottom of the fuel filter/water separator by turning it counterclockwise.



2. Drain the filter until clear fuel is visible.

3. Turn the drain valve clockwise to close the valve. Do not overtighten the drain valve as this could cause damage to the fuel filter/water separator.

Draining the fuel filter/water separator – 6.0L Power Stroke engine

The vehicle is equipped with a module located on the frame-rail under the driver-side floorboard near the transmission.

Water should be drained from the module assembly whenever the warning light comes on or every 8,000 km (5,000 miles). The WATER

IN FUEL light will come on when approximately 100 cc (0.2 pints) of water accumulates in the module.



Maintenance and specifications


Replace the fuel filter with Motorcraft Part No. F81Z-9N184-AA (FD-4596).

1. Stop the vehicle and **shut off** the engine.



The vehicle must be stopped with the engine off when draining the HFCM. Fuel may ignite if separator is drained while the engine is running or vehicle is moving.

2. Locate the module and place an appropriate container under the drain plug (see illustration).



3. Remove the drain plug by turning it counterclockwise. Allow to drain for approximately 25 seconds or until clean fuel is observed. Install the drain plug by turning it clockwise until it is firmly seated.
4. Verify that the drain plug is closed and sealed, then remove the container from under the vehicle.
5. Restart the engine and check WATER IN FUEL indicator light; it should be illuminated. If it continues to illuminate, have the fuel system checked and repaired.


Draining the fuel filter/water separator - Cummins B engine

Refer to your engine operator's manual for service procedures.

Maintenance and specifications

Fuel filter replacement - Caterpillar 3126E engine

The fuel filter/water separator is located on the left side of the engine. Replace the fuel filter/water separator as recommended in the general maintenance information section, or sooner if it becomes plugged. Vehicles operated on fuel with more than average impurities may require replacement of the fuel filter more frequently. The spin-on filter has a water drain valve built into the bottom of the filter canister.



Removal

1. Using an oil filter wrench, remove the filter.
2. Carefully clean the mating surfaces.

Installation

1. Fill the filter with clean, fresh diesel fuel.
2. Coat the filter seal with clean, fresh diesel fuel.
3. Hand-tighten the filter until it seats firmly against the mount, then tighten (by hand) an additional $\frac{1}{3}$ to $\frac{1}{2}$ turn.
4. Start the engine and check for fuel leaks.


Fuel filter replacement - 6.0L Power Stroke engine

Your vehicle is equipped with two fuel filters; one mounted on top of the engine and the other is mounted inside the frame rail under the driver-side floorboard near the transmission. Both filters should be replaced at the same time.

Maintenance and specifications


Removal - Engine-mounted fuel filter

1. Remove the fuel filter cap by turning counterclockwise.
2. Remove and discard the old fuel filter element.
3. Carefully clean the mating surfaces.




Removal - in-line fuel filter

1. Remove the fuel filter cap by turning counterclockwise.



2. Remove and discard the old fuel filter element.
3. Carefully clean the mating surfaces.



Installation-both

The engine will not run properly if the fuel filter is not installed in housing.

1. Install new fuel filter into the fuel filter housing.
2. Tighten cap onto fuel filter housing slowly, allowing fuel to soak into the fuel filter element. Tighten cap until it contacts the housing.

Maintenance and specifications

After replacing the fuel filter, the engine will purge the trapped air as it runs. The engine may run roughly and smoke until the air is completely eliminated.

Using a fuel which has more than average impurities may require the fuel filter to be replaced more frequently than the service interval specifies.

Fuel filter replacement - Cummins B engine

Refer to your engine operator's manual for service intervals and procedures.

FUEL CONSUMPTION IMPROVEMENT MEASURES

There are two important factors you can control to improve fuel economy: the mechanical condition of your vehicle and how you drive it.

A properly maintained vehicle will deliver better performance than a neglected vehicle. Always follow your maintenance schedule to keep your vehicle in top operating condition.

Also, your driving habits have a significant influence on use of fuel. By following these suggestions, you can stretch your fuel use:

- Avoid changes in speed as much as possible.
- Anticipate changing traffic conditions. Sudden stops and fast acceleration waste fuel.
- Avoid extensive idling.
- Do not drive with your foot resting on the brake pedal.

Essentials of good fuel economy

Measuring techniques

Your best source of information about actual fuel economy is you, the driver. You must gather information as accurately and consistently as possible. Fuel expense, frequency of fillups or fuel gauge readings are NOT accurate as a measure of fuel economy. We do not recommend taking fuel economy measurements during the first 1,600 km (1,000 miles) of driving (engine break-in period). You will get a more accurate measurement after 3,000 km–5,000 km (2,000 miles–3,000 miles).

The advertised fuel capacity of the fuel tank(s) on your vehicle is equal to the rated refill capacity of the fuel tank(s) as listed in *Fuel tanks* in this chapter. The advertised capacity is the amount of the Indicated Capacity and the Empty Reserve combined. Indicated Capacity is the difference in the amount of fuel in a full tank and a tank when the fuel

Maintenance and specifications

gauge indicates empty. Empty Reserve is the small amount of usable fuel remaining in the fuel tank after the fuel gauge indicates empty.

The amount of Empty Reserve varies and should not be relied upon to increase driving range. When refueling your vehicle after the fuel gauge indicates empty, you might not be able to refuel the full amount of the advertised capacity of the fuel tank due to the empty reserve still present in the tank.

Filling the tank

For consistent results:

- Use the same fill rate setting (low — medium — high) each time during filling.
- Allow three automatic click-offs when filling.
- Always use fuel of a known quality, preferably a national brand.
- Have the vehicle loading and distribution the same every time.
- When refueling a vehicle equipped with dual fuel tanks, if the two tanks are not filled equally, the fuel gauge reading may fluctuate slightly until the fuel level between the two tanks balance out and become equal.

Your results will be most accurate if your filling method is consistent.

Note: For vehicles equipped with dual fuel tanks, engine performance may degrade if fuel is not added to both tanks when refueling.

Calculating fuel economy

1. Fill the fuel tank(s) completely and record the initial odometer reading (in kilometers or miles).
2. Each time you fill the tank(s), record the amount of fuel added (in liters or gallons).
3. After at least three to five tank fill-ups, fill the fuel tank(s) and record the current odometer reading.
4. Subtract your initial odometer reading from the current odometer reading.
5. Follow one of the simple calculations in order to determine fuel economy:
 - Multiply liters used by 100, then divide by total kilometers traveled.
 - Divide total miles traveled by total gallons used.

Keep a record for at least one month and record the type of driving (city or highway). This will provide an accurate estimate of the vehicle's fuel

Maintenance and specifications

economy under current driving conditions. Additionally, keeping records during summer and winter will show how temperature impacts fuel economy. In general, lower temperatures give lower fuel economy.

Driving style — good driving and fuel economy habits

Give consideration to the lists that follow and you may be able to change a number of variables and improve your fuel economy.

Habits

- Smooth, moderate operation can yield up to 10% savings in fuel.
- Steady speeds without stopping will usually give the best fuel economy.
- Anticipate stopping; slowing down may eliminate the need to stop.
- Sudden or hard accelerations may reduce fuel economy.
- Slow down gradually.
- Driving at reasonable speeds (traveling at 88 km/h [55 mph] uses 15% less fuel than traveling at 105 km/h [65 mph]).
- Using the air conditioner or defroster may reduce fuel economy.
- Resting your foot on the brake pedal while driving may reduce fuel economy.

Conditions

- Carrying unnecessary weight may reduce fuel economy.
- Fuel economy may decrease with lower temperatures during the first 12–16 km (8–10 miles) of driving.
- Flat terrain driving improves fuel economy over hilly roads.
- Transmissions give their best fuel economy when operated in the top cruise gear and with steady pressure on the accelerator.
- Close windows for highway driving.

NOISE EMISSIONS – EXTERIOR

In order to comply with the federal exterior noise regulations, your vehicle may be equipped with noise emission items. Depending on the vehicle configuration, it may have all or some of the following items:

Air Intake System

- **Air Cleaner:** should be inspected and its location should not be altered. Do not alter inlet and outlet piping.

Maintenance and specifications

Body

- **Wheel Well:** splash shields, cab shields and under-hood insulation should be inspected for deterioration, dislocation, and orientation.

Cooling System

- Check the fan for damage to blades; replace, if damaged, with the recommended parts. Inspect for fan to shroud interference, and any damage to shroud such as cracks and holes.
- The fan ratio should not be changed and the fan spacer dimensions and positions should not be altered.
- Inspect the fan clutch for proper operation, make sure that the fan is disengaged when cooling of the engine is not required.
- Check for proper operation of radiator shutters, if equipped. The shutters should be open during normal operating temperatures.

Engine and Driveline System

- **Transmission Enclosure:** inspect for cracks, holes, and tears. Clean any deposits such as oil, dirt, and stones.
- Engine valve covers and block covers are made to damp out engine mechanical noise and, if needed, should be replaced with recommended parts. Check for mechanical isolations.

Exhaust System

- Inspect the exhaust system for leaks at various joint connections and tighten the clamps.
- Do a visual inspection for cracks or holes in the muffler and tail pipe.
- Always use the recommended parts when items need to be replaced.
- The tail pipe elbow or offset tail pipe orientation must not be changed from the standard position as originally received.
- To avoid abnormal changes in vehicle sound levels, it is necessary for the owner to perform inspections and necessary maintenance at the intervals shown in the *General Maintenance Information* section.

CHASSIS-MOUNTED CHARGE AIR COOLER

Inspect charge air cooler daily

With the engine off, visually inspect the charge air cooler core assembly for debris and clogging of external fins. Prior to engine operation, remove any debris blocking the core.

- Turbocharger-to-charge air cooler

Maintenance and specifications

- Charge air cooler-to-intake manifold pipe
- Mounting bracket
- Chassis-mounted charge air cooler core

Inspect air intake piping

- Check for accumulation of salt deposits (where applicable). If present, disassemble and clean the complete air intake piping system. If the intake piping is pitted, use RTV silicone to seal joints against leakage.
- Check for loose hoses and clamps.
- Check for ruptured or collapsed hoses.
- Check air cleaner housing for cracks.

ELECTRICAL SYSTEM INSPECTIONS

Periodically inspect electrical connector and on the outside of the cab, on the engine and frame for corrosion and tightness. Exposed terminals such as the fuel sender, cranking motor, alternator and feed-through studs should be cleaned and re-coated with a lubricant sealing grease such as Motorcraft XG-3, or equivalent. This should include the ground cable connector for batteries, engine and cab as well as the jump starting stud.

Accessory feed connections

Vehicle electrical systems are complex and often include electronic components such as engine and transmission controls, instrument panels, ABS, etc. While most systems operate on battery voltage (12 volts), some systems can be as high as 90 volts or as low as five volts. Refer to the Electrical Circuit Diagram Manuals, available from your vehicle's manufacturer, to assure that any additional body lights and accessories are connected to circuits that are both appropriate and not overloaded. No modification should be made to any vehicle control system without first contacting your dealer.

SUSPENSION INSPECTION

Note: Do not adjust air suspension height to any setting other than the specified setting. Altering the height setting will change the driveline angle and may result in unwarrantable component damage, such as transmission component damage.

Verify drive axle air suspension height and height control valve performance at engine lube oil change intervals.

Maintenance and specifications

Periodically:

- Check condition of spring leaves for evidence of fatigue, bending or breakage.
- Check condition of suspension mounting brackets and bushings.
- Check that torque rod mounting fasteners are tight.
- Check to be sure the suspension alignment is maintained at all time.
- Check U-bolts after the chassis has been operating under load for 1,600 km (1,000 miles) or six months, whichever comes first, the U-Bolt nuts must be re-torqued. The U-Bolt nuts thereafter must be re-torqued every 58,000 km (36,000 miles). The U-Bolt and nut threads and seats should be cleaned and lubricated to assure a “like new” condition when re-torquing.

Note: See the *U-Bolt Nut Torque* chart later in this section.

Supporting your vehicle for service

When performing service repairs on your vehicle, first prepare the vehicle by doing the following:

1. Park the vehicle on a level concrete floor.
2. Set the parking brake and block the wheels to prevent the vehicle from moving.
3. Select a jack (floor jack preferred) with a rated capacity sufficient to lift and hold up the vehicle.
4. Raise the vehicle with the jack applied to the axle(s). DO NOT use the bumper as a lifting point.
5. Support the vehicle with floor stands under the axle(s). If the axle or the suspension are being serviced, support the vehicle with floor stands under the frame side-members, preferably between the axles.



Do not use a jack when working under a vehicle. It may give way, causing the vehicle to fall and result in property damage, personal injury or death. Always use floor stands to support the vehicle.

Maintenance and specifications

FRAME AND TOW HOOKS

Your vehicle's chassis is manufactured with frame rails of either mild carbon steel, or HSLA steel. Each must be handled in a specific manner to assure maximum service life. Before attempting frame repair or modification, consult the service manual or your dealer.

It is important, particularly on vehicles where the tow hooks are used frequently to inspect the front and rear tow hooks for damage or a loose mounting.

U-BOLT NUT TORQUE

U-bolt diameter (nominal)	U-bolt diameter (nominal)	
	N.m	Ft. lbs.
3/4 inch flanged lock nut	353–407	260–300
7/8 inch hex head with washer (Air suspension axles; except with 14ACC, 14ADN and 14ADP axles)	543–610	400–450
7/8 inch hex head with washer (including air suspension axles 14ACC, 14ADN and 14ADP axles)	353–407	260–300
1 inch hex head with washer	441–543	325–400

Air suspension U-bolt checks and re-torquing procedures

1. Inspect the threads of the U-bolt and nut for rust and debris. Clean the threads if contaminated.
2. Using a torque wrench, determine if any nuts can be turned with a force below the specified torque.
3. Using the lowest discovered torqued nut as a starting point, retighten the nuts using the sequence listed under *Air suspension U-bolt and U-bolt nut installation*.

Air suspension U-bolt and U-bolt nut installation

1. Inspect the threads of the U-bolt and nut for rust and debris. Clean the threads if contaminated.
2. Install the U-bolts and nuts and torque the nuts to 20 N.m. (15 ft. lbs.), using a diagonal pattern.
3. Re-torque the nuts to 136 N.m. (100 ft. lbs.), using a diagonal pattern.
4. Re-torque the nuts to 271 N.m. (200 ft. lbs.), using a diagonal pattern.

Maintenance and specifications

5. Re-torque the nuts to 542 (400 ft. lbs.), using a diagonal pattern. (For vehicles equipped with 14ACC, 14 ADN and 14ADP axles, do not use Step 6.)
6. Re-torque the nuts to 576 N.m. (425 ft. lbs.), using a diagonal pattern. (For vehicles equipped with 14ACC, 14 ADN and 14ADP axles.)
7. Use the same diagonal pattern with each U-bolt nut re-torque.

Spring U-bolt checks

Check U-bolt nuts and re-torque every 58,000 km (36,000 miles) after initial 1,600 km (1,000 mile) re-torque. The U-bolt and nut threads and seats should be cleaned and lubricated to assure peak condition when re-torqued.

PROPELLER SHAFT

At the regular lubrication interval, check the universal joints for any evidence of wear or looseness. Should propeller shaft vibrations occur, stop the vehicle immediately to avoid possible hazardous consequences or damage to other components.

REAR AXLE LUBRICANT

Refer to your general maintenance information section for rear axle lubricant level checks and lubricant change intervals.

Your rear axle may be filled with an optional synthetic lubricant which allows the use of extended service intervals. A tag on the filler plug will identify the use of the synthetic lubricant.

Use only a lubricant that meets manufacturer specifications (refer to *Lubricant specifications* in this chapter).

Use of a non-approved rear axle lubricant may cause internal axle component damage.

Check your rear axle lubricant level using the following procedure:

1. Park the vehicle on level ground.
2. Set the parking brake and shift into N (Neutral) (automatic transmission) or 1 (First) (manual transmission) and turn the engine off.
3. Clean any dirt from around the rear axle filler plug.
4. Remove the filler plug and inspect the lubricant level.
5. The lubricant level should be up to the bottom of the filler plug opening.
6. If necessary, add enough lubricant through the filler plug opening so that the lubricant level is at the bottom of the opening.
7. Clean and install the filler plug securely.

Maintenance and specifications

Drain and refill your rear axle lubricant using the following procedure:

1. Drain the rear axle while the lubricant is warm.
2. Park the vehicle on level ground.
3. Set the parking brake and shift into N (Neutral) (automatic transmission) or 1 (First) (manual transmission) and turn the engine off.
4. Clean any dirt from around the rear axle filler and drain plugs.
5. Remove the filler and drain plugs and drain the lubricant into a suitable container. Dispose all used automotive fluids in a responsible manner following your local authorized standards.
6. Clean and install the drain plug securely.
7. Add enough lubricant through the filler plug opening so that the lubricant level is up to the bottom of the opening.
8. Clean and install the filler plug securely.

WHEELS

General

Wheel bearings should be inspected, lubricated and adjusted at regular intervals. This is especially important if operating in deep sand, mud, or water. Refer to *Lubricant specifications* in this chapter.

The tires equipped on this vehicle are appropriate for the maximum speed rating of the vehicle as set by the manufacturer for this application. This maximum vehicle speed should not be modified, nor should any modifications be made to the vehicle in an attempt to increase the maximum vehicle speed. Please see your dealer if additional details are needed.

Oil lubricated front wheel bearings

During normal vehicle duty cycle, the lube and air inside the hub/wheel cavity expands and if not vented, causes pressure build-up that could cause accelerated seal wear.

There are two venting methods:

- a slit or small hole in the rubber check vent or
- the window

You can use either of these methods to prevent pressure build-up.

Normal maintenance

Over a period of time, if not routinely cleaned, a slight film of oil can collect dirt around the rubber fill plug and face, which could appear to be a leak. Routine cleaning ensures that the lube level can be easily observed through the clear window as intended. In situations where the window is

Maintenance and specifications


clean on the outside but discolored on the inside, the lube level may be checked by inserting a finger through the rubber check vent hole.

The specified lube level for a clear window type hubcaps is from the minimum line to + 5/16 inch above the minimum line.


If the lube level should suddenly drop dramatically below the minimum level, see the Service Manual for diagnostic procedure.

Installation, tightening and alignment

8-lug wheel



10-lug wheel



When installing wheels, be certain that the threads on studs and nuts are clean to permit correct torquing of nuts. The mounting surfaces of rims, wheels, spacer rings and clamps must be free of dirt, rust, lubricants or damage.

Use a wire brush to clean the mounting contact surfaces. Do not use lubricant on threads.

After the rim or wheel has been properly tightened, it should be checked for alignment. Rotate the wheel with a piece of chalk attached to a steady, firm surface, and placed to just barely clear the outside surface of the tire bead seat. This procedure will point out the high spot. A high spot does not necessarily mean that the lug nuts have been unevenly tightened. This condition or misalignment could be caused by a bent wheel.


Maintenance and specifications

Checking the alignment of the wheel/rim installation is more important on cast spoke rims since the rims can be drawn out of alignment when improperly tightened. Use the following installation procedures.

Disc wheel with flange nuts (hub-piloted)


Front wheel mounting of flange nut system

1. Flange nut
2. Wheel(s)
3. Brake drum
4. Wheel stud (22 mm)
5. Wheel hub



Rear wheel mounting of flange nut system

1. Flange nut
2. Wheel(s)
3. Brake drum
4. Wheel stud (22 mm)
5. Wheel hub




1. Slide inner rear or front tire and wheel in position over studs and push it back as far as possible. Use care so that the threads on studs are not damaged.
2. Position the outer rear tire and wheel in place over the studs and push it back as far as possible. Use care so that the threads on studs are not damaged.
3. Run the nuts on the studs until they contact the wheel(s). Rotate the wheel assembly a half-turn to permit the parts to seat.

Maintenance and specifications

4. Draw up the nuts alternately following the crisscross sequence illustrated under *Installation, tightening and alignment*. Do not fully tighten the nuts. This will allow uniform seating of the nuts and assure even face-to-face contact of the wheel and hub.
5. Continue tightening the nuts to the torque specifications in the torque chart using the same crisscross sequence shown.
6. After operating the vehicle approximately 80 km (50 miles), check the nuts for tightness. Some natural seating of parts may be encountered and the torque on the nuts will drop. Retighten all nuts to specifications. Once a week, inspect and retighten the wheel stud nuts.

Aluminum rear disc wheel with flange nuts (hub-piloted)



1. Flange nut
2. Wheel(s)
3. Brake drum
4. Wheel stud (22 mm)
5. Wheel hub
6. Wheel locator pad

Prior to re-installing rear aluminum hub-piloted wheels, clean each wheel locator pad on the hub from all dirt, rust and foreign material. Apply a

Maintenance and specifications

light coat of chassis grease, never-seize or disc brake corrosion control grease, only to the wheel locator pad.

When installing the tire and rim assembly on disc-brake equipped axles, make sure the tire valve stem clears the brake caliper. The use of a tire manufacturer's stem forming tool is the only acceptable method of obtaining clearance when necessary.

Note: Always observe the following instructions:

- Always loosen rim clamps before complete removal of nut from stud (cast spoke wheels). With loosened nuts on stud, strike clamps with a heavy hammer and be sure each clamp is loose.
- Always deflate tires completely before removing locks or side rings.
- Always inflate tires in a safety cage.
- Never mix rim side rings or lock rings of different types, manufacturers or sizes.
- Never use cracked, bent or badly rusted parts.
- Never re-inflate flat tires on-vehicle; use the spare tire.
- Never add air until each side ring or lock ring is fully seated.
- Never hammer side ring or lock ring on a partially- or fully-inflated tire.



Failure to follow these instructions could result in property damage, personal injury or death

Proper torque

It is important to tighten and maintain wheel and rim mounting nuts to the proper torque. Loose nuts or over-tightened nuts can lead to premature wear and possible failure of the wheel and/or mounting hardware.

Changing wheel types

Consult your dealer or wheel/rim distributor before attempting any wheel or fastener changes.



Use only the same type and style wheels and mounting hardware to replace original parts. Failure to do so may result in an assembly that looks fine, but does not fit together properly. This could possibly cause wheel or fastener failures which could result in property damage, personal injury or death.

Maintenance and specifications



Do not attempt to mix stud-piloted wheels or fasteners with hub-piloted wheels or fasteners.



Do not change from aluminum wheels to steel wheels or vice-versa without changing the mounting hardware required or, with flange-nut mounting systems, changing the hub and stud assembly.

WHEEL NUT TORQUE

Size	Nut mounting	Torque	
		N.m.	ft. lbs.
22 mm	Flange	610–678	450–500

Note: Do not use lubrication on dry threads. Where excessive corrosion exists, a light coat of lubricant on the first three threads of the stud bolt is permitted. Keep lubricant away from:

- Hex nut and rim clamp contact surfaces.
- Cap nut ball face and ball seat on the disc wheel.
- Flange nut washer surface and flat on the disc wheel.

TIRE/WHEEL RIM SELECTION AND INFLATION PRESSURES

Tire Size, Load Range (PR)	Wheel Width (in.) and Type	Single Rear Axle: Max. Tire and Wheel Capacity kg. (lb.)/ kPa @ (psi) (cold) by Axle	
		Front	Rear
	Tubeless Type Radial Ply		
10R22.5 F (12)	7.50 10H (I.S.O.)	4,671 (10,300)/ 698 (100)	8,745 (19,280)/ 698 (100)
10R22.5 G (14)	7.50 10H (I.S.O.)	4,671 (10,300)/ 698 (100)	9,525 (21,000)/ 711 (115)
11R22.5 G (14)	8.25 10H (I.S.O.)	5,478 (12,080)/ 703 (105)	10,213 (22,520)/ 703 (105)
245/70R19.5	6.75 8H (I.S.O.)	4,671 (10,300)/ 698 (100)	8,745 (19,280)/ 698 (100)

Maintenance and specifications

LUBRICATION AND MAINTENANCE INTERVALS

New vehicles are lubricated at the factory. After the vehicle is placed in operation, regular lubrication intervals, based on the type of service and road conditions, should be established. Thorough lubrication at the specified intervals will insure outstanding life cycle value and will reduce overall expense.

The lubrication intervals specified should be performed at whatever interval occurs first, whether it is months, kilometer (miles) or hours. Only lubricants of superior quality, such as Motorcraft lubricants, should be used. The use of inferior products will reduce the service life of the vehicle or result in failure of its components.

Unless otherwise specified, never add lubricant unless it is the same grade as that which is already being used. If the grade is not known or not available, drain, flush and refill with new lubricant.

The interval between lubrication periods, oil changes, etc. depends entirely upon operating conditions. The loads carried, speeds, road and weather conditions all contribute to the frequency of lubrication periods.

In some types of operation, and where operating conditions are extremely severe (such as in deep water, mud or unusually dusty conditions), the vehicle may require lubrication after every 24 hours of operation.

Maintenance intervals

Maintenance intervals are provided for three types of general vehicle environments: On-Highway, City and Severe Service. In all applications, the actual intervals is determined by monitoring kilometers (miles) and time and when the engine is due for an oil change. When the engine oil change is required prior to the truck lubrication interval, it is recommended that the lubrication be performed at the same time in order to reduce your vehicle's time out of service.

- **On-Highway:** 96,000 km (60,000 miles) or more annually.
- **City:** 95,000 km (59,000 miles) or less annually.
- **Severe Service:** 32,000 km (20,000 miles) or less annually on/off road in dirty conditions.

Maintenance and specifications

LUBRICANT SPECIFICATIONS

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Non-driving front axle			
Eaton-Spicer axle (generic) - front axle wheel bearing oil	Multipurpose EP gear lube of API GL-5 quality meeting MIL-PRF-2105E specifications including synthetic* lubricants. (* Do not mix conventional and synthetic lubricants.)	SAE 75W: -40°C to -26°C (-40°F to -15°F)	Motorcraft SAE 75W-90 Premium 4x4 Front Axle Lubricant / XY-75W90-TQL
		SAE 75W-80: -40°C to 27°C (-40°F to 80°F)	Motorcraft SAE 75W-90 Premium 4x4 Front Axle Lubricant / XY-75W90-TQL
		SAE 75W-90: -40°C to 38°C (-40°F to 100°F)	Motorcraft SAE 75W-90 Premium 4x4 Front Axle Lubricant / XY-75W90-TQL
		SAE 75W-140: -40°C and above (-40°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 80W-90: -26°C to -38°C (-15°F to 100°F)	Motorcraft SAE 80W-90 Premium Rear Axle Lubricant / XY-80W90-QL
		SAE 80W-140: -26°C and above (-15°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 85W-140: -12°C and above (10°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
International / Spicer axle - front axle wheel bearing oil	Multipurpose EP gear lube of API GL-5 quality meeting MIL-PRF-2105E specifications including synthetic* lubricants. (* Do not mix conventional and synthetic lubricants.)	SAE 75W: -40°C to 0°C (-40°F to 32°F)	Motorcraft SAE 75W-90 Premium 4x4 Front Axle Lubricant / XY-75W90-TQL
		SAE 75W-90: -40°C to 38°C (-40°F to 100°F)	Motorcraft SAE 75W-90 Premium 4x4 Front Axle Lubricant / XY-75W90-TQL
		SAE 75W-140: -40°C and above (-40°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 80W: -26°C to 21°C (-15°F to 70°F)	Motorcraft SAE 80W-90 Premium Rear Axle Lubricant / XY-80W90-QL
		SAE 80W-140: -26°C and above (-15°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 90W: -12°C to 38°C (10°F to 100°F)	SAE 90 Hypoid Gear Oil / C6AZ-19580-E
		SAE 85W-140: -12°C and above (10°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 140W: 4°C and above (40°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Meritor - front axle wheel bearing oil	Fill at the factory with Synthetic SAE 75W-90, will have a tag attached to fill plug that reads as follows: "Filled with synthetic lube. Do not mix."	SAE 75W-90	Motorcraft SAE 75W-90 Synthetic Rear Axle Lubricant / XY-75W90-GLS
Rockwell - front axle wheel bearing oil	Multipurpose EP gear lube of API GL-5 quality meeting MIL-PRF-2105E specifications including synthetic* lubricants. (* Do not mix conventional and synthetic lubricants.)	SAE 85W-140: -12°C and above (10°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 85W-90: -26°C and above (-15°F and above)	Motorcraft SAE 80W-90 Premium Rear Axle Lubricant / XY-80W90-QL
		SAE 75W-90: -40°C and above (-40°F and above)	Motorcraft SAE 75W-90 Premium 4x4 Front Axle Lubricant / XY-75W90-TQL
		SAE 75W: -40°C to 2°C (-40°F to 36°F)	Motorcraft SAE 75W-90 Premium 4x4 Front Axle Lubricant / XY-75W90-TQL
	Heavy duty engine oil: MIL-L-2104B, C, D or E (API-CD, CE, SF or SG)	SAE 40 or 50: -12°C and above (10°F and above)	—
	Heavy duty engine oil: MIL-L-2104B, C, D or E (API-CD, CE, SF or SG)	SAE 30: -26°C and above (-15°F and above)	Motorcraft SAE 30 Super Duty Motor Oil / XO-30-QSD

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Eaton-Spicer axle, International-Spicer axle - Front axle wheel bearing grease, tie rod ends, drag link, kingpin and bushing	EP2 Lithium complex-based moly grease (or equivalent) GC/LB NLGI #2 multi-purpose lithium complex grease	Note: Eaton-Spicer and Meritor Easy Steer axles: With chassis load on axle, force grease through thrust bearings; then with axle lifted clear of the floor, force grease between kingpin and bushing surfaces.	Motorcraft Premium Long Life Grease / XG-1-C
Steering			
Power steering fluid change	MERCON®	—	Motorcraft Mercon Multi-Purpose (ATF) Transmission Fluid / XT-2-QDX
Steering gear Ross TAS-Output Seal	GC/LB NLGI #2 lithium complex-based moly grease or multi-purpose lithium complex grease	—	Motorcraft Premium Long Life Grease / XG-1-C
Steering column U-joints / slip joint	Light engine oil	—	Motorcraft SAE 5W-30 Super Premium Motor Oil / XO-5W30-QSP
Propeller shaft			
U-joint	GC/LB NLGI #2 lithium complex-based moly grease or multi-purpose lithium complex grease	—	Motorcraft Premium Long Life Grease / XG-1-C

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Clutch			
Release bearing / shafts / fork	GC/LB NLGI #2 lithium complex-based moly grease or multi-purpose lithium complex grease	—	Motorcraft Premium Long Life Grease / XG-1-C
Cooling system			
Coolant - 6.0L Powerstroke engine	WSS-M97B51-A1	—	Motorcraft Premium Gold Engine Coolant / VC-7-A
Coolant - Cummins B and Caterpillar engines	Refer to engine operator manual		
Windshield washer			
Washer fluid	WSB-M8B16-A2	—	Motorcraft Premium Windshield Washer Concentrate / ZC-32-A
Transmission			
Eaton-Fuller	Petroleum oil: Engine oil API-SL or API-CF (MIL-L-2104E or MIL-L-46152E)	SAE 50: -12°C (above 10°F)	—
		SAE 40: -12°C (below 10°F)	—
	Mineral gear oil: API-GL-1 (rust and oxidation inhibited)	SAE 80W-90: -12°C (above 10°F)	—
		SAE 75W: -12°C (below 10°F)	—
	Synthetic oil: Eaton®, Roadranger® synthetic CD-50 transmission fluid	CD SAE 50: All temperatures	—

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
International-Spicer (non-synchronized) (lubricants are listed in order of preference)	Petroleum oil: Engine oil API-SL or API-CF (MIL-L-2104E or MIL-L-46152E)	SAE 50: -18°C (above 0°F)	—
		SAE 40: -18°C (below 0°F)	—
	Mineral gear oil: API-GL-1 (rust and oxidation inhibited) (EP gear oils are not acceptable)	SAE 90: -18°C (above 0°F)	—
		SAE 80: -18°C (below 0°F)	—
Synthetic oil: Synthetic Engine Oil meeting MIL-L-2104E or MIL-L-46152E, API-SL or API-CF	CD SAE 50: All temperatures	—	
International-Spicer (synchronized) (lubricants are listed in order of preference)	Petroleum oil: Engine oil API-SL or API-CF (MIL-L-2104E or MIL-L-46152E)	SAE 50: -12°C (above 10°F)	—
		SAE 40: -12°C (below 10°F)	—
	Mineral gear oil: API-GL-1 (rust and oxidation inhibited)	SAE 90: -12°C (above 10°F)	—
		SAE 80W: -12°C (below 10°F)	—
Synthetic oil: Synthetic Engine Oil meeting MIL-L-2104E or MIL-L-46152E, API-SL or API-CF	SAE 50: All temperatures	—	

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Meritor	Petroleum oil: Heavy Duty Engine Oil MIL-L-2104E or API-SL or API-CF (previous API designations acceptable)	SAE 50: -12°C (above 10°F)	—
		SAE 40: -12°C (above 10°F)	—
		SAE 30: -12°C (below 10°F)	—
	Mineral gear oil with rust and oxidation inhibitor API-GL-1* (* Do not use multi-weight and GL-5 EP gear oils; they may cause transmission failure or damage.)	SAE 90: -12°C (above 10°F)	—
		SAE 80: -12°C (below 10°F)	—
Synthetic oil: MIL-L-2104E or MIL-L-46152D (* Do not use multi-weight and GL-5 EP gear oils; they may cause transmission failure or damage.) —	SAE 50: All temperatures	—	
Allison	Refer to transmission manual	—	—
Rear axle			
Eaton-Spicer - two-speed axles	RHEOLUBE 362 (or equivalent) (Eaton part number 113741)	—	—

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Eaton - single-speed axles	Generic lubricant	SAE 75W: -40°C to -26°C (-40°F to -15°F)	Motorcraft SAE 75W-90 Fuel Efficient High Performance Axle Lubricant / XY-75W90-FEHP
		SAE 75W-80: -40°C to 27°C (-40°F to 80°F)	Motorcraft SAE 75W-90 Fuel Efficient High Performance Axle Lubricant / XY-75W90-FEHP
		SAE 75W-90: -40°C to 38°C (-40°F to 100°F)	Motorcraft SAE 75W-90 Fuel Efficient High Performance Axle Lubricant / XY-75W90-FEHP
		SAE 75W-140: -40°C and above (-40°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 80W-90: -26°C to 38°C (-15°F to 100°F)	Motorcraft SAE 80W-90 Premium Rear Axle Lubricant / XY-80W90-QL
		SAE 80W-140: -26°C and above (-15°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 85W-140: -12°C and above (10°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
International-Spicer - single-speed	Multipurpose EP gear lube of API GL-5 quality meeting MIL-PRF-2105E specifications including synthetic lubricants	SAE 75W: -40°C to 0°C (-40°F to 32°F)	Motorcraft SAE 75W-90 Fuel Efficient High Performance Axle Lubricant / XY-75W90-FEHP
		SAE 75W-90: -40°C to 38°C (-40°F to 100°F)	Motorcraft SAE 75W-90 Fuel Efficient High Performance Axle Lubricant / XY-75W90-FEHP
		SAE 75W-140: -40°C and above (-40°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 80W: -26°C to 21°C (-15°F to 70°F)	Motorcraft SAE 75W-90 Fuel Efficient High Performance Axle Lubricant / XY-75W90-FEHP
		SAE 80W-140: -26°C and above (-15°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 90W: -12°C to 38°C (10°F to 100°F)	SAE 90 Hypoid Gear Oil / C6AZ-19580-E
		SAE 85W-140: -12°C and above (10°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 140W: 4°C and above (40°F and above)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Meritor - single-speed axle (cont'd)	Fill at the factory with Synthetic SAE 75W-90, will have a tag attached to fill plug that reads as follows: "Filled with synthetic lube. Do not mix."	—	Motorcraft SAE 75W-90 Synthetic Rear Axle Lubricant / XY-75W90-GLS
	Multipurpose EP gear lube of API GL-5 quality meeting MIL-PRF-2105E specifications including synthetic* lubricants. (* Do not mix conventional and synthetic lubricants.)	SAE 85W-140: -12°C (above 10°F)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 85W-140: -26.1°C (above -15°F)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
		SAE 80W-90: -26.1°C (above -15°F)	Motorcraft SAE 80W-90 Premium Rear Axle Lubricant / XY-80W90-QL
		SAE 75W maximum outside temperature 1.6°C (35°F); Above -40°C (-40°F)	Motorcraft SAE 75W-90 Fuel Efficient High Performance Axle Lubricant / XY-75W90-FEHP
		SAE 75W-140: Above -40°C (above -40°F)	Motorcraft SAE 75W-140 High Performance Rear Axle Lubricant / XY-75W140-QL
Cab components			
Hydraulic lift pump fluid	Dexron III	—	Motorcraft Mercon Multi-Purpose (ATF) Transmission Fluid / XT-2-QDX

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Cab latch and lock livers	Mobile SHC 32 Low Temperature Lubricant (or equivalent)	—	—
Cab latch pivots; Door check, hinges, latches and strikers; Seat adjuster slides	GC/LB NLGI #2 lithium complex-based moly grease (or equivalent) or multi-purpose lithium complex grease	—	Motorcraft Premium Long Life Grease / XG-1-C
Cab latch pivot pins	Light engine oil	—	Motorcraft SAE 5W-30 Super Premium Motor Oil / XO-5W30-QSP
Door lock cylinders	Lock oil	—	Motorcraft Penetrating and Lock Lubricant / XL-1
Door window regulators	NGLI #2 multipurpose lithium complex grease	—	Motorcraft Multi-Purpose Grease Spray / XL-5 or Motorcraft Multi-Purpose Grease / XG-4
Weatherstripping	Silicone lubricant	—	Motorcraft Silicone Spray / XL-6
Engine oil			
6.0L Powerstroke engine	API CI-4 / SL	SAE 15W-40 above -12°C (10°F)	Motorcraft SAE 15W-40 Super Duty Motor Oil / XO-15W40-QSD
		SAE 10W-30 -23°C to 32°C (-10°F to 90°F)	Motorcraft SAE 10W-30 Super Duty Motor Oil / XO-10W30-QSD
		SAE 0W-30 below -18°C (0°F)	Motorcraft SAE 0W-30 Super All Season Motor Oil / XO-0W30-LAS

Maintenance and specifications

Component / Component vendor	Lubrication type	Vendor recommendations: Viscosity / Ambient temperature / Notes	Equivalent Ford part name / number
Cummins B and Caterpillar 3126E engines	Refer to engine operator manual		
Brake fluid			
All vehicles	DOT 3, ESA-M6C25-A	—	Motorcraft High Performance Motor Vehicle Brake Fluid / PM-1

REFILL CAPACITIES

Rear axle

Axle code	Weight capacity - kg (lbs.)	Description	Fluid capacity - liters (pints) ^{1,2}
S135-S	6123 (13500)	Single rear axle, single reduction	11.6 (24.5)
4S150-S	7031 (15500)	Single rear axle, single reduction	11.6 (24.5)
17060S	7938 (17500)	Single rear axle, single reduction	13.3 (28.0)
19055T	7938 (17500)	Single rear axle, two-speed	13.3 (28.0)
M190-T	8618 (19000)	Single rear axle, two-speed	17.0 (35.0)
19060S	8618 (19000)	Single rear axle, single reduction	13.2 (28.0)
21060S	9525 (21000)	Single rear axle, single reduction	13.2 (28.0)
21060D	9525 (21000)	Single rear axle, single reduction	13.2 (28.0)
M210T	9525 (21000)	Single rear axle, two-speed	16.0 (33.0)

Maintenance and specifications

Axle code	Weight capacity - kg (lbs.)	Description	Fluid capacity - liters (pints) ^{1,2}
23090S	10432 (23000)	Single rear axle, single reduction	18.5 (39.0)
23090D	10432 (23000)	Single rear axle, single reduction with driver-controlled locking differential	18.5 (39.0)
23082T	10432 (23000)	Single rear axle, two-speed	17.5 (37.0)

¹ Quantities listed are approximate. Fill axle until the lubricant level is at the bottom of the filler hole, with the vehicle on level ground.

² If hubs are removed, add an additional 0.75 liter (1.6 pints) of axle lubricant. Add lubricant through the axle vent.

Engine coolant and oil

Engine type	Engine coolant (approximate capacity)	Engine oil (approximate capacity)
6.0L Powerstroke	25.7L (54.4 pints)	18.0L (19 quarts)
Caterpillar 3126E	28.4 (60.0)	¹
Cummins B	23.1 (24.4)	¹

¹ Refer to the engine operator manual for engine oil refill capacities.

Power steering system

Steering gear	Power steering fluid volume (cubic inches/liters/pints)
	V8 engine
TAS40 steering gear	506/8.3/17.6
TAS65 steering gear	533/8.7/18.4

Maintenance and specifications

Transmission

Description	Liters	Pints
MD-3060P 5-speed automatic	27.4	58.0 ¹
MD-3560P 5-speed automatic	27.4	58.0 ¹
MD-3060P 6-speed automatic	27.4	58.0 ¹
FS-4205A 5-speed manual	5.4	11.5
MD-3066P 6-speed automatic	27.4	58.0 ¹
FS-5406A 6-speed manual	9.2	19.5
FS-5406N 6-speed manual	9.2	19.5
MD-3560P 6-speed automatic	27.4	58.0 ¹
2000P Series 5-speed automatic	18.0	38.0 ¹
2400 Series 5-speed automatic	18.0	38.0 ¹
FS-5205A 5-speed manual	5.9	12.5
FS-6406N 6-speed manual	9.2	19.5
FS-6406A 6-speed manual	9.2	19.5
ES066-7B 7-speed manual	9.9	20.9
ES56-7B 7-speed manual	9.9	20.9
FR-9210B 10-speed manual	11.1	23.5
RT-8908LL 10-speed manual	13.2	28.0

¹Total fluid capacity (dry transmission and torque converter).

Air conditioner refrigerant - r134a

Kg. (lbs.)	Oz.
.85 (1.87)	30

Note: This system uses PAG-type refrigerant oil.

Refrigerant fitting torque

Captured washer nut: 19–21 N.m. (170–190 inch lbs.)

Note: This system uses mineral based refrigerant oil to lubricate o-rings and fittings.

Maintenance and specifications

Fuel tanks

Standard tanks are listed as such; all other tanks available for your vehicle are optional equipment.

Vehicle	Tank type	Liters	Gallons
F-650 Low Profile (standard), F-650 Dock Height	Single, steel rectangular	132	35
F-650 Low Profile, F-650 Dock Height (standard), F-750 Pick-up and Delivery (standard), F-750 Severe Service (standard)	Single, steel rectangular	170	45
F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Single, steel rectangular	189	50
F-650–Low Profile, F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Single, steel rectangular	246	65
F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Single, steel D-style	246	65

Maintenance and specifications

Vehicle	Tank type	Liters	Gallons
F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Single, steel D-style	302	80
F-650 Low Profile, F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel rectangular	114 (LH)/170 (RH)	30 (LH)/45 (RH)
F-650 Low Profile, F-650 Dock Height	Dual, steel rectangular	132 (RH)/170 (LH)	35 (RH)/45 (LH)
F-650 Low Profile, F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel rectangular	170/170	45/45
F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel D-style	189/189	50/50
F-650 Low Profile, F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel rectangular	170 (RH)/246 (LH)	45 (RH)/65 (LH)

Maintenance and specifications

Vehicle	Tank type	Liters	Gallons
F-650 Low Profile, F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel rectangular	170 (LH)/246 (RH)	45 (LH)/65 (RH)
F-650 Low Profile, F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel rectangular	246/246	65/65
F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel D-style	246/246	65/65
F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel D-style	246 (LH)/302 (RH)	65 (LH)/80 (RH)
F-650 Dock Height, F-750 Pick-up and Delivery, F-750 Severe Service	Dual, steel D-style	302/302	80/80

VEHICLE IDENTIFICATION NUMBER (VIN)

The VIN is printed on the Vehicle Rating Decal attached to the vehicle. The VIN also serves as the warranty number. If you ever find it necessary to communicate with Ford Motor Company about your vehicle, always include the VIN in your communication.

General maintenance information

GENERAL MAINTENANCE INFORMATION

The Scheduled Maintenance Services listed in this section are required because they are considered essential to the life and performance of your vehicle.

Ford Motor Company recommends you perform the Owner Maintenance Services listed in this section. These services are matters of day-to-day care that are important to the proper operation of your vehicle. In addition to the conditions described in the Owner Maintenance Checklist, be alert for any unusual noise, vibration or other indication that your vehicle may need service and attend to it promptly.

Use only recommended fuels, lubricants, fluids and service parts conforming to Ford specifications. Motorcraft parts are designed and built for best performance in your vehicle. Using these parts for replacement is your assurance that Ford-Built quality stays in your vehicle.

SCHEDULED MAINTENANCE

The maintenance or replacement of the emission control devices (or systems) in your new Ford Motor Company vehicle (or engine) may be performed at your expense. These services may be performed by any automotive repair establishment or individual using automotive parts equivalent to those with which your vehicle or engine was originally equipped. If any parts other than Ford, Motorcraft, or Ford authorized, remanufactured parts are used for maintenance replacements (or for the service) of components effecting the emission control, the owner should be assured that such parts are warranted by their manufacturer to be equivalent to genuine Ford Motor Company Parts in performance and durability. Please consult your warranty information booklet for complete warranty information.

Authorized dealer maintenance

Your authorized dealer specializes in knowing all about Ford Motor Company vehicles rather than knowing a little about all makes.

There are Ford or Ford of Canada dealer service shops ready to serve you wherever you drive in the U.S. or Canada. They stock Ford and Motorcraft parts, and Ford Chemicals and lubricants. You can be confident that these meet the same exacting design and quality standards as those used to build the vehicle originally. Dealer Service Technicians have available training in the latest product developments and service techniques.

General maintenance information

OWNER MAINTENANCE

You can do much of the maintenance your vehicle requires yourself, if you have the time and a reasonable amount of mechanical ability. If you prefer to have this work done professionally, your authorized dealer stands ready to help you.

All mechanical components and attachments are important in that they could affect the performance of vital components and systems. If replacement becomes necessary, they must be replaced with parts having the same part number or with equivalent parts. Torque values of the attaching parts must be used as specified during any reassembly procedure to assure proper retention.

EMISSIONS CONTROL SYSTEM

To assure the emissions control systems operate effectively, you should have the services listed in the maintenance schedule performed at the specified time and km/mileage intervals. You should avoid running out of fuel or turning off the ignition while the vehicle is in motion, especially at high speeds.



Because of high engine compartment and exhaust system temperatures resulting from emissions equipment, do not park, idle or operate your vehicle in dry grass or other dry ground cover where the possibility of ground fire exists.

Do not make unauthorized modifications to the engine or vehicle. Modifications causing increased amounts of unburned fuel to reach the exhaust system can significantly increase the temperature of the engine compartment and/or the exhaust system.

Avoid driving your vehicle if it does not operate properly. If the engine diesels (more than five seconds of engine run-on after shut-off), misfires, surges, stalls or backfires, see your dealer. Be alert for fluid leakage, odor, smoke, loss of oil pressure, or charge indicator or over temperature warning.

Do NOT use diesel fuel blended with waste oil in engines equipped with a catalytic converter-muffler. Waste lube oil blending in fuel will plug the catalytic converter-muffler, resulting in a significant loss of engine power.

Emissions control system(s) laws

Federal law prohibits vehicle manufacturers, dealers and other persons engaged in the business of repairing, servicing, selling, leasing or trading

General maintenance information

motor vehicles, as well as fleet operators from knowingly removing or rendering an emissions control device or system inoperative. Further, modifications of the emissions control system(s) could create liability on the part of individual owners under the laws of some states. In Canada, modification of the emissions control system could create liability under applicable Federal or Provincial laws.

NOISE EMISSIONS WARRANTY, PROHIBITED TAMPERING ACTS AND MAINTENANCE

On January 1, 1978, Federal regulations became effective governing the noise emissions on trucks over 4,536 kgs. (10,000 lbs.) GVWR. The following statements concerning prohibited tampering acts and maintenance and the noise warranty are found in the Warranty Guide, and are applicable to completed trucks.

Tampering with noise control system prohibited

Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative, by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the following acts listed:

Vehicle System	Acts
Acoustical Shielding	Removal of noise shields, hood blanket, tunnel liner or acoustical absorptive material.
Engine	Removal or rendering inoperative the engine speed governor so as to allow engine speed to exceed manufacturer specifications. Removal of engine mounted noise shield or oil pan enclosure.

General maintenance information

Vehicle System	Acts
Engine Air Induction System	Removal of the air duct, silencer, air cleaner, and/or air cleaner element and baffle in air cleaner; re-indexing of air cleaner.
Exhaust System	Removal or rendering inoperative exhaust system components including the catalytic converter - muffler assembly, inlet pipe, outlet pipe, resonator and flexpipe. Rotation of horizontal exhaust system directional outlet pipe to cause the exhaust to be emitted in a direction other than downward.
Engine Cooling System	Removal or rendering inoperative the fan clutch. Removal or modification of the fan shroud. Replacing a fixed fan with a fan of increased diameter, different number of blades or different pitch width.

MAINTENANCE

Instructions for maintenance and service of the noise control system have been included in the Required Maintenance Services and in the General Maintenance Checklist. To further help minimize noise emissions degradation throughout the life of the vehicle, Ford Motor Company recommends that this vehicle should be operated in the manner described within the Owner Guide. Caution should be exercised by the owner when installing replacement parts to be sure that a tampering act (as outlined above) is not committed. Note any inspection and service performed in the Maintenance Record.

EMISSIONS INFORMATION LABEL

Emissions information appears on the Important Engine Information Decal located on or near the engine.

General maintenance information

SCHEDULED MAINTENANCE SERVICES

Maintenance service adjustments must conform to specifications contained in this manual, and those shown on the Important Engine Information Decal. The following services are to be performed at scheduled intervals because they are considered essential to the life and performance of your vehicle. Ford recommends that you perform maintenance on all designated items to achieve best vehicle operation.

Scheduled maintenance beyond 161,000 km (100,000 miles) should be continued as before 161,000 km (100,000 miles).

SPECIAL OPERATING CONDITIONS

If your driving habits **frequently** include one or more the following conditions:

- Short trips of **less** than 16 km (ten miles) when outside temperatures remain below freezing.
- Operating during **hot weather** in stop-and-go “rush hour” traffic.
- Operating in severe dust conditions.
- Extensive idling, or low speed operation such as door-to-door delivery service.
- High speed operation with a fully loaded vehicle (max. GVW).
- Snowplowing.

Perform the following:

- Change engine oil and oil filter every three months, 8,000 km (5,000 miles) or 125 hours of engine service.
- If operating in severe dust conditions, replace the air cleaner filter more often than regular intervals as determined by the air filter restriction indicator. Make sure that the air filter restriction indicator is in good working order.
- Lube the manual transmission and the rear axle every 48,279 km (30,000 miles) or 6 months, whichever comes first.
- See the Allison, Cummins and Caterpillar Operator’s Manual.

General maintenance information

AIR BRAKE ADJUSTMENT



Failure to maintain proper air brake adjustment can result in reduction or loss of braking ability.

Air brake inspection and adjustment should be performed by a qualified service technician in accordance with the instructions in the Ford Truck Service Manual.

Cam brakes - automatic slack adjusters

Inspect standard air brakes equipped with automatic slack adjusters for proper brake adjustment every four months or 32,000 km (20,000 miles) whichever occurs first.

However, more frequent inspection is required if your vehicle's brakes are subjected to heavy use or adverse operating conditions such as:

- Frequent brake applications while fully loaded.
- Operation on hilly or mountainous terrain.
- Frequent operation on dirt, gravel or mud.

Some aftermarket brake linings also require more frequent inspections.

General maintenance information

SCHEDULED MAINTENANCE GUIDE

MAINTENANCE SERVICES AND RECORD RETENTION

The maintenance record form which follows is for your convenience. In addition to recording the services performed, you should retain copies of your receipts for the services. You also should keep records of any emission control systems maintenance services performed on your vehicle.

Maintenance Record

Warranty _____
Start Date _____ Engine Displacement _____
Vehicle Identification Number _____ Owner Name _____

IMPORTANT — This document should remain with the vehicle at all times.

General maintenance information

Daily Owner Checks	Engine system
	Check the air filter restriction indicator
	Check the engine oil
	Inspect the coolant level - for Powerstroke engine (for Caterpillar and Cummins engines, refer to the Owner's Manual)
	Brake system
	Drain the air brake system reservoir - manual valve
	Check the air brake system reservoir automatic drain valve operation
	Transmission system
	Visually check the automatic transmission for fluid leakage
	Steering system
	Check the power steering pump fluid level and check the system for leaks
	Check the entire vehicle for evidence of fluid leaks
	U.S. Department of Transportation, Federal Highway Administration requirements (ensure that the entire system is functioning properly)
	Check the service brakes
	Check the parking brake
	Check the steering mechanism
	Check the lighting devices and reflectors
	Check the tires
	Check the horn
	Check the windshield wipers
Check the rear vision mirrors	
Check the wheels and rims	
Check the emergency equipment	

General maintenance information

<p>Check every oil change Oil change intervals are as follows: Powerstroke - 10,000 ; Caterpillar - 15,000 ; Cummins - 15,000 (refer to the Caterpillar and Cummins service manuals for further instructions and information)</p>	<p>Engine system</p>
	<p>Check the engine cooling system - hoses, clamps and protection</p>
	<p>Inspect the drive belts</p>
	<p>Exhaust system</p>
	<p>Inspect the entire exhaust system (including the inlet pipe(s), muffler(s), outlet pipe(s), clamps and fasteners) for holes, leakage, breakage, corrosive damage and separation from other components. Adjust, service or replace with the same or the equivalent part. (Also a noise emission control service)</p>
	<p>Suspension system</p>
	<p>Lubricate the front and rear spring pins</p>
	<p>Tighten the front and rear spring U-bolts to the specified torque</p>
	<p>Driveline and rear axle system</p>
	<p>Lubricate the U-joints and the slip yoke</p>
	<p>Brake system</p>
	<p>Lube the air brake foot control valve, hinge and roller</p>
	<p>Inspect the drum brake linings through the inspection holes</p>
	<p>Lubricate the brake camshafts (air brakes)</p>
	<p>Lubricate the brake slack adjuster (air brakes)</p>
	<p>Lubricate rear caliper slide rails</p>
	<p>Inspect the disc brake pads and the piston boots (hydraulic brakes)</p>
	<p>Clutch system</p>
	<p>Lubricate the clutch release cross shaft and all linkages</p>
	<p>Check the clutch fluid</p>
	<p>Fuel system</p>
	<p>Drain the accumulated water or sediment from the fuel tank(s)</p>
	<p>Steering system</p>
<p>Lubricate the steering shaft(s), U-joints and splines when equipped with grease fittings</p>	
<p>Lubricate the front axle spindle pins</p>	
<p>Lubricate the steering linkage when equipped with grease fittings</p>	
<p>Grease the power steering gear output shaft</p>	
<p>* Coolant protection checks should be made just prior to the onset of freezing weather, where applicable. If coolant is dirty or rusty in appearance, the system should be drained, flushed and refilled with the prescribed solution of cooling system fluid and water. Use only permanent type coolant that meets Ford specifications WSS-M97B51-A1. See the engine manufacturer's operating guide for supplemental corrosion inhibitor specifications.</p>	

General maintenance information

In addition to the items to be performed daily or at each oil change, the following need to be completed as specified:

GENERAL MAINTENANCE SERVICES

Listed below are vehicle checks that should be made periodically either by the owner or a qualified technician. It is recommended that deficiencies be brought to the attention of your dealer or another qualified service outlet as soon as possible in order that advice regarding the need for service or replacement can be obtained.

Maintenance Operation	Frequency — Observation
Clean body/door drain holes.	At least twice annually.
Clean windshield wiper blades.	As required.
Replace windshield wiper blades.	If wiping the blades with a clean cloth and mild detergent and washing the windshield with a cleaner does not restore a clean wipe.
Lubricate body lock cylinders, door and hood hinges.	Difficult to operate or noisy.
Check headlamp alignment.	Lamp beams in wrong position when vehicle operating loaded.
Check windshield washer fluid level. Add fluid if required.	If washers do not spray fluid when operated.

General maintenance information

Maintenance Operation	Frequency - Observation
Inspect the automatic slack adjuster function	Insufficient power shown in loaded practice stop
Check the operation of the brakes, the clutch, and the steering (*a,b)	Vehicle handling qualities not up to par
Inspect the vehicle for missing, damaged, or mislocated noise shields	Excessive noise emanates from under the cab or engine compartment
Check the engine performance and the engine governor	Excessive engine noise
Inspect the fan, the fan shroud, and the fan clutch	Engine overheats, fans runs at high speed constantly, excessive fan noise, or fan wobble due to worn bearings
Check for operation of ABS warning lamp	At each engine start up
Inspect the entire exhaust system (including inlet pipe, muffler, outlet pipe and all exhaust clamps and fasteners) for holes, leakage, breakage, looseness and corrosive damage	Excessive noise or the smell of fumes is experienced
Inspect the engine air induction system (including the air ducts, the air cleaner, and the air cleaner element) for loose fitting, damaged or missing components	Excessive noise emanates from the engine compartment
Inspect the tires and check the air pressure (*c)	Poor steering, wandering or excessive tire wear
Balance the wheels and the tires	Vibration or abnormal tire wear indicates imbalance
Check the front end alignment (*c)	Poor steering, wandering or excessive tire wear

General maintenance information

Maintenance Operation	Frequency - Observation
Check the transmission and engine mountings (*b)	Hard shifting or excessive vibration
Check and adjust transmission controls (*b)	High effort to shift or noisy transmission
Check fuel pump pressure	Insufficient full-throttle power or backfiring
Clean radiator cap seal. Clean and inspect the cap surface on the radiator	When the cap does not hold pressure
Check the battery terminals for corrosion	Whenever electrical power supply has diminished
Tighten the wheel mounting nuts to the specified torque. Refer to <i>Servicing your wheels and tires</i>	Required initially at 800 and 1,600 km (500 and 1,000 miles). Perform again at 800 and 1,600 km (500 and 1,000 mile) intervals after each tire removal/replacement.
*a During maintenance and repair, protect the fuel tube and the hose assemblies, the power steering lines, and the brake lines from the external heat, the acids and the abrasion that could damage the lines.	
*b Check for (free) linkage action and ensure that (return) spring force is adequate to maintain pedal free play.	
*c Adjust, repair or replace as required with the same or equivalent parts.	

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - ON HIGHWAY (On Highway: 60,000 Miles or more Annually) - Miles, Kilometers or Months - Whichever Occurs First																						
	Miles (000)	15	30	45	60	75	90	105	120	135	150	Kilometers (000)	24	48	72	96	120	144	168	192	216	240	
	Months	3	6	9	12	15	18	21	24	27	30		3	6	9	12	15	18	21	24	27	30	
	Non-driving front axle																						
Wheel bearing - oil type - check level	•	•	•	•	•	•	•	•	•	•	•												
Wheel bearing - oil type - change oil							•																
Wheel bearing - grease type - repack			•		•																		
Tie rod ends - lubricate	•	•	•	•	•	•	•	•	•	•	•												
Drag link - lubricate	•	•	•	•	•	•	•	•	•	•	•												
King pin and bushing - lubricate	•	•	•	•	•	•	•	•	•	•	•												
Brake system - hydraulic																							
Master cylinder - check level	•	•	•	•	•	•	•	•	•	•	•												
Park brake relay lever / linkage - lubricate					•																		
Steering																							
Power steering fluid - check level	•	•	•	•	•	•	•	•	•	•	•												
Power steering fluid - change fluid																							
Power steering filter - replacement																							
Five years or 800,000 km (500,000 miles)																							
Steering gear sheppard - input bearing - lubricate	•	•	•	•	•	•	•	•	•	•	•												
Steering gear Ross TAS - output shaft - lubricate																							
Steering column u-joints / slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•												
Propeller shaft SPL																							
U-joint - lubricate	•			•																			

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - ON HIGHWAY (Continued)												
	(On Highway: 60,000 Miles or more Annually) - Miles, Kilometers or Months - Whichever Occurs First												
	Miles (000)	15	30	45	60	75	90	105	120	135	150		
	Kilometers (000)	24	48	72	96	120	144	168	192	216	240		
Months	3	6	9	12	15	18	21	24	27	30			
Propeller shaft non-SPL													
U-joint and slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Brake system - air													
Slack adjusters - lubricate					•								
S-cam - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Clutch													
Release bearing / shafts / forks - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Cooling system													
Coolant - check level	•	•	•	•	•	•	•	•	•	•	•	•	•
Coolant - check freeze protection	•	•	•	•	•	•	•	•	•	•	•	•	•
Extended life coolant - add extender													
Extended life coolant - replace													
See engine manufacturer's recommendation													
See engine manufacturer's recommendation													
Engine - Refer to engine manual for Caterpillar and Cummins. 6.0L Powerstroke - see 6.0L Engine section at end of chart													
Transmission													
Automatic and Ahto-shift transmissions													
Manual transmission - check fluid level	•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton-Fuller manual transmission - petroleum oil change													
Eaton-Fuller manual transmission - synthetic oil change													
Factory fill w/synthetic at 800,000 km (500,000 miles); Converted to synthetic at 400,000 km (250,000 miles)													

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - ON HIGHWAY (Continued)													
	(On Highway: 60,000 Miles or more Annually) - Miles, Kilometers or Months - Whichever Occurs First													
	Miles (000)	15	30	45	60	75	90	105	120	135	150			
	Kilometers (000)	24	48	72	96	120	144	168	192	216	240			
	Months	3	6	9	12	15	18	21	24	27	30			
Rear axle														
Fluid level - check		•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton / Dana / Spicer petroleum oil - change					•									
Eaton / Dana / Spicer synthetic oil - change														
		Factory fill w/synthetic at 800,000 km (500,000 miles); Converted to synthetic at 400,000 km (250,000 miles) or three years												
Cab components														
Door hinges / Latches / Strikers - lubricate, check link					•								•	
Door lock cylinders - lubricate									•					•
Seat adjuster slides - lubricate									•					•

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - ON HIGHWAY (On Highway: 60,000 Miles or more Annually) - Miles, Kilometers or Months - Whichever Occurs First																						
	Miles (000)	165	180	195	210	225	240	255	270	285	300	Kilometers (000)	264	288	312	336	360	384	408	432	456	480	
	Months	33	36	39	42	45	48	51	54	57	60												
	Non-driving front axle																						
Wheel bearing - oil type - check level	•	•	•	•	•	•	•	•	•	•	•												
Wheel bearing - oil type - change oil		•																					
Wheel bearing - grease type - repack			•																				
Tie rod ends - lubricate	•	•	•	•	•	•	•	•	•	•	•												
Drag link - lubricate	•	•	•	•	•	•	•	•	•	•	•												
King pin and bushing - lubricate	•	•	•	•	•	•	•	•	•	•	•												
Brake system - hydraulic																							
Master cylinder - check fluid level	•	•	•	•	•	•	•	•	•	•	•												
Park brake relay level / linkage - lubricate		•																					
Steering																							
Power steering fluid - check level	•	•	•	•	•	•	•	•	•	•	•												
Power steering fluid - change level																							
Power steering filter - replacement		•																					
Five years or 800,000 km (500,000 miles)																							
Steering gear sheppard - input bearing - lubricate	•	•	•	•	•	•	•	•	•	•	•												
Steering gear Ross TAS - output seal - lubricate		•																					
Steering column u-joints / slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•												
Propeller shaft SPL																							
U-joint - lubricate	•																						

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - ON HIGHWAY (Continued)											
	(On Highway: 60,000 Miles or more Annually) - Miles, Kilometers or Months - Whichever Occurs First											
	Miles (000)	165	180	195	210	225	240	255	270	285	300	
	Kilometers (000)	264	288	312	336	360	384	408	432	456	480	
	Months	33	36	39	42	45	48	51	54	57	60	
Propeller shaft non-SPL												
U-joint and slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	
Brake system - air												
Slack adjusters - lubricate		•				•					•	
S-cam - lubricate	•	•	•	•	•	•	•	•	•	•	•	
Clutch												
Release bearing / shafts / fork - lubricate	•	•	•	•	•	•	•	•	•	•	•	
Cooling system												
Coolant - check level	•	•	•	•	•	•	•	•	•	•	•	
Coolant - check freeze protection	•	•	•	•	•	•	•	•	•	•	•	
Extended life coolant - add extender											See engine manufacturer's recommendation	
Extended life coolant - replace											See engine manufacturer's recommendation	
Engine - Refer to engine manual for Caterpillar and Cummins. 6.0L Powerstroke - see 6.0L Engine section at end of chart												
Transmission												
Automatic transmission and Auto-shift transmissions											Refer to transmission operator's manual	
Manual transmission - check fluid level	•	•	•	•	•	•	•	•	•	•	•	
Eaton Fuller manual transmission - petroleum oil change											•	
Eaton Fuller manual transmission - synthetic oil change											Factory fill w/synthetic at 800,000 km (500,000 miles); Converted to synthetic at 400,000 km (250,000 miles)	

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - ON HIGHWAY (Continued)												
	(On Highway: 60,000 Miles or more Annually) - Miles, Kilometers or Months - Whichever Occurs First												
	Miles (000)	165	180	195	210	225	240	255	270	285	300		
	Kilometers (000)	264	288	312	336	360	384	408	432	456	480		
Months	33	36	39	42	45	48	51	54	57	60			
Rear axle													
Fluid level - check	•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton / Dana / Spicer petroleum oil - change													
Eaton / Dana / Spicer synthetic oil - change													
	Factory fill w/synthetic at 800,000 km (500,000 miles); Converted to synthetic at 400,000 km (250,000 miles) or three years												
Cab components													
Door hinges / Latches / Strikers - lubricate, check link		•							•				•
Door lock cylinders - lubricate			•							•			•
Seat adjuster slides - lubricate											•		•

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - CITY																						
	City - 59,000 Miles or Less Annually - Miles, Kilometers or Months - Whichever Occurs First																						
	Miles (000)	10	20	30	40	50	60	70	80	90	100	Kilometers (000)	16	32	48	64	80	96	112	128	144	160	
	Months	3	6	9	12	15	18	21	24	27	30	Months	3	6	9	12	15	18	21	24	27	30	
Non-driving front axle																							
Wheel bearing - oil type - check level	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Wheel bearing - oil type - change oil				•																			
Wheel bearing - grease type - repack				•																			
Tie rod ends - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Drag link - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
King pin and bushing - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Brake system - hydraulic																							
Master cylinder - check fluid level	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Park brake relay lever / linkage - lubricate				•																			
Steering																							
Power steering fluid - check level	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Power steering fluid - change fluid					•																		
Power steering filter - replacement					•																		
Five years or 80,000 km (50,000 miles)																							
Steering gear sheppard - input bearing - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Steering gear Ross TAS - output seal - lubricate				•																			
Steering column u-joints / slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Propeller shaft SPL																							
U-joint - lubricate	•																						

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - CITY (Continued)												
	City - 59,000 Miles or Less Annually - Miles, Kilometers or Months - Whichever Occurs First												
	Miles (000)	10	20	30	40	50	60	70	80	90	100		
	Kilometers (000)	16	32	48	64	80	96	112	128	144	160		
Months	3	6	9	12	15	18	21	24	27	30			
Propeller shaft non-SPL													
U-joint and slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Brake system - air													
Slack adjusters - lubricate				•								•	
S-cam - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Clutch													
Release bearing / shafts / fork - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Cooling system													
Coolant - check level	•	•	•	•	•	•	•	•	•	•	•	•	•
Coolant - check freeze protection	•	•	•	•	•	•	•	•	•	•	•	•	•
Extended life coolant - add extender													See engine manufacturer's recommendation
Extended life coolant - replace													See engine manufacturer's recommendation
Engine - refer to engine manual for Caterpillar and Cummins. 6.0L Powerstroke, see 6.0L engine section at end of charts													
Transmission													
Automatic and Auto-shift transmissions													Refer to transmission operator's manual
Manual transmission - check fluid level	•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton Fuller manual transmission - petroleum oil change						•							•

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - CITY (Continued)												
	City - 59,000 Miles or Less Annually - Miles, Kilometers or Months - Whichever Occurs First												
	Miles (000)	10	20	30	40	50	60	70	80	90	100		
	Kilometers (000)	16	32	48	64	80	96	112	128	144	160		
Months	3	6	9	12	15	18	21	24	27	30			
Rear axle													
Fluid level - check	•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton / Dana / Spicer petroleum oil - change						•							•
Cab components													
Door hinges / latches / strikers - lubricate, check link			•						•				•
Door lock cylinders - lubricate			•						•				•
Seat adjuster slides - lubricate			•						•				•

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - CITY																						
	City - 59,000 Miles or Less Annually - Miles, Kilometers or Months - Whichever Occurs First																						
	Miles (000)	110	120	130	140	150	160	170	180	190	200	Kilometers (000)	176	192	208	224	240	256	272	288	304	320	
	Months	33	36	39	42	45	48	51	54	57	60	Months	33	36	39	42	45	48	51	54	57	60	
Non-driving front axle																							
Wheel bearing - oil type - check level	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Wheel bearing - oil type - change oil		•																					
Wheel bearing - grease type - repack		•																					
Tie rode ends - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Drag link - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
King pin and bushing - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Brake system - hydraulic																							
Master cylinder - check fluid level	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Park brake relay lever / linkage - lubricate		•																					
Steering																							
Power steering fluid - check level	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Power steering fluid - change fluid		•																					
Power steering filter - replacement		•																					
Five years or 80,000 km (50,000 miles)																							
Steering gear sheppard - input bearing - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Steering gear Ross TAS - output seal - lubricate		•																					
Steering column u-joints / slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Propeller shaft SPL																							
U-joint - lubricate	•																						

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - CITY (Continued)												
	City - 59,000 Miles or Less Annually - Miles, Kilometers or Months - Whichever Occurs First												
	Miles (000)	110	120	130	140	150	160	170	180	190	200		
	Kilometers (000)	176	192	208	224	240	256	272	288	304	320		
Months	33	36	39	42	45	48	51	54	57	60			
Propeller shaft non-SPL													
U-joint and slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Brake system - air													
Slack adjusters - lubricate		•					•						•
S-cam - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Clutch													
Release bearing / shafts / fork - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Cooling system													
Coolant - check level	•	•	•	•	•	•	•	•	•	•	•	•	•
Coolant - check freeze protection	•	•	•	•	•	•	•	•	•	•	•	•	•
Extended life coolant - add extender													
Extended life coolant - replace													
See engine manufacturer's recommendation													
See engine manufacturer's recommendation													
Engine - refer to engine manual for Caterpillar and Cummins. 6.0L Powerstroke, see 6.0L engine section at end of charts													
Transmission													
Automatic and Auto-shift transmission													
Manual transmission - check fluid level	•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton Fuller manual transmission - petroleum oil change													
Eaton Fuller manual transmission - synthetic oil change		•											

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - CITY (Continued)														
	City - 59,000 Miles or Less Annually - Miles, Kilometers or Months - Whichever Occurs First														
	Miles (000)	110	120	130	140	150	160	170	180	190	200				
	Kilometers (000)	176	192	208	224	240	256	272	288	304	320				
Months	33	36	39	42	45	48	51	54	57	60					
Rear axle															
Fluid level - check	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton / Dana / Spicer petroleum oil - change					•										•
Eaton / Dana / Spicer synthetic oil - change		•													
Cab components															
Door hinges / latches / strikers - lubricate, check link		•								•					•
Door lock cylinders - lubricate		•								•					•
Seat adjuster slides - lubricate		•								•					•

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - SEVERE SERVICE																																								
	Severe Service - On/Off Road in Dirty Conditions, 20,000 Miles or Less Annually - Miles, Km or Months - Whichever Occurs First																																								
	Miles (000)	5	10	15	20	25	30	35	40	45	50	Kilometers (000)	8	16	24	32	40	48	56	64	72	80	Months	3	6	9	12	15	18	21	24	27	30								
Non-driving front axle																																									
Wheel bearing - oil type - check level	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			
Wheel bearing - oil type - change oil					•																																				
Wheel bearing - grease type - repack					•																																				
Tie rod ends - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
Drag link - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
King pin and bushing - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
Brake system - hydraulic																																									
Master cylinder - check fluid level	•																																								
Park brake relay lever / linkage - lubricate																																									
Steering																																									
Power steering fluid - check fluid level	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Power steering fluid - change fluid																																									
Steering gear sheppard - input bearing - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Steering gear Ross TAS - output seal - lubricate																																									
Steering column u-joints / slip joints - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Propeller shaft - SPL																																									
Slip joint - inspect boot	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
U-joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - SEVERE SERVICE (Continued)												
	Severe Service - On/Off Road in Dirty Conditions, 20,000 Miles or Less Annually - Miles, Km or Months - Whichever Occurs First												
	Miles (000)	5	10	15	20	25	30	35	40	45	50		
	Kilometers (000)	8	16	24	32	40	48	56	64	72	80		
Months	3	6	9	12	15	18	21	24	27	30			
Propeller shaft - non-SPL													
U-joint and slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Brake system - air													
Slack adjusters - lubricate				•								•	
S-cam - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•
Clutch													
Release bearing / shafts / forks	•	•	•	•	•	•	•	•	•	•	•	•	•
Cooling system													
Coolant - check level	•	•	•	•	•	•	•	•	•	•	•	•	•
Coolant - check freeze protection	•	•	•	•	•	•	•	•	•	•	•	•	•
Extended life coolant - add extender	See engine manufacturer's recommendation												
Extended life coolant - replace	See engine manufacturer's recommendation												
Engine - refer to engine manual for Caterpillar and Cummins. 6.0L Powerstroke see 6.0L engine section at end of charts													
Transmission													
Automatic and Auto-shift transmissions	Refer to transmission operator's manual												
Manual transmission - check fluid level	•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton Fuller manual transmission - petroleum oil change				•								•	

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - SEVERE SERVICE (Continued)													
	Severe Service - On/Off Road in Dirty Conditions, 20,000 Miles or Less Annually - Miles, Km or Months - Whichever Occurs First													
	Miles (000)	5	10	15	20	25	30	35	40	45	50			
	Kilometers (000)	8	16	24	32	40	48	56	64	72	80			
Months	3	6	9	12	15	18	21	24	27	30				
Rear axle														
Fluid level - check	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Eaton / Dana / Spicer - petroleum oil change				•									•	
Eaton / Dana / Spicer - synthetic oil change					•									•
Cab components														
Door hinges / latches / strikers - lubricate, check link									•					•
Door lock cylinders - lubricate									•					•
Seat adjuster slides - lubricate									•					•

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - SEVERE SERVICE													
	Severe Service - On/Off Road in Dirty Conditions, 20,000 Miles or Less Annually - Miles, Km or Months - Whichever Occurs First													
	Miles (000)	55	60	65	70	75	80	85	90	95	100			
	Kilometers (000)	88	96	104	112	120	128	136	144	152	160			
Months	33	36	39	42	45	48	51	54	57	60				
Non-driving front axle														
Wheel bearing - oil type - check level	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Wheel bearing - oil type - change oil	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Wheel bearing - grease type - repack	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Tie rod ends - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Drag link - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•
King pin and bushing - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Brake system - hydraulic														
Master cylinder - check fluid level	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Park brake relay lever / linkage - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Steering														
Power steering fluid - check level	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Power steering fluid - change fluid	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Power steering filter - replacement	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Steering gear sheppard - input bearing - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Steering gear Ross TAS - output seal - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Steering column u-joints / slip joint - lubricate	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Propeller shaft- SPL														
Slip joint - inspect boot	•	•	•	•	•	•	•	•	•	•	•	•	•	•

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - SEVERE SERVICE (Continued)										
	Severe Service - On/Off Road in Dirty Conditions, 20,000 Miles or Less Annually - Miles, Km or Months - Whichever Occurs First										
	Miles (000)	55	60	65	70	75	80	85	90	95	100
	Kilometers (000)	88	96	104	112	120	128	136	144	152	160
	Months	33	36	39	42	45	48	51	54	57	60
U-joint - lubricate		•	•	•	•	•	•	•	•	•	•
Propeller shaft non-SPL											
U-joint and slip joint - lubricate		•	•	•	•	•	•	•	•	•	•
Brake system - air											
Slack adjusters - lubricate			•				•				•
S-cam - lubricate		•	•	•	•	•	•	•	•	•	•
Clutch											
Release bearing / shafts / fork - lubricate		•	•	•	•	•	•	•	•	•	•
Cooling system											
Coolant - check level		•	•	•	•	•	•	•	•	•	•
Coolant - check freeze protection		•	•	•	•	•	•	•	•	•	•
Extended life coolant - add extender		See engine manufacturer's recommendation									
Extended life coolant - replace		See engine manufacturer's recommendation									
Engine - refer to engine manual for Caterpillar and Cummins. 6.0L Powerstroke see 6.0L engine section at end of charts											
Transmission											
Automatic and Auto-shift transmissions		Refer to transmission operator's manual									
Manual transmission - check fluid level		•	•	•	•	•	•	•	•	•	•
Eaton Fuller manual transmission - petroleum oil change			•				•				•

General maintenance information

Component	LUBRICATION MAINTENANCE LEVEL CHART - SEVERE SERVICE (Continued)											
	Severe Service - On/Off Road in Dirty Conditions, 20,000 Miles or Less Annually - Miles, Km or Months - Whichever Occurs First											
	Miles (000)	55	60	65	70	75	80	85	90	95	100	
		88	96	104	112	120	128	136	144	152	160	
		33	36	39	42	45	48	51	54	57	60	
Eaton Fuller manual transmission - synthetic oil change		•					•					
Rear axle												
Fluid level - check	•	•	•	•	•	•	•	•	•	•	•	•
Eaton / Dana / Spicer petroleum oil - change		•					•					•
Eaton / Dana / Spicer synthetic oil - change		•					•					
Cab components												
Door hinges / latches / strikers - lubricate, check link		•					•					•
Door lock cylinders - lubricate		•					•					•
Seat adjuster slides - lubricate		•					•					•
Daily inspections												
Check oil level												•
Check coolant level ¹												•
Drain water separator for fuel system												•
Inspect for external leakage all systems												•
Inspect air restriction indicator ³												•

General maintenance information

6.0 Powerstroke Engine														
Component	Miles (000)		10	20	30	40	50	60	70	80	90	100	110	120
	Hours		350	700	1050	1400	1750	2100	2450	2800	3150	3500	3850	4200
	Kilometers (000)		16	32	48	64	80	96	112	128	144	160	176	192
	Months		6	12	18	24	30	36	42	48	54	60	66	72
Change engine oil and filter ²			•	•	•	•	•	•	•	•	•	•	•	•
Inspect belt			•	•	•	•	•	•	•	•	•	•	•	•
Clean fuel filter pre-strainer ¹			•	•	•	•	•	•	•	•	•	•	•	•
Change fuel filter ^{1,5}				•			•			•		•		•
Measure air intake restriction ^{3,4}				•			•			•		•		•
Service the cooling system												•		
Inspect electrical system (A) (Every 12 months, 160,000 km [100,000 miles] or 3,800 hours)				•				•				• (A)		•
Pressurize air induction system (every 12 months)				•				•				•		•

General maintenance information

6.0 Powerstroke Engine												
Component	130	140	150	160	170	180	190	200	210	220	230	250
	Miles (000)											
	4550	4900	5250	5600	5950	6300	6650	7000	7350	7700	8050	8400
	Hours											
Component	208	224	240	256	272	288	304	320	336	352	368	384
	Kilometers (000)											
Component	78	84	90	96	102	108	114	120	126	132	138	144
	Months											
Change engine oil and filter ²	•	•	•	•	•	•	•	•	•	•	•	•
Inspect belt	•	•	•	•	•	•	•	•	•	•	•	•
Clean fuel filter pre-strainer ¹	•	•	•	•	•	•	•	•	•	•	•	•
Change fuel filter ^{1,5}												
Measure air intake restriction ^{3,4}	•	•	•	•	•	•	•	•	•	•	•	•
Service the cooling system			•									
Inspect electrical system (A) (Every 12 months, 160,000 km [100,000 miles] or 3,800 hours)		•		•		•		•		• (A)		•
Pressurize air induction system (every 12 months)		•		•		•		•		•		•

¹If refueling source is prone to water contamination, also clean the fuel filter pre-strainer.

²If fuel is more than 0.5% but less than 1.0% sulfur, change oil at 75% of regular interval. If 1.0% or higher, change oil at 50% of scheduled interval.

³Service air cleaner element as required.

⁴Refer to PCED manual for specification.

⁵Change according to transfer pump minimum specifications.

General maintenance information

Maintenance Record

Maintenance Intervals/ Service Performed	Date Service Performed	Mileage	Service Shop Name and Address

General maintenance information

Maintenance Intervals/ Service Performed	Date Service Performed	Mileage	Service Shop Name and Address

General maintenance information

Maintenance Record

Maintenance Intervals/ Service Performed	Date Service Performed	Mileage	Service Shop Name and Address

General maintenance information

Maintenance Intervals/ Service Performed	Date Service Performed	Mileage	Service Shop Name and Address

Index

- A**
- Air cleaner filter188
 - Air conditioning30
 - manual heating and air conditioning system30
 - Air suspension114
 - Anti-lock brake system (see Brakes)112
 - Audio system (see Radio)32, 34, 37, 41
 - Automatic transmission117
 - fluid, adding186
 - fluid, checking186
 - fluid, refill capacities225
 - fluid, specification212
 - Auxiliary power point54
 - Axle131, 165, 204
 - lubricant specifications212
 - refill capacities223
- B**
- Battery180
 - charging system warning light20
 - jumping a disabled battery143
 - voltage gauge25
 - BeltMinder76
 - Brakes95–96, 99, 165
 - adjustment168
 - anti-lock112–113
 - anti-lock brake system (ABS) warning light20, 112
 - brake warning light20
 - fluid, checking and adding168, 180
 - fluid, specifications212
 - parking97–98, 102, 169
- C**
- Bulbs49
 - Cassette tape player41
 - Catalytic converter (see Emission control)188
 - CD-single premium32, 34, 37
 - Cell phone use54
 - Child safety restraints80
 - child safety belts80
 - Child safety seats83
 - attaching with tether straps87
 - in front seat85
 - in rear seat85
 - tether anchorage hardware87
 - Child safety seats - booster seats81
 - Cleaning your vehicle
 - chrome and aluminum parts160
 - engine compartment160
 - exterior162
 - instrument panel161
 - interior161
 - interior trim161
 - plastic parts160
 - washing159
 - waxing159
 - wheels160
 - Climate control (see Air conditioning or Heating)29–30
 - Clutch122, 184
 - adjusting185
 - fluid184
 - operation while driving122
 - specifications212
 - Controls
 - power seat69

Index

- Coolant175
 checking and adding175
 refill capacities224
 specifications212
 temperature gauge25
- Cruise control
(see Speed control)58
- Customer Assistance136, 150
 Getting assistance outside the
 U.S. and Canada150, 156
 Getting roadside assistance ...136
 Getting the service you
 need150
 Ordering additional owner's
 literature157
 The Dispute Settlement
 Board152
 Utilizing the
 Mediation/Arbitration
 Program155
- D**
- Daytime running lamps
(see Lamps)47
- Defects, reporting158
- Defrost29–30
 windshield29–30
 with heating and air
 conditioning system30
 with standard heating
 system29
- Doors
 lubricant specifications212
- Driving under special
conditions
 through water93
- E**
- Emergencies, roadside
 jump-starting143
- Emission control system ..199, 230
 catalytic converter188
- Engine
 cleaning160
 lubrication specifications212
- Engine fan179
- Engine oil171
 checking and adding171
 oil pressure gauge25
 recommendations172
 refill capacities224
 specifications212
- F**
- Flashers, hazard137
- Fuel190
 calculating fuel economy197
 capacity226
 choosing the right fuel191
 filling your vehicle with fuel ..190
 filter, specifications193, 195
 gauge25
 improving fuel economy197
 running out of fuel89, 192
 safety information relating to
 automotive fuels190
- Fuses137

Index

- G**
- Gas mileage
(see Fuel economy)197
 - Gauges25
 - battery voltage gauge25
 - engine coolant temperature gauge25
 - engine oil pressure gauge25
 - fuel gauge25
 - odometer25
 - speedometer25
 - tachometer25
 - trip odometer25
- H**
- Hazard flashers137
 - Headlamps47
 - aiming48
 - daytime running lights47
 - flash to pass47
 - high beam47
 - warning chime20
 - Heating29–30
 - heater only system29
 - manual heating and air conditioning system30
 - Hood170
- I**
- Ignition
 - chime20
 - removing the key127, 130
 - Infant seats (see Safety seats) ..83
 - Instrument panel
 - cleaning161
 - lighting up panel and interior48
- J**
- Jump-starting your vehicle143
- K**
- Keys
 - key in ignition chime20
 - removing from the ignition127, 130
- L**
- Lamps
 - bulb replacement
 - specifications chart49
 - cargo lamps48
 - daytime running light47
 - headlamps47
 - headlamps, flash to pass47
 - high beams47
 - instrument panel, dimming48
 - interior lamps49
 - replacing bulbs49–51
 - Lane change indicator
(see Turn signal)48
 - Lights, warning and indicator20
 - air suspension20
 - anti-lock brakes (ABS)20, 112
 - brake20
 - charging system20
 - safety belt20
 - service engine soon20
 - traction control off20
 - turn signal indicator20
 - Lubricant specifications212

Index

M

Maintenance and Care	233
Manual transmission	123
lubricant specifications	212
Mirrors	56
fold away	57
heated	57
side view mirrors (power)	56

O

Odometer	25
----------------	----

P

Paint chips, repairing	159
Panic alarm feature, remote entry system	63
Parking brake	97–98, 102
warning light	20
Power door locks	62
Power mirrors	56
Power point	54
Power steering	183
fluid, checking and adding	183
fluid, refill capacity	224
fluid, specifications	212
Power Windows	55

R

Radio	32, 34, 37, 41
Relays	141
Remote entry system	62–63
illuminated entry	65
locking/unlocking doors	62–63

panic alarm	63
replacement/additional transmitters	64
replacing the batteries	64
Roadside assistance	136

S

Safety belts (see Safety restraints)	71–73
Safety defects, reporting	158
Safety restraints	71–73
belt minder	76
cleaning the safety belts	79
extension assembly	79
for adults	72–73
for children	80
lap belt	74
warning light and chime	20, 75
Safety seats for children	83
Seat belts (see Safety restraints)	71
Seats	66
child safety seats	83
heated	70
Servicing your vehicle	233
Special notice	5
Specification chart, lubricants	212
Speed control	58
Speedometer	25
Starting your vehicle	88
jump starting	143
preparing to start your vehicle	88
Steering	183

Index

- Steering wheel
controls53, 58
tilting53
Suspension114, 201
- T**
- Tachometer25
Temperature control
(see Climate control)29–30
Tires
checking the pressure210
Towing
wrecker146
Traction control
off light20
Transmission117, 123
automatic operation117
fluid, checking and adding
(automatic)186
fluid, checking and adding
(manual)186
fluid, refill capacities225
lubricant specifications212
manual operation123
Turn signal48
- V**
- Vehicle loading94–95
Voltmeter (see Battery voltage
gauge)25
- W**
- Warning chimes20
Warning lights (see Lights)20
Warranty coverage5
Washer fluid179
Washing your vehicle159
Water, Driving through93
Waxing your vehicle159
Wheels205
Windows
power55
Windshield
defrosting29–30
Windshield washer fluid and
wipers52
checking and cleaning52
operation52
replacing wiper blades53
Wrecker towing146

