

ESSENTIAL INFORMATION

FUEL TYPE AND TANK CAPACITY – Your fuel tank capacity is 15 gallons (56.8L). Your vehicle is designed to use “Regular” unleaded gasoline with an octane rating of 87. Do not use gasoline labeled as “Regular” in high altitude areas that are sold with octane ratings less than 87. Do not use E85 fuels because your vehicle was not designed to run on fuels with more than 10% ethanol.

TIRE PRESSURE – Your tire pressure is properly set at the dealership according to the recommended specifications found on the Safety Compliance Certification Label or Tire Label located on the B-Pillar or the edge of the driver’s door. Check your tire pressure at least once a month and before long trips (including spare). As an added safety feature, your vehicle has been equipped with a **Tire Pressure Monitoring System (TPMS)** that illuminates a low tire pressure warning light  when one or more of your tires is significantly under-inflated. Improperly inflated tires can affect vehicle handling and can fail suddenly, possibly resulting in loss of vehicle control. Refer to the Tires, Wheels and Loading chapter in your Owner’s Guide for more information.

UNIQUE SERVICE INTERVALS – Please check your Owner’s Guide for proper service intervals. Special caution is required when servicing brake pads. Please refer to the Scheduled Maintenance Guide chapter in your Owner’s Guide for information on servicing brake pads.

FUEL PUMP/HIGH VOLTAGE SHUT-OFF SWITCHES – The fuel pump shut-off switch is located in the front passenger’s footwell, behind a flip-up cover. The high voltage shut-off switch is located on the passenger side of the rear cargo area, in the jack compartment behind the jack access door. These switches provide added protection by discontinuing fuel to the engine and by shutting off power to the high voltage battery in case of an accident. For more information, please see your Owner’s Guide.

SOS POST-CRASH ALERT SYSTEM™ – Your vehicle is equipped with the SOS Post-Crash Alert System™. This system provides audible and visual alarms in the event of a crash which causes the deployment of airbags or the activation of the safety belt pretensioners. The turn signals will flash and the horn will sound. To deactivate the system, press the hazard flasher control , or you can press  on your remote transmitter.

LOCATION OF SPARE TIRE – Your vehicle is equipped with a temporary spare tire located under the vehicle, just forward of the rear bumper. The temporary spare tire is designed for emergency use only and should be replaced as soon as possible. The jack and tools are located in the right rear cargo area, behind an access panel. For complete details on how to change your tire, refer to the Roadside Emergencies chapter in your Owner’s Guide.

EASY FUEL™ ‘NO CAP’ FUEL SYSTEM – Your vehicle has a ‘no cap’ fuel system which allows you to simply open the fuel filler door, insert the nozzle and start fueling. Wait about five seconds before pulling out the nozzle in order to allow any residual fuel to drain into the tank. The Easy Fuel™ system is self-sealing and therefore protected against dust, dirt, water, snow and ice. If you need to fill your fuel tank with a portable fuel container, use the fuel funnel which is located inside the rear passenger side cargo compartment access door. Slowly insert the funnel into the Easy Fuel™ system and fill the tank with fuel from the container. When done, clean the funnel or properly dispose of it. Extra funnels can be purchased from your authorized dealer. **Do not** use aftermarket funnels as they will not work with the Easy Fuel™ system and may cause damage.

ROADSIDE ASSISTANCE – Your new Ford Escape Hybrid comes with the assurance and support of 24-hour emergency roadside assistance. Roadside assistance includes such services as: lockout assistance, limited fuel delivery, battery jump starts, changing a flat tire, towing, and winch out. To receive roadside assistance in the United States, call 1 (800) 241-3673. In Canada, call 1 (800) 665-2006.

Ford Motor Company
Customer Relationship Center
P.O. Box 6248
Dearborn, MI 48121
1-800-392-3673 (FORD)
(TDD for the hearing impaired:
1-800-232-5952)

May 2009
First Printing
Quick Reference Guide

AM6J 19G217 AA



This Quick Reference Guide is not intended to replace your vehicle Owner’s Guide which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner’s Guide carefully as you begin learning about your new vehicle and refer to the appropriate sections when questions arise.

All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Ford dealer is the best source for the most current information.

For detailed operating and safety information, please consult your Owner’s Guide.



DUAL AUTOMATIC TEMPERATURE CONTROL

A. AUTO/DRIVER TEMPERATURE – Press the control to activate/deactivate full automatic operation. The system will automatically determine fan speed, airflow distribution, A/C on or off and either outside or recirculated air to heat or cool the vehicle to reach the desired temperature. Turn the control to increase/decrease the temperature on the driver side of the vehicle. **Note:** This control will also determine the temperature for the entire vehicle cabin when the passenger temperature control (PASS TEMP) is not engaged.

B. REAR DEFROSTER – Press to activate the rear window defroster and clear the rear window of thin ice and fog. Press again to deactivate. The rear window defroster will turn off automatically after a predetermined amount of time, if a low battery condition is detected, or when the ignition is turned off or to the accessory position.

C. DEFROST  – Distributes outside air through the windshield defroster vents and demister vents. It can be used to clear the windshield of fog and thin ice.

D. HEATED SEATS  – Press to activate or deactivate the driver or passenger heated seat.

E. FLOOR AND DEFROST  – Distributes air through the windshield defroster vents, demister vents, floor vents and rear seat floor vents.

F. POWER : : AND FAN  – Press to turn the system on/off. Press +  or –  to manually increase/decrease the fan speed.

G. A/C – Press to activate/deactivate air conditioning. Use with recirculated air  to improve cooling performance and efficiency.

H. MAX A/C – Activates air conditioning and distributes recirculated, conditioned air through the instrument panel vents to provide maximum cooling performance.

I. RECIRCULATED AIR  – Press to activate/deactivate air circulation inside the vehicle cabin. Recirculated air may reduce the amount of time needed to cool down the vehicle and may also help reduce undesirable odors from entering the vehicle. Recirculated air engages automatically when MAX A/C is selected.

J. PASS TEMP – Press to activate passenger side temperature control. Turn the control to decrease/increase the temperature setting for the passenger side of the vehicle. Press again to deactivate (the driver side settings will then determine the temperature for the entire vehicle cabin).



A. RADIO – Press to access the Radio menu and select from AM, FM1, FM2, SAT1, SAT2 or SAT3 (satellite radio, if activated) modes.

B. MEDIA – Press to access the Media menu and select from CD, DVD or Jukebox features among others. Jukebox allows you to save your favorite music to the system’s hard drive for later access. You can then choose to play specific artists, genres, tracks or albums. You can even choose to create your own playlists.

C. SOUND – Press to access the Sound menu and make adjustments to Bass, Treble, Balance, Fade, SCV (Speed compensated volume), DSP and the visualizer.

D. MENU – Press to access menu selections of Display options, Setting the clock, Feedback settings, System settings and Valet mode.

E. PHONE – Press to activate the Phone menu (if equipped with SYNC®). Refer to the SYNC® section in the Navigation supplement for more information.

F. I (INFORMATION) – Press to access the Information menu and select from options such as ‘Where am I’, the system Calendar, the Help menu as well as hybrid screens and SIRIUS® Travel Link™ (if activated).

G. DEST – Press to access the Destination menu and to set a destination. In this menu you can select from: Quick Destinations (Emergency listings such as Police and Hospitals or previously set favorite destinations), Standard destinations or Edit Route.

H. MAP – Press to view the navigation map.

VOICE RECOGNITION – Your system is equipped with an advanced voice recognition system which allows you to speak certain commands to the system. Press  on your steering wheel and say a command or ‘Help’ after the prompt.

HYBRID VEHICLE SCREENS – Press the  hard button and then press the HEV tab on the touchscreen to select from the Energy Flow screen, Fuel Economy screen and also the Power and Efficiency screen. The Energy Flow screen displays a graphical representation of how power is transferred in the hybrid system. The Fuel Economy screen displays average fuel economy while the Power and Efficiency screen displays braking efficiency, vehicle power, accessory power (such as air conditioning), engine on reasons and also driving efficiency information.

Refer to your navigation supplement for more information.



IN-DASH CD/MP3 RADIO

A. ON/OFF/VOL – Press to turn on or off. Turn to increase or decrease the volume.

B. DIRECT – Press DIRECT and then, using the memory presets (0-9), enter in the numbers of the desired station, track, MP3 folder (if available) or satellite channel (if activated).

C.  – Press to access special phone features if equipped with SYNC®. Refer to your SYNC® supplement for more information.

D. SCAN – Press for a brief sampling of radio stations or CD/MP3 tracks. Press again to stop.

E. AM/FM – Press repeatedly to select AM, FM1 or FM2 frequency band.

F. CD – Press to enter CD/MP3 mode. If a disc is already loaded into the system, CD/MP3 play will begin where it ended last.

G. SEEK/TRACK – Press to access the previous/next strong radio station, satellite channel (if equipped) or CD track.

H. AUX – Press repeatedly to access LINE IN (auxiliary audio mode) or SYNC® (if equipped).

I. SIRIUS – Press repeatedly to cycle through SAT1, SAT2 and SAT3 modes. SIRIUS® Satellite Radio is a subscription-based satellite radio service that broadcasts music, sports, news and entertainment programming. For more information and a complete list of SIRIUS® satellite radio channels, visit www.sirius.com in the United States, www.sirius-canada.ca in Canada, or call SIRIUS® at 1-888-539-7474.

J. MENU – Press repeatedly to cycle through various menu options including SATELLITE RADIO MENU (if satellite radio is active). When SATELLITE RADIO MENU appears in the display, press OK and then press  to access more options.

K. SOUND – Press repeatedly to access settings for: Bass, Treble, Fade, Balance, Speed compensated volume (if equipped) and ALL SEATS (Occupancy mode, if equipped). When the desired selection appears in the display, press  SEEK/TRACK  to make adjustments.

L. CLOCK – Press to set the time. The display will read SET TIME. Use the memory presets (0-9) to enter in the desired time, hours and minutes. The clock will then start from that time.

M. EJECT – Press to eject a CD from the system.

ADDITIONAL FEATURES

MOON ROOF – (if equipped) The moon roof is equipped with an automatic, one-touch, opening, closing and venting feature. To open, press and release the rear portion of the control located in the overhead console. To stop motion at any time during the one-touch opening, press the control a second time. To close, press and release the front portion of the control until the glass stops moving. To open the moon roof to the vent position, press the front portion of the control. To close, press and hold the rear portion of the control until the glass stops moving.

INTEGRATED KEYHEAD TRANSMITTER (IKT) REMOTE ENTRY SYSTEM –

- Press  once to lock all doors. Press again to confirm all doors and liftgate are closed and locked.
- Press  once to unlock the driver’s door. Press again within five seconds to unlock all doors.
- Press  to activate the panic alarm. Press again or turn the ignition on to deactivate.
- Press  twice within three seconds to open the liftgate glass.
- Car finder: Press  twice within three seconds to locate your vehicle. The horn will chirp and the turn lamps will flash.

SYNC® – (if equipped) SYNC® is a hands-free communications and entertainment system with special phone and media features. For more information, please refer to the SYNC® supplement or to the SYNC® section in the Navigation supplement. Please also feel free to visit www.SyncMyRide.com.



ADVANCETRAC® WITH ROLL STABILITY CONTROL™ (RSC®) STABILITY ENHANCEMENT SYSTEM – Your vehicle equipped with the AdvanceTrac® stability enhancement system helps you to maintain stability and steerability of your vehicle during a variety of road conditions. If your vehicle becomes stuck in the snow, mud or sand, try turning off the AdvanceTrac® system to allow wheel spin and help increase momentum to dig the vehicle out. The system defaults to on and the control will illuminate when turned off. Refer to your Owner’s Guide for safety information and more details.

MyKey™ – Allows you to program certain driving restrictions on any standard key in order to promote good driving habits. When MyKey™ is programmed:

- Belt-Minder® cannot be disabled and will sound continuously and the audio will be muted until the safety belt is buckled.
- Audible and visual low fuel warnings are provided.
- Certain features cannot be turned off such as the reverse sensing system.
- Audio volume can be limited.
- Vehicle speed can be limited.
- Audible and visual speed warnings can be configured at preselected speeds.
- AdvanceTrac® can be programmed so that it cannot be turned off.

For complete information, refer to MyKey™ in the Locks and Security chapter in your Owner’s Guide.

INTEGRATED BLIND SPOT MIRRORS – Blind spot mirrors have an integrated convex mirror in the upper corner on the outside mirrors. These mirrors help increase visibility alongside the vehicle; thereby helping you to see a vehicle which may be in your blind spot. As a vehicle approaches, the image will transition from the main mirror to the blind spot mirror. Refer to your Owner’s Guide for more information.

REARVIEW CAMERA – (if equipped) This system provides a visual display of the area behind the vehicle. The display automatically appears in the rear view mirror or navigation screen (if equipped) when the vehicle is in Reverse (R) and uses colors (green, yellow and red) to alert you of your proximity to objects. **Note:** Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your Owner’s Guide for safety information, more detail and limitations.



 **2010 ESCAPE HYBRID**
QUICK REFERENCE GUIDE



HYBRID OPERATION The Ford Escape Hybrid is a whole new kind of SUV that combines electric and gasoline propulsion without compromise, to provide breakthrough performance and efficiency. It requires no special fuels and never has to be plugged in. Familiarizing yourself with these unique characteristics will help ensure optimal performance from your new vehicle.

NORMAL VEHICLE OPERATION

Starting – Turn the ignition key to the start position while your vehicle is in P (Park). The green ‘Ready Indicator’ light  will appear in the instrument cluster, letting you know that the vehicle is ready for driving. The engine may not start because this hybrid vehicle is equipped with Silent Key Start. This fuel saving feature allows your vehicle to be ready to drive without requiring the gas engine to be running. This indicator will remain on while the vehicle is on, whether the engine is running or not, to indicate the vehicle is capable of movement (using its electric motor, engine or both). “Ready to Drive” will also appear momentarily in the message center. **Note:** You may notice higher engine speeds upon start-up. This temporary condition is normal and necessary to warm up the engine and minimize emissions.

Driving – The gas engine automatically starts and stops to provide power when it’s needed and to save fuel when it’s not. While coasting at low speeds, coming to a stop or standing, the gas engine normally shuts down and the vehicle operates in electric-only mode. Conditions that cause the engine to start up or remain running include:

- Considerable vehicle acceleration.
- Vehicle speed of approximately 44 mph (71 km/h) or above.
- Ascending a hill.
- Charge level of high voltage battery is low.
- Very high or low outside temperature (to provide system cooling/heating).

Stopping – The gas engine may shut off as you come to a stop to conserve fuel. Restarting the vehicle is not required. Simply step on the accelerator when you are ready to drive.

Transmission Operation – Due to the technologically advanced, electronically controlled Continuously Variable Transaxle (eCVT) you will not feel shift changes like those of a non-hybrid vehicle. Your hybrid’s transmission is designed to do its work seamlessly. Since engine speed is controlled by the transmission, it may seem elevated at times. This is normal hybrid operation and helps deliver fuel efficiency and performance.

Neutral – It is not recommended to idle in N (Neutral) for extended periods of time because this will discharge your high voltage battery and decrease fuel economy. Because of the unique nature of the hybrid vehicle, the engine will not start in the N (Neutral) position. Also, the engine cannot provide power to the hybrid system in N (Neutral).

Low Gear – L (Low gear) is designed to mimic the enhanced engine braking available in non-hybrid vehicles. Low gear will produce high engine speeds to provide necessary engine braking. This is normal and will not damage your vehicle.

Reverse – R (Reverse gear) vehicle speed is limited to 22 mph (35 km/h).

UNIQUE HYBRID OPERATING CHARACTERISTICS

Battery – Your hybrid has a high voltage battery. A cool battery ensures battery life and provides the best possible performance. Your hybrid high voltage battery may periodically recondition itself to ensure maximum efficiency. You may notice slight changes in drivability during this process, but it’s an important part of your Ford Escape Hybrid’s high voltage battery optimization features. The high voltage battery is cooled by cabin air drawn from vent holes in the driver-side cargo trim panel. Avoid placing objects over the vent holes which would block airflow to the high voltage battery.

Engine – The engine speed in your hybrid is not directly tied to your vehicle speed. Your vehicle’s engine and transmission are designed to deliver the power you need at the most efficient engine speed. **During heavy accelerations, your hybrid may reach high engine speeds (up to 6000 RPM). This is a characteristic of the Atkinson cycle engine technology helping to maximize your hybrid’s fuel economy.** In prolonged mountainous driving, you may also see the engine tachometer changing without your input. This is intentional and maintains the battery charge level. You may also notice during extended downhill driving that your engine continues to run instead of shutting off. During this “engine braking,” the engine stays on, but it’s not using any fuel. You may also hear a slight whine or whistle when operating your vehicle. This is the normal operation of the electric generator in the hybrid system.

Braking – Your hybrid has standard hydraulic braking and regenerative braking. Regenerative braking is performed by your transmission; it captures brake energy and stores it in your high voltage battery.

Driving to Optimize Fuel Economy – Your fuel economy should improve throughout your hybrid’s break-in period. As with any vehicle, fuel economy can be significantly impacted by your driving habits and accessory usage. For best results, keep in mind these tips:

Tire Inflation – Keep tires properly inflated and use only the recommended size.

Driver Habits – Aggressive driving increases the amount of energy required to move your vehicle. In general, better fuel economy is achieved with mild to moderate acceleration and deceleration. Moderate braking is particularly important since it allows you to maximize the energy captured by the regenerative braking system. **Note:** Having your engine running is not always an indication of inefficiency – in some cases it is actually more efficient than driving in electric mode.

Additional Tips –

- Do not carry extra loads.
- Be mindful of adding external accessories that may increase aerodynamic drag.
- Observe posted speed limits.
- Perform all scheduled maintenance.
- There is no need to wait for your engine to “warm up.” The vehicle is ready to drive immediately after starting.



1. HEADLAMP CONTROLS –

- : Turns the headlamps off.
- : Turns on parking lamps.
- : Turns on low beam headlamps.
- : Autolamps (if equipped) Automatically turns the exterior lamps on/off based on available daylight.
- : Turns on fog lamps (if equipped) by pulling the control towards you.

2. MULTI-FUNCTION LEVER – Rotate the end of the control up/down to increase/decrease the speed of the wipers.

- Push the end of the stalk:
- quickly for a single swipe without fluid.
 - and hold briefly for three swipes with washer fluid.
 - and hold for a longer wash cycle.

To operate your rear window wiper, turn the rear wiper control to 1 (intermittent speed), 2 (normal speed) or O (off). For a rear wash cycle, rotate and hold the rear wiper control to either  position.

Note: For optimal wiper performance, clean your blades and glass regularly. Refer to your Owner’s Guide for more information.

3. STEERING WHEEL CONTROLS – To set the speed:

1. Press ON.
2. Accelerate to the desired speed.
3. Press SET + and take your foot off the accelerator.
 - To set a higher speed, press and hold SET + or press SET + repeatedly until the desired speed is reached.
 - To set a lower speed, press and hold SET – or press SET – repeatedly until the desired speed is reached.

- To return to a previously set speed, press RES.
- To turn off, depress the brake pedal or press OFF.

VOL +/- : Press to increase/decrease volume levels.

: Press to access the previous/next radio station, CD track or preset satellite radio channel.

MEDIA: Press repeatedly to access all possible media sources.

 : Press to access voice recognition, if equipped.

: Press to access SYNC® phone features, if equipped.

Use extreme caution when using any device or feature that may take your attention off the road. Your primary responsibility is the safe operation of the vehicle. Only use non-essential features and devices when it is safe to do so.

4. SERVICE ENGINE SOON LIGHT  – Illuminates briefly when ignition is turned on. Solid illumination after start indicates the On-Board Diagnostics System has detected a malfunction. Contact your authorized dealer as soon as possible.

5. MESSAGE CENTER – The message center displays important vehicle information through a constant monitoring of vehicle systems. The system will also notify you of potential vehicle problems with a display of system warnings followed by long indicator chime. Please refer to your Owner’s Guide for more information.

6. HAZARD FLASHER

7. ABS WARNING LIGHT  – The ABS light  illuminates briefly when the ignition is turned on. If the ABS light remains on or continues to flash, a malfunction has been detected. Contact your authorized dealer as soon as possible. Normal braking (less ABS) is still functional unless the brake warning light  is also illuminated.

8. BATTERY GAUGE – The battery gauge provides information about your vehicle’s energy usage. When the pointer is directed at ASSIST, this means the battery is providing extra power to boost the vehicle’s acceleration. When it’s pointing to CHARGE, extra energy is being stored in the battery while idling, coasting or slowing down.

9. STOP SAFELY HAZARD WARNING LIGHT  ! – Indicates a hybrid component failure or fault that will cause the vehicle to shut down or fail to start. For additional information, please see your Owner’s Guide.

10. READY INDICATOR  – Illuminates after the vehicle has successfully started. The vehicle is ready to drive even if you don’t hear the engine running.

11. PASSENGER AIRBAG OFF – The passenger airbag off indicator light will illuminate when the passenger’s front airbag is off. For additional information, refer to your Owner’s Guide for safety information and more details.

12. ACTIVE PARK ASSIST – (if equipped) The Active Park Assist system can detect an available parallel parking space and automatically steer the vehicle into that space. The system instructs the driver with visual and/or audible instructions with regard to braking, accelerating and shifting gears in order to safely park the vehicle. To initiate Active Park Assist, press the AUTO P control and follow the system instructions as prompted by the message center. To stop the parking procedure, grab the steering wheel or press the control again. For complete information, please refer to Active Park Assist in the Driving chapter of your Owner’s Guide.

13. USB PORT – (if equipped) The USB port allows you to plug in media playing devices, memory sticks, and also to charge devices if they support this feature. For more information, please refer to your SYNC® supplement or the SYNC® section in your Navigation supplement (if equipped).

14. POWER POINT 110 VAC – This outlet is used for powering electrical devices that require up to 150W. Exceeding this limit will cause the power point to cut off the power temporarily to provide overload protection. The green indicator light will illuminate when the power point is ready to supply power and will blink when it is in fault mode. You do not need an adapter to plug in an electrical device.

15. AUXILIARY INPUT JACK – The auxiliary input jack provides a way to connect your portable music player to the in-vehicle audio system. This allows the audio from a portable music player to be played through the vehicle speakers. For additional information, please see your Owner’s Guide.

16. POWER AND EFFICIENCY SCREEN – (if equipped) Your navigation system (if equipped) has special hybrid screens which display Energy Flow, Fuel Economy, and Power and Efficiency information. The Power and Efficiency screen provides additional information about brake efficiency, vehicle power, accessory power (such as air conditioning), engine on reasons and driving efficiency information. To access, press the I hard button on your navigation system, select the HEV tab and then press the Power and Efficiency button. For more information, please refer to your navigation supplement.

REVERSE SENSING SYSTEM – The reverse sensing system may warn you if there is an object behind the vehicle. A warning tone will sound which increases in frequency as the object gets closer and then will sound continuously when the object is less than 10 inches away. The system is active when the vehicle is in Reverse (R) and traveling less than 3 mph (5km/h). **Note:** Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your Owner’s Guide for safety information, more detail and limitations.

AMBIENT LIGHTING – (if equipped) Press  repeatedly to turn the feature on, cycle through your color options and turn the feature off. Ambient lighting will illuminate the footwells, cupholders and console bin with a choice of several colors. The control is located on the center console.

SECURICODE™ KEYLESS ENTRY SYSTEM – Allows you to lock or unlock the doors as well as open the liftgate without a key. Ensure that you have your five digit factory code located on your owner’s wallet card in the glove box.

- To unlock the driver’s door, enter your five digit factory code.
- To unlock all doors and the liftgate, enter your five digit factory code and, within five seconds, press 3-4.
- To open the liftgate glass, enter your five digit factory code and, within five seconds, press 5-6.
- To lock all vehicle doors and the liftgate, press 7-8 and 9-0 at the same time (you do not need to enter your factory code first).