

Ford**Mondeo**
Owner's handbook

Feel the difference



The information contained in this publication was correct at the time of going to print. In the interest of development the right is reserved to change specifications, design or equipment at any time without notice and without incurring any obligations. This publication, or part thereof, may not be reproduced nor translated without our approval. Errors and omissions excepted.

© Ford Motor Company 2007

All rights reserved.

Part number: 8S7J-19A321-DA (CG3536en) 06/2007 20070727130405

Table of contents

Introduction

About this handbook.....	7
Symbols glossary.....	7
Parts and accessories.....	7

Quick start

Quick start.....	10
------------------	----

Child safety

Child seats.....	19
Booster cushions.....	20
Child seat positioning.....	22
ISOFIX anchor points.....	25
Child safety locks.....	27

Occupant protection

Principle of operation.....	28
Fastening the seat belts.....	31
Seat belt height adjustment.....	31
Seat belt reminder.....	31
Using seat belts during pregnancy.....	32
Disabling the passenger airbag.....	32

Keys and remote controls

Using the key.....	34
General information on radio frequencies.....	34
Programming the remote control.....	34
Changing the remote control battery.....	34

Locks

Locking and unlocking.....	36
Global opening and closing.....	38
Keyless entry.....	40

Engine immobiliser

Principle of operation.....	44
Coded keys.....	44
Arming the engine immobiliser.....	44
Disarming the engine immobiliser.....	44

Alarm

Principle of operation.....	45
Arming the alarm.....	47
Disarming the alarm.....	47

Steering wheel

Adjusting the steering wheel.....	49
Audio control.....	49

Wipers and washers

Windscreen wipers.....	51
Autowipers.....	51
Windscreen washers.....	52
Rear window wiper and washers.....	52
Headlamp washers.....	53
Checking the wiper blades.....	53
Changing the wiper blades.....	53

Lighting

Lighting control.....	56
Autolamps.....	57
Front fog lamps.....	57

Table of contents

Rear fog lamps.....	57
Headlamp levelling.....	58
Hazard warning flashers.....	59
Adaptive front lighting system (AFS).....	59
Direction indicators.....	61
Interior lamps.....	61
Removing a headlamp.....	62
Changing a bulb.....	63
Bulb specification chart.....	71

Windows and mirrors

Electric windows.....	73
Exterior mirrors.....	75
Electric exterior mirrors.....	76
Interior mirror.....	77
Auto-dimming mirror.....	78

Instruments

Gauges.....	79
Warning lamps and indicators.....	81
Audible warnings and indicators.....	84

Information displays

General information.....	85
Trip computer.....	94
Personalised settings.....	96
Information messages.....	99

Climate control

Principle of operation.....	109
Air vents.....	109
Manual climate control.....	110
Automatic climate control.....	113

Heated windows and mirrors.....	116
Auxiliary heater.....	116
Electric sunroof.....	120

Seats

Sitting in the correct position.....	124
Manual seats.....	124
Electric seats.....	125
Head restraints.....	127
Rear seats.....	127
Heated seats.....	128
Ventilated seats.....	129

Convenience features

Sun blinds.....	130
Instrument lighting dimmer.....	130
Clock.....	130
Cigar lighter.....	130
Ashtray.....	131
Auxiliary power sockets.....	131
Cup holders.....	132
Glove box.....	132
Storage compartments.....	132
Map pockets.....	133
Memory function.....	133
Glasses holder.....	135
Auxiliary input (AUX IN) socket.....	135

Starting the engine

General information.....	136
Ignition switch.....	136
Keyless starting.....	136
Steering wheel lock.....	138
Starting a petrol engine.....	139
Starting a diesel engine.....	140

Table of contents

Diesel particulate filter (DPF).....	140
Switching off the engine.....	141

Fuel and refuelling

Safety precautions.....	142
Fuel quality - Petrol.....	142
Fuel quality - Diesel.....	142
Catalytic converter.....	142
Fuel filler flap.....	143
Refuelling.....	144
Fuel consumption.....	144
Technical specifications.....	144

Transmission

Manual transmission.....	147
Automatic transmission.....	148

Brakes

Principle of operation.....	151
Hints on driving with ABS.....	151
Parking brake.....	152

Stability control

Principle of operation.....	153
Using stability control.....	153

Hill launch assist (HLA)

Principle of operation.....	155
Using HLA.....	155

Active suspension

Principle of operation.....	158
Using active suspension.....	158

Parking aid

Principle of operation.....	159
Using the parking aid.....	159

Cruise control

Principle of operation.....	161
Using cruise control.....	161

Adaptive cruise control (ACC)

Principle of operation.....	163
Using ACC.....	165
Forward alert function.....	168

Load carrying

General information.....	170
Luggage anchor points.....	170
Sliding loadspace floor.....	170
Rear under floor storage.....	172
Cargo nets.....	173
Luggage covers.....	174
Roof racks and load carriers.....	174
Dog guard.....	174
Load retaining fixtures.....	176

Towing

Towing a trailer.....	179
Detachable tow ball.....	179

Driving hints

Running-in.....	183
-----------------	-----

Emergency equipment

First aid kit.....	184
--------------------	-----

Table of contents

Warning triangle.....	184
-----------------------	-----

Status after a collision

Inspecting safety system components.....	186
--	-----

Fuses

Fuse box locations.....	187
Changing a fuse.....	189
Fuse specification chart.....	190

Vehicle recovery

Towing points.....	200
Towing the vehicle on four wheels.....	201

Maintenance

General information.....	202
Opening and closing the bonnet.....	203
Engine compartment overview - 1.6L Duratec-16V Ti-VCT (Sigma).....	204
Engine compartment overview - 2.0L Duratec-HE (M14).....	205
Engine compartment overview - 2.3L Duratec-HE (M14).....	206
Engine compartment overview - 2.5L Duratec-ST (V15).....	207
Engine compartment overview - 1.8L Duratorq-TDCi (Kent) Diesel.....	209
Engine compartment overview - 2.0L Duratorq-TDCi (DW) Diesel.....	210

Engine compartment overview - 2.2L Duratorq-TDCi (DW) Diesel.....	211
Engine oil dipstick - 1.6L Duratec-16V Ti-VCT (Sigma).....	212
Engine oil dipstick - 2.0L Duratec-HE (M14)/2.3L Duratec-HE (M14).....	212
Engine oil dipstick - 2.5L Duratec-ST (V15).....	213
Engine oil dipstick - 1.8L Duratorq-TDCi (Kent) Diesel.....	213
Engine oil dipstick - 2.0L Duratorq-TDCi (DW) Diesel/2.2L Duratorq-TDCi (DW) Diesel.....	213
Engine oil check.....	213
Engine coolant check.....	214
Brake and clutch fluid check.....	215
Power steering fluid check.....	215
Washer fluid check.....	216
Technical specifications.....	216

Vehicle care

Cleaning the exterior.....	220
Cleaning the interior.....	221
Repairing minor paint damage.....	221

Vehicle battery

Battery care.....	222
Using booster cables.....	222

Wheels and tyres

General information.....	224
Changing a road wheel.....	224
Tyre repair kit.....	229
Run flat tyres.....	234
Tyre care.....	235

Table of contents

Using winter tyres.....	236	Type approvals.....	277
Using snow chains.....	236		
Tyre pressure monitoring system.....	236		
Technical specifications.....	238		

Vehicle identification

Vehicle identification plate.....	242
Vehicle identification number (VIN).....	242

Technical specifications

Technical specifications.....	243
-------------------------------	-----

Telephone

General information.....	252
Telephone setup.....	252
Bluetooth setup.....	254
Telephone controls.....	255
Using the telephone - Vehicles Without: Navigation System.....	256
Using the telephone - Travel Pilot EX.....	259

Voice control

Principle of operation.....	262
Using voice control.....	263
Audio unit commands.....	263
Telephone commands.....	268
Navigation system commands.....	273
Climate control commands.....	273

Appendices

Electromagnetic compatibility.....	276
------------------------------------	-----

Introduction

ABOUT THIS HANDBOOK

Thank you for choosing Ford. We recommend that you take some time to get to know your vehicle by reading this handbook. The more that you know about it, the greater the safety and pleasure you will get from driving it.

Note: *This handbook describes every model and option, sometimes even before they are generally available. It may describe options not fitted to your vehicle.*

Note: *Always use and operate your vehicle in line with all applicable laws and regulations.*

Note: *Pass on this handbook when selling your vehicle. It is an integral part of the vehicle.*

SYMBOLS GLOSSARY

Symbols in this handbook

WARNING



You risk death or serious injury to yourself and others if you do not follow the instructions highlighted by the warning symbol.

CAUTION



You risk damaging your vehicle if you do not follow the instructions highlighted by the caution symbol.

Symbols on your vehicle



When you see these symbols, read and follow the relevant instructions in this handbook before touching or attempting adjustment of any kind.

PARTS AND ACCESSORIES

Now you can be sure that your Ford parts are Ford parts

Your Ford has been built to the highest standards using high quality Ford Original Parts. As a result, you can enjoy driving it for many years.

Should the unexpected occur and a major part needs replacing, we recommend that you accept nothing less than Ford Original Parts.

The use of Ford Original Parts ensures that your vehicle is repaired to its pre-accident condition and maintains its maximum residual value.

Ford Original Parts match Ford's stringent safety requirements and high standards of fit, finish and reliability. Quite simply, they represent the best overall repair value, including parts and labour costs.


Introduction

Now it is easier to tell if you have really been given Ford Original Parts. The Ford logo is clearly visible on the following parts if they are Ford Original Parts. If your vehicle has to be repaired, look for the clearly visible Ford branding and make sure that only Ford Original Parts have been used.

Look for the Ford logo on the following parts

Sheet metal



- Bonnet
- Doors
- Luggage compartment lid or tailgate



E88678


Bumper and radiator grille

- Radiator grille
- Front and rear bumper



E88505

Exterior mirror




E88506

Glass

- Rear window
- Side glass
- Windscreen

Introduction



E88507

Lighting

- Rear lamps
- Headlamp




E88508

Quick start

QUICK START


Instrument panel overview - left-hand drive



E87719

Quick start

Instrument panel overview - right-hand drive



E87720


- A Lighting controls. See **Lighting control** (page 56).
- B Air vents. See **Air vents** (page 109).
- C Direction indicators. See **Direction indicators** (page 61).
Telephone control buttons. See **Telephone controls** (page 255).
Voice control buttons. See **Using voice control** (page 263).
- D Instrument cluster. See **Gauges** (page 79).
- E Information display controls. See **Information displays** (page 85).
- F Wiper lever. See **Windscreen wipers** (page 51).
- G Start Button. See **Keyless starting** (page 136).
- H Audio or navigation unit. See separate handbook.

Quick start

- I Stability control (ESP)switch. See **Using stability control** (page 153).
- J Parking aid switch. See **Using the parking aid** (page 159).
- K Hazard warning flasher switch. See **Hazard warning flashers** (page 59).
- L Passenger airbag deactivation warning lamp. See **Disabling the passenger airbag** (page 32).
- M Heated windscreen and heated rear window switches. See **Heated windows and mirrors** (page 116).
- N Climate controls. See **Manual climate control** (page 110). See **Automatic climate control** (page 113).
- O Cigar lighter. See **Cigar lighter** (page 130).
- P Ignition switch. See **Ignition switch** (page 136).
- Q Cruise control switches. See **Using cruise control** (page 161). Adaptive cruise control switches. See **Using ACC** (page 165).
- R Steering wheel adjustment lever. See **Adjusting the steering wheel** (page 49).
- S Horn.
- T Cruise control switches. See **Using cruise control** (page 161). Adaptive cruise control switches. See **Using ACC** (page 165).
- U Driver Knee airbag. See **Principle of operation** (page 28).
- V Storage compartment. See **Storage compartments** (page 132).

Quick start


Keyless entry



E78276

Passive locking and unlocking requires a valid passive key to be located within one of the three external detection ranges.


Unlocking the vehicle



E78278

Pull a door handle to unlock all the doors and the luggage compartment lid and disarm the alarm.

Locking the vehicle




E87384



E87435

See **Keyless entry** (page 40).

Keyless starting



E85766

Quick start

Press the start button.

See **Keyless starting** (page 136).

Engine idle speed after starting

The engine may idle at a higher speed than normal immediately after starting from cold.


See **Starting the engine** (page 136).

Adjusting the steering wheel

WARNING



Never adjust the steering wheel when the vehicle is moving.



E71221

See **Adjusting the steering wheel** (page 49).

Electric folding mirrors



E72623

See **Electric exterior mirrors** (page 76).

Information displays



E70499

Use the arrow buttons to navigate through the menus and press **OK** to make a selection.

See **Information displays** (page 85).

Quick start

Autolamps




E70719

The headlamps will come on and go off automatically depending on the ambient light.

See **Lighting control** (page 56).


Direction indicators



E70727


Note: Tap the lever up or down to make the direction indicators flash only three times.

Autowipers



E70696

- A Single wipe
- B Autowipers
- C Normal wipe
- D High speed wipe



E70316


- A High sensitivity
- B Low sensitivity


See **Autowipers** (page 51).

Quick start

Memory function

WARNING

 Do not use the memory store function when the vehicle is moving.



E86768

- A Seat adjustment controls.
B Memory pre-set buttons.

1. Vehicles without keyless starting, insert the ignition key and turn it to position **I** or **II**. Vehicles with keyless starting, press the start button.
2. Adjust the seat and exterior mirrors to the desired position.
3. Press and hold the desired pre-set button **B** for at least 3 seconds.
4. A message will be shown in the display.
5. A chime will sound to confirm.

See **Memory function** (page 133).


Manual climate control

Heating the interior quickly




E71377

Cooling the interior quickly



E71381

Defrosting and demisting the windscreen



E71382

Quick start

See **Manual climate control** (page 110).

Automatic climate control




E70304

See **Automatic climate control** (page 113).

Selecting reverse gear


Vehicles with a 6-speed transmission

Vehicles with a petrol engine



E75051

Vehicles with a diesel engine



E75052

See **Manual transmission** (page 147).

Automatic transmission

Selector lever positions




E80836

- P Park
- R Reverse
- N Neutral

Quick start

- D Drive
- S Manual shifting and sport mode


WARNING


 Apply the brakes before moving the selector lever and keep them applied until you are ready to move off.

See **Automatic transmission** (page 148).

Fuel filler flap


WARNINGS

 Take care when refuelling to avoid spilling any residual fuel from the fuel pipe nozzle.

 We recommend that you wait at least 10 seconds before removing the fuel pipe nozzle to allow any residual fuel to drain into the fuel tank.

When you insert the fuel pipe nozzle, a spring loaded inhibitor will open if the correct size nozzle is detected. This will prevent filling up with the wrong fuel.

See **Fuel filler flap** (page 143).



E86613

Press the flap to open it. Open the flap fully until it engages.


Child safety


CHILD SEATS



E68916

WARNINGS


 Secure children that are less than 150 centimetres tall or less than 12 years of age in a suitable, approved child restraint, in the rear seat.

 Original text according to ECE R94.01: Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an air bag in front of it!


 Read and follow the manufacturer's instructions when you are fitting a child restraint.

 Do not modify child restraints in any way.

 Do not hold a child on your lap when the vehicle is moving.

 Do not leave unattended children in your vehicle.

WARNINGS

 If your vehicle has been involved in an accident, have the child restraints checked by properly trained technicians.

Note: *Mandatory use of child restraints varies from country to country.*

A choice of ECE approved child restraints which have been specifically tested and approved for your vehicle are available from your Dealer.

Child restraints for different mass groups

Use the correct child restraint as follows:

Baby safety seat



E68918

Secure children that weigh less than 13 kilogrammes in a rearward facing baby safety seat in the rear seat.

Child safety

Child safety seat



E68920

Secure children that weigh between 13 and 18 kilogrammes in a child safety seat in the rear seat.

BOOSTER CUSHIONS

WARNINGS

⚠ Do not install a booster seat or a booster cushion with only the lap strap of the seat belt.

⚠ Do not install a booster seat or a booster cushion with a seat belt that is slack or twisted.

⚠ Do not put the seat belt under your child's arm or behind its back.

⚠ Do not use pillows, books or towels to boost your child's height.

⚠ Make sure that your children sit in an upright position.

WARNINGS

⚠ Secure children that weigh more than 15 kilogrammes but are less than 150 centimetres tall in a booster seat or a booster cushion.

Booster seat



E70710

We recommend that you use a booster seat that combines a cushion with a backrest instead of a cushion only. The raised seating position will allow you to position the shoulder strap of the adult seat belt over the centre of your child's shoulder and the lap strap tightly across its hips.

Child safety

Booster cushion



E68924

Integrated booster cushion

WARNINGS



Do not use the raised integrated booster cushion together with a child safety seat.




The integrated booster cushion can be used for children that weigh between 22 and 36 kilogrammes (49 and 79 pounds).

CAUTION




Remove the rear seat head restraint unless the child's head exceeds the top of the backrest. See **Head restraints** (page 127).

Unlocking



E94860

Note: Make sure that the locking mechanism is fully engaged.




E94861

The raised seating position will allow you to position the shoulder strap of the adult seat belt over the centre of your child's shoulder and the lap strap tightly across its hips.

Child safety


Locking

Note: Make sure that there are no obstructions in the linkage area before locking the integrated booster cushion.



E94862


Note: Make sure that the locking mechanism is fully engaged.




E94870

CHILD SEAT POSITIONING

WARNINGS

 When using a child restraint with a support leg on a second row seat, make sure the support leg rests securely on the floor.

 When using a forward facing child seat on a second row seat, always remove the head restraint from that seat.

Note: When using a child restraint on a front seat, it may prove difficult to tighten the lap section of the seat belt without slack remaining. If this is the case, adjust the seatback to the fully upright position and raise the height of the seat. See **Seats** (page 124).

Child safety

Seating positions	Mass group categories				
	0	0+	I	II	III
	Up to 10 kg	Up to 13 kg	9 - 18 kg	15 - 25 kg	22 - 36 kg
Front passenger seat with airbag ON	X	X	UF ¹	UF ¹	UF ¹
Front passenger seat with airbag OFF	U ¹	U ¹	U ¹	U ¹	U ¹
Rear seats	U	U	U	U	U

X Not suitable for children in this mass group.

U Suitable for universal category child restraints approved for use in this mass group.

U¹ Suitable for universal category child restraints approved for use in this mass group. However, we recommend that you secure children in a government approved child restraint, in the rear seat.

UF¹ Suitable for universal category forward facing child restraints approved for use in this mass group. However, we recommend that you secure children in a government approved child restraint, in the rear seat.

ISOFIX child restraints

Seating positions	Mass group categories				
	0	0+	I	II	III
	Up to 10 kg	Up to 13 kg	9 - 18 kg	15 - 25 kg	22 - 36 kg
Rear seat ISOFIX restraints	IL	IL	IL, IUF**	X	X
Rear seat ISOFIX classes*	E	C, D, E	A, B, B1, C, D	X	X

X Not suitable for children in this mass group.

Child safety

IUF Suitable for universal category ISOFIX child restraints approved for use in this mass group.

IL Suitable for the following ISOFIX child restraints: Roemer Duo ISOFIX (group **1**), Roemer Babysafe ISOFIX (group **0+**). In addition, any semi-universal ISOFIX child restraint may be used if indicated in the child seat manufacturers vehicle list.

* As defined by ECE-R16.


Note: ** *When you are purchasing an ISOFIX restraint, make sure that you know the correct mass group and ISOFIX size class for the intended seating locations.*

Note: ** *Make sure that the top tether mechanism does not interfere with the luggage cover.*

Child safety

ISOFIX ANCHOR POINTS


WARNING

 Use an anti-rotation device when using the ISOFIX system. We recommend the use of a top tether or support leg.

Your vehicle is fitted with ISOFIX anchor points that accommodate universally approved ISOFIX child restraints.

The ISOFIX system comprises two rigid attachment arms on the child restraint that attach to anchor points on the outboard rear seats, where the cushion and backrest meet. Tether anchor points are fitted behind the outboard rear seats for child restraints with a top tether.

Top tether anchor points



E87146




E93616



E93514

Attaching a child seat with top tethers


WARNING

 Do not attach a tether strap to anything other than the correct tether anchor point.

Note: Where applicable, remove the luggage cover to ease installation. See **Luggage covers** (page 174).

Child safety


Note: On 4-door vehicles, make sure the tether strap tightening mechanism remains accessible when the seatback is fully engaged.



E87591


1. Place the child seat on the back seat cushion and fold the relevant seatback forwards. See **Rear seats** (page 127).
2. Remove the head restraint. See **Head restraints** (page 127).

WARNING

 Make sure the top tether strap is not slack or twisted and is properly located on the anchor point.

3. Route the tether strap to the anchor point.

WARNING

 Make sure that the seatback is secure and fully engaged in the catch.

4. Push the seatback to the upright position.




E87145



5. Push the child seat back firmly to engage the ISOFIX lower anchor points.
6. Tighten the tether strap in line with the child seat manufacturer's instructions.

Child safety

CHILD SAFETY LOCKS

WARNING

 You cannot open the doors from inside if you have put the child safety locks on.



E73697


- A Lock
- B Unlock


Occupant protection


PRINCIPLE OF OPERATION

Airbags


WARNINGS


 Do not modify the front of your vehicle in any way. This could adversely affect deployment of the airbags.


 Original text according to ECE R94.01: Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an airbag in front of it!

 Wear a seat belt and keep sufficient distance between yourself and the steering wheel. Only when you use the seat belt properly, can it hold you in a position that allows the airbag to achieve its optimum effect. See **Sitting in the correct position** (page 124).

 Have repairs to the steering wheel, steering column, seats, airbags and seat belts carried out by a properly trained technician.

 Keep the areas in front of the airbags free from obstruction. Do not affix anything to or over the airbag covers.


 Do not poke sharp objects into areas where airbags are fitted. This could damage and adversely affect deployment of the airbags.

 Use seat covers designed for seats with side airbags. Have these fitted by a properly trained technician.

Note: You will hear a loud bang and see a cloud of harmless powdery residue if an airbag deploys. This is normal.

Note: Only wipe airbag covers with a damp cloth.

Driver and front passenger airbags



E74302


The driver and front passenger airbags will deploy during significant frontal collisions or collisions that are up to 30 degrees from the left or the right. The airbags will inflate within a few thousandths of a second and deflate on contact with the occupants, thus cushioning forward body movement. During minor frontal collisions, overturns, rear collisions and side collisions, the driver and front passenger airbags will not deploy.

Occupant protection

Driver knee airbag

CAUTION

 Do not attempt to open the driver knee airbag cover.




E86311

The driver knee airbag will deploy during frontal collisions or collisions that are up to 30 degrees from the left or the right. The airbag will inflate within a few thousandths of a second and deflate on contact with the occupants, thus providing a cushion between the driver's knees and the steering column. During overturns, rear collisions and side collisions, the knee airbag will not deploy.

Note: *The knee airbag has a lower deployment threshold than the front airbags. During a minor collision, it is possible that only the knee airbag deploys.*

Side airbags




E72658

Side airbags are fitted inside the seatback of the front seats. A label indicates that side airbags are fitted to your vehicle.

The side airbags will deploy during significant lateral collisions. Only the airbag on the side affected by the collision will deploy. The airbags will inflate within a few thousandths of a second and deflate on contact with the occupants, thus providing protection for the chest and shoulder areas. During minor lateral collisions, overturns, front collisions and rear collisions, the side airbags will not deploy.

Occupant protection

Curtain airbags




E75004


Curtain airbags are fitted inside the trim panels over the front and rear side windows. Moulded badges in the B-pillar trim panels indicate that curtain airbags are fitted to your vehicle.

The curtain airbags will deploy during significant lateral collisions. Only the airbag on the side affected by the collision will deploy. The airbag will inflate within a few thousandths of a second and deflate on contact with the occupants, thus providing protection for the head. During minor lateral collisions, front collisions, rear collisions, or overturns the curtain airbags will not deploy.


Seat belts


WARNINGS


 Wear a seat belt and keep sufficient distance between yourself and the steering wheel. Only when you use the seat belt properly, can it hold you in a position to achieve its optimum effect. See **Sitting in the correct position** (page 124).

 Never use a seat belt for more than one person.

 Use the correct buckle for each seat belt.

 Do not use a seat belt that is slack or twisted.

 Do not wear thick clothing. The seat belt must fit tightly around your body to achieve its optimum effect.


 Position the shoulder strap of the seat belt over the centre of your shoulder and position the lap strap tightly across your hips.

The driver and front passenger seat belt retractors are fitted with a seat belt pretensioner. Seat belt pretensioners have a lower deployment threshold than the airbags. During minor collisions, it is possible that only the seat belt pretensioners will deploy.

Occupant protection


FASTENING THE SEAT BELTS

WARNING

 Insert the tongue into the buckle until you hear a distinct click. You have not fastened the seat belt properly if you do not hear a click.



E74124



E85817

Pull the belt out steadily. It may lock if you pull it sharply or if the vehicle is on a slope.

Press the red button on the buckle to release the belt. Let it retract completely and smoothly.

SEAT BELT HEIGHT ADJUSTMENT




E87511

Note: *Lifting the slider slightly while pressing the locking button makes it easier to release the locking mechanism.*

To raise or lower, press the locking button on the adjuster and move as necessary.

SEAT BELT REMINDER

WARNING

 Do not sit on top of a fastened seat belt to prevent the seat belt reminder from coming on. The occupant protection system will only provide optimum protection when you use the seat belt properly.

Occupant protection




The seat belt reminder warning lamp illuminates and an audible warning will sound if you or your front seat passenger have not fastened your seat belts and the vehicle exceeds 10 km/h (6 mph). It will also illuminate if your seat belts are unfastened when the vehicle is moving. The audible warning will go off after five minutes but the seat belt reminder warning lamp will remain on until you fasten your seat belts.

Deactivating the seat belt reminder

See your dealer.

USING SEAT BELTS DURING PREGNANCY



E68587

WARNING



Position the seat belt correctly for your safety and that of your unborn child. Do not use only the lap strap or the shoulder strap.

Position the lap strap comfortably across your hips and low beneath your pregnant abdomen. Position the shoulder strap between your breasts, above and to the side of your pregnant abdomen.

DISABLING THE PASSENGER AIRBAG

WARNING



Make sure that the passenger airbag is disabled when using a rearward facing child restraint on the front passenger seat.




E71313

Occupant protection

Fitting the passenger airbag deactivation switch

WARNING


 If you need to fit a child restraint on a seat protected by an operational airbag in front of it, have a passenger airbag deactivation switch fitted. Ask your dealer for further information.

Note: *The key switch is located in the glove compartment with an airbag deactivation lamp in the instrument panel.*

If the airbag warning lamp illuminates or flashes when you are driving, this indicates a malfunction. See

Warning lamps and indicators (page 81). Remove the child restraint and have the system checked immediately.

Disabling the passenger airbag



E71312

A Disabled


B Enabled

Turn the switch to position **A**.

When you switch the ignition on, check that the passenger airbag deactivation warning lamp illuminates.

Enabling the passenger airbag

WARNING

 Make sure that the passenger airbag is enabled when you are not using a child restraint on the front passenger seat.

Turn the switch to position **B**.

Keys and remote controls

USING THE KEY


Remote control with flip key blade



E74382

GENERAL INFORMATION ON RADIO FREQUENCIES

CAUTION

 The radio frequency used by your remote control can also be used by other short distance radio transmissions (e.g. amateur radios, medical equipment, wireless headphones, remote controls and alarm systems). If the frequencies are jammed, you will not be able to use your remote control. You can lock and unlock the doors with the key.

Note: You could unlock the doors if you press the buttons on the remote control unintentionally.


The operating range between your remote control and your vehicle varies depending on the environment.

PROGRAMMING THE REMOTE CONTROL

You can programme a maximum of eight remote controls to use with your vehicle (including any supplied with your vehicle). Ask your dealer for instructions.

CHANGING THE REMOTE CONTROL BATTERY

Remote control with a folding key blade



E74383

1. Insert a screwdriver as far as possible into the slot on the side of the remote control, push it towards the key blade and remove the key blade.

Keys and remote controls



E74384


2. Twist the screwdriver in the position shown to start separating the two halves of the remote control.



E74385


3. Twist the screwdriver in the position shown to separate the two halves of the remote control.

CAUTION

 Do not touch the battery contacts or the printed circuit board with the screwdriver.

4. Carefully prise out the battery with the screwdriver.
5. Install a new battery (3V CR 2032) with the + facing downwards.
6. Assemble the two halves of the remote control.
7. Install the key blade.


Remote control without a folding key blade



E74386

1. Insert a screwdriver into the recess on the back of the key and remove the key blade.
2. Release the retaining clips with the screwdriver and separate the two halves of the remote control.

CAUTION

 Do not touch the battery contacts or the printed circuit board with the screwdriver.

3. Carefully prise out the battery with the screwdriver.
4. Install a new battery (3V CR 2032) with the + facing downwards.
5. Assemble the two halves of the remote control.
6. Install the key blade.

Locks

LOCKING AND UNLOCKING


Central locking

You can only centrally lock the doors if they are all closed.

Note: The driver's door can be unlocked with the key. This needs to be used if the remote control or keyless entry is not functioning.

Double locking

WARNING

 Do not activate double locking when persons or animals are inside the vehicle. You will not be able to unlock the doors from the inside if you have double locked them.



E71961

Double locking is a theft protection feature that prevents someone from opening the doors from the inside. You can only double lock the doors if they are all closed.


Locking and unlocking confirmation

When you unlock the doors, the direction indicators will flash once.

When you lock the doors, the direction indicators will flash twice.

Note: If your vehicle has double locking, the direction indicators will only flash twice once you have activated double locking.

Locking and unlocking the doors with the key



E71962


- A Unlock
- B Lock

Locks

Double locking the doors with the key

Turn the key to the lock position twice within three seconds to double lock the doors.

Locking and unlocking the doors and the luggage compartment lid with the remote control



E87379

- A Unlock
- B Lock
- C Luggage compartment lid unlock

Locking the doors and the luggage compartment lid with the remote control


Press button **B** once.

Double locking the doors and the luggage compartment lid with the remote control

Press button **B** twice within three seconds.

Locking and unlocking the doors from inside

Front doors



E71958

- A Lock all doors
- B Unlock all doors

Rear doors

To lock the rear doors individually, press button **A** and close the door when leaving the vehicle.

Luggage compartment lid

Opening the luggage compartment lid with the remote control

Press button **C** on the remote control twice within three seconds.

Locks


Closing the luggage compartment lid

4-door




E89131

5-door



E89132

Estate



E89133

A recessed grip is incorporated inside the luggage compartment lid to facilitate closing.

Automatic relocking

The doors will relock automatically if you do not open a door within 45 seconds of unlocking the doors with the remote control. The door locks and the alarm will return to their previous state.

Reprogramming the unlocking function

If the unlocking function is reprogrammed so that only the driver's door is unlocked (See **Programming the remote control** (page 34).), note the following:

When you press the unlock button either all the doors are unlocked or only the driver's door is unlocked. Pressing the unlock button again unlocks all the doors.


GLOBAL OPENING AND CLOSING

You can also operate the electric windows with the ignition off via the global opening and global closing function.

Note: *Global closing will only operate if you have set the memory correctly for each window. See **Electric windows** (page 73).*

Locks

Global opening



E71955

To open all the windows, press and hold the **unlock** button for at least three seconds. Press either the **lock** or the **unlock** button again to stop the opening function.


Global closing

Vehicles without the key free system

WARNING




Take care when using global closing. In an emergency, press a button immediately to stop.



E71956

To close all the windows, press and hold the **lock** button for at least three seconds. Press any button again to stop the closing function. The anti-trap function is also active during global closing.

Vehicles with the key free system



E78275

WARNING



Take care when using global closing. In an emergency, press the button on the driver's door handle to stop.

Locks

Note: *Global closing can be activated using the button on the driver's door handle. Global opening and closing can also be activated using the buttons on the passive key.*

To close all the windows, press and hold the button on the driver's door handle for at least two seconds. The anti-trap function is also active during global closing.

KEYLESS ENTRY

General information

WARNING



The keyless entry system may not function if the key is close to metal objects or electronic devices such as mobile phones.


Note: *If the door handles are pulled repeatedly during a short period of time without the presence of a valid passive key, the system will become inoperable for 30 seconds.*

The passive entry system will not function if:

- The passive key frequencies are jammed.
- The passive key battery is flat.

Note: *If the passive entry system does not function, you will need to use the key blade to lock and unlock your vehicle.*

The keyless system allows the driver to operate the vehicle without the use of a key or remote control.



E78276


Passive locking and unlocking requires a valid passive key to be located within one of the three external detection ranges. These are located approximately one and a half metres from the driver and front passenger door handles and the luggage compartment lid.

Passive key

The vehicle can be locked and unlocked with the passive key. The passive key can also be used as a remote control. See **Locking and unlocking** (page 36).

Locks

Locking the vehicle



E87384



E87435

WARNING



The vehicle does not lock itself automatically. If no locking button is pressed, the vehicle will remain unlocked.

Note: If locking from the luggage compartment lid, the passive key must be within the luggage compartment lid detection range.

Locking buttons are located on each of the front doors and the luggage compartment lid.

To activate central locking and arm the alarm:

- Press a locking button once.

To activate double locking, to arm the alarm and the interior sensors:

- Press a locking button twice within three seconds.

Note: Once activated, the vehicle will remain locked for approximately three seconds. This is to allow you to pull a door handle and check if the vehicle is locked. When the delay period is over, the doors can be opened again, provided the passive key is within the respective detection range.

Luggage compartment lid


Note: The luggage compartment lid cannot be closed and will pop back up if the passive key is located inside the luggage compartment.

Note: If a second valid passive key is located within the luggage compartment lid detection range, the luggage compartment lid can be closed.

Unlocking the vehicle

Note: If the vehicle remains locked for longer than five days, the key free system will enter an energy-saving mode. This is to reduce the discharge of the vehicle battery. When the vehicle is unlocked while in this mode, the reaction time of the system may be a little longer than normal. Unlocking the vehicle once will deactivate the energy-saving mode.

Locks



E78278

Pull one of the door handles or the luggage compartment lid handle.

Note: *A valid passive key must be located within the detection range of that door.*

One long flash of the direction indicators confirms that all the doors, the luggage compartment lid and the fuel filler flap have been unlocked and that the alarm has been disarmed.

Unlocking only the driver's door

If the unlocking function is reprogrammed so that only the driver's door is unlocked (See **Keys and remote controls** (page 34).), note the following:

If the driver's door is the first door which is opened, the other doors and the luggage compartment lid will remain locked. All the other doors can be unlocked from inside the vehicle by pressing the unlock button next to the driver's door handle. Doors can be unlocked individually by pulling the interior door handles on those doors.

If the front passenger door or one of the rear doors is the first door which is opened, **all** the doors and the luggage compartment lid will be unlocked.

Disabled keys

Any keys left inside the vehicle interior when it is locked will be disabled.

A disabled key cannot be used to turn the ignition on or start the engine.

In order to use these passive keys again, they have to be enabled.

To enable all your passive keys, unlock the vehicle using a passive key or the remote control unlocking function.


All passive keys will then be enabled if the ignition is turned on or the vehicle is started using a valid key.

Locks

Locking and unlocking the doors with the key blade

2. Remove the key blade and insert it into the lock.

Type 1



E78284

1. Slide the release slider in the direction of the arrow and pull out the key blade with your thumb.
2. Remove the key blade and insert it into the lock.

Type 2



E87964

1. Carefully remove the cover.

Engine immobiliser

PRINCIPLE OF OPERATION

The engine immobiliser is a theft protection system that prevents someone from starting the engine with an incorrectly coded key.

CODED KEYS

Note: *Do not shield your keys with metal objects. This may prevent the receiver from recognising your key as a valid one.*

Note: *Have all of your remaining keys erased and recoded if you lose a key. Ask your dealer for further information. Have replacement keys recoded together with your existing keys.*

If you lose a key, you can obtain a replacement from your Ford Dealer. If possible, provide them with the key number from the tag provided with the original keys. You can also obtain additional keys from your Ford Dealer.

ARMING THE ENGINE IMMOBILISER

The engine immobiliser is armed automatically a short time after you have switched the ignition off.

DISARMING THE ENGINE IMMOBILISER

The engine immobiliser is disarmed automatically when you switch the ignition on with a correctly coded key.

If the message **Immobiliser active** appears in the information display, your key has not been recognised. Remove the key and try again.

If you are unable to start the engine with a correctly coded key, this indicates a malfunction. The message **Immobiliser active** will appear in the information display when you switch on the ignition. Have the immobiliser checked immediately.

Alarm

PRINCIPLE OF OPERATION

Alarm system

Your vehicle may be equipped with one of the following alarm systems:

- Perimeter alarm.
- Perimeter alarm with interior sensors.
- Category one alarm with interior sensors and battery back-up sounder.
- Category one alarm with interior sensors, battery back-up sounder and tilt sensors.

Perimeter alarm

The perimeter alarm is a deterrent against unauthorised access to your vehicle through the doors and the bonnet. It also protects the audio unit.

Interior sensors



E71401

WARNING



The sensors in the interior lamp unit must not be covered up. Do not activate the alarm with full guard if any persons, animals or other moving objects are inside the vehicle.

The sensors act as a deterrent against unauthorised intrusion by sensing any movement within the vehicle.

Battery back-up sounder

The battery back-up sounder is an extra alarm system which will sound a siren when the alarm is triggered. It is armed directly when you lock the vehicle. The sounder has its own battery and will sound an alarm siren even if someone disconnects the vehicle battery or the battery back-up sounder itself.

Tilt sensors

The tilt sensors detect if someone attempts to steal a wheel or tow the vehicle away by sensing changes in the inclination of the vehicle.

Note: *When travelling on a ferry with the alarm armed, deactivate the tilt sensors by selecting reduced guard. This will prevent the alarm from being triggered by the movement.*

Triggering the alarm

Once armed, the alarm is triggered in any of the following ways:

- If someone opens a door, the tailgate or the bonnet without a valid key or remote control.
- If someone removes the audio or navigation system.
- If the ignition is turned to position **I**, **II** or **III** without a valid key.
- If the interior sensors detect movement within the vehicle.

Alarm

- On vehicles with a battery back-up sounder, if someone disconnects the vehicle battery or the battery back-up sounder itself.
- If the tilt sensors detect a change in the inclination of the vehicle.

If the alarm is triggered, the alarm horn will sound for 30 seconds and the hazard warning flasher will flash for five minutes.

Any further attempts to perform one of the above will trigger the alarm again.

Full and reduced guard

Full guard

Full guard is the standard setting.

In full guard, the interior and tilt sensors are activated when you arm the alarm.

Note: *This may result in false alarms if animals or moving objects are inside the vehicle or, on vehicles with tilt sensors, when travelling on a ferry.*

Reduced guard

In reduced guard, the interior and tilt sensors are deactivated when you arm the alarm.

Note: *You can set the alarm to reduced guard for the current ignition cycle only. The next time you switch on the ignition, the alarm will be reset to full guard.*

Ask on Exit

You can set the information display to ask you each time which level of guard you wish to set.

If you select **Ask on Exit**, the message **Reduced guard?** appears in the instrument cluster display each time you switch the ignition off.

If you wish to arm the alarm with reduced guard, press the **OK** button when this message appears.

If you wish to arm the alarm with full guard, leave the vehicle without pressing the **OK** button.


Selecting full or reduced guard

Note: *Selecting **Reduced** does not set the alarm permanently to reduced guard. It sets it to reduced guard only for the current ignition cycle. If you regularly set the alarm to reduced guard, select **Ask on Exit**.*



E70499

Alarm



E74509

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Alarm** and press the right arrow button.
4. Highlight **Reduced** or **Full guard**. If you prefer to be asked each time you switch off the ignition, select **Ask on Exit**.
5. Press the **OK** button to confirm the selection.
6. Press the left arrow button to exit the menu. To return to the trip computer display directly, hold the left arrow button pressed.

Information messages

See **Information messages** (page 99).

ARMING THE ALARM

To arm the alarm, lock the vehicle. See **Locks** (page 36).

DISARMING THE ALARM

Vehicles without keyless entry

Perimeter alarm

Disarm and silence the alarm by unlocking the doors with the key and switching the ignition on with a correctly coded key, or unlocking the doors or the luggage compartment lid with the remote control.

Category one alarm

Disarm and silence the alarm by unlocking the doors with the key and switching the ignition on with a correctly coded key within 12 seconds, or unlocking the doors or the luggage compartment lid with the remote control.

Vehicles with keyless entry

Note: A valid passive key must be located within the detection range of that door for keyless entry. See **Keyless entry** (page 40).

Perimeter alarm

Disarm and silence the alarm by unlocking the doors and switching the ignition on, or unlocking the doors or the luggage compartment lid with the remote control.

Alarm

Category one alarm

Disarm and silence the alarm by unlocking the doors and switching the ignition on within 12 seconds, or unlocking the doors or the luggage compartment lid with the remote control.

Steering wheel


ADJUSTING THE STEERING WHEEL

WARNING



Never adjust the steering wheel when the vehicle is moving.

Note: Make sure that you are sitting in the correct position. See **Sitting in the correct position** (page 124).



E95178




E95179

WARNING



Make sure that you fully engage the locking lever when returning it to its original position.

AUDIO CONTROL



E72288

- A Volume up
- B Seek up
- C Volume down
- D Seek down
- E Mode

Mode

Press and **hold** the mode button to select the audio source.

Press the mode button to:

- tune the radio to the next preset station
- play the next CD
- play the other side of a cassette tape

Steering wheel

- accept an incoming telephone call.
- end a telephone call.

Seek

Press a seek button to:


- tune the radio to the next station up or down the frequency band
- play the next or the previous CD track
- fast forward or rewind the cassette tape.

Press and **hold** a seek button to:

- tune the radio up or down the frequency band
- seek through a CD track.

Wipers and washers


WINDSCREEN WIPERS



E70696

- A Single wipe
- B Intermittent wipe
- C Normal wipe
- D High speed wipe

Intermittent wipe




E70315

- A Short wipe interval
- B Intermittent wipe
- C Long wipe interval

AUTOWIPERS

CAUTIONS

- ⚠ Do not switch autowipers on in dry weather conditions. The rain sensor is very sensitive and the wipers may operate if dirt, mist or flies hit the windscreen.
- ⚠ Replace the wiper blades as soon as they begin to leave bands of water and smears. If you do not replace them, the rain sensor will continue to detect water on the windscreen and the wipers will operate, even though the majority of the windscreen is dry.
- ⚠ Fully defrost the windscreen in icy conditions before you switch autowipers on.
- ⚠ Switch autowipers off before you enter a car wash.



E70315

- A High sensitivity
- B On
- C Low sensitivity

Wipers and washers

If you switch autowipers on, the wipers will not cycle until water is detected on the windscreen. The rain sensor will then continuously measure the amount of water on the windscreen and adjust the speed of the wipers automatically.

Adjust the sensitivity of the rain sensor using the rotary control. With low sensitivity, the wipers will operate when the sensor detects a lot of water on the windscreen. With high sensitivity, the wipers will operate if the sensor detects a small amount of water on the windscreen.


WINDSCREEN WASHERS

WARNING



Do not operate the windscreen washers for more than 10 seconds or when the reservoir is empty.


Note: *The washer jets are heated when the ignition is on.*



E70776

REAR WINDOW WIPER AND WASHERS

Intermittent wipe



E70777

Reverse gear wipe

The rear window wiper will operate automatically when you select reverse gear if the wiper lever is in position **B**, **C** or **D**.


Washer

WARNING



Do not operate the rear window washer for more than 10 seconds or when the reservoir is empty.


Wipers and washers



E70777

Pull the lever fully towards the steering wheel and hold it to operate the washer.

HEADLAMP WASHERS




E70776

The headlamp washers will operate with the windscreen washers when the headlamps are on.

Note: To stop the washer fluid reservoir emptying quickly, the headlamp washers will not operate every time that you use the windscreen washers.

CHECKING THE WIPER BLADES



E66644

Run the tip of your fingers over the edge of the blade to check for roughness.

Clean the wiper blade lips with water applied with a soft sponge.

CHANGING THE WIPER BLADES

Windscreen wiper blades

CAUTIONS

⚠ Set the windscreen wipers in the service position to change the wiper blades.


⚠ You can use the service position in winter to provide easier access to the wiper blades for freeing them from snow and ice. The windscreen wipers will return to their normal position as soon as you switch on the ignition so make sure that you fully defrost the windscreen before you switch on the ignition.

Wipers and washers

Service position



E85833




E75188

Switch off the ignition and move the wiper lever to position **A** within three seconds. Release the lever when the windscreen wipers have moved to the service position.

Changing the windscreen wiper blades

Set the windscreen wipers in the service position and lift the wiper arms.



E72899

1. Press the locking button.
2. Remove the wiper blade.


Note: Make sure that the wiper blade locks into place.

3. Install in the reverse order.

Rear window wiper blades

Changing the rear window wiper blades - Estate

1. Lift the wiper arm.



E86456

2. Position the wiper blade at right angles to the wiper arm.
3. Disengage the wiper blade from the wiper arm.
4. Remove the wiper blade.


Wipers and washers

Note: Make sure that the wiper blade locks into place.

5. Install in the reverse order.

Changing the rear window wiper blades - 5-door

1. Lift the wiper arm.



E86457

2. Press the locking button.
3. Remove the wiper blade.


Note: Make sure that the wiper blade locks into place.

4. Install in the reverse order.

Lighting

LIGHTING CONTROL

Lighting control positions



E70718

- A Off
- B Side and tail lamps
- C Headlamps

Parking lamps

CAUTION


⚠ Prolonged use of the parking lamps will discharge the battery.

Switch off the ignition.

Both sides

Set the lighting control to position **B**.


One side



E75505

- A Right-hand side
- B Left-hand side

Main and dipped beam



E70725

Pull the lever fully towards the steering wheel to switch between main and dipped beam.

Headlamp flasher

Pull the lever slightly towards the steering wheel.

Lighting


Home safe lighting

Switch the ignition off and pull the direction indicator lever towards the steering wheel to switch the headlamps on. You will hear a short tone. The headlamps will go off automatically after three minutes with any door open, or 30 seconds after the last door has been closed.

With all doors closed, but within the 30 second delay, opening any door will result in the three minute timer starting again.

The home safe lights can be cancelled by either pulling the direction indicator lever towards the steering wheel again or by turning the ignition switch on.

AUTOLAMPS



E70719

Note: *If you have switched autolamps on, you can only switch the main beam on when autolamps has switched the headlamps on.*


The headlamps will come on and go off automatically depending on the ambient light.

FRONT FOG LAMPS



E70721

WARNING


 Only use the front fog lamps when visibility is considerably restricted by fog, snow or rain.


REAR FOG LAMPS



E70720

WARNINGS


 Only use the rear fog lamps when visibility is restricted to less than 50 metres.

 Do not use the rear fog lamps when it is raining or snowing and visibility is more than 50 metres.

Lighting

HEADLAMP LEVELLING

Note: Vehicles with Xenon headlamps are equipped with automatic headlamp levelling.



E70722

A Raised headlamp beams

B Lowered headlamp beams

You can adjust the level of the headlamp beams according to the vehicle load.

Recommended headlamp levelling switch positions

Load		Load in luggage compartment	Switch position
Front seats	Second row seats		
1-2	-	-	0
1-2	-	-	0 (0.5 ²)
1-2	3	-	1 (0.5 ²)
1-2	3	Max ¹	3 (0.5 ²)
1	-	Max ¹	4 (1.5 ²)

¹ See **Vehicle identification** (page 242).

² Vehicles with active suspension.

Lighting


HAZARD WARNING FLASHERS



Note: Depending on applicable laws and regulations in the country for which your vehicle was originally built, the hazard warning flashers may flash if you brake heavily.

For item location: See **Quick start** (page 10).

ADAPTIVE FRONT LIGHTING SYSTEM (AFS)



E72897

- A without AFS
- B with AFS


Lighting

The AFS adjusts the headlamp dipped beam depending on vehicle direction and speed. It improves visibility when you are driving at night and helps to reduce headlamp glare for oncoming drivers.

The system will not operate when the vehicle is stationary, when you have switched on the daytime running lamps or when you have selected reverse gear.

A message will appear in the information display if the system malfunctions. See **Information messages** (page 99). The headlamps will move to a fixed central or dipped position. Have the system checked as soon as possible.

Cornering lamps




E72898

- A Headlamp beam
- B Cornering lamp beam

The cornering lamps illuminate the inside of a corner when you are turning.

Lighting

DIRECTION INDICATORS




E70727

Note: Tap the lever up or down to make the direction indicators flash only three times.

INTERIOR LAMPS

Courtesy lamp



E71945


- A Off
- B Door contact
- C On

If you set the switch to position **B**, the courtesy lamp will come on when you unlock or open a door or the luggage compartment lid. If you leave a door open with the ignition switch off, the courtesy lamp will go off automatically after some time to prevent the vehicle battery from discharging. To switch it back on, switch on the ignition for a short time.

The courtesy lamp will also come on when you switch off the ignition. It will go off automatically after a short time or when you start or restart the engine.

If you set the switch to position **C** with the ignition switch off, the courtesy lamp will come on. It will go off automatically after a short time to prevent the vehicle battery from discharging. To switch it back on, switch on the ignition for a short time.

Reading lamps




E71946

If you switch off the ignition, the reading lamps will go off automatically after some time to prevent the vehicle battery from discharging. To switch them back on, switch on the ignition for a short time.

Lighting

Vanity mirror lamps



E72900

- A Off
- B On

If you switch off the ignition, the vanity mirror lamps will go off automatically after a short time to prevent the vehicle battery from discharging. To switch them back on, switch on the ignition for a short time.


REMOVING A HEADLAMP

WARNING




Have Xenon bulbs changed by a trained technician. There is a risk of electric shock.

1. Open the bonnet. See **Opening and closing the bonnet** (page 203).



E85995


2. Remove the screws.



E88843


3. Remove the plastic screw and retainer.

Lighting



E85996


4. Carefully pull the corner of the grille and bumper towards the front of the vehicle.
5. Carefully lift the corner of the headlamp and push it as far as possible towards the back of the vehicle.



E88982

6. Carefully pull the headlamp towards the centre of the vehicle, behind the grille and bumper, to disengage it from the lower outer fixing point.
7. Remove the headlamp.

CAUTION




 When fitting the headlamp, take care not to damage the locating points.

Note: When fitting the headlamp, make sure that you fully engage the headlamp in the lower outer fixing point.



Note: When fitting the headlamp, tighten the front screw first and then the rear screw.

CHANGING A BULB

WARNINGS

-  Switch the lights and the ignition off.
-  Let the bulb cool down before removing it.
-  Have Xenon bulbs changed by a trained technician. There is a risk of electric shock.

CAUTIONS

-  Do not touch the glass of the bulb.
-  Only fit bulbs of the correct specification. See **Bulb specification chart** (page 71).

Note: The following instructions describe how to remove the bulbs. Fit replacements in the reverse order unless otherwise stated.


Lighting

Headlamp

Note: Remove the covers to gain access to the bulbs.

Direction indicator

1. Remove the headlamp. See **Removing a headlamp** (page 62).




E72259

2. Turn the bulb holder anti-clockwise and remove it.
3. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Headlamp main beam

1. Remove the headlamp. See **Removing a headlamp** (page 62).




E72261

2. Disconnect the electrical connector.
3. Release the clip and remove the bulb.

Headlamp dipped beam

1. Remove the headlamp. See **Removing a headlamp** (page 62).




E72260

2. Turn the bulb holder anti-clockwise and remove it.
3. Remove the bulb.

Lighting

Cornering lamp


1. Remove the headlamp. See **Removing a headlamp** (page 62).



E72262

2. Disconnect the electrical connector.
3. Release the clip and remove the bulb.

Side repeaters



E85999

1. Carefully remove the side repeater.

2. Hold the bulb holder, turn the housing anti-clockwise and remove it.
3. Remove the bulb.


Approach lamp



E72264

Note: Position the mirror glass as far inwards as possible.

1. Insert a screwdriver into the gap between the mirror housing and the mirror glass and release the metal retaining clip.




E72265

Lighting

2. Remove the lamp.
3. Remove the bulb.

Front fog lamps




Note: You cannot separate the fog lamp bulb from the bulb holder.

Note: Do not remove the screws.

1. Loosen the screws.
2. Remove the lamp.
3. Disconnect the electrical connector.
4. Turn the bulb holder anti-clockwise and remove it.

Rear lamps

Direction indicator, tail and brake lamp




1. Remove the trim panel.



2. Unclick the bulb holder.

Lighting




E86005

- A Direction indicator
- B Tail and brake lamp


3. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Reversing lamp, tail lamp and fog lamp




E86006

1. Remove the trim panel.



E86007

2. Unclip the bulb holder.



E86008

- A Reversing lamp
- B Tail lamp
- C Fog lamp

3. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Lighting

Central high mounted brake lamp

Remove the trim panel


4-door



E87617

1. Detach the clips.

5-door



E87618

1. Remove the screws.
2. Detach the clips.


Estate



E87619

1. Detach the clips.

Remove the lamp



E87620


1. Insert a suitable object into the holes.
2. Carefully pull the lamp towards the front of the vehicle to release the spring clips.

Lighting



E86002


3. Remove the lamp.



E79601

4. Unclip the bulb holder.
5. Remove the bulb.

Number plate lamp




E72789

1. Carefully release the spring clip.
2. Remove the lamp.
3. Remove the bulb.

Interior lamp

Vehicles without interior sensors




E72788

1. Carefully prise out the lens.
2. Remove the lens.
3. Remove the bulb.

Lighting

Vehicles with interior sensors



E72787

1. Carefully prise out the lens.
2. Remove the lens.
3. Remove the bulb.

Reading lamps

Vehicles without interior sensors




E72796

1. Carefully prise out the lens.
2. Remove the lens.


3. Remove the bulb.

Vehicles with interior sensors



E72786

1. Carefully prise out the lamp.
2. Turn the bulb holder anti-clockwise and remove it.




E73939

3. Remove the bulb.

Lighting


Vanity mirror lamp



E72785

1. Carefully prise out the lamp.
2. Remove the bulb.

Luggage compartment lamp



E72784

1. Carefully prise out the lamp.
2. Remove the bulb.

BULB SPECIFICATION CHART

Lamp	Specification	Power (watt)
Front direction indicator	PY21W	21
Headlamp main beam	H1	55
Headlamp dipped beam	H7	55
Cornering lamp	H1	55
Side repeater	W5W	5
Approach lamp	W5	5
Front fog lamp	H8	35 ¹
Front fog lamp	H11	55 ¹
Side lamp	W5W	5
Rear direction indicator	PY21W	21

Lighting


Lamp	Specification	Power (watt)
Brake and tail lamp	P21/5W	21/5
Tail lamp	P21/4W	4
Rear fog lamp	P21/5W	21/5
Reversing lamp	P21W	21
Central high mounted brake lamp	5 x W5W	5
Number plate lamp	W5W	5
Interior lamp	Festoon	10
Reading lamp	BA 9s	5
Vanity mirror lamp	W5W	5
Luggage compartment lamp	W5W	5

¹Fit a replacement with the same rating as the one you have removed.

Windows and mirrors

ELECTRIC WINDOWS

WARNING

 Do not operate the electric windows unless they are free from obstruction.

Note: If you operate the switches often during a short period of time, the system might become inoperable for a certain time to prevent damage due to overheating.

Note: You can operate the windows for several minutes after you switch off the ignition. They will be deactivated as soon as a door is opened.

Note: If you operate both the switch on the relevant door and the switch for that window on the driver's door at the same time, the window will stop moving.

Switch on the ignition to operate the electric windows.

Global opening and global closing

You can also operate the electric windows with the ignition off via the global opening and global closing function. See **Global opening and closing** (page 38).

Note: Global opening and global closing will open or close the windows automatically only on vehicles equipped with four electric windows.

Note: Global closing will only operate if you have set the memory correctly for each window.


Driver's door switches



E70848

You can operate all the windows with the switches on the door trim panel of the driver's door.

Front and rear passengers' door switches



E70849

Windows and mirrors

Opening and closing the windows automatically

Press or lift the switch to the second action point and release it. Press or lift it again to stop the windows.

Safety switch for rear windows

Note: *You can always operate the rear windows from the driver's door.*




E70850

A switch in the driver's door disables the rear electric window switches.

The light in the switch illuminates and the lights in the rear window switches go off when the rear windows are disabled.

Anti-trap function


WARNING

 Careless closing of the windows can override the protection function and cause injuries.

The electric windows will stop automatically while closing and reverse some distance if there is an obstacle in the way.

Overriding the anti-trap function

CAUTION

 While you close the window for the third time, the anti-trap function is disabled. Make sure there are no obstacles in the way of the closing window.


To override this protection function when there is a resistance, for example, in the winter, proceed as follows:

1. Close the window twice until it reaches the resistance and let it reverse.
2. Close the window a third time to the resistance. The anti-trap function is disabled and you cannot close the window automatically. The window will override the resistance and you can close it fully.
3. If the window does not close after the third attempt, have it checked by a properly trained technician.

Windows and mirrors

Resetting the memory of the electric windows

WARNING


 The anti-trap function is deactivated until you have reset the memory.

After the battery has been disconnected from the vehicle you must reset the memory separately for each window:

1. Lift the switch until the window is fully closed. Hold the switch lifted for one more second.
2. Release the switch and lift it again, two or three times, for one more second.
3. Open the window and try to close it automatically.
4. Reset and repeat procedure if the window does not close automatically.

Safety mode

WARNING

 The anti-trap function is not active during this procedure.

If the system detects a malfunction, it enters a safety mode. The windows will move for only about 0.5 seconds at a time and then stop again. Close the windows by pressing the switch again when the windows stop moving. Have this checked immediately.


EXTERIOR MIRRORS

Convex mirrors




E71042

WARNING

 Do not overestimate the distance of the objects that you see in the convex mirror. Objects seen in convex mirrors will appear smaller and further away than they actually are.

Folding mirrors




E71043

Make sure that you fully engage the mirror in its support when returning it to its original position.

Windows and mirrors


ELECTRIC EXTERIOR MIRRORS



E70846

- A Left-hand mirror
- B Off
- C Right-hand mirror

Mirror tilting positions



E70847

The electric exterior mirrors are fitted with a heating element that will defrost or demist the mirror glass. See **Heated windows and mirrors** (page 116).

Electric folding mirrors

The electric folding mirrors operate with the ignition on.

Note: You can operate the mirrors (mirror tilting and folding) for several minutes after you switch off the ignition. They will be deactivated as soon as a door is opened.



E72623

Press the button to fold or unfold the mirrors.

If you press the switch again while the mirrors are moving, they will stop and reverse the direction of movement.

Windows and mirrors

Note: When the mirrors are operated often during a short period of time, the system may become inoperable for a period of time to prevent damage due to overheating.

Reverse mirror dipping

Depending on the selected mirror position (**A** or **C**), the relevant exterior mirror will dip whenever you select reverse gear, giving you a view of the kerb.

When you first use this feature, the mirrors will dip to a preset position. You can programme the degree of dipping using the following sequence:

Note: You can disable this feature by leaving the electric exterior mirror selector switch in position **B**.

The exterior mirrors will return to the original position:

- If the vehicle speed exceeds 10 km/h (6 mph).
- Approximately 10 seconds after reverse gear has been disengaged.
- If the electric exterior mirror selector switch is returned to position **B**.

Passive setting

1. Turn the ignition on. Do not start the engine.
2. Select the desired exterior mirror (**A** or **C**).
3. Select reverse gear, the selected exterior mirror will adjust to a preset position.

4. Adjust the mirrors to the required dipped position.


5. Disengage reverse gear.

The settings will be stored automatically.

Active setting

1. Turn the ignition on. Do not start the engine.
2. Select the desired exterior mirror (**A** or **C**).
3. Select reverse gear, the selected exterior mirror will adjust to a preset position.
4. Adjust the mirror to the required dipped position.
5. Press and hold the desired pre-set button until a single chime sounds to confirm. See **Memory function** (page 133).


INTERIOR MIRROR



Dip the mirror to reduce glare when driving at night.

Windows and mirrors

AUTO-DIMMING MIRROR




E71028

The auto-dimming mirror will adjust automatically when hit by glaring light from behind. It will not work when you have selected reverse gear.

Instruments

GAUGES

Type 1 and 2




E72984

- A Tachometer
- B Engine coolant temperature gauge
- C Fuel gauge
- D Speedometer

Instruments

Type 3



E87713

- A Tachometer
- B Speedometer
- C Engine coolant temperature gauge
- D Fuel gauge
- E Message centre. See **Information displays** (page 85).

Engine coolant temperature gauge

Shows the temperature of the engine coolant. At normal operating temperature, the needle will remain in the centre section.

CAUTION



Do not restart the engine until the cause of overheating has been resolved.

Instruments

If the needle moves towards 120°C, the engine is overheating. Stop the engine, switch the ignition off and determine the cause **once the engine has cooled down**. See **Engine coolant check** (page 214).

Fuel gauge

The arrow adjacent to the fuel pump symbol tells you on which side of your vehicle the fuel filler cap is located.

WARNING LAMPS AND INDICATORS

The following warning lamps and indicators will illuminate briefly when you switch the ignition on to confirm that the system is operational:

- ABS
- Airbag
- Brake system
- Engine
- Frost
- Ignition
- Oil pressure (all except 2.5L Duratec-ST)
- Stability control (ESP).

If a warning or indicator lamp does not illuminate when the ignition is switched on, it indicates a malfunction. Have the system checked by properly trained technician.

ABS warning lamp



It will flash when the system is operating. If it illuminates when driving, this indicates a malfunction. Have the system checked by a properly trained technician. You will continue to have normal braking (without ABS) but have this checked as soon as possible.

Airbag warning lamp



If it does not illuminate, if it stays on or illuminates intermittently or continuously while driving, this indicates a malfunction. Have the system checked by a properly trained technician.

Brake system warning lamp

WARNING



Reduce your speed gradually. Use your brakes with great care. Do not step on the brake pedal abruptly.



If it illuminates when you are driving, this indicates a malfunction in one of the brake circuits. Check the brake fluid level. See **Brake and clutch fluid check** (page 215).

WARNING



Have this checked immediately.

Instruments

If the brake system warning lamp illuminates with the ABS warning lamp or the stability control (ESP) warning lamp, this indicates a malfunction. Stop your vehicle as soon as it is safe to do so and have this checked before continuing your journey.

Cruise control indicator



It will illuminate when you have set a speed using the cruise control system. See

Using cruise control (page 161). On vehicles with adaptive cruise control (ACC), the indicator will illuminate when ACC is active. See

Using ACC (page 165).

Direction indicators



Flashes during operation. A sudden increase in the rate of flashing warns of a failed

indicator bulb. See **Changing a bulb** (page 63).

Engine warning lamp



If it illuminates with the engine running, this indicates a malfunction. If it flashes when you are driving,

reduce the speed of your vehicle immediately. If it continues to flash, avoid heavy acceleration or deceleration. Have the system checked by a properly trained technician immediately.

Forward alert indicator



It will illuminate when this feature is active. See

Forward alert function (page 168).

Front fog lamp indicator



It will illuminate when you switch the front fog lamps on.

Frost warning lamp



It will illuminate and glow orange when the outside air temperature is between 4°C (39.2°F) and 1°C (33.8°F). It will glow red when the temperature is below 1°C (33.8°F).

Glow plug indicator



See **Starting a diesel engine** (page 140).

Headlamp indicator



It will illuminate when you switch the headlamp dipped beam or the side and tail lamps on.

Instruments

Ignition warning lamp



If it illuminates when you are driving, this indicates a malfunction. Switch off all unnecessary electrical equipment. Have the system checked by a properly trained technician immediately.

Low fuel level warning lamp



If it illuminates, refuel as soon as possible.

Main beam indicator



It will illuminate when you switch the headlamp main beam on. It will flash when you use the headlamp flasher.

Maximum engine speed indicator



It will illuminate when the maximum engine speed is reached.

Message indicator



It will illuminate when a new message is stored in the information display. See **Information messages** (page 99).

Oil pressure warning lamp

CAUTION



Do not resume your journey if the oil pressure warning lamp illuminates despite the oil level being correct. Have the system checked by a properly trained technician immediately.



If the lamp stays on after starting or illuminates during a journey, this indicates a malfunction. Stop your vehicle as soon as it is safe to do so and switch the engine off. Check the engine oil level. See **Engine oil check** (page 213).

Rear fog lamp indicator



It will illuminate when you switch the rear fog lamps on.

Seat belt reminder



See **Seat belt reminder** (page 31).

Instruments

Stability control (ESP) warning lamp



While driving, it flashes during activation of the system. After switching on the ignition, if it does not illuminate or illuminates continuously while driving, this indicates a malfunction. During a malfunction, the system switches off. Have the system checked by a properly trained technician as soon as possible.

If you switch ESP off, the warning lamp will illuminate. The lamp will go out when you switch the system back on or when you switch the ignition off.

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Chimes** and press the right arrow button.
4. Highlight the chime and press the **OK** button to switch the chime on and off.
5. Press the left arrow button to exit the menu. Hold the left arrow button pressed to return to the trip computer display.

AUDIBLE WARNINGS AND INDICATORS

Switching the chimes on and off

You can deactivate certain chimes.
To set which chimes should sound:



E70499

Information displays

GENERAL INFORMATION

WARNING




Do not operate the information display controls when the vehicle is moving.

Note: *The information display will remain on for several minutes after you switch off the ignition.*

Various systems on your vehicle can be controlled using the buttons on your steering wheel. Corresponding information is displayed in the information display.

For detailed instructions on audio, navigation, phone etc. refer to the appropriate manual.

Controls



E70499

Press the **up** and **down** arrow buttons:

- to scroll through the trip computer displays
- to scroll through and highlight the options within a menu.

Press the **right** arrow button:

- to enter the main menu from the trip computer displays
- to enter a sub-menu.

Press the **left** arrow button to exit a menu.

Hold the **left** arrow button pressed at any time to return to the main menu display (escape button).

Note: *The system will return to the trip computer displays automatically if you do not press any button for a period of time.*

Press the **OK** button to choose and confirm a setting.


Instrument cluster functions

Function	Type 1	Type 2	Type 3
Trip computer	X	X	X
Information messages	X	X	X

Information displays

Function	Type 1	Type 2	Type 3
Clock setup	X	X	X
Display settings	-	X	X
Park heater setup	-	X	X
Navigation control	-	-	X
CD control	-	-	X
CD changer control	-	-	X
Radio control	-	-	X
Phone control	-	-	X
Auxiliary input control	-	-	X

Type 1


09:00
Ø  102 km/h
123456 km 234.2 km

Press the **up** and **down** arrow buttons on the steering wheel to scroll through the trip computer displays. See **Trip computer** (page 94).

E80604


Information displays

Menu structure



E87751

Type 2


09:00
 Average Fuel 6.3 $\frac{l}{100km}$
123456 km 234.2 km

E74426

Press the **up** and **down** arrow buttons on the steering wheel to scroll through the trip computer displays. See **Trip computer** (page 94).


Information displays

Menu structure



E87752

Information displays



E87753

Information displays

Type 3



E88048

Use the controls to scroll through the menu displays.

Note: After a short period of time, the display will enter a screen saver mode. To access the menus from here, press the **left** arrow button.

Device list

The highlighted icon shows the current menu in use.

-  Navigation
-  CD
-  CD changer
-  Radio
-  Phone
-  Trip computer
-  Settings
-  Auxiliary input

Information displays

Menu structure

Navigation



CD



CD changer



Radio



Phone



- Home
- Destinat. mem. — Destinations
- Destinat. A-Z — Destinations
- Last destinat. — Destinations
- Cancel guidan.

— Folder / Tracks


- CD 1 — Folder / Tracks
- CD 2 — Folder / Tracks
- CD 3 — Folder / Tracks
- CD 4 — Folder / Tracks
- CD 5 — Folder / Tracks
- CD 6 — Folder / Tracks

- Station list — Stations
- FM 1 / FM — Stations
- FM 2 — Stations
- FM 3 — Stations
- FM - AST — Stations
- MW / AM — Stations
- LW / AM-AST — Stations


- Phone book — Numbers
- Redial
- Incoming calls — Numbers
- Outgoing calls — Numbers
- Call status

E87754

Information displays




Information displays



E87756

Information displays



TRIP COMPUTER

Odometer

Registers the total mileage of the vehicle.

Tripmeter

Registers the mileage of individual journeys.

Distance to empty

Indicates the approximate distance the vehicle will travel on the fuel remaining in the tank. Changes in driving pattern may cause the value to vary.

Average fuel consumption

Indicates the average fuel consumption since the function was last reset.

Information displays


Average speed

Indicates the average speed calculated since the function was last reset.

Outside air temperature

Shows the outside air temperature.


Type 1 and 2



E74428

- A Trip computer
- B Odometer
- C Tripmeter

The trip computer includes the following information displays:



E74441

Press the **up** and **down** arrow buttons on the steering wheel to scroll through the trip computer displays.

Note: The position of the trip computer display may vary depending on the information shown in the display.

Resetting the trip computer using the main menu

To reset a particular display:

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Reset Trip** with the up and down arrow buttons and press the right arrow button.
3. Highlight the function to be reset.
4. Press the right arrow button to select the function.
5. Hold the **OK** button pressed.

To reset all three displays, select **All values** and hold the **OK** button pressed.

Information displays

Type 3



E88049

A Trip computer

Resetting the trip computer using the main menu

To reset a particular display:

1. Highlight **Trip Computer** with the up and down arrow buttons and press the right arrow button.
2. Highlight the function to be reset.
3. Hold the **OK** button pressed.

PERSONALISED SETTINGS

The following information is displayed in the information display if you have selected it:

Help screen, radio, navigation and phone information

The help screen appears for a few seconds when you switch the ignition on.

If the radio, navigation or telephone is operating, information relating to this system is displayed in the information display.

To select which information is displayed in the information display:

Type 1 and 2

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Display** and press the right arrow button.
4. Highlight **Configure** and press the right arrow button.
5. To toggle the **Help screen**, **Radio Info** and **Phone Info** on and off, highlight the desired setting and press the **OK** button to confirm the setting.
6. Press the left arrow button to exit the menu. Hold the left arrow button pressed to return to the trip computer display.

Type 3

1. Highlight **Settings** with the up and down arrow buttons and press the right arrow button.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Display** and press the right arrow button.

Information displays

4. Highlight **Configure** and press the right arrow button.
5. To toggle the **Help screen** and **NAV Info** on and off, highlight the desired setting and press the **OK** button to confirm the setting.

Navigation information

You can also choose when the navigation information is displayed in the information display. Three options are available:

- **Always off:** No navigation information is displayed in the information display.
- **On guidance:** The navigation information will only appear when the navigation system provides a guidance instruction. This function is only available on certain navigation systems.
- **Always on:** Navigation information will always appear in the information display when the navigation system is operating.

To set when navigation information should be displayed:

Type 1 and 2

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Display** and press the right arrow button.

4. Highlight **Configure** and press the right arrow button.
5. Highlight **Nav Info** and press the right arrow button.
6. Highlight the desired setting and press the **OK** button to confirm the setting.
7. Press the left arrow button to exit the menu. Hold the left arrow button pressed to return to the trip computer display.

Type 3

1. Highlight **Settings** with the up and down arrow buttons and press the right arrow button.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Display** and press the right arrow button.
4. Highlight **Configure** and press the right arrow button.
5. Highlight **Nav Info** and press the right arrow button.
6. Highlight the desired setting and press the **OK** button to confirm the setting.

Language

A choice of eleven languages are available:

English, German, Italian, French, Spanish, Turkish, Russian, Dutch, Polish, Swedish and Portuguese.

Information displays

Type 1 and 2

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Display** and press the right arrow button.
4. Highlight **Language** and press the right arrow button.
5. Highlight the desired setting and press the **OK** button to confirm the setting.
6. Press the left arrow button to exit the menu. Hold the left arrow button pressed to return to the trip computer display.

Type 3

1. Highlight **Settings** with the up and down arrow buttons and press the right arrow button.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Display** and press the right arrow button.
4. Highlight **Language** and press the right arrow button.
5. Highlight the desired setting and press the **OK** button to confirm the setting.

Units of measure

Note: *The outside air temperature is only displayed in degrees Celsius and cannot be set to degrees Fahrenheit.*

To select metric or imperial units:

Type 1 and 2

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Display** and press the right arrow button.
4. Highlight **Measure Unit** and press the right arrow button.
5. Highlight the desired setting and press the **OK** button to confirm the setting.
6. Press the left arrow button to return to exit the menu. Hold the left arrow button pressed to return to the trip computer display.

Type 3

1. Highlight **Settings** with the up and down arrow buttons and press the right arrow button.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Display** and press the right arrow button.

Information displays

4. Highlight **Measure Unit** and press the right arrow button.
5. Highlight the desired setting and press the **OK** button to confirm the setting.

INFORMATION MESSAGES



E70499

Press **OK** to acknowledge and remove some messages from the information display. Other messages will be removed automatically after a short time.

With instrument cluster type 3, certain messages need to be confirmed before you can access the menus.

Message indicator



The message indicator illuminates to supplement some messages. It will be red or amber depending on the severity of the message and will remain on until the cause of the message has been rectified.

Message symbols



See Owner's handbook.



Have the system checked at the next service.



Have the system checked as soon as possible.



Stop your vehicle as soon as it is safe to do so.

Viewing current messages

Type 1 and 2

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Information** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Messages** and press the right arrow button.
4. Use the up and down buttons to view the current messages.

Type 3

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Settings** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Information** with the up and down arrow buttons and press the right arrow button.

Information displays

4. Highlight **Messages** and press the right arrow button.
5. Use the up and down buttons to view the current messages.

Active suspension

Message	Message warning lamp	Meaning
IVDC malfunction	amber	The active suspension has malfunctioned. Have this checked as soon as possible. See Using active suspension (page 158).
IVDC comfort	-	The active suspension is set to the comfort setting.
IVDC normal	-	The active suspension is set to the normal setting.
IVDC sport	-	The active suspension is set to the sport setting.

Alarm

Message	Message warning lamp	Meaning
Alarm triggered	amber	The alarm has been triggered. Check your vehicle for signs of unauthorised access.
Alarm system service reqd.	-	The alarm has malfunctioned. Have this checked as soon as possible.

Information displays

Battery and charging system

Message	Message warning lamp	Meaning
Overvoltage: Stop safely!	red	The charging system voltage is above its normal operating range. Stop your vehicle as soon as it is safe to do so and switch off the ignition. Have this checked as soon as possible.
Low battery	amber	The battery voltage is low. Have this checked as soon as possible.

Climate control

Message	Message warning lamp	Meaning
Aux. Heater on	amber	The auxiliary heater is on.

Cruise control / Adaptive cruise control (ACC)

Message	Message warning lamp	Meaning
Cruise control active	-	Cruise control is on.
Cruise control standby	-	Cruise control is on standby.
ACC unavailable	-	Stability control (ESP) may be switched off. Switch ESP back on and try ACC again. Otherwise try switching the ignition off and on to clear this message.
ACC malfunction	amber	The ACC has malfunctioned. Have this checked as soon as possible.

Information displays

Message	Message warning lamp	Meaning
Clean radar sensor	amber	There may be something blocking the radar sensor. Clear any dirt, snow, water or other objects from the front grille area.
Forward Alert malfunction	amber	Forward alert has malfunctioned. Have this checked as soon as possible.

Doors open

Message	Message warning lamp	Meaning
Driver door open	red	The driver side front door is open.
Driver side rear door open	red	The driver side rear door is open.
Passenger door open	red	The passenger side front door is open.
Passenger side rear door open	red	The passenger side rear door is open.
Luggage comp. open	red	The luggage compartment is open.
Bonnet open	red	The bonnet is open.

Engine immobiliser

Message	Message warning lamp	Meaning
Immobiliser active	amber	The engine immobiliser is on. See Engine immobiliser (page 44).

Information displays

Hill launch assist (HLA)

Message	Message warning lamp	Meaning
Hill Launch not available	amber	HLA has malfunctioned. Have this checked as soon as possible.
Hill Launch Assist active	-	HLA is on.
Hill Launch Assist off	-	HLA is off.
Please use park brake !	amber	HLA is deactivated due to a malfunction. Use the parking brake normally on hills. See Hill launch assist (HLA) (page 155).

Keyless system

Message	Message warning lamp	Meaning
Steering malfunction	red	The steering system has malfunctioned. Have this checked as soon as possible.
Key not detected	amber	A valid passive key has not been recognised.
Car operative Press STOP	amber	The engine is still running. Switch the ignition off. See Keyless starting (page 136).
Key outside car	amber	A valid passive key has not been detected inside the vehicle.
Key battery low	amber	Change the battery as soon as possible.
Steering locked - Retry	-	The steering lock is still active. Press the start button.

Information displays

Lighting

Message	Message warning lamp	Meaning
Front lights malfunction	amber	The adaptive front lighting system (AFS) has malfunctioned. Have this checked as soon as possible.
Low beam: Bulb fault	-	One or both of the headlamp dipped beam bulbs have blown. Check the headlamp dipped beam bulbs. See Changing a bulb (page 63).
Rear fog light: Bulb fault	-	One or both of the rear fog lamp bulbs have blown. Check the rear fog lamp bulbs. See Changing a bulb (page 63).
Stop lamps: Bulb fault	-	One or both of the brake lamp bulbs have blown. Check the brake lamp bulbs. See Changing a bulb (page 63).
Trailer stopl.: Bulb fault	-	One or both of the brake lamp bulbs on your trailer have blown. Check the brake lamp bulbs on your trailer.
Trailer turnl.: Bulb fault	-	One or both of the direction indicator bulbs on your trailer have blown. Check the direction indicator bulbs on your trailer.

Maintenance

Message	Message warning lamp	Meaning
Engine malfunction	red	The engine system has malfunctioned. Have this checked as soon as possible.
Check engine oil level	amber	The engine oil level is low. Check the engine oil level as soon as possible. See Engine oil check (page 213).

Information displays

Message	Message warning lamp	Meaning
Water detected in fuel	amber	There is water in the fuel. Have this checked as soon as possible.
Low washer fluid level	-	The washer fluid level is low. Check the washer fluid level. See Washer fluid check (page 216).
Service oil	-	The engine oil needs to be changed. Have the engine oil changed as soon as possible.

Occupant protection

Message	Message warning lamp	Meaning
Crash mode	-	Have the system checked as soon as possible.

Power steering

Message	Message warning lamp	Meaning
Power steering malfunction	amber	The power steering system has malfunctioned. Have this checked as soon as possible.

Information displays

Stability control (ESP)

Message	Message warning lamp	Meaning
ESP off	-	Stability control is off.
ESP malfunction	-	Stability control has malfunctioned. Have this checked as soon as possible.

Transmission

Message	Message warning lamp	Meaning
Transmission malfunction	red	The transmission has malfunctioned. Have this checked as soon as possible.
Transmission overtemperature	amber	The transmission is over heating. Have this checked as soon as possible.

Tyre pressure monitoring system

Message	Message warning lamp	Meaning
Check tyre!	red	The tyre indicated has continued to deflate. Check the tyre and inflate it to the recommended pressure. See Technical specifications (page 238).
Check tyre pressures	red	One or more of the tyres are significantly under-inflated. This message may be displayed after a new sensor has been installed. Check the tyres and inflate them to the recommended pressure. See Technical specifications (page 238).

Information displays

Message	Message warning lamp	Meaning
Check tyre	amber	The tyre indicated is significantly under-inflated. Check your tyres and inflate them to the recommended pressure. See Technical specifications (page 238).
Tyre monitor malfunction	amber	You have installed a temporary spare wheel. Install a correctly inflated full size wheel with a sensor as soon as possible. When a malfunction occurs, the system may not be able to detect or signal low tyre pressure.
		Up to three sensors have malfunctioned, an unapproved accessory is interfering with the system or a general malfunction has been detected. Have the system checked as soon as possible. When a malfunction occurs, the system may not be able to detect or signal low tyre pressure.
Inflate tyres for high speed	amber	The tyre pressures are not suitable for driving at 160 km/h (100 mph). Inflate the tyres to the recommended pressure. See Technical specifications (page 238). This message will be displayed for only a few seconds with a low tyre pressure warning.
Tyre sensors not detected	-	You have installed wheels and tyres that do not have sensors. The tyre pressures will not be monitored.
		All sensors have malfunctioned or an unapproved accessory is interfering with the system. Have this checked as soon as possible.

Information displays

Voice control

Message	Message warning lamp	Meaning
Voice control Please speak	-	Voice control is on.
Voice control Not recognised	-	Check voice control.
Voice control Not allowed	-	Voice control is not allowed in this mode.

Climate control


PRINCIPLE OF OPERATION

Outside air

Keep the air intakes forward of the windscreen free from obstruction (snow, leaves etc.) to allow the climate control system to function effectively.

Recirculated air

CAUTION

 Prolonged use of recirculated air may cause the windows to mist up. If the windows mist up, follow the settings for defrosting and demisting the windscreen.

The air currently in the passenger compartment will be recirculated. Outside air will not enter the vehicle.

Heating

Heating performance depends on the temperature of the engine coolant.

Air conditioning

Note: The air conditioning operates only when the temperature is above 4°C (39°F).

Note: If you use the air conditioning, the fuel consumption of your vehicle will be higher.

Air is directed through the evaporator where it is cooled. Humidity is extracted from the air to help keep the windows free of mist. The resulting condensation is directed to the outside of the vehicle and it is therefore normal if you see a small pool of water under your vehicle.

General information on controlling the interior climate

Fully close all the windows.

Warming the interior

Direct the air towards your feet. In cold or humid weather conditions, direct some of the air towards the windscreen and the door windows.

Cooling the interior

Direct the air towards your face.

AIR VENTS


Front air vents



E71942

Climate control

Rear air vents




E89129

- A Open
- B Close

MANUAL CLIMATE CONTROL

Blower



E75470

- A Off


Note: If you switch the blower off, the windscreen may mist up.

Temperature control



E75471

Air distribution control



E71379

- A Windscreen
- B Footwell and windscreen
- C Footwell
- D Face level and footwell
- E Face level
- F Face level and windscreen

You can set the air distribution control to any position between the symbols.


Climate control

Recirculated air



Press the button to toggle between outside air and recirculated air.

Heating the interior quickly



E71377

Ventilation



E71378

Set the air distribution control, blower and air vents to suit your requirements.


Air conditioning

Switching the air conditioning on and off




If you turn the blower off, the air conditioning will turn off. When you turn the blower on again, the air conditioning will come on automatically.

Cooling with outside air



E71380


Cooling the interior quickly



E71381

Climate control

Defrosting and demisting the windscreen



E71382

When the temperature is above 4°C (39°F), the air conditioning will switch on automatically. Make sure that the blower is on. The indicator in the switch will illuminate during defrosting and demisting.


If you move the air distribution control to a position other than **A**, the **A/C** will remain on.

You can switch the air conditioning and recirculated air on and off while the air distribution control is set to position **A**.

If necessary, switch the heated windows on. See **Heated windows and mirrors** (page 116).

Note: To defrost or demist the rear side windows, set the second row air vents to the defrosting and demisting position. See **Air vents** (page 109).

Reducing interior air humidity



E71383

Climate control

AUTOMATIC CLIMATE CONTROL

Automatic climate control



E80737

The system controls the temperature, amount and distribution of the air flow automatically and adjusts them according to the driving and weather conditions. Press the **AUTO** button to switch auto mode on.

The system in your vehicle is dual-zone automatic climate control. When the system is in mono mode, all the temperature zones are linked to the driver's zone. When you switch mono mode off, the dual-zone system allows you to set different temperatures for the driver's and front passenger's side.

Note: Avoid adjusting the settings when the vehicle interior is extremely hot or cold. The automatic climate control adjusts to the current circumstances automatically. For the system to function properly, the side and centre vents should be fully open.

Note: At low outside temperatures, when the system is in auto mode, the air stream will be directed to the windscreen and the side windows as long as the engine is cold.

Note: For information on the automatic climate control, on vehicles fitted with a combined Navigation and automatic climate control system, see separate handbook.

Climate control

Setting the temperature



E70304

You can set the temperature between 16°C (61°F) and 28°C (82°F) in steps of 0.5°C (1°F). In position **LO** (below 16°C [61°F]) the system will switch to permanent cooling, in position **HI** (above 28°C [82°F]) to permanent heating, and will not regulate a stable temperature.

Mono mode

In mono mode, the temperature settings for both the driver's and passenger's side are linked. If you adjust the temperature using the rotary control on the driver's side, the same temperature will be set for the passenger's side. **MONO** is shown in the display.

To switch mono mode off

Select a temperature for the passenger's side using the rotary control on the passenger's side. Mono mode will switch off and **MONO** disappears from the display. The temperature for the driver's side will remain unchanged. You can now adjust the driver's and passenger's side temperatures independently of each other. The temperatures are shown in the display. You can set a difference of up to 4°C (7°F).

Note: If you set a difference of greater than 4°C (7°F), the temperature on the other side will be adjusted so that the difference remains at 4°C (7°F).

Note: If you set one of the sides to **HI** or **LO**, both sides will be set to **HI** or **LO**.

To switch mono mode back on



Press the **MONO** button. **MONO** is shown in the display, and the passenger's side temperature will be adjusted to the driver's side temperature.

Blower

High speed



Low speed



Use the buttons to adjust the blower speed.

The blower setting is shown in the display.




To return to auto mode, press the **AUTO** button.

Climate control

Air distribution

To adjust air distribution, press the desired button. Any combination of settings can be selected simultaneously.



E70308

- A Footwell
- B Face level
- C Windscreen

Windscreen defrosting and demisting



When you select windscreen defrosting and demisting, **A**, **B** and **C** switch off automatically and the air conditioning switches on. Outside air will flow into the vehicle. You cannot select recirculated air.

The blower speed and the temperature control operate automatically and cannot be adjusted manually. The blower is set to high speed and the temperature to **HI**.

When you select windscreen defrosting and demisting, the heated screens switch on automatically and switch off after a short time.

To return to auto mode, press the **AUTO** button.

Note: To defrost or demist the rear side windows, adjust the rear air vents. See **Air vents** (page 109).

Switching the air conditioning on and off



Press the button. **A/C OFF** or **A/C ON** is shown in the display.

Recirculated air



Press the button to change between outside air and recirculated air.

Note: When the system is in auto mode and the interior and exterior air temperatures are quite hot, the system selects recirculated air automatically to maximise cooling of the interior. Once the selected temperature is reached, the system will automatically reselect outside air.

Switching the automatic climate control on and off



E70980

Climate control

Use the buttons to switch the system on and off.

When switched off, the heating, ventilation and air conditioning system is switched off and recirculated air is selected.

HEATED WINDOWS AND MIRRORS

Heated windows

Use the heated windows to defrost or demist the windscreen or rear window.

Note: *The heated windows operate only when the engine is running.*

Heated windscreen



Heated rear window



Heated exterior mirrors

Electric exterior mirrors are fitted with a heating element that will defrost or demist the mirror glass. They will switch on automatically when you switch the heated rear window on.

AUXILIARY HEATER

Parking heater

WARNING



The parking heater must not be operated at filling stations, near sources of combustible vapours or dust or in enclosed spaces.

The parking heater operates independently of the vehicle heater by heating the engine's coolant circuit. It is fed from the vehicle fuel tank. You can also use it while the vehicle is in motion to help the vehicle heater warm up the interior more quickly.

Used properly, the parking heater provides the following benefits:

- It preheats the interior of the vehicle.
- It keeps the windows clear of ice in the event of frost and prevents condensation.
- It avoids cold starts and allows the engine to reach operating temperature sooner.

Note: *The parking heater will only operate if there is at least 7.5 litres (1.6 gallons) of fuel in the fuel tank and the ambient temperature is below 15°C (59°F). The heater will not operate if the battery is low.*

Note: *The heating depends on the outside air temperature.*

Climate control

Note: When the parking heater is activated, exhaust fumes may come from under the sides of the vehicle. This is normal.

Note: On vehicles with a manual heating, ventilation and air conditioning system, the heating of the vehicle interior is dependent on the temperature, air distribution and blower control settings.

To prevent the battery from discharging:

- Once the parking heater has performed one heating cycle, the next programmed heating cycle will only be carried out if you have started the vehicle's engine in between.
- After a heating cycle, drive the vehicle for at least the period of the heating cycle.

Programming the parking heater

Note: The programmed time is the time at which you wish the vehicle to be warm and ready to drive, not the time at which the heater switches on.

Note: You must programme the times at least 70 minutes in advance of the time you wish to set.


Note: You must set the time and date correctly. See **Clock** (page 130).

To programme the heating times:



E70499

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Park Heater** and press the right arrow button.



E74467

Climate control

- The functions **Program 1** and **Program 2** allow you to programme up to two heating cycles for each day of the week. These times will remain stored and the heater will warm up the vehicle at these times on these days every week.
- The function **One-Time** allows you to programme one heating cycle for one specific day.
- The function **Active now** automatically switches on the heater.


Programming the functions Program 1 and Program 2

Program 1	
[07:55]	>
<input type="checkbox"/> Monday	
<input type="checkbox"/> Tuesday	
<input checked="" type="checkbox"/> Wednesday	
<input type="checkbox"/> Thursday	
<input type="checkbox"/> Friday	✓

E74468

1. Highlight **Program 1** and press the right arrow button.
2. Highlight the day on which the heater should warm up the vehicle.
3. Press the **OK** button to confirm the selection. A cross appears in the box next to the day to show that this day is selected.

4. Continue in the same way to select all the days on which the heater should warm up the vehicle.
5. To set the time at which the vehicle should be warmed up, highlight the time at the top of the display and press the right arrow button.
6. Press the **OK** button and the hours flash. Use the up and down arrow buttons to adjust the individual settings and the left and right arrow buttons to move to the next or previous setting.
7. When you have finished, press the **OK** button again to confirm the selection.

Parkheater Program 1

07:55
01:12:2006
OK = change

E74469

You can use the function **Program 2** to set a second cycle, for example different times on different days or twice on the same day. The programming procedure is the same as for the function **Program 1**.

Climate control

Programming the function One-Time

1. Highlight **One-Time** and press the right arrow button.
2. Press the **OK** button and the hours flash. Use the up and down arrow buttons to adjust the individual settings and the left and right arrow buttons to move to the next or previous setting.
3. When you have finished, press the **OK** button again to confirm the selection.

Active now

Highlight **Active now** and press the **OK** button. A cross appears in the box next to the function to show that the heater is activated.

To deactivate the heater, highlight **Active now** and press the **OK** button again.

Diesel auxiliary heater (depending on country)

The diesel auxiliary heater (PTC electrical heater) aids in warming the engine and the vehicle interior on vehicles with a diesel engine. It is switched on or off automatically depending on the outside air temperature, the coolant temperature and the alternator load.

Fuel operated heater (depending on country)

The fuel operated heater aids in warming the engine and the vehicle interior on vehicles with a petrol or diesel engine. It is switched on or off automatically depending on the outside air temperature and the coolant temperature, unless you have deactivated it. When the fuel operated heater is operating, **Aux. Heater on** is displayed in the information display. See **Information displays** (page 85).

To deactivate the fuel operated heater:




E70499

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down arrow buttons and press the right arrow button.

Climate control


3. Highlight **Aux. Heater** and press the **OK** button to toggle the heater on and off. A cross appears in the box when the heater is activated.
4. Press the left arrow button to exit the menu. Hold the left arrow button pressed to return to the trip computer display.

ELECTRIC SUNROOF



E78054

WARNING

 Before operating the electric sunroof you should verify it is free of obstructions and ensure that children and/or pets are not in the proximity of the sunroof opening. Failure to do so could result in serious personal injury. It is the primary responsibility of the supervising adults to never leave a child unattended in a vehicle and to never leave the keys in an unattended vehicle.

Note: When the switches are operated often during a short period of time, the system might become inoperable for a certain time to prevent damage due to overheating.


Note: The electric sunroof can also be operated with the ignition off via the global opening and global closing function. See **Global opening and closing** (page 38).

There are two ways of opening the sunroof – the rear of the sunroof lifts open or the sunroof opens from the front, sliding back under the roof. The sunroof opens and closes whilst the switch is pressed.

Switch on the ignition to operate the electric sunroof.


The power sunroof is operated by a switch located between the sun visors.

Opening and closing the sunroof




E72188

Climate control



E72185


- A Press to close
- B Press to open



E72185

- A Press to open
- B Press to close

Tilting the sunroof



E72189

Opening and closing the sunroof automatically

Note: When opening automatically, the sunroof will stop about 8 cm from the fully opened position. This position reduces the buffeting noise which is sometimes heard when the sunroof is fully open. The sunroof will only stop automatically in this position when the sunroof is opened automatically.

To open or close the sunroof automatically press either side of the switch to the second action point and release it completely. Press again to stop.

When the closed position is reached, the sunroof stops automatically.

Climate control

Sunroof anti-trap protection

WARNINGS



The anti-trap function is deactivated until the memory has been reset. Careless closing of the window can cause injuries.



Careless closing of the electric sunroof can override the anti-trap protection and cause injuries.

The sunroof will stop automatically while closing and reverse some distance if there is an obstacle in the way.

To override anti-trap protection when there is a resistance, e. g. in the winter, proceed as follows:

WARNING



While the sunroof is being closed for the third time, the anti-trap function is disabled. Make sure there are no obstacles in the way of the closing sunroof.

Close the sunroof a third time to the resistance. The anti-trap function is disabled and the sunroof cannot be closed automatically. The sunroof will override the resistance and can then be closed fully.

If the sunroof does not close after the third attempt, have it checked by an expert.

Sunroof safety mode

WARNING



The anti-trap function is not active during this procedure. Make sure that there are no obstacles in the way of the closing sunroof.

If the system detects a malfunction, it enters a safety mode. The sunroof will move for only about 0.5 seconds at a time and then stop again. Close the sunroof by pressing the button again when the sunroof stops moving. When the rear of the sunroof is lifted, lift the rear all the way and then close the sunroof. Have the system checked by an expert immediately.

Sunroof relearning

WARNING



The anti-trap function is not active during this procedure. Make sure that there are no obstacles in the way of the closing sunroof.

In case the sunroof no longer closes properly, follow this relearning procedure:


Climate control

- Tilt the rear of the sunroof as far as possible. Release the button.
- Press and hold the same button again for 30 seconds until you see the sunroof move.
- Release the button and immediately press and hold it again. The sunroof will close, open fully and then close again. Do not release the button before the sunroof has reached the closed position for the second time.

If the button is not pressed continuously, the relearning function will be interrupted. Start the procedure once more from the beginning.

Seats

SITTING IN THE CORRECT POSITION



E68595

WARNINGS



Do not adjust the seats when the vehicle is moving.



Only when you use the seat belt properly, can it hold you in a position that allows the airbag to achieve its optimum effect.

When you use them properly, the seat, head restraint, seat belt and airbags will provide optimum protection in the event of a collision. We recommend that you:


- sit in an upright position with the base of your spine as far back as possible.
- do not recline the seatback more than 30 degrees.
- adjust the head restraint so that the top of it is level with the top of your head and as far forwards as possible, remaining comfortable.

- keep sufficient distance between yourself and the steering wheel. We recommend a minimum of 254 millimetres (10 inches) between your breastbone and the airbag cover.
- hold the steering wheel with your arms slightly bent.
- bend your legs slightly so that you can press the pedals fully.
- position the shoulder strap of the seat belt over the centre of your shoulder and position the lap strap tightly across your hips.

Make sure that your driving position is comfortable and that you can maintain full control of your vehicle.

MANUAL SEATS


Moving the seats backwards and forwards



E70728

Seats

WARNING


 Rock the seat backwards and forwards after releasing the lever to make sure that it is fully engaged in its catch.

Adjusting the lumbar support




E70729

Adjusting the height of the driver's seat



E70730


Adjusting the angle of the seatback



E70731

ELECTRIC SEATS





2-way electric seat



E70733

Seats

8-way electric seat




E70734


Seats


HEAD RESTRAINTS

Adjusting the head restraint

WARNINGS

 Raise the rear head restraint when the rear seat is occupied by a passenger.

 When using a forward facing child restraint on a rear seat, always remove the head restraint from that seat.



E71879


Adjust the head restraint so that the top of it is level with the top of your head and as far forwards as possible, remaining comfortable.


Removing the head restraint

Press the locking buttons and remove the head restraint.

REAR SEATS


WARNINGS

 When folding the seatbacks down, take care not to get your fingers caught between the seatback and seat frame.

 Make sure that the seats and the seatbacks are secure and fully engaged in their catches.

Folding the seatbacks down

CAUTION

 Lower the head restraints.



E86611


1. Press the unlock buttons down and hold them there.

Seats


2. Push the seatback forwards.


Creating a level load floor

WARNING

 Make sure the red indicator is not showing when you engage the seat in the catches.

CAUTION

 Lower the head restraints.




E86612

1. Insert your fingers between the seat cushion and seatback and fold the seat cushion forwards.
2. Press the unlock buttons down and hold them there.
3. Push the seatback forwards.


HEATED SEATS

CAUTION

 Operating this function with the engine off will drain the battery.



E70601




E71224

Note: The settings are stored when you switch off the ignition.

Seats


VENTILATED SEATS

CAUTION

 Operating this function with the engine off will drain the battery.



E70601



E70602

Note: When the seat is being ventilated, the heater may switch on automatically. This is to prevent the flow of air becoming uncomfortably cool.

Note: The air in the vehicle interior is used to ventilate the seats. The cooling effect therefore depends on the temperature of the vehicle interior. Switch on the air conditioning if necessary and set the air distribution to footwell. See **Climate control** (page 109).


Note: The settings are stored when the ignition is switched off.

Convenience features

SUN BLINDS

Pull the blind up and attach it to the hooks **(A)**.

Side windows



E74809

Rear window



E86514

INSTRUMENT LIGHTING DIMMER



E70723

CLOCK


Note: Some navigation systems will automatically set the date and time on the clock using GPS signals.

Note: See **General information** (page 85).

1. From the main menu, select the clock function.
2. Select the option required.
3. Press **OK**.
4. Using the right, left, up and down arrow buttons, select and change the value.
5. Press **OK**.


CIGAR LIGHTER

CAUTIONS

 If you use the socket when the engine is not running, the battery may discharge.


Convenience features

CAUTIONS

 Do not hold the cigar lighter element pressed in.

Note: Switch the ignition on to use the cigar lighter. You can also use it for up to 30 minutes after you have switched the ignition off.

Note: You can use the socket to power 12 volt appliances that have a maximum current rating of 15 Amperes. Use only Ford accessory connectors or connectors specified for use with SAE standard sockets.




E72972

Press the element in to use the cigar lighter. It will pop out automatically.

ASHTRAY

Front ashtray



E72974

To empty, pull out the complete ashtray.

Rear ashtray




E73705

To remove the ashtray, open it, press it down against the spring and remove it.

AUXILIARY POWER SOCKETS



CAUTION

 If you use the socket when the engine is not running, the battery may discharge.

Convenience features


Note: You can use the socket when the ignition is switched off.

Note: You can use the socket to power 12 volt appliances that have a maximum current rating of 15 Amperes. Use only Ford accessory connectors or connectors specified for use with SAE standard sockets.




STORAGE COMPARTMENTS

WARNING


 Do not drive with any storage compartment lid open. Make sure that you secure the lid before setting off.

CAUTION

 Do not keep heat-sensitive items and liquids in any storage compartment.

CUP HOLDERS

WARNING


 Do not place hot drinks in the cup holders when the vehicle is moving.

GLOVE BOX

Cooled glove box


Note: You can cool the glove box using air from the air conditioning system.

Convenience features




E72980

MAP POCKETS



E74686



E73704



E72905

MEMORY FUNCTION

WARNINGS




Before activating the seat memory, make sure that the area immediately surrounding the seat is clear of obstructions and that all occupants are clear of moving parts.



Do not use the memory store function when the vehicle is moving.

Convenience features



E86768

- A Seat adjustment controls
See **Electric seats** (page 125).
- B Memory pre-set buttons

Up to four different driver's seat and exterior mirror positions can be stored in the memory. Your preferred setting for the reverse mirror dipping feature can also be stored. See **Electric exterior mirrors** (page 76).

Setting a memory pre-set

Passive setting

When this feature is enabled, the vehicle stores the seating and mirror positions for up to four remote controls or passive keys. Next time the vehicle is unlocked, the position of the seat and mirrors will adjust to the last used position. You can have this function deactivated, see your dealer.

Each time you turn the ignition off, the current seat and mirror settings are stored on the remote control or passive key used.

Active setting

1. Turn the ignition on.
2. Adjust the seat and exterior mirrors to the desired position.
3. Press and hold the desired pre-set button **B** until a single chime sounds to confirm.

Easy entry easy exit

To allow the driver to enter and exit the vehicle with ease, the driver's seat will automatically:

- Move back after you perform a recall with the remote control or passive key.
- Move back after the driver's door is opened, unless the engine is running.
- Move to the driving position (linked to the key used to recall) after closing the driver's door and switching the ignition on or a passive key is recognised within the vehicle.

You can have this function deactivated, see your dealer.

Convenience features

Recalling a stored seat position

Note: To stop seat movement during a recall, press any driver seat adjustment control, any of the memory buttons or any mirror control switch. Seat movement will also stop if you move the vehicle.

Passive recall

Note: If easy entry easy exit is enabled, the driver's seat will move to the entry and exit position. You can have this function deactivated, see your dealer.


Note: If more than one passive keys are in range, the memory function will move to the settings of the first key stored.

When you unlock the vehicle with the remote control or pull the driver door handle with a passive key in range, the seat and mirrors will move to the position stored on that remote control or passive key.


Active recall

Press the pre-set button associated with the desired driving position. The seat and mirrors will move to the position stored on that pre-set.

GLASSES HOLDER



AUXILIARY INPUT (AUX IN) SOCKET



See separate audio handbook.

Starting the engine

GENERAL INFORMATION


General points on starting

If the battery has been disconnected the vehicle may exhibit some unusual driving characteristics for approx. 8 kilometres (5 miles) after reconnecting the battery.

This is because the engine management system must realign itself with the engine. Any unusual driving characteristics during this period may be disregarded.


Starting the engine by towing or pushing

WARNING

 To prevent damage you must not push or tow start your vehicle. Use booster cables and a booster battery. See **Using booster cables** (page 222).

IGNITION SWITCH

WARNING

 Never return the key to the **0** position when the vehicle is in motion.



E72128

0 The ignition is off.

I The ignition and all main electrical circuits are disabled.

Note: *Do not leave the ignition key in this position for too long to avoid discharging the battery.*


II The ignition is switched on. All electrical circuits are operational. Warning lamps and indicators illuminate. This is the key position when driving. You must also select it when being towed.

III The starter motor is activated. Release the key as soon as the engine starts.

KEYLESS STARTING

WARNINGS

 The keyless starting system may not function if the key is close to metal objects or electronic devices such as mobile phones.

 Always check that the steering wheel lock is deactivated before attempting to move your vehicle. See **Steering wheel lock** (page 138).

Note: *A valid passive key must be located inside the vehicle to switch the ignition on and start the engine.*

Note: *To start your engine you must also fully depress the brake or clutch pedal, depending on the transmission fitted.*

Starting the engine




E85766

Ignition on

Press the start button once. All electrical circuits are operational, warning lamps and indicators illuminate.

Starting with automatic transmission

CAUTION


 Release the start button as soon as the engine starts.

Note: *Releasing the start button or the brake pedal during engine start will stop the engine cranking and return to ignition on.*

1. Make sure the transmission is in **P** or **N**.
2. Fully depress the brake pedal.
3. Press the start button.

Starting with manual transmission

CAUTION

 Release the start button as soon as the engine starts.

Note: *Releasing the start button or the clutch pedal during engine start will stop the engine cranking and return to ignition on.*

1. Fully depress the clutch pedal.
2. Press the start button.

Starting a diesel engine

Note: *Engine cranking will not commence until the engine glow plug cycle has been completed. This may take several seconds in extremely cold conditions.*

Note: *Continue to press the start button and the clutch or brake pedal until engine cranking begins.*

Failure to start

The passive starting system will not function if:

- The passive key frequencies are jammed.
- The passive key battery is flat.

If you are unable to start your vehicle carry out the following procedure.

Starting the engine


Type 1



E87382


1. Hold the key next to the steering column shroud exactly as shown.
2. With the key in this position you can use the start button to switch the ignition on and start your vehicle.

Type 2



E87381

1. Carefully prise out the cover.



E85767

2. Insert the key into the key holder.
3. With the key in this position you can use the start button to switch the ignition on and start your vehicle.

Stopping the engine

When your vehicle is stationary, press the start button to stop the engine. The ignition, all electrical circuits, warning lamps and indicators will be switched off.

STEERING WHEEL LOCK

WARNING



Always check that the steering is unlocked before attempting to move your vehicle.

Vehicles without keyless starting

To activate the steering wheel lock;

1. Remove the key from the ignition switch.

Starting the engine

2. Turn the steering wheel.

Vehicles with keyless starting

Your vehicle has an electronically controlled steering wheel lock. This operates automatically.

The steering wheel lock is activated if the ignition is off, the engine not running and your vehicle is stationary.

The steering wheel lock is deactivated when the ignition is switched on.


STARTING A PETROL ENGINE

Note: *You can only operate the starter for a maximum of 30 seconds at a time.*

Cold or hot engine

All vehicles

CAUTION

 When the temperature is below -20°C (-4°F), switch the Ignition on for at least one second before starting the engine. This will make sure that the maximum fuel pressure is established for starting the engine.

Vehicles with manual transmission

Note: *Do not touch the accelerator pedal.*

1. Fully depress the clutch pedal.

2. Start the engine.

Vehicles with automatic transmission

Note: *Do not touch the accelerator pedal.*

1. Select park or neutral.
2. Fully depress the brake pedal.
3. Start the engine.

All vehicles

If the engine does not start within 15 seconds, wait for a short period and try again.

If the engine does not start after **three** attempts, wait 10 seconds and follow the **Flooded engine** procedure.

If you have difficulty starting the engine when the temperature is below -25°C (-13°F), press the accelerator pedal between 1/4 to 1/2 of its travel and try again.

Flooded engine

Vehicles with manual transmission

1. Fully depress the clutch pedal.
2. Fully depress the accelerator pedal and hold it there.
3. Start the engine.

Vehicles with automatic transmission

1. Select park or neutral.
2. Fully depress the accelerator pedal and hold it there.

Starting the engine

3. Fully depress the brake pedal.
4. Start the engine.

All vehicles

If the engine does not start, repeat the **Cold or hot engine** procedure.

Engine idle speed after starting

The speed at which the engine idles immediately after starting will vary depending on the engine temperature.

If the engine is cold then the idle speed will automatically be increased.

The idle speed will slowly decrease to the normal level as the engine warms up.

STARTING A DIESEL ENGINE

Cold or hot engine

All vehicles

Note: When the temperature is below -15°C (5°F), you may need to crank the engine for up to 25 seconds. If you consistently operate the vehicle in such temperatures, we recommend that you have an engine block heater fitted.

Note: Continue cranking the engine until it starts.

Note: You can only operate the starter for a maximum of 30 seconds at a time.



Switch the ignition on and wait until the glow plug indicator goes off.

Vehicles with manual transmission

Note: Do not touch the accelerator pedal.

1. Fully depress the clutch pedal.
2. Start the engine.

Vehicles with automatic transmission

1. Select park or neutral.
2. Fully depress the brake pedal.
3. Start the engine.

DIESEL PARTICULATE FILTER (DPF)

The DPF forms part of the emissions reduction systems fitted to your vehicle. It filters harmful diesel particulates (soot) from the exhaust gas.

Regeneration

WARNING



Do not park your vehicle over dry leaves or dry grass. The regeneration process requires very high exhaust gas temperatures and the exhaust will continue to radiate a considerable amount of heat after you have switched the engine off. This is a potential fire hazard.

Starting the engine

Unlike a normal filter which requires periodic replacement, the DPF has been designed to regenerate, or clean itself to maintain operating efficiency. The regeneration process takes place automatically. However, some driving conditions mean that you must support the regeneration process.

If you drive only short distances or your journeys contain frequent stopping and starting, you must initiate the regeneration process every 500-800 kilometres (300-500 miles). To do this, drive your vehicle at 80 km/h (50 mph) for 40 kilometres (25 miles) in the lowest possible gear whenever it is safe to do so. Alternatively, drive normally but use a lower gear.

SWITCHING OFF THE ENGINE

Vehicles with a turbocharger

CAUTION



Do not switch the engine off when it is running at high speed. If you do, the turbocharger will continue running after the engine oil pressure has dropped to zero. This will lead to premature turbocharger bearing wear.

Release the accelerator pedal. Wait until the engine has reached idle speed and then switch it off.

Fuel and refuelling

SAFETY PRECAUTIONS

WARNINGS



Stop refuelling after the fuel nozzle stops the second time. Additional fuel will fill the expansion space in the fuel tank which could lead to fuel overflowing. Fuel spillage could be hazardous to other road users.



Do not use any kind of flames or heat near the fuel system. The fuel system is under pressure. There is a risk of injury if the fuel system is leaking.

FUEL QUALITY - PETROL

Note: *We recommend that you use only high quality fuel without additives or other engine treatments.*

CAUTION



Do not use leaded petrol or petrol with additives containing other metallic compounds (e.g. manganese-based). They could damage the emission system.

Use **minimum 95 octane unleaded** petrol that meets the specification defined by **EN 228**, or equivalent.

FUEL QUALITY - DIESEL

Note: *We recommend that you use only high quality fuel without additives or other engine treatments.*

WARNING



Do not mix diesel with oil, petrol or other liquids. This could cause a chemical reaction.

CAUTION



Do not add kerosene, paraffin or petrol to diesel. This could cause damage to the fuel system.

Note: *We do not recommend the prolonged use of additives intended to prevent fuel waxing.*

Use diesel that meets the specification defined by **EN 590**, or equivalent.

You can use diesel that contains up to 5% RME (bio diesel).

CATALYTIC CONVERTER

Driving with a catalytic converter

CAUTIONS



Avoid running out of fuel.



Do not crank the engine for long periods.



Do not run the engine when a spark plug lead is disconnected.



Do not push-start or tow-start your vehicle. Use booster cables. See **Using booster cables** (page 222).




Do not switch the ignition off when driving.

Fuel and refuelling


Parking


WARNING

 Do not park your vehicle over dry leaves or dry grass. The exhaust will continue to radiate a considerable amount of heat after you have switched the engine off. This is a potential fire hazard.


FUEL FILLER FLAP


WARNINGS

 Take care when refuelling to avoid spilling any residual fuel from the fuel pipe nozzle.

 We recommend that you wait at least 10 seconds before removing the fuel pipe nozzle to allow any residual fuel to drain into the fuel tank.

CAUTION

 If you use a high pressure spray to wash your vehicle, only spray the fuel filler flap briefly from a distance not less than 20 centimetres (8 inches).



E86613

Press the flap to open it. Open the flap fully until it engages.

When you insert the fuel pipe nozzle, a spring loaded inhibitor will open if the correct size nozzle is detected. This will prevent filling up with the wrong fuel.


Vehicles with diesel engine

Vehicles with tyre repair kit



E86734

Vehicles without tyre repair kit




E86645

A funnel is located in the spare wheel well. Use this when refilling with a fuel can.

Fuel and refuelling

REFUELLING

CAUTION

 Do not attempt to start the engine if you have filled the fuel tank with the incorrect fuel. This could damage the engine. Have the system checked by a properly trained technician immediately.

They are intended as a comparison between makes and models of vehicles. They are not intended to represent the real world fuel consumption you may get from your vehicle. Real world fuel consumption is governed by many factors including; driving style, high speed driving, stop/start driving, air conditioning usage, the accessories fitted and towing etc.

Your Ford dealer can give you advice on improving your fuel consumption.

FUEL CONSUMPTION

The CO₂ and fuel consumption figures are derived from laboratory tests according to EEC Directive 80/1268/EEC and subsequent amendments and are carried out by all vehicle manufacturers.

TECHNICAL SPECIFICATIONS

4-door and 5-door

Fuel consumption figures

Variant	Urban	Extra-urban	Combined	CO ₂ emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
1.6L Duratec-Ti-VCT (110 PS)	10 (28.2)	5.6 (50.4)	7.2 (39.2)	172
1.6L Duratec-Ti-VCT (125 PS)	10.3 (27.4)	5.7 (49.6)	7.4 (38.2)	177
2.0L Duratec-HE (145 PS)	11.2 (25.2)	6 (47.1)	7.9 (35.8)	189

Fuel and refuelling

Variant	Urban	Extra-urban	Combined	CO2 emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
2.3L Duratec-HE (161 PS)	13.8 (20.5)	6.7 (42.2)	9.3 (30.4)	223
2.5L Duratec-ST (220 PS)	13.6 (20.8)	6.8 (41.5)	9.3 (30.4)	222
1.8L Duratorq-TDCi (100 PS)	7.4 (38.2)	4.7 (60.1)	5.7 (49.6)	151
1.8L Duratorq-TDCi (125 PS)	7.5 (37.7)	4.8 (58.9)	5.8 (48.7)	154
2.0L Duratorq-TDCi, 6-speed manual transmission	7.6 (37.2)	4.9 (57.6)	5.9 (47.9)	156
2.0L Duratorq-TDCi (130 PS), 6-speed automatic transmission	9.8 (28.8)	5.6 (50.4)	7.1 (39.8)	189
2.2L Duratorq-TDCi, 6-speed manual transmission	Information not available	Information not available	Information not available	Information not available
2.2L Duratorq-TDCi, 6-speed automatic transmission	Information not available	Information not available	Information not available	Information not available

Fuel and refuelling

Estate

Fuel consumption figures

Variant	Urban	Extra-urban	Combined	CO2 emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
1.6L Duratec-Ti-VCT (110 PS)	10 (28.2)	5.6 (50.4)	7.2 (39.2)	172
1.6L Duratec-Ti-VCT (125 PS)	10.3 (27.4)	5.7 (49.6)	7.4 (38.2)	177
2.0L Duratec-HE (145 PS)	11.2 (25.2)	6 (47.1)	7.9 (35.8)	189
2.3L Duratec-HE (161 PS), 6-speed automatic transmission	13.8 (20.5)	6.7 (42.2)	9.3 (30.4)	223
2.5L Duratec-ST (220 PS)	13.6 (20.8)	6.8 (41.5)	9.3 (30.4)	222
1.8L Duratorq-TDCi	7.5 (37.7)	4.8 (58.9)	5.8 (48.7)	154
2.0L Duratorq-TDCi	7.6 (37.2)	4.9 (57.6)	5.9 (47.9)	156
2.0L Duratorq-TDCi (130 PS), 6-speed automatic transmission	9.8 (28.8)	5.6 (50.4)	7.1 (39.8)	189
2.2L Duratorq-TDCi, 6-speed manual transmission	Information not available	Information not available	Information not available	Information not available
2.2L Duratorq-TDCi, 6-speed automatic transmission	Information not available	Information not available	Information not available	Information not available

Transmission

MANUAL TRANSMISSION

All vehicles

CAUTIONS


⚠ Do not engage reverse gear when the vehicle is moving. This can cause damage to the transmission.

⚠ Do not apply any undue lateral force to the gear lever when changing from 5th to 4th gear. This could lead to the inadvertent selection of 2nd gear and can cause damage to the transmission.

Note: Fully depress the clutch pedal and wait for three seconds before you select first gear.

Vehicles with a 5-speed transmission


Selecting reverse gear



E75050

Vehicles with a 6-speed transmission (2.5L Duratec-ST engine)


Selecting reverse gear



E75051

Vehicles with a 6-speed transmission (Turbo diesel engines)

Selecting reverse gear



E75052

Transmission

AUTOMATIC TRANSMISSION


Selector lever positions



E80836

P	Park
R	Reverse
N	Neutral
D	Drive
S	Sport mode and manual shifting

WARNING

 Apply the brakes before moving the selector lever and keep them applied until you are ready to move off.

Note: A cold engine has a higher idle speed. This will increase the tendency for your vehicle to **creep** when you have selected a drive gear.

Press the button on the selector lever to select reverse and park.

The selector lever position will be shown in the information display.

Park

WARNINGS



Select park only when your vehicle is stationary.



Apply the parking brake and select park before leaving your vehicle. Make sure that the selector lever is latched in position.

Note: An audible warning will sound if you open the driver's door and you have not selected park.

In this position, power is not transmitted to the drive wheels and the transmission is locked. You can start the engine with the selector lever in this position.

Reverse

WARNING



Select reverse only when your vehicle is stationary and the engine is at idle speed.

Neutral


In this position, power is not transmitted to the drive wheels but the transmission is not locked. You can start the engine with the selector lever in this position.

Drive

Select drive to shift automatically through the forward gears.

Transmission

Sport mode and manual shifting



E80837

Note: A shift will occur only when the vehicle speed and the engine speed are appropriate.

Note: When you select position **S**, a gear change may occur depending on the accelerator pedal position in relation to actual vehicle speed.

Activate sport mode by moving the selector lever to position **S**. Sport mode will remain active until you shift manually up or down the gears.

Select manual shifting to shift manually through the forward gears. Push the selector lever forwards to shift down and pull it backwards to shift up.

Drive modes

The transmission will select the appropriate gear for optimum performance based on ambient temperature, road gradient, vehicle load and driver input.

Hints on driving with an automatic transmission

Moving off

1. Release the parking brake.
2. Release the brake pedal and press the accelerator pedal.

Stopping

1. Release the accelerator pedal and press the brake pedal.
2. Apply the parking brake.

Kickdown

Press the accelerator pedal fully with the selector lever in the drive position to select the next lowest gear for optimum performance. Release the accelerator pedal when you no longer require kickdown.

Emergency park position release lever

Use the lever to move the selector lever from the park position in the event of an electrical malfunction or if your vehicle has a flat battery.

Transmission



E87934

1. Remove the centre console side panel.



E87935


Note: *The lever is yellow.*

1. Insert a flat-bladed screwdriver into the slot and turn the screwdriver clockwise 90 degrees.

Brakes


PRINCIPLE OF OPERATION

Dual circuit braking system




E71353

WARNING

 If a brake circuit fails, you will notice a softer feel to the brake pedal. Press the brake pedal firmly and allow for increased stopping distances. Stop and have this checked immediately. Do not continue your journey.

Your vehicle is fitted with a diagonally split, dual circuit brake system. If a brake circuit fails, the other remains operational.

Disc brakes



E71354

Wet brake discs result in reduced braking efficiency. Dab the brake pedal when driving from a car wash to remove the film of water.

ABS

WARNING

 The ABS does not relieve you of your responsibility to drive with due care and attention.

The ABS helps you to maintain full steering and directional stability when you brake heavily in an emergency, by preventing the road wheels from locking. The ABS monitors the speed of each road wheel and varies the pressure to each brake. The ABS optimizes the tyre-to-road adhesion when you brake heavily.

HINTS ON DRIVING WITH ABS



E71355

When the ABS is operating, the brake pedal will pulse. This is normal. Maintain pressure on the brake pedal.

Brakes

The ABS will not eliminate the dangers inherent when:

- you drive too close to the vehicle in front of you.
- the vehicle is aquaplaning.
- you take corners too fast.
- the road surface is poor.

PARKING BRAKE

Applying the parking brake



E66567

WARNING



Make sure that the parking brake is applied before you release the lever.

Note: *Do not press the release button when you apply the parking brake.*

1. Press the brake pedal firmly.
2. Pull the parking brake lever upwards to its fullest extent.

Parking on a hill

If you have to park facing uphill, select first gear and turn the front wheels away from the kerb. If you have to park facing downhill, select reverse gear and turn the front wheels towards the kerb.

Releasing the parking brake

1. Press the brake pedal firmly.
2. Pull the parking brake lever upwards slightly, press the release button and push the lever downwards.

Stability control


PRINCIPLE OF OPERATION

Electronic stability programme (ESP)

WARNING



ESP does not relieve you of your responsibility to drive with due care and attention.



E72903

- A without ESP
- B with ESP

The ESP supports stability when the vehicle starts to slide away from your intended path. This is performed by braking individual wheels and reducing engine torque as needed.

The system also provides an enhanced traction control function by reducing engine torque if the wheels spin when you accelerate. This improves your ability to pull away on slippery roads or loose surfaces, and improves comfort by limiting wheel spin in hairpin bends.

Stability control (ESP) warning lamp

The ESP warning lamp will flash when the system is operating. See **Warning lamps and indicators** (page 81).

Emergency brake assist

WARNING



Emergency brake assist does not relieve you of your responsibility to drive with due care and attention.

Emergency brake assist will detect when you brake heavily by measuring the rate at which you press the brake pedal. It will provide maximum braking efficiency as long as you press the pedal. Emergency brake assist can reduce stopping distances in critical situations.

USING STABILITY CONTROL



Stability control

Press and hold the switch for one second. The switch will illuminate. A message will be shown in the display. See **Information messages** (page 99).

Press the switch again to turn the system on. The system will be switched on automatically every time you switch the ignition on.

Hill launch assist (HLA)

PRINCIPLE OF OPERATION

The hill launch assist (HLA) system makes it easier to pull away when the vehicle is on a slope without the need to use the parking brake.

When the HLA is active, the vehicle will remain stationary on the slope for two to three seconds after you release the brake pedal. During this time, you have time to move your foot from the brake to the accelerator pedal and pull away. The brakes are released automatically once the engine has developed sufficient drive to prevent the vehicle from rolling down the slope. This is an advantage when pulling away on a slope, for example from a car park ramp, traffic lights or when reversing uphill into a parking space.

WARNING



The HLA does not replace the parking brake. When you leave the vehicle, always apply the parking brake and select first or reverse gear.

USING HLA

The HLA can operate in either automatic or manual mode. If you select automatic mode, the HLA is activated automatically when the vehicle is on a slope and you press the brake pedal. If you select manual mode, you must activate the HLA using the brake pedal.

To set the HLA mode:



E70499

Hill Launch
<input type="radio"/> Off
<input checked="" type="radio"/> Auto
<input type="radio"/> Manual

E74629

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down buttons and press the right arrow button.
3. Highlight **Hill Launch** and press the right arrow button.
4. Highlight the desired setting and press the **OK** button to confirm the setting. If **Off** is selected, the HLA is switched off and cannot be activated either automatically or manually.

Hill launch assist (HLA)

5. Press the left arrow button to exit the menu. To return to the trip computer display directly, hold the left arrow button pressed.

Note: When HLA is in manual activation mode, only use the HLA when pulling away uphill on gradients greater than 3%. If the vehicle is on the flat or on a downhill slope, an active HLA will make it difficult to pull away smoothly.

Activating the HLA

WARNINGS



You must remain in the vehicle once you have activated the HLA. Any attempt to leave the vehicle will deactivate the HLA automatically.



The HLA is active only if the message **Hill Launch Assist active** is displayed in the information display. During all times you are responsible for controlling the vehicle, supervising the HLA and intervening, if required.

You can activate the HLA only if the following conditions have been met:

- The engine is running.
- The HLA is switched on (automatic or manual mode).
- The parking brake is fully disengaged.
- On vehicles with manual transmission, the clutch pedal is pressed.
- On vehicles with automatic transmission, the driver door is closed.
- No failure mode is present.

To activate the HLA in automatic mode:

1. Press the brake pedal to bring the vehicle to a complete standstill. Keep the brake pedal depressed.
2. If the sensors detect that the vehicle is on a slope and the right driving direction is selected (first gear if the vehicle is pointing uphill, reverse gear if the vehicle is pointing downhill), the HLA will be activated automatically. **Hill Launch Assist active** will appear in the display.
3. When you remove your foot from the brake pedal, the vehicle will remain on the slope without rolling away for approximately two to three seconds.
4. Pull away using the accelerator and clutch pedal. The brakes will be released automatically.

To activate the HLA in manual mode:

1. Press the brake pedal to bring the vehicle to a complete standstill. Keep the brake pedal depressed.
2. Quickly jab the brake pedal further until **Hill Launch Assist active** appears in the display. The HLA is now active.

Hill launch assist (HLA)

3. When you remove your foot from the brake pedal, the vehicle will remain on the slope without rolling away for approximately two to three seconds.
4. Pull away using the accelerator and clutch pedal. The brakes will be released automatically.

WARNING



When HLA is active and the system detects a failure, the HLA is deactivated and the message **Please use park brake!** followed by **Hill Launch A .not available** will be displayed. The vehicle is still safe to be driven and can be repaired during the next service. The message **Hill Launch A. not available** will also be displayed with manual activation during a failure or if one of the activation criteria is not met. If you have switched the HLA off, no messages will be displayed.

Deactivating the HLA

To deactivate the HLA, perform **one** of the following:

- Apply the parking brake.
- Wait for two to three seconds until the HLA deactivates automatically.
- If a forward gear was selected when the HLA became active, select reverse gear.
- If reverse gear was selected when the HLA became active, select a forward gear.

Hill Launch Assist off will appear in the instrument cluster display.

Active suspension

PRINCIPLE OF OPERATION

The active suspension provides improved handling, comfort and stability by continuously adjusting the damper properties to the current road and driving conditions. This system in conjunction with the ABS system offers the benefit of potentially shorter stopping distances on rough road surfaces.

Depending on your preferences and driving style, you can choose between three different settings:

Comfort

In this setting, the dampers are smoothly adjusted to the road and driving conditions while still offering maximum stability in critical driving situations. The body movements are softened by the dampers, giving you a comfortable driving feel.

Normal

This setting provides optimum performance during normal but sporty driving. The body movements are still comfortable, however the vehicle will react stronger to the road and driving conditions compared to the comfort setting. The dynamic behaviour of the vehicle in this setting is similar to the typical Ford passenger car performance.


Sport

In this setting, the dampers are more sporty and maximum body control is provided. The body will follow the road to reduce roll during hard cornering giving you the feeling of a typical sports car.

USING ACTIVE SUSPENSION

Selecting a setting

Note: After you select a setting, you may not immediately notice a difference in the vehicle's handling. The effect of the continuously controlled damping depends on the road surface and driving conditions.



E70475

You can change the setting while driving.

System malfunction

The active suspension system will switch off automatically if it malfunctions. The suspension will be set to a fail-safe condition that will enable you to continue driving but you will not be able to change the suspension setting. Have this checked as soon as possible.

Parking aid

PRINCIPLE OF OPERATION

WARNING



The parking aid does not relieve you of your responsibility to drive with due care and attention.

CAUTIONS



The sensors may not detect objects in heavy rain or other conditions that cause disruptive reflections.



The sensors may not detect objects with surfaces that absorb ultrasonic waves.



The sensors may not detect objects that are close to the vehicle (approximately 30 centimetres [11 inches] to the rear and above or below the sensors).



If you use a high pressure spray to wash your vehicle, only spray the sensors briefly from a distance not less than 20 centimetres (8 inches).

Note: The parking aid may emit false tones if it detects a signal using the same frequency as the sensors or if the vehicle is fully laden.

Note: The outer sensors may detect the side walls of a garage. If the distance between the outer sensor and the side wall remains constant for three seconds, the tone will switch off. As you continue, the inner sensors will detect rearward objects.

USING THE PARKING AID

Note: Keep the sensors free from dirt, ice and snow. Do not clean with sharp objects.

Switching the parking aid on and off

Note: The parking aid switches off automatically when you start the engine or when you exceed 16 km/h (10 mph).

Note: Vehicles fitted with a trailer tow module not approved by us may not correctly detect obstacles.

Note: On vehicles fitted with a tow ball arm, the rear sensors are deactivated automatically when any trailer lamps (or lighting boards) are connected to the 13-pin socket via a trailer tow module we have approved. On vehicles fitted with a trailer tow module not approved by us, you have to switch the parking aid off using the switch.

Note: The front and rear sensors are always activated or deactivated together.

Note: On vehicles fitted with automatic transmission, the parking aid will not operate in position **P**.


The parking aid is per default off. To switch the parking aid on, press the switch in the instrument panel or select reverse gear.

The light in the switch illuminates when the parking aid is activated.

To turn it off, press the switch again.

Parking aid

Manoeuvring with the parking aid



E72902

CAUTIONS

⚠ The parking aid does not detect obstacles moving away from the vehicle. They will only be detected shortly after they start to move towards the vehicle again.

⚠ Take particular care when reversing with a tow ball arm or rear fitted accessories e.g. a bicycle carrier, as the rear parking aid will only indicate the distance from the bumper to the obstacle.

Note: *If a high pitch warning tone sounds for three seconds and the light in the switch is flashing, it indicates a malfunction. The system will be disabled. Have the system checked by properly trained technicians.*

You will hear an intermittent tone at a distance of up to 180 centimetres (71 inches) between the obstacle and rear bumper, 80 centimetres (31 inches) between the obstacle and front bumper and 60 centimetres (24 inches) to the side. Decreasing the distance accelerates the intermittent tone. A continuous tone will start at a distance of less than 30 centimetres (11 inches).

You will hear an alternating tone from the front and rear if obstacles are closer than 30 centimetres (11 inches) to the front and rear bumpers.


Cruise control

PRINCIPLE OF OPERATION


Cruise control allows you to control your speed using the switches on the steering wheel. You can use cruise control when you exceed 30 km/h (20 mph).

USING CRUISE CONTROL

WARNING


 Do not use cruise control in heavy traffic, on twisty roads or when the road surface is slippery.

Switching cruise control on



E70612

Setting a speed




E70615

Press the **SET+** switch or the **SET-** switch to store and maintain your current speed. The cruise control indicator illuminates.

Changing the set speed

WARNING

 When you are going downhill, your speed may increase above the set speed. The system will not apply the brakes. Change down a gear and press the **RES** switch to assist the system in maintaining the set speed.

Note: If you accelerate by pressing the accelerator pedal, the set speed will not change. When you release the accelerator pedal, you will return to the speed that you previously set.

Press the **SET+** switch or the **SET-** switch to accelerate or decelerate.

Cruise control

Cancelling the set speed



E70614

Press the brake pedal or the **CAN** switch. The system will no longer control your speed. The cruise control indicator will go off but the system will retain the speed that you previously set.


Switching cruise control off



E70613

Press the **OFF** switch. The system will not retain the speed that you previously set. The cruise control indicator will go off.

Resuming the set speed



E70616

Press the **RES** switch. The cruise control indicator illuminates and the system will attempt to resume the speed that you previously set.

Adaptive cruise control (ACC)

PRINCIPLE OF OPERATION

The adaptive cruise control system is designed to help you maintain a gap from the vehicle ahead or a set road speed if there is no slower vehicle ahead. The system is intended to provide enhanced operation of the vehicle when following other vehicles which are in the same lane and travelling in the same direction.

WARNINGS



Adaptive cruise control is not a collision warning or avoidance system. The separate forward alert function provides a collision warning and mitigation feature. See

Forward alert function (page 168). You must intervene if the system does not detect a vehicle in front.



Adaptive cruise control cannot cover all traffic, weather and road conditions.



When driving you are responsible for maintaining the correct distance and speed, even when adaptive cruise control is used. You must always pay attention to the traffic conditions and intervene when adaptive cruise control is not maintaining a suitable speed or suitable distance.



The adaptive cruise control does not brake for slow or stationary vehicles.

WARNINGS



When ACC is activated, you may hear some unusual sounds during automatic braking. This is normal and caused by the automatic braking system.

The adaptive cruise control system is based on the use of a radar sensor which projects a beam directly forward of the vehicle. This beam will detect any vehicle ahead within the system's range.

The radar sensor is mounted behind the front grille, immediately to the right of the Ford badge (when viewed from the front of the vehicle).

When using ACC, follow the strict guidelines below:

- Only use adaptive cruise control when conditions are favourable, for example on motorways and main roads with steady free flowing traffic.
- Do not use in poor visibility, specifically fog, heavy rain, spray or snow.
- Do not use on icy or slippery roads.
- It is your responsibility to stay alert, drive safely and be in control of the vehicle at all times.


Adaptive cruise control (ACC)

- Keep the front of the vehicle free from dirt, metal badges or objects, including vehicle front protectors and additional lights which may prevent the sensor from operating.
- Do not use ACC when entering or leaving a motorway.


The radar sensor has a limited field of vision. In some situations it may detect a vehicle other than the one expected or not detect any vehicle at all.

Detection beam issues


A



B



C



E71621 L

Detection issues can occur:

- When driving on a different line to the vehicle in front (**A**).
- With vehicles that edge into your lane that can only be detected once they have moved fully into your lane (**B**). Motorcycles may be detected late, or not at all.
- There may be issues with the detection of vehicles in front when going into and coming out of a bend (**C**). The detection beam will not follow sharp curves in the road.

WARNING




In these cases ACC may brake late or unexpectedly. The driver should stay alert and intervene if necessary.

Automatic braking with ACC

Adaptive cruise control will automatically brake for you, if required to maintain the set gap between your vehicle and the one detected in front. This braking capacity is limited to approximately 30% of the total manual braking capacity to ensure smooth and comfortable cruising. If the car needs to brake more heavily than this, and you do not intervene by braking manually, an alarm will sound and a warning symbol will be displayed in the cluster.

Adaptive cruise control (ACC)


WARNING

 You must take immediate action once alerted, as the ACC braking will not be sufficient to keep a safe distance to the vehicle in front.

USING ACC

The system is operated by adjustment controls mounted on the steering wheel. The system is deactivated when the brakes or clutch are used, the gear selector is moved to a neutral position or if the accelerator pedal is depressed for a longer period. The system will change to standby mode, allowing you full manual control of the vehicle.

Note: If the accelerator is depressed for a short period, for example when overtaking, the system is temporarily deactivated and then reactivated when the accelerator pedal is released. **ACC override** is displayed in the information display.



E82310


- A ACC on/off
- B ACC cancel

- C Forward alert on/off
- D ACC gap increase
- E ACC gap decrease

Switching ACC on

Press switch **A**. The system is set to standby mode and **Standby** is displayed in the information display.

Setting a speed



E70615

Note: The system must be in **Standby** mode.

Press the **SET+** switch or the **SET-** switch to select your desired cruise speed. The speed is displayed in the information display and stored as the set speed. The **ACC** indicator illuminates.

Note: Vehicle speed may be increased and decreased at intervals of 5 km/h or 5 mph. Smaller increases of 1 km/h or 1 mph may be set by pressing the **RES** switch.


Adaptive cruise control (ACC)

Changing the set speed

Press the **SET+** switch or the **SET-** switch to accelerate or decelerate.

Note: *If the system does not react to these changes the reason may be that the gap interval to the vehicle in front prevents an increase in speed.*

Setting the vehicle gap




E82311

The distance between you and the vehicle detected in front is maintained by a variable setting. There are five steps which are represented by horizontal bars displayed in the information display. One bar denotes the smallest gap and five bars indicate the largest gap. These bars are shown empty when in standby mode and filled when in active mode.

If no vehicle is detected in front, then only your vehicle is displayed in the information display below the bars. The system will maintain the set speed when conditions permit. The set gap is maintained and displayed.

If a vehicle is detected by the sensor, the display will show another vehicle above the horizontal bars:



E82312

This is a follow mode, and the system will accelerate or decelerate as necessary to maintain the set gap.

Press switch **E** to decrease the gap or switch **D** to increase the gap. The gap selected will be represented by the number of bars in the display. The recommended gap setting is three to five bars.

Note: *The gap setting is time dependant and therefore the distance will automatically adjust with your speed. For example on a gap setting of three bars, the time gap is 1.8 seconds. This will mean that at a speed of 100 km/h (62 mph), the distance to the vehicle in front will be maintained at 50 metres (164 feet)*

Adaptive cruise control (ACC)

CAUTION

 Use the appropriate gap setting in accordance with local traffic regulations.

Cancelling ACC

Press either the brake or clutch pedal, or switch **B**. The system will return to standby mode but will retain the set speed and gap in the memory. The **ACC** indicator will go off.

Resuming ACC

Press the **RES** switch. The **ACC** indicator illuminates and the system will resume with the previously set speed and vehicle gap setting if conditions permit.

Switching ACC off

Press switch **A**.

Note: Pressing switch **A** does not return the system to standby mode. The stored speed is not retained.

Note: To temporarily deactivate the system press switch **B**.

Automatic deactivation

The system is dependent on various other safety systems, for example ABS and ESP. If any of these systems are malfunctioning or reacting to an emergency, the system is automatically deactivated.

In the event of automatic deactivation a signal will sound and the message **ACC cancel** is displayed in the information display. You must then intervene and adapt your driving and speed to vehicles in front.

An automatic deactivation can be due to the:

- vehicle speed falling below 30 km/h (20 mph)
- wheels lose traction
- brake temperature is high, for example when driving on mountainous or hilly roads
- engine speed is too low
- radar sensor is covered
- parking brake or electric parking brake (EPB) is applied.

If the engine speed drops too low, a message is displayed in the information display instructing you to change down a gear (manual transmission only). If you do not follow this recommendation then the system will go into automatic deactivation mode.

Note: The system will not operate if the electronic stability programme (ESP) has been manually switched off.

Adaptive cruise control (ACC)

FORWARD ALERT FUNCTION

The system assists you by warning of the risk of a collision, and reducing the severity of a collision with a vehicle in front. This works by using two methods:

- You are alerted to a potential collision so you may brake earlier than normal.
- Brake support is activated to enable full braking effectiveness.

The collision alerts will only occur if the system is switched on, however the brake support is always on and cannot be turned off. Warnings are both visual and audible. Brake support is activated automatically if necessary to reduce the collision speed. The brake support system only reduces the collision speed if you brake immediately once alerted.

WARNINGS



Never wait for a collision warning. When driving you are responsible for maintaining the correct distance and speed, even when the system is used.



The system will only react to vehicles in front travelling in the same direction and will not react to slow or stationary vehicles.



Never drive in a manner to provoke the system. The system is designed to assist in emergencies only.

The system alerts you by warning chimes and a visual warning in the information display. When forward alert is activated a red flashing warning triangle is displayed in the information display.

Note: You can deactivate the warning chimes by using the buttons on the steering wheel. See **Audible warnings and indicators** (page 84).

The system does not operate in all driving situations and traffic, weather and road conditions.

The radar sensor detects vehicles in front that are driving in the same direction as you. If the risk of collision still increases after the initial warning then brake support is activated. Brake support prepares the brake system for rapid braking and the brakes are applied gently, which may be noticed as a slight jerk. If the brake pedal is depressed sufficiently quickly then braking is implemented with full brake function, even if the force on the pedal is light.

CAUTION




Warnings may be triggered late, be absent or triggered unnecessarily if the traffic situation means that the radar sensor cannot accurately detect a vehicle in front. The system uses the same radar sensors as adaptive cruise control (ACC) and therefore has the same limitations. See **Principle of operation** (page 163).

Adaptive cruise control (ACC)

Note: *The system may be used with or without the ACC system being activated.*

Switching forward alert on/off



E94165

The indicator will illuminate.

Adjusting the warning sensitivity

You may adjust the system warning sensitivity using the buttons on the steering wheel. See **General information** (page 85).

This controls how early the visual and audible warning is activated.

Load carrying

GENERAL INFORMATION

WARNINGS

-  Use load securing straps to an approved standard, e.g. DIN.
-  Make sure that you secure all loose items properly.
-  Place luggage and other loads as low and as far forward as possible within the luggage or loadspace.
-  Do not drive with the tailgate or rear door open. Exhaust fumes may enter the vehicle.
-  Do not exceed the maximum front and rear axle loads for your vehicle. See **Vehicle identification** (page 242).

LUGGAGE ANCHOR POINTS

Estate



E86912


4-door and 5-door




E86913

SLIDING LOADSPACE FLOOR

WARNING

-  Do not slide the loadspace floor rearwards when the vehicle is standing on an incline of 15 degrees or more and facing uphill.

CAUTION

-  The maximum permissible weight on the sliding loadspace floor is 200 kilogrammes (441 pounds).


The maximum permissible weight on the end of the sliding loadspace floor when the floor is in the fully extended position (slid outside the luggage compartment) is 120 kilogrammes (265 pounds).

Load carrying



E74810

Press the unlocking handle and pull the loadspace floor rearwards. It will stop and engage at a midway position.



E74811

To slide it out fully, press the unlocking handle again and pull it out until it engages in the end position.


To slide it forwards, press the unlocking handle and push it forwards.

Note: You do not have to exert as much pressure on the unlocking handle if you push the loadspace floor forwards slightly when operating it.

Storage compartment



A storage compartment is located in the floor at the rear of the luggage compartment.

To gain access to the storage compartment, lift up the sliding loadspace floor as follows:



E74812

Load carrying




1. Hold the floor with one hand and release the support leg with the other hand.
2. Insert the support leg back into the clip.
3. Lower the floor.
4. Press the unlocking handle and pull the loadspace floor rearwards until it drops into position on the rails.

REAR UNDER FLOOR STORAGE

Vehicles with a sliding loadspace floor

Raise the loadspace floor to gain access to the storage compartment. See **Sliding loadspace floor** (page 170).

Vehicles without a sliding loadspace floor



E87689

E74813

1. Press the unlocking handle and pull the loadspace floor rearwards a short way.
2. Lift up the rear of the floor (1).
3. Push the floor forwards until it engages at the front (2).
4. Release the support leg from the clip on the underside of the floor.
5. Insert the end into the square retainer in the left-hand rail (3).
6. Lift the storage compartment cover using the loop.


To return the loadspace floor to the normal position:

Load carrying

CARGO NETS

Luggage retention net

Installing the net



E87052

1. Push the ends of the upper bar towards each other and insert them into the retainers on the roof. Push the bar forwards into the narrow section of the retainers.



E87053

2. Attach the net to the luggage anchor points. See **Luggage anchor points** (page 170).



E87054

3. Tighten the belts.

Removing the net




E87135


1. Release the belts.
2. Remove the net from the luggage anchor points.
3. Remove the upper bars.

Load carrying

LUGGAGE COVERS

WARNING


 Do not place objects on the luggage cover.



E72969

Pull out the cover and secure it in the retaining points.

Release it from the retaining points and let it roll back into the case. Clip the retaining hook onto the case.




E72970

To remove or install the cover, push either end of the case inwards.

ROOF RACKS AND LOAD CARRIERS


Roof rack

WARNINGS

 If you use a roof rack, the fuel consumption of your vehicle will be higher and you may experience different driving characteristics.

 Read and follow the manufacturer's instructions when you are fitting a roof rack.

CAUTION


 Do not exceed the maximum permissible roof load of 75 kilogrammes (165 pounds) (including the roof rack).

Check the security of the roof rack and tighten its fittings as follows:

- before starting
- after driving 50 kilometres (30 miles)
- at 1 000 kilometres (600 miles) intervals.

DOG GUARD

CAUTION

 Keep a distance of at least one centimetre between the dog guard and the seats in front of it.

Load carrying


Installing the dog guard

Installing behind the front seats





E86848

1. Push the ends of the bar on the grille towards each other and insert them into the retainers on the roof. Push the bar forwards into the narrow section of the retainers.



E87782

2. Attach the dog guard to the lower anchor points. Do not tighten the screws.




E87783

3. Attach the grille to the lower bar with the handwheels. Do not tighten the handwheels.
4. Tighten the screws at the lower anchor points.
5. Tighten the handwheels.


Load carrying

Installing behind the rear seats



E86848

1. Push the ends of the bar on the grille towards each other and insert them into the retainers on the roof. Push the bar forwards into the narrow section of the retainers.




E86842

3. Tighten the handwheels.
Remove in the reverse order.


LOAD RETAINING FIXTURES

WARNING

 Do not exceed the maximum permissible load of 60 kilograms (132 pounds) on two load retaining fixtures and 30 kilograms (66 pounds) on one.

Check the security of the load retaining fixtures and tighten its fittings as follows:

- before starting
- after driving 50 kilometres (30 miles)
- at 1 000 kilometres (600 miles) intervals.




E86841

2. Attach the dog guard to the luggage anchor points. See **Luggage anchor points** (page 170).

Load carrying


Installing the load retaining fixtures





E75003

Installing the load bracket

WARNINGS


 Install the load bracket with the longest section towards the rear of the vehicle. If you install it the wrong way round, it may not hold the box in place in the event of an accident.

 Do not exceed the maximum permissible load of 20 kilograms (44 pounds).



E76378


1. Turn the box over.
2. Position the load bracket.
3. Secure the load bracket with four screws.



E76379

4. Slide the captured bolts onto the load retaining fixture.

Load carrying




E76380

5. Secure the load bracket with the two wing nuts.
6. Remove in the reverse order.

Towing

TOWING A TRAILER

WARNING

 Do not exceed the maximum vehicle and trailer weight stated on the vehicle identification plate. See **Vehicle identification** (page 242).

Note: *Not all vehicles are suitable or approved to have tow bars fitted. Check with your dealer first.*

Place loads as low and central to the axle(s) of the trailer as possible. If you are towing with an unladen vehicle, the load in the trailer should be placed toward the nose, within the maximum nose load, as this gives the best stability.

Note: *The maximum trailer nose weight can be found on the manufacturers data plate on the tow bar.*

The stability of the vehicle to trailer combination is very much dependant on the quality of the trailer.

In high altitude regions, the stipulated maximum permitted gross train weight must be reduced by 10% for every 1 000 metres (3 281 feet).

Steep gradients


WARNING


 The overrun brake on a trailer is not controlled by ABS.


Change down a gear before you reach a steep downhill gradient.


DETACHABLE TOW BALL

WARNINGS

 When not in use, always transport the tow ball arm securely fastened in the luggage compartment.

 Take special care when fitting the tow ball arm as the safety of the vehicle and the trailer depends on this.

 Do not use any tools for mounting or dismounting the tow ball arm. Do not modify the trailer coupling. Do not disassemble or repair the tow ball arm.




E71328

A 13-pin trailer socket and the tow ball arm seat are provided underneath the rear bumper. Turn the trailer socket down through 90 degrees until it engages in the end position.

Towing


Unlocking the tow ball arm mechanism



E71329

1. Remove the protecting cap (1). Insert the key and turn it clockwise to unlock (2).
2. Hold the tow ball arm. Pull the handwheel out and turn it clockwise until it clicks (3).
3. The red mark on the handwheel must align with the green mark on the tow ball.
4. Release the handwheel. The tow ball arm is unlocked.

Inserting the tow ball arm



E71330

WARNING




The tow ball arm may only be inserted when completely unlocked.

1. Pull out the plug.
2. Insert the tow ball arm vertically and press it upwards until it engages (1). Do not hold your hand near the handwheel.
3. The green mark on the handwheel must align with the green mark on the tow ball.


Towing

4. To lock, turn the key anti-clockwise and remove the key **(2)**.
5. Pull the protecting cap from the key bow and press it onto the lock.

Driving with a trailer




WARNING

 If any of the below conditions cannot be met, do not use the tow bar and have it checked by a properly trained technician.

Before starting your journey, make sure that the tow ball arm is properly locked. Check:

- the green marks are aligned.
- the handwheel **(A)** is correctly fitted to the tow ball arm.
- you have removed the key **(B)**.
- the tow ball arm is securely positioned. It must not move when jerked.

Removing the tow ball arm




1. Unhitch the trailer.
2. Remove the protecting cap. Press the cap into the key bow. Insert the key and unlock **(1)**.
3. Hold the tow ball arm. Pull the handwheel out, turn it clockwise against the stop **(2)** and remove the tow ball arm **(3)**.
4. Release the handwheel.

When unlocked in this way, the tow ball arm can be reinserted at any time.

Towing

Driving without a trailer

Keep a note of the key number. In case of loss, replacement keys are available from the manufacturer by stating the 4-digit key number.



E94771

1. Remove the tow ball arm.
2. Insert the plug into its seat (1).

WARNING



Never unlock the tow ball arm with the trailer attached.

Maintenance

CAUTION



Remove the tow ball arm and protect the seat with the plug before steam cleaning your vehicle.

Keep the system clean. Periodically lubricate bearings, sliding surfaces, and locking balls with resin-free grease or oil and the lock with graphite.

Driving hints

RUNNING-IN

Tyres

WARNING



New tyres need to be run-in for approximately 500 kilometres (300 miles). During this time, you may experience different driving characteristics.

Brakes and clutch

WARNING



Avoid heavy use of the brakes and clutch if possible for the first 150 kilometres (100 miles) in town and for the first 1 500 kilometres (1 000 miles) on motorways.

Engine

CAUTION




Avoid driving too fast during the first 1 500 kilometres (1 000 miles). Vary your speed frequently and change up through the gears early. Do not labour the engine.

Emergency equipment


FIRST AID KIT

4-door




E87654

5-door



E87655


Estate



E87656

WARNING TRIANGLE


4-door



E87657

Emergency equipment

5-door



E87658

Estate with full size spare wheel




E87772

Estate with medium size spare wheel



E87771

Vehicles with tyre repair kit



E87659

See **Rear under floor storage** (page 172).

Status after a collision

INSPECTING SAFETY SYSTEM COMPONENTS


Seat belts

Belts subjected to strain, as a result of an accident, should be renewed and the anchorages checked by a properly trained technician.

Fuses

FUSE BOX LOCATIONS

Engine compartment fuse box




E72588

Central fuse box




E72589

1. Loosen the screws.



E72590

2. Turn the knob through 90 degrees and release the fuse box from the retaining bracket.
3. Lower the fuse box and pull it towards you.




E72622

4. Remove the cover to gain access to the fuses (vehicles with a cooled glove box).
5. Install in the reverse order.


Fuses

Rear fuse box - 4-door and 5-door



E87481


1. Remove the cover.



E87482


2. Remove the relevant fuse box cover.

Rear fuse box - Estate



E87479

1. Release the catches.
2. Remove the cover.



E87480

3. Remove the relevant fuse box cover.

Fuses

CHANGING A FUSE

WARNINGS



Do not modify the electrical system of your vehicle in any way. Have repairs to the electrical system and the replacement of relays and high current fuses carried out by a properly trained technician.



Switch the ignition and all electrical equipment off before touching or attempting to change a fuse.

CAUTION



Fit a replacement fuse with the same rating as the one you have removed.

Note: *You can identify a blown fuse by a break in the filament.*


Note: *All fuses, except high current fuses, are a push fit.*

Note: *A fuse puller is located in the engine compartment fuse box.*

Fuses

FUSE SPECIFICATION CHART

Engine compartment fuse box



E75525

Fuse	Ampere rating	Colour	Circuits protected
F1	10	red	Transmission control module
F2	5	tan	Glow plug monitoring (diesel engines)

Fuses

Fuse	Ampere rating	Colour	Circuits protected
F3	80 ¹	clear	Engine cooling fan (2.3L Duratec-HE)
F3	80 ¹	clear	Electric hydraulic power steering (EHPAS) (2.0L Duratorq-TDCi)
F4	60	blue	Glow plugs
F5	60	blue	Engine cooling fan
F6	10	red	HEGO sensors 1 (engine management), variable valve timing (engine management)
F7	5	tan	Relay coils
F8	10	red	Powertrain control module
F9	-	-	Not used
F10	10	red	Engine control module
F11	10	red	Valves, MAF control (engine management)
F12	10	red	Water in fuel sensor, coils, MAF (engine management, diesel engine)
F13	15	blue	Air conditioning relay
F14	15	blue	Diesel filter heater
F15	40	orange	Starter relay
F16	80	clear	Diesel auxiliary heater (PTC)
F17	60	blue	Central fuse box supply A
F18	60	blue	Central fuse box supply B
F19	60	blue	Rear fuse box supply C
F20	60	blue	Rear fuse box supply D
F21	-	-	Not used
F22	30	green	Windscreen wiper module

Fuses


Fuse	Ampere rating	Colour	Circuits protected
F23	25 ¹	clear	Heated rear window
F23	30 ¹	green	Heated rear window
F24	30	green	Headlamp washer
F25	30	green	ABS valves
F26	40	orange	ABS pump
F27	30	green	Fuel fired heater
F28	40	orange	Heater blower
F29	–	–	Not used
F30	–	–	Not used
F31	15	blue	Horn
F32	–	–	Not used
F33	5	tan	Light switch module, engine compartment fuse box coils
F34	40	orange	Heated windscreen (left-hand side)
F35	40	orange	Heated windscreen (right-hand side)
F36	5	tan	ABS
F37	10	red	Heated front washer jets
F38	5	tan	Adaptive cruise control (ACC)
F39	15	blue	Adaptive front lighting system (AFS)
F40	–	–	Not used
F41	20	yellow	Instrument panel
F42	10	red	Engine control module, transmission control module, electric hydraulic power steering (EHPAS) 15 feed

Fuses

Fuse	Ampere rating	Colour	Circuits protected
F43	5	tan	Headlamp levelling, adaptive front lighting system (AFS)
F44	20	yellow	Vacuum pump (2.5L Duratec-HE)
F45	15	blue	Rear window wiper

¹Fit a replacement with the same rating as the one you have removed.

Central fuse box



E75527

Fuses

Fuse	Ampere rating	Colour	Circuits protected
F1	5	tan	Rain sensor
F2	10	red	SRS (airbag) supply
F3	5	tan	Yaw rate sensor (ESP)
F4	7.5	brown	Electronic feed, accelerator pedal supply, electronic fuse
F5	15	blue	Rear window wiper
F6	15	blue	Audio system (including voice control)
F7	7.5	brown	Steering wheel module
F8	5	tan	Instrument cluster
F9	15	blue	Main beam
F10	20	yellow	Power sunroof
F11	7.5	brown	Reversing lamps
F12	–	–	Not used
F13	15	blue	Front fog lamp
F14	15	blue	Windscreen washers
F15	10	red	Adaptive cruise control (ACC)
F16	–	–	Not used
F17	10	red	Interior lamps
F18	5	tan	Engine immobiliser
F19	15	blue	Cigar lighter
F20	–	–	Not used
F21	5	tan	Audio unit, rain sensor
F22	20	yellow	Fuel pump
F23	–	–	Not used


Fuses

Fuse	Ampere rating	Colour	Circuits protected
F24	5	tan	Ignition switch
F25	10	red	Fuel filler flap
F26	5	tan	Battery backup sounder (alarm system), OBD II (board computer diagnostics)
F27	5	tan	Steering column unit, climate control module
F28	5	tan	Brake lamp switch

Fuses

Rear fuse box


4-door and 5-door



E87483

Fuses

Estate



E75526

Fuse	Ampere rating	Colour	Circuits protected
FA1	25	clear	Door module (left-hand front) (window up/down, central locking, electric folding mirror, heated mirror)

Fuses

Fuse	Ampere rating	Colour	Circuits protected
FA2	25	clear	Door module (right-hand front) (window up/down, central locking, electric folding mirror, heated mirror)
FA3	25	clear	Door module (left-hand rear) (window up/down)
FA4	25	clear	Door module (right-hand rear) (window up/down)
FA5	10	red	Rear locking (without rear door modules)
FA6	15	blue	Auxiliary power socket
FA7	5	tan	Relay coils
FA8	20	yellow	Steering column lock
FA9	–	–	Not used
FA10	30	green	Electric driver's seat
FA11	20	yellow	Accessories, trailer module
FA12	–	–	Not used
FB1	5	tan	Parking aid module
FB2	15	blue	Suspension module
FB3	15	blue	Heated driver's seat
FB4	15	blue	Heated front passenger seat
FB5	15	blue	Left-hand rear heated seat
FB6	-	-	Not used
FB7	15	blue	Right-hand rear heated seat
FB8	–	–	Not used
FB9	30	green	Electric front passenger seat
FB10	10	red	Anti-theft alarm horn


Fuses

Fuse	Ampere rating	Colour	Circuits protected
FB11	–	–	Not used
FB12	–	–	Not used
FC1	-	-	Not used
FC2	-	-	Not used
FC3	-	-	Not used
FC4	-	-	Not used
FC5	7.5	brown	CD changer, rear seat entertainment system
FC6	-	-	Not used
FC7	5	tan	Seat memory function module
FC8	20	yellow	Keyless entry
FC9	–	–	Not used
FC10	–	–	Not used
FC11	–	–	Not used
FC12	–	–	Not used

Vehicle recovery

TOWING POINTS

Front towing eye



E87280


Rear towing eye



E87282


Note: On vehicles with a towbar, the towing eye cannot be installed at the rear of the vehicle. Use the towbar to tow a vehicle.

Vehicles without tyre repair kit



E87283

Vehicles with tyre repair kit




E87281

The screw-in towing eye is located in the spare wheel well.

The towing eye must **always** be carried in the vehicle.

Insert your finger into the hole on the underside of the cover and prise off the cover. Install the towing eye.

CAUTION


 The screw-in towing eye has a **left-hand thread**. Turn it **anti-clockwise** to install it.


Vehicle recovery

TOWING THE VEHICLE ON FOUR WHEELS


All vehicles

WARNINGS

 Switch the ignition on when your vehicle is being towed. The steering lock will engage and the direction indicators and brake lamps will not work if you do not.

 The brake servo and the power steering pump do not operate unless the engine is running. Press the brake pedal harder and allow for increased stopping distances and heavier steering.

CAUTIONS


 Too much tension in the tow rope could cause damage to your vehicle or the vehicle that is towing.

 Do not use a rigid tow bar on the front towing eye.


Drive off slowly and smoothly without jerking the vehicle that is towing.


Vehicles with automatic transmission


CAUTIONS


 Do not tow your vehicle faster than 50 km/h (30 mph) or further than 50 kilometres (30 miles).

CAUTIONS

 If a speed of 50 km/h (30 mph) and a distance of 50 kilometres (30 miles) is to be exceeded the drive wheels must be lifted clear of the ground.

 In the event of a mechanical failure of the transmission the drive wheels must be lifted clear of the ground.

 Do not tow your vehicle backwards.

 Select neutral when your vehicle is being towed.

Maintenance

GENERAL INFORMATION

Have your vehicle serviced regularly to help maintain its roadworthiness and resale value. There is a large network of Ford Authorised Repairers that are there to help you with their professional servicing expertise. We believe that their specially trained technicians are best qualified to service your vehicle properly and expertly. They are supported by a wide range of highly specialised tools developed specifically for servicing your vehicle.

In addition to regular servicing, we recommend that you carry out the following additional checks.

WARNINGS



Switch the ignition off before touching or attempting adjustment of any kind.



Do not touch the electronic ignition system parts after you have switched the ignition on or when the engine is running. The system operates at high voltage.



Keep your hands and clothing clear of the engine cooling fan. Under certain conditions, the fan may continue to run for several minutes after you have switched the engine off.

Daily checks

- Exterior lamps.
- Interior lamps.
- Warning lamps and indicators.

Check when refuelling

- Engine oil level. See **Engine oil check** (page 213).
- Brake fluid level. See **Brake and clutch fluid check** (page 215).
- Washer fluid level. See **Washer fluid check** (page 216).
- Tyre pressures (when cold). See **Wheels and tyres** (page 224).
- Tyre condition. See **Wheels and tyres** (page 224).

Monthly checks

- Engine coolant level (engine cold). See **Engine coolant check** (page 214).
- Pipes, hoses and reservoirs for leaks.
- Power steering fluid level. See **Power steering fluid check** (page 215).
- Air conditioning operation.
- Parking brake operation.
- Horn operation.
- Tightness of wheel nuts. See **Wheels and tyres** (page 224).


Maintenance

OPENING AND CLOSING THE BONNET

Opening the bonnet




E73698



E87785

Raise the bonnet slightly and move the catch towards the left-hand side of the vehicle.



E87786

Open the bonnet and support it with the strut.

Closing the bonnet

WARNING




Make sure that the bonnet is closed properly.

Lower the bonnet and allow it to drop from under its own weight for the last 20 – 30 centimetres (8 - 11 inches).

Maintenance

ENGINE COMPARTMENT OVERVIEW - 1.6L DURATEC-16V TI-VCT (SIGMA)



E87714

- A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 215).
- B Engine oil filler cap¹. See **Engine oil check** (page 213).
- C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 215).
- D Battery. See **Vehicle battery** (page 222).
- E Engine compartment fuse box. See **Fuses** (page 187).
- F Air cleaner. No maintenance necessary.
- G Screen washer fluid reservoir. See **Washer fluid check** (page 216).
- H Engine oil dipstick¹. See **Engine oil check** (page 213).


Maintenance

I Power steering fluid reservoir. See **Power steering fluid check** (page 215).

J Engine coolant reservoir. See **Engine coolant check** (page 214).

¹The filler caps and the engine oil dipstick are coloured for easy identification.

ENGINE COMPARTMENT OVERVIEW - 2.0L DURATEC-HE (MI4)



E73231

A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 215).

B Engine oil filler cap¹. See **Engine oil check** (page 213).

C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 215).

D Battery. See **Battery care** (page 222).


E Engine compartment fuse box. See **Fuse specification chart** (page 190).

Maintenance

- F Air cleaner. No maintenance necessary.
- G Screen washer fluid reservoir. See **Washer fluid check** (page 216).
- H Engine oil dipstick¹. See **Engine oil check** (page 213).
- I Power steering fluid reservoir. See **Power steering fluid check** (page 215).
- J Engine coolant reservoir. See **Engine coolant check** (page 214).

¹The filler caps and the engine oil dipstick are coloured for easy identification.

ENGINE COMPARTMENT OVERVIEW - 2.3L DURATEC-HE (MI4)



E81313


- A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 215).
- B Engine oil filler cap¹. See **Engine oil check** (page 213).

Maintenance

- C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 215).
- D Battery. See **Battery care** (page 222).
- E Engine compartment fuse box. See **Fuse specification chart** (page 190).
- F Air cleaner. No maintenance necessary.
- G Screen washer fluid reservoir. See **Washer fluid check** (page 216).
- H Engine oil dipstick¹. See **Engine oil check** (page 213).
- I Power steering fluid reservoir. See **Power steering fluid check** (page 215).
- J Engine coolant reservoir. See **Engine coolant check** (page 214).

¹The filler caps and the engine oil dipstick are coloured for easy identification.

ENGINE COMPARTMENT OVERVIEW - 2.5L DURATEC-ST (VI5)



E73232


Maintenance

- A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 215).
- B Engine oil filler cap¹. See **Brake and clutch fluid check** (page 215).
- C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 215).
- D Battery. See **Battery care** (page 222).
- E Engine compartment fuse box. See **Fuse specification chart** (page 190).
- F Screen washer fluid reservoir. See **Washer fluid check** (page 216).
- G Air cleaner. No maintenance necessary.
- H Engine oil dipstick¹. See **Brake and clutch fluid check** (page 215).
- I Power steering fluid reservoir. See **Power steering fluid check** (page 215).
- J Engine coolant reservoir. See **Engine coolant check** (page 214).

¹The filler caps and the engine oil dipstick are coloured for easy identification.

Maintenance

ENGINE COMPARTMENT OVERVIEW - 1.8L DURATORQ-TDCI (KENT) DIESEL



E73233

- A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 215).
- B Engine oil filler cap¹. See **Engine oil check** (page 213).
- C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 215).
- D Battery. See **Battery care** (page 222).
- E Engine compartment fuse box. See **Fuse specification chart** (page 190).
- F Air cleaner. No maintenance necessary.
- G Screen washer fluid reservoir. See **Washer fluid check** (page 216).
- H Engine oil dipstick¹. See **Engine oil check** (page 213).


Maintenance

I Power steering fluid reservoir. See **Power steering fluid check** (page 215).

J Engine coolant reservoir. See **Engine coolant check** (page 214).

¹The filler caps and the engine oil dipstick are coloured for easy identification.

ENGINE COMPARTMENT OVERVIEW - 2.0L DURATORQ-TDCI (DW) DIESEL



E73234

A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 215).

B Engine oil filler cap¹. See **Engine oil check** (page 213).

C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 215).

D Battery. See **Battery care** (page 222).


E Engine compartment fuse box. See **Fuse specification chart** (page 190).

Maintenance

- F Air cleaner. No maintenance necessary.
- G Screen washer fluid reservoir. See **Washer fluid check** (page 216).
- H Engine oil dipstick¹. See **Engine oil check** (page 213).
- I Power steering fluid reservoir. See **Power steering fluid check** (page 215).
- J Engine coolant reservoir. See **Engine coolant check** (page 214).

¹The filler caps and the engine oil dipstick are coloured for easy identification.

ENGINE COMPARTMENT OVERVIEW - 2.2L DURATORQ-TDCI (DW) DIESEL



E87715


- A Brake and clutch fluid reservoir (right-hand drive): See **Brake and clutch fluid check** (page 215).
- B Engine oil filler cap¹: See **Engine oil check** (page 213).

Maintenance

- C Brake and clutch fluid reservoir (left-hand drive): See **Brake and clutch fluid check** (page 215).
- D Battery: See **Vehicle battery** (page 222).
- E Engine compartment fuse box: See **Fuses** (page 187).
- F Air cleaner: No maintenance necessary.
- G Screen washer fluid reservoir: See **Washer fluid check** (page 216).
- H Engine oil dipstick¹: See **Engine oil check** (page 213).
- I Power steering fluid reservoir: See **Power steering fluid check** (page 215).
- J Engine coolant reservoir: See **Engine coolant check** (page 214).


¹The filler caps and the engine oil dipstick are coloured for easy identification.

ENGINE OIL DIPSTICK - 1.6L DURATEC-16V TI- VCT (SIGMA)



- A MIN
- B MAX


ENGINE OIL DIPSTICK - 2.0L DURATEC-HE (MI4)/2.3L DURATEC-HE (MI4)



- A MIN
- B MAX


Maintenance

ENGINE OIL DIPSTICK - 2.5L DURATEC-ST (VI5)




- A MIN
B MAX

ENGINE OIL DIPSTICK - 1.8L DURATORQ-TDCI (KENT) DIESEL



- A MIN
B MAX

ENGINE OIL DIPSTICK - 2.0L DURATORQ-TDCI (DW) DIESEL/2.2L DURATORQ-TDCI (DW) DIESEL



- A MIN
B MAX

ENGINE OIL CHECK

CAUTION

! Do not use oil additives or other engine treatments. Under certain conditions, they could damage the engine.

Note: The oil consumption of new engines reaches its normal level after approximately 5 000 kilometres (3 000 miles).

Checking the oil level

CAUTION

! Make sure that the level is between the **MIN** and the **MAX** marks.

Maintenance

Note: Check the level before starting the engine.

Note: Make sure that your vehicle is on level ground.


Note: Oil expands when it is hot. The level may therefore extend a few millimetres beyond the **MAX** mark.

Remove the dipstick and wipe it with a clean, lint free cloth. Replace the dipstick and remove it again to check the oil level.

If the level is at the **MIN** mark, top up immediately.

Topping up


WARNINGS

 Only top up when the engine is cold. If the engine is hot, wait 10 minutes for the engine to cool down.

 Do not remove the filler cap when the engine is running.

Remove the filler cap.

CAUTION


 Do not top up further than the **MAX** mark.

Top up with fluid that meets the Ford specification. See **Technical specifications** (page 216).


ENGINE COOLANT CHECK

Checking the coolant level

WARNING

 Do not allow the fluid to touch your skin or eyes. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.

CAUTION


 Make sure that the level is between the **MIN** and the **MAX** marks.

Note: Coolant expands when it is hot. The level may therefore extend beyond the **MAX** mark.


If the level is at the **MIN** mark, top up immediately.

Topping up

WARNINGS

 Only top up when the engine is cold. If the engine is hot, wait 10 minutes for the engine to cool down.


 Do not remove the filler cap when the engine is running.


 Do not remove the filler cap when the engine is hot. Wait for the engine to cool down.

Unscrew the cap **slowly**. Any pressure will escape slowly as you unscrew the cap.

Maintenance

CAUTIONS


 Do not spill coolant on any part of the engine.

 Do not top up further than the **MAX** mark.


Top up with fluid that meets the Ford specification. See **Technical specifications** (page 216).

BRAKE AND CLUTCH FLUID CHECK

WARNING

 Do not allow the fluid to touch your skin or eyes. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.

CAUTION

 Make sure that the level is between the **MIN** and the **MAX** marks.


Note: *The brake and the clutch systems are supplied from the same reservoir.*

If the level is at the **MIN** mark, top up immediately.

Topping up

Remove the filler cap.


CAUTION

 Do not top up further than the **MAX** mark.


Top up with fluid that meets the Ford specification. See **Technical specifications** (page 216).

POWER STEERING FLUID CHECK

WARNING

 Do not allow the fluid to touch your skin or eyes. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.

CAUTION


 Make sure that the level is between the **MIN** and the **MAX** marks.

If the level is at the **MIN** mark, top up immediately.

Topping up

Remove the filler cap.

CAUTION

 Do not top up further than the **MAX** mark.

Top up with fluid that meets the Ford specification. See **Technical specifications** (page 216).

Maintenance

WASHER FLUID CHECK

Note: The front and rear washer systems are supplied from the same reservoir.

TECHNICAL SPECIFICATIONS

Vehicle fluids

Item	Recommended fluid	Specification
Engine oil	Ford or Motorcraft Formula E SAE 5W-30 Engine Oil*	WSS-M2C913-B
Power steering fluid	Ford or Motorcraft Power Steering Fluid	WSS-M2C204-A2
Coolant	Motorcraft SuperPlus Antifreeze	WSS-M97B44-D
Brake fluid	Ford or Motorcraft Super DOT 4 Brake Fluid	ESD-M6C57-A

CAUTION



Do not use oils which do not meet the specifications or requirements. Use of unsuitable oil may lead to engine damage which is not covered by your Warranty.

* You can use an alternative **SAE 5W-30** engine oil, providing it meets the specification defined by **WSS-M2C913-B**.

Note: If you operate your vehicle in temperatures below -20°C (-4°F), you must not use **SAE 10W-40** engine oil.

Topping up the oil: If you are unable to find an oil that meets the specification defined by **WSS-M2C913-B**, you must use **SAE 5W-30** (preferred), **SAE 5W-40** or **SAE 10W-40** that meets the specification defined by either **ACEA A1/B1** (preferred) or **ACEA A3/B3**. Using these oils can result in longer engine cranking periods, reduced engine performance, reduced fuel economy and increased emission levels.

Maintenance

Capacities

Variant	Item	Capacity in litres (gallons)
All	Power steering system	MAX mark
All	Windscreen and rear window washer system	3.8 (0.8)
1.6L Duratec-16V Ti-VCT	Engine lubrication system - including the oil filter	4.1 (0.9)
1.6L Duratec-16V Ti-VCT	Engine lubrication system - excluding the oil filter	3.8 (0.8)
1.6L Duratec-16V Ti-VCT	Engine cooling system	6.0 (1.3)
1.6L Duratec-16V Ti-VCT	Fuel tank	70 (15.4)
2.0L Duratec-HE	Engine lubrication system - including the oil filter	4.3 (1.0)
2.0L Duratec-HE	Engine lubrication system - excluding the oil filter	3.9 (0.9)
2.0L Duratec-HE	Engine cooling system	6.2 (1.4)
2.0L Duratec-HE	Fuel tank	70 (15.4)
2.3L Duratec-HE	Engine lubrication system - including the oil filter	4.3 (1.0)
2.3L Duratec-HE	Engine lubrication system - excluding the oil filter	3.9 (0.9)
2.3L Duratec-HE	Engine cooling system	6.9 (1.5)
2.3L Duratec-HE	Fuel tank	70 (15.4)

Maintenance

Variant	Item	Capacity in litres (gallons)
2.5L Duratec-ST	Engine lubrication system - including the oil filter	5.8 (1.3)
2.5L Duratec-ST	Engine lubrication system - excluding the oil filter	5.5 (1.2)
2.5L Duratec-ST	Engine cooling system	7.1 (1.6)
2.5L Duratec-ST	Fuel tank	70 (15.4)
1.8L Duratorq-TDCi	Engine lubrication system - including the oil filter	5.6 (1.2)
1.8L Duratorq-TDCi	Engine lubrication system - excluding the oil filter	5.0 (1.1)
1.8L Duratorq-TDCi	Engine cooling system	7.9 (1.7)
1.8L Duratorq-TDCi	Fuel tank	70 (15.4)
2.0L Duratorq-TDCi	Engine lubrication system - including the oil filter	5.5 (1.2)
2.0L Duratorq-TDCi	Engine lubrication system - excluding the oil filter	5.0 (1.1)
2.0L Duratorq-TDCi	Engine cooling system	8.1 (1.8)
2.0L Duratorq-TDCi	Fuel tank	70 (15.4)
2.2L Duratorq-TDCi	Engine lubrication system - including the oil filter	6.0 (1.3)
2.2L Duratorq-TDCi	Engine lubrication system - excluding the oil filter	5.4 (1.2)


Maintenance

Variant	Item	Capacity in litres (gallons)
2.2L Duratorq-TDCi	Engine cooling system	8.4 (1.9)
2.2L Duratorq-TDCi	Fuel tank	70 (15.4)


Vehicle care


CLEANING THE EXTERIOR


WARNING

 If you use a car wash with a waxing cycle, make sure that you remove the wax from the windscreen.

CAUTIONS

 Some car wash installations use water at high pressure. This could damage certain parts of your vehicle.


 Remove the aerial before using an automatic car wash.


 Switch the heater blower off to prevent contamination of the fresh air filter.

We recommend that you wash your vehicle with a sponge and lukewarm water containing a car shampoo.

Cleaning the headlamps


CAUTIONS

 Do not scrape the headlamp lenses or use abrasives or chemical solvents to clean them.

 Do not wipe the headlamps when they are dry.

Cleaning the rear window


CAUTION

 Do not scrape the inside of the rear window or use abrasives or chemical solvents to clean it.

Use a clean, lint free cloth or a damp chamois leather to clean the inside of the rear window.


Cleaning the chrome trim


CAUTION


 Do not use abrasives or chemical solvents. Use soapy water.

Body paintwork preservation

CAUTIONS

 Do not polish your vehicle in strong sunshine.

 Do not allow polish to touch plastic surfaces. It could be difficult to remove.

 Do not apply polish to the windscreen or rear window. This could cause the wipers to become noisy and they may not clear the window properly.

We recommend that you wax the paintwork once or twice a year.

CLEANING THE INTERIOR

Seat belts

WARNINGS



Do not use abrasives, or chemical solvents to clean them.



Do not allow moisture to penetrate the seat belt retractor mechanism.

Clean the seat belts with interior cleaner or water applied with a soft sponge. Let the seat belts dry naturally, away from artificial heat.

REPAIRING MINOR PAINT DAMAGE

CAUTION



Remove apparently harmless looking substances from the paintwork immediately (e.g. bird droppings, tree resins, insect remains, tar spots, road salt and industrial fall out).

You should repair paintwork damage caused by stones from the road or minor scratches as soon as possible. A choice of products is available from your Ford Dealer. Read and follow the manufacturer's instructions.

Vehicle battery

BATTERY CARE



The battery requires very little maintenance. The fluid level is checked regularly during the routine service inspections.

USING BOOSTER CABLES

CAUTIONS

- ⚠ Connect batteries with only the same nominal voltage.
- ⚠ Always use booster cables with insulated clamps and adequate size cable.
- ⚠ Do not disconnect the battery from the vehicle's electrical system.

To connect the booster cables



E75183


- A Flat battery vehicle
- B Booster battery vehicle


Vehicle battery

- C Positive connection cable
- D Negative connection cable

1. Position the vehicles so that they do not touch one another.
2. Switch off the engine and any electrical equipment.
3. Connect the positive (+) terminal of vehicle **B** with the positive (+) terminal of vehicle **A** (cable **C**).
4. Connect the negative (-) terminal of vehicle **B** to the ground connection on the left-hand side suspension turret of vehicle **A** (cable **D**).

CAUTIONS


 **Do not connect to the negative (-) terminal of the flat battery.**

 Make sure that the jump leads are clear of any moving parts.

To start the engine

1. Run the engine of vehicle **B** at moderately high speed.
2. Start the engine of vehicle **A**.
3. Run both vehicles for a minimum of three minutes before disconnecting the cables.

CAUTION



 Do not switch on the headlamps when disconnecting the cables. The peak voltage could blow the bulbs.

Disconnect the cables in the reverse order.

Wheels and tyres

GENERAL INFORMATION

CAUTIONS

-  Use only approved wheel and tyre sizes. Using other sizes could damage the vehicle and will make the National Type Approval invalid.
-  If you change the diameter of the tyres from that fitted at the factory, the speedometer may not display the correct speed. Take the vehicle to your dealer to have the engine management system reprogrammed.

A decal with tyre pressure data is located in the driver's door opening at the B-pillar.

Check and set the tyre pressure at the ambient temperature in which you are intending to drive the vehicle and when the tyres are cold.




CHANGING A ROAD WHEEL

Locking wheel nuts

You can obtain a replacement locking wheel nut key and replacement locking wheel nuts from your dealer using the reference number certificate.

Vehicle jack

WARNINGS

-  The vehicle jack supplied with your vehicle should only be used when changing a wheel in emergency situations.
-  Before using the vehicle jack, check that it is not damaged or deformed and that the thread is lubricated and free from foreign matter.
-  Never place anything between the jack and the ground, or the jack and the vehicle.


Note: *Vehicles with a tyre repair kit or run flat tyres are not equipped with a vehicle jack or a wheel brace.*

It is recommended to use a workshop type hydraulic jack for changing between summer and winter tyres.

Note: *Use a jack with a minimum lifting capacity of 1.5 tonnes and a lifting plate with a minimum diameter of 80 millimetres (3.1 inches).*

Wheels and tyres

Vehicles without tyre repair kit or run flat tyres



E86843

- B Wheel brace
- C Space for locking wheel nut key



Your vehicle jack and wheel brace are located in the spare wheel well.

Jacking and lifting points

CAUTION

⚠ Use only the specified jacking points. If you use other positions, you may damage the body, steering, suspension, engine, braking system or the fuel lines.


A Jack



E92658

Wheels and tyres

- A Emergency use only
- B Maintenance



E93184

Indentations in the sills **A** show the location of the jacking points.



E93020

Vehicles with side skirts






E92932



E95345

Removing a road wheel

WARNINGS

-  Park your vehicle in such a position that neither the traffic nor you are hindered or endangered.
-  Set up a warning triangle.
-  Make sure that the vehicle is on firm, level ground with the wheels pointing straight ahead.

Wheels and tyres

WARNINGS

⚠ Switch off the ignition and apply the parking brake.

⚠ If your vehicle has a manual transmission, select first or reverse gear. If it has an automatic transmission, select park.

⚠ Have the passengers leave the vehicle.

⚠ Secure the diagonally opposite wheel with an appropriate block or wheel chock.

⚠ Make sure that the arrows on directional tyres point in the direction of rotation when the vehicle is moving forwards. If you have to fit a spare wheel with the arrows pointing in the opposite direction, have the tyre refitted in the correct direction by a properly trained technician.

⚠ Do not work underneath the vehicle when it is supported only by a jack.

⚠ Make sure that the jack is vertical to the jacking point and the base is flat on the ground.

CAUTION

⚠ Do not lay alloy wheels face down on the ground, this will damage the paint.

Note: *The spare wheel is located under the floor cover in the luggage compartment.*

1. Insert the flat end of the wheel brace between the rim and the hub cover and carefully remove the hub cap or cover.



E71948

2. Install the locking wheel nut key.
3. Fully extend the wheel brace.
4. Slacken the wheel nuts.
5. Jack up the vehicle until the tyre is clear of the ground.
6. Remove the wheel nuts and the wheel.


Installing a road wheel

WARNINGS

⚠ Use only approved wheel and tyre sizes. Using other sizes could damage the vehicle and will make the National Type Approval invalid. See **Technical specifications** (page 238).

Wheels and tyres

WARNINGS

 Do not fit run flat tyres on vehicles that were not originally fitted with them. Please contact your dealer for more details regarding compatibility.

CAUTION

 Do not install alloy wheels using wheel nuts designed for use with steel wheels.

Note: Make sure the wheel and hub contact surfaces are free from foreign matter.


Note: Make sure that the cones on the wheel nuts are against the wheel.

1. Install the wheel.
2. Install the wheel nuts finger tight.



E71948


3. Install the locking wheel nut key.



E75442

4. Partially tighten the wheel nuts in the sequence shown.
5. Lower the vehicle and remove the jack.
6. Fully tighten the wheel nuts in the sequence shown. See **Technical specifications** (page 238).
7. Install the hub cap or cover using the ball of your hand.

WARNING

 Have the wheel nuts checked for tightness and the tyre pressure checked as soon as possible.

Note: If the spare wheel is different in size or construction to the road wheels, have this replaced as soon as possible.

Wheels and tyres

TYRE REPAIR KIT

Your vehicle may not have a spare tyre. In this case it will have an emergency tyre repair kit that can be used to repair **one** flat tyre.

The tyre repair kit is located in the spare wheel well.

General information

WARNINGS



Depending on the type and extent of tyre damage, some tyres can only be partially sealed or not sealed at all. Loss of tyre pressure can affect vehicle handling, leading to loss of vehicle control.



Do not use the tyre repair kit if the tyre has already been damaged as a result of being driven under inflated.



Do not try to seal damage other than that located within the visible tread of the tyre.



Do not try to seal damage to the tyre's sidewall.

The tyre repair kit seals most tyre punctures [with a diameter of up to six millimetres (1/4 inch)] to temporarily restore mobility.

Observe the following rules when using the kit:

- **Drive with caution and avoid making sudden steering or driving manoeuvres**, especially if the vehicle is heavily loaded or you are towing a trailer.
- The kit will provide you with an emergency temporary repair, enabling you to continue your journey to the next vehicle or tyre dealer, or to drive a maximum distance of 200 kilometres (125 miles).
- Do not exceed a **maximum speed of 80 km/h (50 mph)**.
- Keep the kit out of the reach of children.
- Only use the kit when the ambient temperature is between -30°C (-22°F) and $+70^{\circ}\text{C}$ ($+158^{\circ}\text{F}$).

Using the tyre repair kit

WARNINGS



Compressed air can act as an explosive or propellant.



Never leave the tyre repair kit unattended while in use.

CAUTION



Do not keep the compressor operating for more than 10 minutes.


Note: Use the tyre repair kit only for the vehicle with which it was supplied.

Wheels and tyres





- Park your vehicle at the roadside so that you do not obstruct the flow of traffic and so that you are able to use the kit without being in danger.
- Apply the parking brake, even if you have parked on a level road, to make sure that the vehicle will not move.
- Do not attempt to remove foreign objects like nails or screws penetrating the tyre.
- Leave the engine running while the kit is in use, but not if the vehicle is in an enclosed or poorly ventilated area (for example, inside a building). In these circumstances, switch the compressor on with the engine turned off.
- Replace the sealant bottle with a new one before the expiry date (see top of bottle) is reached.
- Inform all other users of the vehicle that the tyre has been temporarily sealed with the tyre repair kit and make them aware of the special driving conditions to be observed.

Inflating the tyre


WARNINGS

-  Check the sidewall of the tyre prior to inflation. If there are any cracks, bumps or similar damage, do not attempt to inflate the tyre.


WARNINGS

-  Do not stand directly beside the tyre while the compressor is pumping.
-  Watch the sidewall of the tyre. If any cracks, bumps or similar damage appear, turn off the compressor and let the air out by means of the pressure relief valve **B**. Do not continue driving with this tyre.
-  The sealant contains natural rubber latex. Avoid contact with skin and clothing. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.
-  If the tyre inflation pressure does not reach 1.8 bar (26 psi) within seven minutes, the tyre may have suffered excessive damage, making a temporary repair impossible. In this case, do not continue driving with this tyre.

CAUTION

-  Screwing the bottle onto the bottle holder will pierce the seal of the bottle. Do not unscrew the bottle from the holder as the sealant will escape.

Wheels and tyres



E94973

- A Protective cap
- B Pressure relief valve
- C Hose
- D Orange cap

Wheels and tyres

- E Bottle holder
- F Pressure gauge
- G Power plug with cable
- H Compressor switch
- I Label
- J Bottle lid
- K Sealant bottle

1. Open the lid of the tyre repair kit.
2. Peel off the label **I** showing the maximum permissible speed of 80 km/h (50 mph) from the casing and attach it to the instrument panel in the driver's field of view. Make sure the label does not obscure anything important.
3. Take the hose **C** and the power plug with cable **G** out of the kit.
4. Unscrew the orange cap **D** and the bottle lid **J**.
5. Screw the sealant bottle **K** clockwise into the bottle holder **E** fully tight.
6. Remove the valve cap from the damaged tyre.
7. Detach the protective cap **A** from the hose **C** and screw the hose **C** firmly onto the valve of the damaged tyre.
8. Make sure that the compressor switch **H** is in position **O**.
9. Insert the power plug **G** into the cigar lighter socket or auxiliary power socket. See **Cigar lighter** (page 130). See **Auxiliary power sockets** (page 131).
10. Start the engine.
11. Move the compressor switch **H** to position **1**.
12. Inflate the tyre for no longer than seven minutes to an inflation pressure of minimum 1.8 bar (26 psi) and a maximum of 3.5 bar (51 psi). Move the compressor switch **H** to position **O** and check the current tyre pressure with pressure gauge **F**.
13. Remove the power plug **G** from the cigar lighter socket or auxiliary power socket.
14. Quickly unscrew the hose **C** from the tyre valve and replace the protective cap **A**. Fasten the valve cap again.
15. Leave the sealant bottle **K** in the bottle holder **E**.
16. Make sure the kit, the bottle lid and the orange cap are stored safely, but still easily accessible in the vehicle. The kit will be required again when you check the tyre pressure.

Wheels and tyres

17. Immediately drive approximately three kilometres (two miles) so that the sealant can seal the damaged area.

Note: When pumping in the sealant through the tyre valve, the pressure may rise up to 6 bar (87 psi) but will drop again after about 30 seconds.

WARNING



If you experience heavy vibrations, unsteady steering behaviour or noises while driving, reduce your speed and drive with caution to a place where it is safe for you to stop the vehicle. Recheck the tyre and its pressure. If the tyre pressure is less than 1.3 bar (19 psi) or if there are any cracks, bumps or similar damage visible, do not continue driving with this tyre.

Checking the tyre pressure

1. Stop the vehicle after driving approximately three kilometres (two miles). Check, and where necessary, adjust the pressure of the damaged tyre.
2. Attach the kit and read the tyre pressure from the pressure gauge **F**.
3. If the pressure of the sealant-filled tyre is 1.3 bar (19 psi) or more, adjust it to the specified pressure. See **Technical specifications** (page 238).
4. Follow the inflation procedure once again to top up the tyre.

5. Check the tyre pressure again from the pressure gauge **F**. If the tyre pressure is too high, deflate the tyre to the specified pressure using the pressure relief valve **B**.
6. Once you have inflated the tyre to its correct tyre pressure, move the compressor switch **H** to position **O**, remove the power plug **G** from the socket, unscrew the hose **C**, fasten the valve cap and replace the protective cap **A**.
7. Leave the sealant bottle **K** in the bottle holder **E** and store the kit away safely in its original location.
8. Drive to the nearest tyre specialist to get the damaged tyre replaced. Before the tyre is removed from the rim, inform your tyre dealer that the tyre contains sealant. Renew the kit as soon as possible after it has been used once.

Note: Remember that emergency roadside tyre repair kits only provide temporary mobility. Regulations concerning tyre repair after usage of tyre repair kit may differ from country to country. You should consult a tyre specialist for advice.

WARNING



Before driving, make sure the tyre is adjusted to the recommended inflation pressure. See **Technical specifications** (page 238). Monitor the tyre pressure until the sealed tyre is replaced.


Wheels and tyres

Empty sealant bottles can be disposed of together with normal household waste. Return remains of sealant to your dealer or dispose of it in compliance with local waste disposal regulations.

RUN FLAT TYRES

Principle of operation


Standard tyre



E75207

- A Wheel rim position with correct tyre pressure
- B Wheel rim position with insufficient tyre pressure
- C Tyre

Run flat tyre



E87667

- A Wheel rim position with correct tyre pressure
- B Wheel rim position with insufficient tyre pressure
- C Tyre
- D Reinforced sidewall

When a standard tyre experiences a drastic loss of inflation pressure, the rim of the wheel brings the full weight of the vehicle to bear on the collapsed sidewalls. You can barely manoeuvre the vehicle and the tyre is destroyed.

Run flat tyres have sturdy, reinforced sidewalls that support the rim should the tyre suffer a loss of inflation pressure.

What to do if a run flat tyre has a puncture

Due to the run-flat properties of these tyres, you may not notice any tyre defect. Your vehicle is equipped with a tyre pressure monitoring system that alerts you to any drop in tyre pressure. See **Technical specifications** (page 238).

Wheels and tyres

In the event of a tyre defect:

- immediately slow down to a maximum speed of 80 km/h (50 mph)
- avoid sudden or erratic braking and steering manoeuvres and be especially careful negotiating bends
- do not drive more than 80 kilometres (50 miles) after the defect is detected
- have the defective tyre replaced as soon as possible.

Replacing run flat tyres

WARNINGS



Make sure that the workshop is aware that your vehicle is equipped with special run flat tyres.



Never repair or reuse run flat tyres that are damaged or have been driven on run flat.

If a run flat tyre has to be replaced, have the respective wheel rim inspected for any damage.




Do not fit a mixture of run flat and standard tyres. In isolated cases, a standard tyre can be temporarily mounted on a vehicle otherwise equipped with run flat tyres. It must be pointed out to the driver that the standard tyre has no runflat properties.



Do not fit run flat tyres on vehicles that were not originally fitted with them. Please contact your dealer for more details regarding compatibility.

Run flat tyres may be sold and mounted only by specially trained and certified tyre dealers.

TYRE CARE



E70415

To make sure the front and rear tyres of your vehicle wear evenly and last longer, we recommend that you swap the tyres from front to rear and vice versa at regular intervals of between 5 000 and 10 000 km (3 000 and 6 000 miles).

CAUTION



Do not scrub the sidewalls of the tyres when you are parking.

If you have to mount a kerb, do so slowly and approach it with the wheels at right-angles to the kerb.


Examine the tyres regularly for cuts, foreign objects and uneven wear of the tread. Uneven wear could mean that the wheel alignment is outside specification.

Check the tyre pressures (including the spare) when cold, every two weeks.

Wheels and tyres

USING WINTER TYRES




CAUTION

 Make sure that you use the correct wheel nuts for the type of wheel the winter tyres are fitted to.


If winter tyres are used, make sure that the tyre pressures are correct. See **Technical specifications** (page 238).

USING SNOW CHAINS

WARNINGS

-  Do not exceed 50 km/h (30 mph).
-  Do not use snow chains on snow-free roads.
-  Do not fit snow chains to 235/45 R 17, 235/40 R 18 or T125/90 R 16 tyres.

CAUTION

 If your vehicle is fitted with wheel trims, remove them before fitting snow chains.





Note: *The ABS will continue to operate normally.*

Only use small link snow chains.



Only use snow chains on the front wheels.

TYRE PRESSURE MONITORING SYSTEM

WARNINGS

-  The system does not relieve you of your responsibility to regularly check the tyre pressures.
-  The system will only provide a low tyre pressure warning. It will not inflate the tyres.
-  The system may take longer to detect low pressure in the tyres if you have fitted snow chains.
-  Do not drive on significantly under-inflated tyres. This may cause the tyres to overheat and fail. Under-inflation reduces fuel efficiency, tyre tread life and may also affect your ability to drive the vehicle safely.

CAUTIONS

-  Do not bend or damage the valves when you are inflating the tyres.
-  Have tyres installed by properly trained technicians.


The system monitors the pressure in the tyres using sensors located on the wheels and a receiver located in your vehicle. When the system detects low pressure in the tyres, a warning message is displayed in the information display. See **Information messages** (page 99).

Wheels and tyres

If a low pressure warning message is displayed in the information display, check the tyre pressures as soon as possible and inflate them to the recommended pressure. See **Technical specifications** (page 238). If this happens frequently, have the cause determined and rectified as soon as possible.

Checking the tyre pressures

Note: If the tyre pressures are greater than or equal to 3.3 bar (48 lbf/in²), you will see the + symbol below the pressure value. The system only measures pressure up to 3.3 bar (48 lbf/in²). The + symbol indicates that the tyre pressures may be higher.




E74435

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Information** with the up and down buttons and press the right arrow button.

3. Highlight **Tyre Pressures** with the up and down buttons and press the right arrow button.
4. Highlight the desired setting and press the **OK** button to confirm the setting.
5. Press the left arrow button to exit the menu. Hold the left arrow button pressed to return to the trip computer display.

Setting the vehicle load



E74434

Correct tyre pressure settings depend on vehicle load. See **Technical specifications** (page 238). The system can only detect low pressure if you have entered the current vehicle load.

1. Press the right arrow button on the steering wheel to enter the main menu.
2. Highlight **Setup** with the up and down buttons and press the right arrow button.

Wheels and tyres

3. Highlight **Tyre Pressures** with the up and down buttons and press the right arrow button.
4. Highlight the desired setting and press the **OK** button to confirm the setting.
5. Press the left arrow button to exit the menu. Hold the left arrow button pressed to return to the trip computer display.

TECHNICAL SPECIFICATIONS

Wheel nut torque

Wheel type	Nm (lb-ft)
All	130 (96)

Tyre pressures (cold tyres)

Up to 80 km/h (50 mph)

Tyre pressures

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
All	T125/90 R 16	4.2 (61)	4.2 (61)	4.2 (61)	4.2 (61)

Wheels and tyres

Up to 160 km/h (100 mph)

Tyre pressures

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
1.6L Duratec-Ti-VCT	205/55 R 16	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratec-HE	215/55 R 16	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratec-HE	235/45 R 17	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratec-HE	235/40 R 18	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.3L Duratec-HE	215/55 R 16	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.3L Duratec-HE	235/45 R 17	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.3L Duratec-HE	235/40 R 18	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.5L Duratec-ST	215/55 R 16	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.5L Duratec-ST	235/45 R 17	2.4 (35)	2.2 (32)	2.5 (36))	2.8 (41)
2.5L Duratec-ST	235/40 R 18	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
1.8L Duratorq-TDCi	205/55 R 16	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
1.8L Duratorq-TDCi	215/55 R 16	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
1.8L Duratorq-TDCi	235/45 R 17	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
1.8L Duratorq-TDCi	235/40 R 18	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratorq-TDCi	215/55 R 16	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratorq-TDCi	235/45 R 17	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratorq-TDCi	235/40 R 18	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.2L Duratorq-TDCi	215/55 R 16	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.2L Duratorq-TDCi	235/45 R 17	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)

Wheels and tyres

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
2.2L Duratorq-TDCi	235/40 R 18	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)

Continuous speed in excess of 160 km/h (100 mph)

Tyre pressures


Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
1.6L Duratec-Ti-VCT	205/55 R 16	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratec-HE	215/55 R 16	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratec-HE	235/45 R 17	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratec-HE	235/40 R 18	2.2 (32)	2.2 (32)	2.5 (36)	2.8 (41)
2.3L Duratec-HE	215/55 R 16	2.4 (35)	2.2 (32)	2.6 (38)	2.8 (41)
2.3L Duratec-HE	235/45 R 17	2.4 (35)	2.2 (32)	2.6 (38)	2.8 (41)
2.3L Duratec-HE	235/40 R 18	2.4 (35)	2.2 (32)	2.6 (38)	2.8 (41)
2.5L Duratec-ST	215/55 R 16	2.5 (36)	2.3 (33)	2.7 (39)	3 (44)
2.5L Duratec-ST	235/45 R 17	2.5 (36)	2.3 (33)	2.7 (39)	3 (44)
2.5L Duratec-ST	235/40 R 18	2.5 (36)	2.3 (33)	2.7 (39)	3 (44)
1.8L Duratorq-TDCi	205/55 R 16	2.4 (35)	2.2 (32)	2.6 (38)	3 (44)
1.8L Duratorq-TDCi	215/55 R 16	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
1.8L Duratorq-TDCi	235/45 R 17	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
1.8L Duratorq-TDCi	235/40 R 18	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)

Wheels and tyres

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
2.0L Duratorq-TDCi	215/55 R 16	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratorq-TDCi	235/45 R 17	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.0L Duratorq-TDCi	235/40 R 18	2.4 (35)	2.2 (32)	2.5 (36)	2.8 (41)
2.2L Duratorq-TDCi	215/55 R 16	2.5 (36)	2.3 (33)	2.7 (39)	3 (44)
2.2L Duratorq-TDCi	235/45 R 17	2.5 (36)	2.3 (33)	2.7 (39)	3 (44)
2.2L Duratorq-TDCi	235/40 R 18	2.5 (36)	2.3 (33)	2.7 (39)	3 (44)

Vehicle identification

VEHICLE IDENTIFICATION PLATE




E85610

- A Vehicle identification number
- B Gross vehicle weight
- C Gross train weight
- D Maximum front axle weight
- E Maximum rear axle weight

The vehicle identification number and maximum weights are shown on a plate located on the lock side of the passenger door aperture at the bottom.

VEHICLE IDENTIFICATION NUMBER (VIN)



E87496


The vehicle identification number is stamped into the floor panel on the right-hand side, beside the front seat. It is also shown on the left-hand side of the instrument panel.

Technical specifications

TECHNICAL SPECIFICATIONS

Vehicle dimensions

4-door



E87088


Item	Dimension description	Dimension in mm (inches)
A	Maximum length	4 844 (190.7)
B	Overall width including exterior mirrors	2 078 (81.8)

Technical specifications

Item	Dimension description	Dimension in mm (inches)
C	Overall height at EC kerb weight	1 453 - 1 500 (57.2 - 59.1)
D	Wheelbase	2 850 (112.2)
E	Front track	1 579 - 1 589 (62.2 - 62.6)
E	Rear track	1 595 - 1 605 (62.8 - 63.2)

Technical specifications

5-door




E87089

Item	Dimension description	Dimension in mm (inches)
A	Maximum length	4 778 - 4 802 (188.1 - 189.1)
B	Overall width including exterior mirrors	2 078 (81.8)
C	Overall height at EC kerb weight	1 453 - 1 500 (57.2 - 59.1)
D	Wheelbase	2 850 (112.2)

Technical specifications

Item	Dimension description	Dimension in mm (inches)
E	Front track	1 579 - 1 589 (62.2 - 62.6)
E	Rear track	1 595 - 1 605 (62.8 - 63.2)

Estate



E87090


Technical specifications

Item	Dimension description	Dimension in mm (inches)
A	Maximum length	4 830 - 4 856 (190.2 - 191.2)
B	Overall width including exterior mirrors	2 078 (81.8)
C	Overall height at EC kerb weight without roof bars	1 466 - 1 512 (57.7 - 59.5)
C	Overall height at EC kerb weight including roof bars	1 502 - 1 548 (59.1 - 61)
D	Wheelbase	2 850 (112.2)
E	Front track	1 579 - 1 589 (62.2 - 62.6)
E	Rear track	1 595 - 1 605 (62.8 - 63.2)

Technical specifications

Towing equipment dimensions

4-door




E87091

Item	Dimension description	Dimension in mm (inches)
A	Bumper – end of tow ball	102 (4)
B	Attachment point – centre of tow ball	1 (0.04)
C	Wheel centre – centre of tow ball	1 150 (45.3)
D	Centre of tow ball – side member	438 (17.2)
E	Inner side of side member	876 (34.5)

Technical specifications

Item	Dimension description	Dimension in mm (inches)
F	Centre of tow ball – centre 1. attachment point	434 (17.1)
G	Centre of tow ball – centre 2. attachment point	707 (27.8)

5-door




E87092

Item	Dimension description	Dimension in mm (inches)
A	Bumper – end of tow ball	100 (3.9)
A	Bumper – end of tow ball (with sport bumper)	90 (3.5)

Technical specifications

Item	Dimension description	Dimension in mm (inches)
B	Attachment point – centre of tow ball	1 (0.04)
C	Wheel centre – centre of tow ball	1 082 (42.6)
D	Centre of tow ball – side member	438 (17.2)
E	Inner side of side member	876 (34.5)
F	Centre of tow ball – centre 1. attachment point	364 (14.3)
G	Centre of tow ball – centre 2. attachment point	637 (25.1)

Estate



E87093

Technical specifications

Item	Dimension description	Dimension in mm (inches)
A	Bumper – end of tow ball	100 - 110 (3.9 - 4.3)
B	Attachment point – centre of tow ball	1 (0.04)
C	Wheel centre – centre of tow ball	1 134 - 1 144 (44.7 - 45)
D	Centre of tow ball – side member	438 (17.2)
E	Inner side of side member	876 (34.5)
F	Centre of tow ball – centre 1. attachment point	419 - 429 (16.5 - 16.9)
G	Centre of tow ball – centre 2. attachment point	692 - 702 (27.2 - 27.6)

Telephone

GENERAL INFORMATION

This section describes the functions and features of the Bluetooth mobile phone and voice control system.

The section covers the following variations:

- a mobile phone with a mobile phone cradle without voice control
- a Bluetooth and voice control system with a mobile phone cradle
- a Bluetooth and voice control system without a mobile phone cradle.

The Bluetooth mobile phone part of the system provides interaction with the audio or navigation system and your mobile phone. It allows you to use the audio or navigation system to make and receive calls without having to use your mobile phone.

The voice control part of the system can be used to control:

- mobile phone calls
- audio system functions
- vehicle climate control functions.

Note: *The mobile phone does not switch off immediately after the ignition key is turned off: the power down delay is preset to 10 minutes. The time period can be adjusted to between 0 and 60 minutes. This, depending on your mobile phone, can be achieved by creating a phonebook entry on your mobile phone with the name **Timer** and the required delay as it's number.*

If the Bluetooth and voice control is used for an extended period of time when the vehicle is stationary, make sure that the engine is running to avoid draining the battery

TELEPHONE SETUP

Requirements for cradle connection

Your phone must be fitted in a mobile phone holder before it can be used as a cradle phone with your handsfree/voice control system. You will be able to purchase the correct holder for your phone from your dealer.

Placing your phone in the cradle

Note: *Your phone must be fitted in a mobile phone holder to allow you to connect the phone to the cradle.*


Connect your phone to the cradle.

1. Place the base of the phone in the cradle connection.

Note: *Make sure that the phone is pushed fully rearwards in the cradle.*

Telephone

2. Push the phone downwards until a click is heard.



Note: The connection to the system will be displayed on your phone.

Phonebook

After start up access to the phonebook can be delayed for up to two minutes.

Phonebook categories

Depending on your phonebook entry, different categories can be displayed in the audio or navigation unit.

For example:

M	Mobile
O	Office
H	Home
F	Fax

Note: Entries may be displayed without a category attachment.

The category can also be indicated as an icon:



Phone



Mobile



Home



Office



Fax

Making a phone an active phone

When using the system for the first time, no phone is connected to the system.

After switching on the ignition the cradle phone and the Bluetooth phone are recognized differently by the system.

Bluetooth phone

After bonding a Bluetooth phone to the system, this becomes the active phone. For further information refer to the phone menu.

However, in some cases the Bluetooth phone has to be activated by pressing the appropriate station button on the audio or navigation unit.

Turning the ignition back on again, the last active phone is picked up by the system.

Telephone

Bond another Bluetooth phone

Note: *Before another Bluetooth phone can be bonded, the existing active Bluetooth connection has to be deactivated by the mobile phone.*

Bond a new Bluetooth phone as described in the requirements for a Bluetooth connection.

Phones stored in the system are accessible by using the phone list on the audio or navigation unit.

Note: *If six (five Bluetooth phones for cradle phone system) Bluetooth phones have been bonded, one of these has to be deleted in order to bond a new phone.*

Cradle phone

With your phone fitted in the mobile phone cradle this does not automatically become the active phone.

In these cases refer to **Changing the active phone** in the appropriate section which describes the system fitted to your vehicle.

BLUETOOTH SETUP

Before you can use your telephone with your vehicle it must be bonded to the vehicle telephone system.

Handling of phones

A phone can be connected to the vehicle system by using either a cradle connection or a Bluetooth connection.

On vehicles with a mobile phone cradle, up to five Bluetooth phones can be bonded to the vehicle system.

On vehicles without a mobile phone cradle, up to six Bluetooth phones can be bonded to the vehicle system.

Note: *If there is an ongoing call when the phone in use is selected as the new active phone, the call is transferred to the vehicle audio system.*

Note: *Even if connected to the car system, your phone can still be used in the usual way.*

Requirements for Bluetooth connection

The following are required before a Bluetooth phone connection can be made.

1. The Bluetooth feature must be activated on the phone and on the audio unit. For additional information, refer to your phone user guide
2. The private mode must not be activated on the Bluetooth phone.
3. Search for audio device.
4. Select **Ford Audio**.
5. The Bluetooth PIN number 0000 must be entered on the phone keypad.

Telephone

Note: A phone call will be disconnected if the audio/navigation system is switched off. If the ignition key is turned to the off position the phone call will remain in progress.

Compatibility of phones

CAUTION

! As no common agreement exists, mobile phone manufacturers are able to implement a variety of profiles in their Bluetooth devices. Because of this, an incompatibility can occur between the phone and hands-free system, which in some cases may significantly degrade the system performance. To avoid this situation, only recommended phones should be used. Please contact your dealer for more details regarding the current compatibility list.

Phones with Symbian operating system

Note: Certain phones require a special file to be installed to enable full phonebook access via Bluetooth. This is referred to as a SIS file and will be available via the Ford website. Please consult your dealer for full details.

TELEPHONE CONTROLS


Ending or rejecting calls

By pressing one of several function buttons on the audio or navigation unit (example: AM/FM, CD/AUX) active calls can be ended or incoming calls can be rejected.

Remote control

One of several different types of remote control may be fitted to your vehicle:

Voice and mode button




E87661

- 1 Voice button
- 2 Mode button

Incoming calls can be accepted by pressing the MODE button once or ended by pressing twice.

Telephone

Voice and accept/reject button



E87662


- 1 Voice button
- 2 Accept/Reject button

The VOICE button is used to activate or switch off the Voice control.

On vehicles with an accept/reject button, phone calls can be accepted and rejected by pressing the appropriate button.


Note: Some audio units have the accept/reject buttons on the front bezel. These operate in the same way.

Mode button on the steering wheel



E87663

Mode button only



E87664

On vehicles without a VOICE button, the MODE button on the remote control is used to activate or switch off the voice control.

Note: You will not be able to use the MODE button to activate the voice control during an incoming or active call.

You will not be able to use the MODE button to control the audio system.

USING THE TELEPHONE - VEHICLES WITHOUT: NAVIGATION SYSTEM

This chapter describes the phone functions of the audio unit.

Note: Refer to your audio guide for details of the controls.

An active phone must be present.

Even if connected to the audio unit, your phone can still be used in the usual way.

Note: You can exit the phone menu by pressing any source button **CD**, **AM/FM** or **AUX**.

Telephone

Making a call

Dialling a number

You can access your phone address book either with the phone docked in the cradle or via Bluetooth. The entries will appear in the audio unit display.

1. Press the **PHONE** or the call accept button.
2. Press the **MENU** button.
3. Keep pressing the **MENU** button until **PHONEBOOK** appears.
4. Press the seek buttons to select the desired phone number.

Note: *Press and hold the seek button to skip to the next letter in the alphabet.*

5. Press the **PHONE** or the call accept button to dial the selected phone number.

If you have an audio unit with a telephone keypad (buttons 0-9, * and #), you can also direct dial by entering the number on the radio display via the keypad and pressing the call accept button:

1. Press the call accept button.
2. Dial the number using the telephone keypad on the audio unit.
3. Press the call accept button.

Note: *If you enter an incorrect digit whilst entering a phone number, press the seek down button to erase the last digit. A long press will erase the complete string of digits.*

*Press and hold **0** to enter a + digit.*

Ending a call

Calls can be ended by either:

- pressing one of the following buttons on the audio unit: **PHONE**, **CD**, **AM/FM** or **ON/OFF**
- pressing the **MODE** button on the remote control
- pressing the call reject button.

Note: *If you have an audio unit with a telephone keypad you can end a call only with the call reject button.*

Redialling a number

1. Press the **PHONE** or the call accept button.
2. Press the **MENU** button.
3. Select the **CALL OUT** list or the **CALL IN** list.

Note: *If the active phone does not provide a call out list, the last outgoing call number/entry is displayed.*

4. Press the seek button on the audio unit.
5. Press the **PHONE** or the call accept button to dial the desired phone number.

Redialling the last dialled number

Note: *This applies to only audio units with a telephone keypad*

1. Press the call accept button.

Telephone

2. Press the call accept button again to display the last dialled number.
3. Press the call accept button a third time to dial the number.

Receiving an incoming call

Accepting an incoming call

Incoming calls can be accepted by either:

- pressing the **PHONE** button
- pressing the **MODE** button on the remote control
- pressing the call accept button.

Rejecting an incoming call

Incoming calls can be rejected by either:

- pressing the call reject button
- pressing the **CD** button
- pressing the **AM/FM** button.

Note: *If you have an audio unit with a telephone keypad you can only reject a call with the call reject button.*

Note: *You cannot reject an incoming call using the remote control.*

Handling a second incoming call

Note: *The second incoming call function must be activated in your phone.*

If there is an incoming call whilst there is an ongoing call, a beep will be heard and you will have the option to end the active call and to accept the incoming call.

Accepting a second incoming call

Second incoming calls can be accepted by either:

- pressing the call accept button
- pressing the **MODE** button on the remote control
- pressing the **PHONE** button.

Note: *This will cancel the ongoing call.*

Rejecting a second incoming call

Second incoming calls can be rejected by pressing either:

- pressing the call reject button
- pressing the **CD** button
- pressing the **AM/FM** button.

Note: *If you have an audio unit with a telephone keypad you can only reject a call with the call reject button.*

Changing the active phone

Note: *Phones must be bonded to the system before they can be made active.*

Using the station storage button

1. Press the **PHONE** button on the audio unit.
2. Press the preset number required (using the station preset buttons 1 - 6).

Note: *This process is only for audio units without a telephone keypad.*

Telephone

Using the audio unit menu

1. Press the **PHONE** or call accept button.
2. Press the **MENU** button on the audio unit.
3. Select the **ACTIVE PHONE** option on the audio unit.
4. Scroll through the different stored phones by using the seek buttons to display the bonded phones.
5. Press the **MENU** button to select the phone which is to be the active phone.

Note: *After bonding a Bluetooth phone to the system, this becomes the active phone.*

Debonding a bonded phone

A bonded phone can be deleted from the system at any time, unless a phone call is in progress.

1. Press the **PHONE** or call accept button.
2. Press the **MENU** button on the audio unit.
3. Select the **DEBOND** option on the audio unit.
4. Scroll through the different phones by using the seek buttons and display the phone to be debonded.
5. Press the **MENU** button to select the phone which is to be debonded.

USING THE TELEPHONE - TRAVEL PILOT EX

This chapter describes the phone functions of the Navigation System TravelPilot EX.

Note: *Refer to your Navigation System TravelPilot EX guide for details of the controls.*

An active phone must be present.

Even if connected to the Navigation System TravelPilot EX, your phone can still be used in the usual way.

Making a call

Dialling a number - cradle phone

Using the cradle phone allows you to access your mobile phone address book. The entries will appear in the TravelPilot EX display.

1. Press the **PHONE** button on the audio unit.
2. Using the **PHONEBOOK** option in the menu.
3. Choose one of the letter areas.
4. Turning the right rotary entry control, select the desired phone number.
5. By pressing the **INFO** button the details of the phonebook entry can be displayed.
6. Press the right rotary entry control button.

Telephone

Dialling a number - Bluetooth phone

Using the Bluetooth phone, phone numbers can be dialled using voice control, refer to the **Voice control** chapter.

Ending a call

Calls can be ended by either:

- pressing the reject button
- pressing the MODE button on the remote switch
- pressing the off button on the navigation system
- pressing the right rotary entry control button.

Redialling a number - cradle phone

1. Press the PHONE button on the audio unit.
2. Press the MENU button.
3. Select the **CALL OUT** list, **CALL IN** list or **REDIAL**.
4. Press the PHONE button on the audio unit to dial the desired phone number.

Redialling a number - Bluetooth phone

1. Press the PHONE button on the audio unit.
2. Press the MENU button.
3. Select **REDIAL**.
4. Press the PHONE button on the audio unit to dial the phone number.

Handling an incoming call

Accepting an incoming call

Incoming calls can be accepted by either:

- pressing the accept button
- pressing the MODE button on the remote control
- pressing the PHONE button on the audio unit
- using the **ACCEPT** option in the menu.

Rejecting an incoming call

Incoming calls can be rejected by either:

- pressing the reject button
- pressing one of the following buttons on the audio unit: CD, AM/FM
- using the **REJECT** option in the menu.

Note: *You cannot reject an incoming call using the remote control MODE button.*

Handling a second incoming call

Note: *The second incoming call function must be activated in your phone.*

If there is an incoming call, whilst there is an ongoing call, a beep will be heard and you will have the option to end the active call and to accept the incoming call.

Telephone

Accepting a second incoming call

Second incoming calls can be accepted by either:

- Pressing the accept button.
- Pressing the MODE button on the remote control.
- Pressing the PHONE button on the audio unit.
- Using the **ACCEPT** option in the menu.

Note: *This will cancel the ongoing call.*

Rejecting a second incoming call

Second incoming calls can be rejected by pressing either:

- The reject button
- one of the following buttons on the audio unit: CD, AM/FM.

Changing the active phone

Note: *Phones must be bonded to the system before they can be made active.*

1. Press the PHONE button on the audio unit.
2. Using the **ACTIVE PHONE** option in the menu, select the active phone from the list using the preset buttons.

Debonding a bonded phone

A bonded phone can be deleted from the system at any time, unless a phone call is in progress.

1. Press the PHONE button on the audio unit.
2. Select the **DEBOND** option in the menu.
3. Select the phone from the list by using the preset buttons.

Note: *After bonding a Bluetooth phone to the system, this becomes the active phone.*

However, in some cases the Bluetooth phone has to be activated by pressing the appropriate station button on the audio or navigation unit.

Voice control

PRINCIPLE OF OPERATION

Voice recognition enables operation of the audio system without the need to divert your attention from the road ahead in order to change settings, or receive feedback from the system.

Whenever you issue one of the defined commands with the system active, the voice recognition system converts your command into a control signal for the audio system. Your inputs take the form of dialogues or commands. You are guided through these dialogues by announcements or questions.

Please familiarise yourself with the functions of the audio system before using voice recognition.

Note: *If the Bluetooth and voice control is used for an extended period of time when the vehicle is stationary, make sure that the engine is running to avoid draining the battery.*

Supported commands

The voice control system allows you to control the following vehicle functions:

- phone
- radio
- CD Player
- climate control
- navigation system.

Note: *The voice control system is language specific. If you require the system to operate in another language please consult your dealer.*

System response

As you work through a voice session the system will prompt you with a beep tone each time the system is ready to proceed.

Do not try to give any commands until the beep tone has been heard. The voice control system will repeat each spoken command back to you.

If you are not sure how to continue say "HELP" for assistance or "CANCEL" if you do not wish to continue.

The "HELP" function provides only a subset of the available voice commands. Detailed explanations of all possible voice commands can be found on the following pages.

Voice commands

All voice commands should be given using a natural speaking voice, as if speaking to a passenger or on the phone. Your voice level should be dependant on the surrounding noise level inside or outside the vehicle but do not shout.

Name tag

The name tag functionality can support the phone, audio and navigation features by using the "STORE NAME" function.

Voice control

- Store up to 20 name tags per function.
- The average recording time for each name tag is approximately 2-3 seconds.

USING VOICE CONTROL

System operation

The order and content of the voice controls are given in the following lists. The tables show the sequence of user voice commands and system responses for each available function.

<> indicates a number or stored name tag to be inserted by the user.

Short cuts


There are a number of voice command short cuts available, which allow you to control some vehicle features without having to follow the complete command menu. These are:

- phone: "MOBILE NAME"¹, "DIAL NUMBER", "DIAL NAME" and "REDIAL"
- CD player: "DISC" and "TRACK"
- climate control: "TEMPERATURE", "FAN", "AUTO MODE", "DEFROSTING/DEMISTING ON" and "DEFROSTING/DEMISTING OFF"
- radio: "TUNE NAME"
- navigation: "ZOOM" and "ROUTE SETTING".

1) Only when the mobile phone is fitted with Bluetooth and voice control

Start communicating with the system

Before you can start talking to the system you first have to press the **VOICE** or **MODE** button for each operation and wait until the system answers with a beep.



E87665

AUDIO UNIT COMMANDS

CD Player/CD Changer

You can choose a disc or track directly by voice control.

Voice control

Overview

The overview below shows the available voice commands for operating your CD player. The following lists will give further information about the complete command menu.

"CD"
"HELP"
"DISC" ^a
"TRACK" ^b

a) Can only be used with a CD changer.

b) Can be used as a shortcut.

Disc

If you have a CD changer you can choose the disc number.

Steps	User says	System answer
1	"CD"	"CD"
2	"DISC" ^a	"DISC NUMBER PLEASE"
3	"<a number between 1 and 6>"	"DISC <number>"

a) Can be used as a shortcut.

Track

You can also choose a track on your CD directly.

Steps	User says	System answer
1	"CD"	"CD"

Voice control

Steps	User says	System answer
2	"TRACK" ^a	"TRACK NUMBER PLEASE"
3	"<a number between 1 and 99>"	"TRACK <number>"

a) Can be used as a shortcut.

Radio

The radio voice commands support the functionality of the radio and allow you to tune radio stations by voice control.

Overview

The overview below shows the available voice commands for operating your radio. The following lists will give further information about the complete command menu.

"RADIO"
"HELP"
"AM"
"FM"
"TUNE NAME" ^a
"DELETE NAME"
"DELETE DIRECTORY"
"PLAY DIRECTORY"
"STORE NAME"

a) Can be used as a shortcut.

Tune frequency

This function allows you to tune your radio by voice commands.

Voice control

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"AM"	"FREQUENCY PLEASE"
	"FM"	"FREQUENCY PLEASE"
3	"<frequency>"	"TUNE <frequency>"

Store name

If you have tuned a radio station, you can store it with a name in the directory.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"STORE NAME"	"STORE NAME" "NAME PLEASE"
3	"<name>"	"REPEAT NAME PLEASE"
4	"<name>"	"STORING NAME" "<name> STORED"

Tune name

This function allows you to call up a stored radio station.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"TUNE NAME" ^a	"NAME PLEASE"
3	"<name>"	"TUNE <name>"

a) Can be used as a shortcut.

Voice control

Delete name

This function allows you to delete a stored radio station.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"DELETE NAME"	"NAME PLEASE"
3	"<name>"	"DELETE <name>" "CONFIRM YES OR NO"
4	"YES"	"DELETED"
	"NO"	"COMMAND CANCELLED"

Play directory

This function allows you to let the system tell you all of the stored radio stations.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"PLAY DIRECTORY"	"PLAY <DIRECTORY>"

Delete directory

This function allows you to delete all stored radio stations at once.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"DELETE DIRECTORY"	"DELETE DIRECTORY" "CONFIRM YES OR NO"
3	"YES"	"RADIO DIRECTORY DELETED"
	"NO"	"COMMAND CANCELLED"

Voice control

TELEPHONE COMMANDS

Overview

Phone

Your phone system allows you to create an additional phonebook. The stored entries can be dialed by voice control. Phone numbers stored by using voice control are stored on the vehicle system and not in your phone.

The overview below shows the available voice commands of the phone system. The following lists will give further information about the complete command menu.

"PHONE"
"HELP"
"MOBILE NAME" ^{a, b}
"DIAL NUMBER" ^a
"DIAL NAME" ^a
"DELETE NAME"
"DELETE DIRECTORY"
"PLAY DIRECTORY"
"STORE NAME"
"REDIAL" ^a
"ACCEPT CALLS"
"REJECT CALLS"

a) Can be used as a shortcut.

b) Only possible on mobiles which are connected by Bluetooth and fitted with voice control and stored name tags.

Voice control

Create a phonebook

Store name

New entries can be stored with the "STORE NAME" command. This feature can be used to dial a number by calling up the name instead of the full phone number.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"STORE NAME"	"STORE NAME" "NAME PLEASE"
3	"<name>"	"REPEAT NAME PLEASE"
4	"<name>"	"STORING NAME" "<name> STORED" "NUMBER PLEASE"
5	"<phone number>"	"<phone number>"
6	"STORE"	"STORING NUMBER" "<phone number>" "NUMBER STORED"

Delete name

Stored names can also be deleted from the directory.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DELETE NAME"	"NAME PLEASE"
3	"<name>"	"DELETE <name>" "CONFIRM YES OR NO"
4	"YES"	"<name> DELETED"
	"NO"	"COMMAND CANCELLED"

Voice control

Play directory

Use this function to let the system tell you all stored entries.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"PLAY DIRECTORY"	"PLAY DIRECTORY"

Delete directory

This function allows you to delete all entries in one go.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DELETE DIRECTORY"	"DELETE DIRECTORY" "CONFIRM YES OR NO"
3	"YES"	"PHONE DIRECTORY DELETED"
	"NO"	"COMMAND CANCELLED"

Phone functions

Mobile name

This function allows you to access phone numbers stored with a name tag in your mobile phone.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"MOBILE NAME" ^{a, b}	"MOBILE NAME" "<phone dependent dialogue>"

a) Can be used as a shortcut.

Voice control

b) Only when the mobile phone is fitted with Bluetooth and voice control (dependant on the mobile phone).

Dial number

Phone numbers can be dialled after giving the name tag voice command.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DIAL NUMBER" ^a	"NUMBER PLEASE"
3	"<phone number>"	"<phone number> CONTINUE?"
4	"DIAL "	"DIALLING"
	"CORRECTION"	"<repeat last part of number> CONTINUE?"

a) Can be used as a shortcut.

Dial name

Phone numbers can be dialled after giving the name tag voice command.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DIAL NAME" ^a	"NAME PLEASE"
3	"<name>"	"DIAL <name>" "CONFIRM YES OR NO"
4	"YES"	"DIALLING"
	"NO"	"COMMAND CANCELLED"

a) Can be used as a shortcut.

Voice control

Redial

This function allows you to redial the last dialled phone number.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"REDIAL" ^a	"REDIAL" "CONFIRM YES OR NO"
3	"YES"	"DIALLING"
	"NO"	"COMMAND CANCELLED"

a) Can be used as a shortcut.

DTMF (Tone dialling)

This function transfers spoken numbers into DTMF tones, i.e. to make a remote enquiry to your home answering machine.

Note: DTMF can only be used during an ongoing call. Press the VOICE button or the MODE button and wait for the system prompt.

Steps	User says	System answer
1		"NUMBER PLEASE"
2	"<numbers 1 to 9, zero, hash, star>"	

Main settings

Accept and reject calls

Calls can be accepted or rejected using the Voice Control.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"ACCEPT CALLS"	"ACCEPT CALLS"

Voice control

Steps	User says	System answer
	"REJECT CALLS"	"REJECT CALLS"

NAVIGATION SYSTEM COMMANDS

Please refer to your separate Navigation handbook for details of the command menus.

CLIMATE CONTROL COMMANDS

Climate

The climate voice commands supports the functionality of the fan speed, temperature and mode settings. Not all functions are available on all vehicles.

Overview

The overview below shows the available voice commands for operating your climate control system. The following lists will give further information about the complete command menu.

"CLIMATE"
"HELP"
"FAN" ^a
"DEFROSTING/DEMISTING ON" ^a
"DEFROSTING/DEMISTING OFF" ^a
"TEMPERATURE" ^a
"AUTO MODE" ^a

a) Can be used as a shortcut. On vehicles fitted with an English language module the "FAN" shortcut is not available.

Voice control

Fan

This function allows you to adjust the fan speed.

Steps	User says	System answer
1	"CLIMATE"	"CLIMATE"
2	"FAN" ^a	"FAN SPEED PLEASE"
3	"MINIMUM"	"FAN MINIMUM"
	"<a number between 1 and 7>"	"FAN <number>"
	"MAXIMUM"	"FAN MAXIMUM"

a) Can be used as a shortcut. On vehicles fitted with an English language module the "FAN" shortcut is not available.

Defrosting/Demisting

Steps	User says	System answer
1	"CLIMATE"	"CLIMATE"
2	"DEFROSTING/DEMISTING ON" ^a	"DEFROSTING/DEMISTING ON"
	"DEFROSTING/DEMISTING OFF" ^a	"DEFROSTING/DEMISTING OFF"

a) Can be used as a shortcut.

Temperature

This function allows you to adjust the temperature.

Steps	User says	System answer
1	"CLIMATE"	"CLIMATE"
2	"TEMPERATURE" ^a	"TEMPERATURE PLEASE"

Voice control

Steps	User says	System answer
3	"MINIMUM"	"TEMPERATURE MINIMUM"
	"<a number between 15 and 29 °C with 0.5 increments>" or "<a number between 59 and 84 °F>"	"TEMPERATURE <number>"
	"MAXIMUM"	"TEMPERATURE MAXIMUM"

a) Can be used as a shortcut.

Auto mode

Steps	User says	System answer
1	"CLIMATE"	"CLIMATE"
2	"AUTO MODE" ^a	"AUTO MODE"

a) Can be used as a shortcut. Can be deactivated by selecting a different temperature or fan speed.


Appendices


ELECTROMAGNETIC COMPATIBILITY


WARNINGS


 Your vehicle has been tested and certified to European legislations relating to electromagnetic compatibility (2004/104/EC). It is your responsibility to ensure that any equipment you have fitted complies with applicable local legislations. Have any equipment fitted by properly trained technicians.


WARNINGS

 Radio frequency (RF) transmitter equipment (e.g. cellular telephones, amateur radio transmitters etc.) may only be fitted to your vehicle if they comply with the parameters shown in the table below. There are no special provisions or conditions for installations or use.

 Do not mount any transceiver, microphones, speakers, or any other item in the deployment path of the airbag system.

 Do not fasten antenna cables to original vehicle wiring, fuel pipes and brake pipes.

 Keep antenna and power cables at least 100mm from any electronic modules and airbags.



E85998

Appendices

Frequency Band MHz	Maximum output power Watt (Peak RMS)	Antenna Positions
1 – 30	50 W	3, 8
30 – 54	50 W	2, 3
68 – 87.5	50 W	1, 2, 3, 4, 5
142 – 176	50 W	1, 2, 3, 4, 5
380 – 512	50 W	1, 2, 3, 4, 5
806 – 940	10 W (2 W ¹)	1, 2, 3, 4, 5 (6 ¹ , 7 ¹)
1200 – 1400	10 W	2
1710 – 1885	10 W (1 W ¹)	1, 2, 3, 4, 5 (6 ¹ , 7 ¹)
1885 – 2025	10 W (1 W ¹)	1, 2, 3, 4, 5 (6 ¹ , 7 ¹)
2400 – 2500	0.1 W	All positions

¹Only for GSM/3G cellular phones, with a patch antenna installed inside of the front windscreen.

Note: After the installation of RF transmitters, check for disturbances from and to all electrical equipment in the vehicle, both in the standby and transmit modes.

Check all electrical equipment:

- with the ignition **ON**
- with the engine running
- during a road test at various speeds.

Check that electromagnetic fields generated inside the vehicle cabin by the transmitter installed do not exceed human exposure limits specified in EU directive 2004/40/EC.

TYPE APPROVALS

Bluetooth/voice recognition system - declaration of conformity

We, the party responsible for compliance, declare under our sole responsibility that the Handset Integration product RX-1C is in conformity with the provisions of the following Council Directive: 1999/5/EC. A copy of the Declaration of Conformity can be found at:

www.nokia.com/phones/declaration_of_conformity

Appendices

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Ford Motor Company is under license. Other trademarks and trade names are those of their respective owners. Nokia Corporation Keilalahdentie 4, 02150 Espoo, Finland

Index

A

A/C

See: Climate control.....109

About this handbook.....7

ABS

See: Brakes.....151

ABS driving hints

See: Hints on driving with ABS.....151

ACC

See: Adaptive cruise control

(ACC).....163

Accessories

See: Parts and accessories.....7

See: Using ACC.....165

Active suspension.....158

Principle of operation.....158

Active suspension

See: Using active suspension.....158

Adaptive cruise control

(ACC).....163

Principle of operation.....163

Adaptive cruise control

See: Using ACC.....165

Adaptive front lighting system

(AFS).....59

Cornering lamps.....60

Adjusting the steering wheel.....49

AFS

See: Adaptive front lighting system

(AFS).....59

Air conditioning

See: Climate control.....109

Air vents.....109

Front air vents.....109

Rear air vents.....110

Alarm.....45

Principle of operation.....45

Appendices.....276

Arming the alarm.....47

Arming the engine immobiliser.....44

Ashtray.....131

Front ashtray.....131

Rear ashtray.....131

Audible warnings and

indicators.....84

Switching the chimes on and off.....84

Audio control.....49

Mode.....49

Seek.....50

Audio unit commands.....263

CD Player/CD Changer.....263

Radio.....265

Auto-dimming mirror.....78

Autolamps.....57

Automatic climate control.....113

Air distribution.....115

Automatic climate control.....113

Blower.....114

Mono mode.....114

Recirculated air.....115

Setting the temperature.....114

Switching the air conditioning on and

off.....115

Switching the automatic climate

control on and off.....115

Windscreen defrosting and

demisting.....115

Automatic transmission.....148

Drive modes.....149

Emergency park position release

lever.....149

Hints on driving with an automatic

transmission.....149

Selector lever positions.....148

Autowipers.....51

Auxiliary heater.....116

Diesel auxiliary heater (depending on

country).....119

Fuel operated heater (depending on

country).....119

Parking heater.....116

Index

Auxiliary input (AUX IN)	
socket.....	135
Auxiliary power sockets.....	131

B

Battery care.....	222
Bluetooth setup.....	254
Compatibility of phones.....	255
Handling of phones.....	254
Requirements for Bluetooth connection.....	254
Bonnet lock	
See: Opening and closing the bonnet.....	203
Booster cables	
See: Using booster cables.....	222
Booster cushions.....	20
Booster cushion.....	21
Booster seat.....	20
Integrated booster cushion.....	21
Brake and clutch fluid check.....	215
Topping up.....	215
Brakes.....	151
Principle of operation.....	151
Bulb changing	
See: Changing a bulb.....	63
Bulb specification chart.....	71

C

Cargo nets.....	173
Luggage retention net.....	173
Car wash	
See: Cleaning the exterior.....	220
Catalytic converter.....	142
Driving with a catalytic converter.....	142
Parking.....	143

Changing a bulb.....	63
Approach lamp.....	65
Central high mounted brake lamp.....	68
Front fog lamps.....	66
Headlamp.....	64
Interior lamp.....	69
Luggage compartment lamp.....	71
Number plate lamp.....	69
Reading lamps.....	70
Rear lamps.....	66
Side repeaters.....	65
Vanity mirror lamp.....	71
Changing a fuse.....	189
Changing a road wheel.....	224
Installing a road wheel.....	227
Jacking and lifting points.....	225
Locking wheel nuts.....	224
Removing a road wheel.....	226
Vehicle jack.....	224
Changing the remote control battery.....	34
Remote control with a folding key blade.....	34
Remote control without a folding key blade.....	35
Changing the wiper blades.....	53
Rear window wiper blades.....	54
Windscreen wiper blades.....	53
Checking the wiper blades.....	53
Child safety.....	19
Child safety locks.....	27
Child seat positioning.....	22
Child seats.....	19
Child restraints for different mass groups.....	19
Cigar lighter.....	130
Cleaning the exterior.....	220
Body paintwork preservation.....	220
Cleaning the chrome trim.....	220
Cleaning the headlamps.....	220
Cleaning the rear window.....	220

Index

Cleaning the interior.....	221	Dog guard.....	174
Seat belts.....	221	Installing the dog guard.....	175
Climate control.....	109	DPF	
Principle of operation.....	109	See: Diesel particulate filter (DPF)....	140
Climate control commands.....	273	Driving hints.....	183
Climate.....	273		
Clock.....	130	E	
Coded keys.....	44	Electric exterior mirrors.....	76
Convenience features.....	130	Electric folding mirrors.....	76
Coolant check		Mirror tilting positions.....	76
See: Engine coolant check.....	214	Reverse mirror dipping.....	77
Cruise control.....	161	Electric seats.....	125
Principle of operation.....	161	2-way electric seat.....	125
Cruise control		8-way electric seat.....	126
See: Using cruise control.....	161	Electric sunroof.....	120
Cup holders.....	132	Opening and closing the sunroof....	120
D		Opening and closing the sunroof	
Detachable tow ball.....	179	automatically.....	121
Driving with a trailer.....	181	Sunroof anti-trap protection.....	122
Driving without a trailer.....	182	Sunroof relearning.....	122
Inserting the tow ball arm.....	180	Sunroof safety mode.....	122
Maintenance.....	182	Tilting the sunroof.....	121
Removing the tow ball arm.....	181	Electric windows.....	73
Unlocking the tow ball arm		Anti-trap function.....	74
mechanism.....	180	Driver's door switches.....	73
Diesel particulate filter (DPF).....	140	Front and rear passengers' door	
Regeneration.....	140	switches.....	73
Direction indicators.....	61	Global opening and global	
Disabling the passenger		closing.....	73
airbag.....	32	Opening and closing the windows	
Disabling the passenger airbag.....	33	automatically.....	74
Enabling the passenger airbag.....	33	Resetting the memory of the electric	
Fitting the passenger airbag		windows.....	75
deactivation switch.....	33	Safety mode.....	75
Disarming the alarm.....	47	Safety switch for rear windows.....	74
Vehicles with keyless entry.....	47	Electromagnetic	
Vehicles without keyless entry.....	47	compatibility.....	276
Disarming the engine		Emergency equipment.....	184
immobiliser.....	44	Engine compartment overview.....	

Index

Engine coolant check.....	214
Checking the coolant level.....	214
Topping up.....	214
Engine immobiliser.....	44
Principle of operation.....	44
Engine oil check.....	213
Checking the oil level.....	213
Topping up.....	214
Engine oil dipstick.....	
Exterior mirrors.....	75
Convex mirrors.....	75
Folding mirrors.....	75

F

Fastening the seat belts.....	31
First aid kit.....	184
Forward alert function.....	168
Adjusting the warning sensitivity.....	169
Switching forward alert on/off.....	169
Front fog lamps.....	57
Fuel and refuelling.....	142
Technical specifications.....	144
Fuel burning heater	
See: Auxiliary heater.....	116
Fuel consumption	
See:	144
Fuel consumption.....	144
Fuel filler flap.....	143
Vehicles with diesel engine.....	143
Fuel quality.....	
Fuse box locations.....	187
Central fuse box.....	187
Engine compartment fuse box.....	187
Rear fuse box - 4-door and	
5-door.....	188
Rear fuse box - Estate.....	188
Fuses.....	187
Fuse specification chart.....	190
Central fuse box.....	193
Engine compartment fuse box.....	190
Rear fuse box.....	196

G

Gauges.....	79
Engine coolant temperature	
gauge.....	80
Fuel gauge.....	81
Gearbox	
See: Transmission.....	147
General information on radio	
frequencies.....	34
Glasses holder.....	135
Global opening and closing.....	38
Global closing.....	39
Global opening.....	39
Glove box.....	132
Cooled glove box.....	132

H

Handbrake	
See: Parking brake.....	152
Hazard warning flashers.....	59
Headlamp levelling.....	58
Recommended headlamp levelling	
switch positions.....	58
Headlamp washers.....	53
Head restraints.....	127
Adjusting the head restraint.....	127
Removing the head restraint.....	127
Heated seats.....	128
Heated windows and mirrors.....	116
Heated exterior mirrors.....	116
Heated windows.....	116
Heating	
See: Climate control.....	109
Hill launch assist (HLA).....	155
Principle of operation.....	155
Hill launch assist	
See: Using HLA.....	155
Hints on driving with ABS.....	151
HLA	
See: Hill launch assist (HLA).....	155

Index

See: Using HLA.....	155	ISOFIX anchor points.....	25
		Attaching a child seat with top tethers.....	25
		Top tether anchor points.....	25
I		J	
Ignition switch.....	136	Jump starting	
Immobiliser		See: Using booster cables.....	222
See: Engine immobiliser.....	44	K	
Information displays.....	85	Keyless entry.....	40
General information.....	85	Disabled keys.....	42
Information messages.....	99	General information.....	40
Active suspension.....	100	Locking and unlocking the doors with the key blade.....	43
Alarm.....	100	Locking the vehicle.....	41
Battery and charging system.....	101	Passive key.....	40
Climate control.....	101	Unlocking the vehicle.....	41
Cruise control / Adaptive cruise control (ACC).....	101	Keyless starting.....	136
Doors open.....	102	Failure to start.....	137
Engine immobiliser.....	102	Ignition on.....	137
Hill launch assist (HLA).....	103	Starting a diesel engine.....	137
Keyless system.....	103	Starting with automatic transmission.....	137
Lighting.....	104	Starting with manual transmission.....	137
Maintenance.....	104	Stopping the engine.....	138
Message indicator.....	99	Keys and remote controls.....	34
Message symbols.....	99	Keys	
Occupant protection.....	105	See: Using the key.....	34
Power steering.....	105	L	
Stability control (ESP).....	106	Lighting control.....	56
Transmission.....	106	Headlamp flasher.....	56
Tyre pressure monitoring system.....	106	Home safe lighting.....	57
Viewing current messages.....	99	Lighting control positions.....	56
Voice control.....	108	Main and dipped beam.....	56
Inspecting safety system components.....	186	Parking lamps.....	56
Seat belts.....	186	Lighting.....	56
Instrument lighting dimmer.....	130		
Instruments.....	79		
Interior lamps.....	61		
Courtesy lamp.....	61		
Reading lamps.....	61		
Vanity mirror lamps.....	62		
Interior mirror.....	77		
Introduction.....	7		

Index

Load carriers	
See: Roof racks and load carriers.....	174
Load carrying.....	170
General information.....	170
Load retaining fixtures.....	176
Installing the load bracket.....	177
Installing the load retaining fixtures.....	177
Locking and unlocking.....	36
Automatic relocking.....	38
Central locking.....	36
Double locking.....	36
Double locking the doors with the key.....	37
Locking and unlocking confirmation.....	36
Locking and unlocking the doors and the luggage compartment lid with the remote control.....	37
Locking and unlocking the doors from inside.....	37
Locking and unlocking the doors with the key.....	36
Luggage compartment lid.....	37
Reprogramming the unlocking function.....	38
Locks.....	36
Luggage anchor points.....	170
4-door and 5-door.....	170
Estate.....	170
Luggage covers.....	174

M

Maintenance.....	202
General information.....	202
Technical specifications.....	216

Manual climate control.....	110
Air conditioning.....	111
Air distribution control.....	110
Blower.....	110
Heating the interior quickly.....	111
Recirculated air.....	111
Temperature control.....	110
Ventilation.....	111
Manual seats.....	124
Adjusting the angle of the seatback.....	125
Adjusting the height of the driver's seat.....	125
Adjusting the lumbar support.....	125
Moving the seats backwards and forwards.....	124
Manual transmission.....	147
All vehicles.....	147
Vehicles with a 5-speed transmission.....	147
Vehicles with a 6-speed transmission (2.5L Duratec-ST engine).....	147
Vehicles with a 6-speed transmission (Turbo diesel engines).....	147
Map pockets.....	133
Memory function.....	133
Easy entry easy exit.....	134
Recalling a stored seat position.....	135
Setting a memory pre-set.....	134
Message centre	
See: Information displays.....	85
Mirrors	
See: Heated windows and mirrors...	116
See: Windows and mirrors.....	73

N

Navigation system	
commands.....	273

Index

O

Occupant protection.....	28
Principle of operation.....	28
Oil check	
See: Engine oil check.....	213
Opening and closing the bonnet.....	203
Closing the bonnet.....	203
Opening the bonnet.....	203

P

Parking aid.....	159
Principle of operation.....	159
Parking aid	
See: Using the parking aid.....	159
Parking brake.....	152
Applying the parking brake.....	152
Parking on a hill.....	152
Releasing the parking brake.....	152
Parts and accessories.....	7
Look for the Ford logo on the following parts	8
Now you can be sure that your Ford parts are Ford parts.....	7
Personalised settings.....	96
Help screen, radio, navigation and phone information.....	96
Language.....	97
Navigation information.....	97
Units of measure.....	98
Power steering fluid check.....	215
Topping up.....	215
Programming the remote control.....	34

Q

Quick start.....	10
------------------	----

R

Rear fog lamps.....	57
Rear seats.....	127
Creating a level load floor.....	128
Folding the seatbacks down.....	127
Rear under floor storage.....	172
Vehicles with a sliding loadspace floor.....	172
Vehicles without a sliding loadspace floor.....	172
Rear window wiper and washers.....	52
Intermittent wipe.....	52
Reverse gear wipe.....	52
Washer.....	52
Refuelling.....	144
Remote control battery	
See: Changing the remote control battery.....	34
Remote control programming	
See: Programming the remote control.....	34
Removing a headlamp.....	62
Repairing minor paint damage.....	221
Roof racks and load carriers.....	174
Roof rack.....	174
Run flat tyres.....	234
Principle of operation.....	234
Replacing run flat tyres.....	235
What to do if a run flat tyre has a puncture.....	234
Running-in.....	183
Brakes and clutch.....	183
Engine.....	183
Tyres.....	183

S

Safety precautions.....	142
Seat belt height adjustment.....	31

Index

Seat belt reminder.....	31
Deactivating the seat belt reminder.....	32
Seats.....	124
Sitting in the correct position.....	124
Sliding loadspace floor.....	170
Storage compartment.....	171
Snow chains	
See: Using snow chains.....	236
Speed control	
See: Cruise control.....	161
Stability control.....	153
Principle of operation.....	153
Stability control	
See: Using stability control.....	153
Starter switch	
See: Ignition switch.....	136
Starting a diesel engine.....	140
Cold or hot engine.....	140
Starting a petrol engine.....	139
Cold or hot engine.....	139
Engine idle speed after starting.....	140
Flooded engine.....	139
Starting the engine.....	136
General information.....	136
Status after a collision.....	186
Steering wheel lock.....	138
Vehicles with keyless starting.....	139
Vehicles without keyless starting.....	138
Steering wheel.....	49
Storage compartments.....	132
Sun blinds.....	130
Sunroof	
See: Electric sunroof.....	120
Switching off the engine.....	141
Vehicles with a turbocharger.....	141
Symbols glossary.....	7
Symbols in this handbook.....	7
Symbols on your vehicle.....	7

T

Technical specifications.....	243
Technical specifications.....	243
Telephone commands.....	268
Create a phonebook.....	269
Main settings.....	272
Phone.....	268
Phone functions.....	270
Telephone controls.....	255
Ending or rejecting calls.....	255
Remote control.....	255
Telephone setup.....	252
Bond another Bluetooth phone.....	254
Making a phone an active phone.....	253
Phonebook.....	253
Phonebook categories.....	253
Placing your phone in the cradle.....	252
Requirements for cradle connection.....	252
Telephone.....	252
General information.....	252
Telephone	
See: Using the telephone.....	
See: Using the telephone.....	
Towing a trailer.....	179
Steep gradients.....	179
Towing points.....	200
Towing the vehicle on four wheels.....	201
All vehicles.....	201
Vehicles with automatic transmission.....	201
Towing.....	179
Transmission.....	147

Index

Trip computer.....	94	Using cruise control.....	161
Average fuel consumption.....	94	Cancelling the set speed.....	162
Average speed.....	95	Changing the set speed.....	161
Distance to empty.....	94	Resuming the set speed.....	162
Odometer.....	94	Setting a speed.....	161
Outside air temperature.....	95	Switching cruise control off.....	162
Tripmeter.....	94	Switching cruise control on.....	161
Type 1 and 2.....	95	Using HLA.....	155
Type 3.....	96	Activating the HLA.....	156
Type approvals.....	277	Deactivating the HLA.....	157
Bluetooth/voice recognition system		Using seat belts during	
- declaration of conformity.....	277	pregnancy.....	32
Tyre care.....	235	Using snow chains.....	236
Tyre pressure monitoring		Using stability control.....	153
system.....	236	Using the key.....	34
Checking the tyre pressures.....	237	Remote control with flip key	
Setting the vehicle load.....	237	blade.....	34
Tyre repair kit.....	229	Using the parking aid.....	159
Checking the tyre pressure.....	233	Manoeuvring with the parking	
General information.....	229	aid.....	160
Inflating the tyre.....	230	Switching the parking aid on and	
Using the tyre repair kit.....	229	off.....	159
Tyres		Using the telephone.....	
See: Wheels and tyres.....	224	Changing the active phone.....	261
		Debonding a bonded phone.....	261
U		Handling an incoming call.....	260
Using ACC.....	165	Handling a second incoming call.....	260
Automatic deactivation.....	167	Making a call.....	259
Cancelling ACC.....	167	Using voice control.....	263
Changing the set speed.....	166	System operation.....	263
Resuming ACC.....	167	Using winter tyres.....	236
Setting a speed.....	165		
Setting the vehicle gap.....	166	V	
Switching ACC off.....	167	Vehicle battery.....	222
Switching ACC on.....	165	Vehicle care.....	220
Using active suspension.....	158	Vehicle identification number	
Selecting a setting.....	158	(VIN).....	242
System malfunction.....	158	Vehicle identification plate.....	242
Using booster cables.....	222	Vehicle identification.....	242
To connect the booster cables.....	222	Vehicle recovery.....	200
To start the engine.....	223	Ventilated seats.....	129

Index

Ventilation	
See: Climate control.....	109
Vents	
See: Air vents.....	109
VIN	
See: Vehicle identification number (VIN).....	242
Voice control.....	262
Principle of operation.....	262

W

Warning lamps and indicators.....	81
ABS warning lamp.....	81
Airbag warning lamp.....	81
Brake system warning lamp.....	81
Cruise control indicator.....	82
Direction indicators.....	82
Engine warning lamp.....	82
Forward alert indicator.....	82
Front fog lamp indicator.....	82
Frost warning lamp.....	82
Glow plug indicator.....	82
Headlamp indicator.....	82
Ignition warning lamp.....	83
Low fuel level warning lamp.....	83
Main beam indicator.....	83
Maximum engine speed indicator.....	83
Message indicator.....	83
Oil pressure warning lamp.....	83
Rear fog lamp indicator.....	83
Seat belt reminder.....	83
Stability control (ESP) warning lamp.....	84
Warning triangle.....	184
Washer fluid check.....	216
Washers	
See: Wipers and washers.....	51
Washing	
See: Cleaning the exterior.....	220

Wheels and tyres.....	224
General information.....	224
Technical specifications.....	238
Windows and mirrors.....	73
Windscreen washers.....	52
Windscreen wipers.....	51
Intermittent wipe.....	51
Winter tyres	
See: Using winter tyres.....	236
Wipers and washers.....	51

Feel the difference

