

FordFocus
Owner's handbook

Feel the difference



The information contained in this publication was correct at the time of going to print. In the interest of development the right is reserved to change specifications, design or equipment at any time without notice and without incurring any obligations. This publication, or part thereof, may not be reproduced nor translated without our approval. Errors and omissions excepted.

© Ford Motor Company 2010

All rights reserved.

Part number: (CG3568en) 09/2010 20101109080227




Table of contents

Introduction

About this handbook.....	7
Symbols glossary.....	7
Parts and accessories.....	7

Quick start

Quick start.....	10
------------------	----

Child safety

Child seats.....	24
Child seat positioning.....	25
Booster cushions.....	27
ISOFIX anchor points.....	28
Child safety locks.....	29

Occupant protection

Principle of operation.....	31
Fastening the seat belts.....	33
Seat belt height adjustment.....	33
Seat belt reminder.....	33
Using seat belts during pregnancy.....	34
Disabling the passenger airbag.....	34

Keys and remote controls

General information on radio frequencies.....	36
Programming the remote control.....	36
Changing the remote control battery.....	36

Locks

Locking and unlocking.....	39
Keyless entry.....	41
Global opening and closing.....	43

Engine immobiliser

Principle of operation.....	45
Coded keys.....	45
Arming the engine immobiliser.....	45
Disarming the engine immobiliser.....	45

Alarm

Principle of operation.....	46
Arming the alarm.....	47
Disarming the alarm.....	47

Steering wheel

Adjusting the steering wheel.....	48
Audio control.....	48
Voice control.....	49

Wipers and washers

Windscreen wipers.....	50
Autowipers.....	50
Windscreen washers.....	51
Rear window wiper and washers.....	51
Headlamp washers.....	52
Checking the wiper blades.....	52
Changing the wiper blades.....	52

Lighting

Lighting control.....	54
Autolamps.....	55
Automatic main beam control.....	55
Front fog lamps.....	57
Rear fog lamps.....	57
Headlamp levelling.....	57
Hazard warning flashers.....	58
Direction indicators.....	58
Cornering lamps.....	59
Interior lamps.....	60
Removing a headlamp.....	61
Changing a bulb.....	61
Bulb specification chart.....	69

Windows and mirrors

Electric windows.....	70
Exterior mirrors.....	71
Electric exterior mirrors.....	72
Auto-dimming mirror.....	73

Table of contents

Blind spot monitor.....	73	Floor mats.....	118
Instruments		Starting the engine	
Gauges.....	76	General information.....	119
Warning lamps and indicators.....	78	Ignition switch.....	119
Audible warnings and indicators.....	80	Steering wheel lock.....	119
		Starting a petrol engine.....	120
Information displays		Starting a diesel engine.....	121
General information.....	82	Keyless starting.....	121
Trip computer.....	89	Diesel particulate filter (DPF).....	123
Personalised settings.....	89	Switching off the engine.....	123
Information messages.....	90		
		Start-stop	
Climate control		Principle of operation.....	124
Principle of operation.....	102	Using start-stop.....	124
Air vents.....	102		
Manual climate control.....	103	Eco mode	
Automatic climate control.....	105	Principle of operation.....	126
Heated windows and mirrors.....	108	Using Eco mode.....	126
Auxiliary heater.....	108		
		Fuel and refuelling	
Seats		Safety precautions.....	127
Sitting in the correct position.....	111	Fuel quality - Petrol.....	127
Manual seats.....	111	Fuel quality - Diesel.....	127
Head restraints.....	112	Catalytic converter.....	127
Electric seats.....	113	Fuel filler flap.....	128
Rear seats.....	114	Refuelling.....	129
Heated seats.....	115	Fuel consumption.....	129
		Technical specifications.....	129
Convenience features			
Instrument lighting dimmer.....	116	Transmission	
Clock.....	116	Manual transmission.....	131
Cigar lighter.....	116	Automatic transmission.....	131
Auxiliary power sockets.....	116		
Cup holders.....	117	Brakes	
Glasses holder.....	117	Principle of operation.....	134
Auxiliary input (AUX IN) socket.....	118	Hints on driving with ABS.....	134
USB port.....	118	Parking brake.....	134
Satellite navigation unit holder.....	118		

Table of contents

Stability control

Principle of operation.....	135
Using stability control.....	135

Hill start assist

Principle of operation.....	137
Using hill start assist.....	137

Parking aid

Principle of operation.....	139
Using the parking aid - Vehicles With: Rear Parking Aid.....	139
Using the parking aid - Vehicles With: Front and Rear Parking Aid.....	140

Active park assist

Principle of operation.....	143
Using active park assist.....	143

Rear view camera

Principle of operation.....	146
Using the rear view camera.....	146

Cruise control

Principle of operation.....	149
Using cruise control.....	149

Adaptive cruise control (ACC)

Principle of operation.....	151
Using ACC.....	153
Forward alert function.....	155

Speed limiter

Principle of operation.....	157
Using the speed limiter.....	157

Driver alert

Principle of operation.....	158
Using driver alert.....	158

Lane departure warning

Principle of operation.....	160
Using lane departure warning.....	160

Lane keeping aid

Principle of operation.....	162
Using the lane keeping aid.....	163

Traffic sign recognition

Principle of operation.....	164
Using traffic sign recognition.....	164

Low speed safety system

Principle of operation.....	166
Using the low speed safety system....	166

Load carrying

General information.....	168
Luggage anchor points.....	168
Luggage covers.....	168
Cargo nets.....	169

Towing

Towing a trailer.....	171
-----------------------	-----

Driving hints

Running-in.....	172
Cold weather precautions.....	172
Driving through water.....	172

Emergency equipment

First aid kit.....	173
Warning triangle.....	173

Fuses

Fuse box locations.....	174
Changing a fuse.....	174
Fuse specification chart.....	175

Table of contents

Vehicle recovery

Towing points.....	183
Towing the vehicle on four wheels.....	183

Maintenance

General information.....	185
Opening and closing the bonnet.....	185
Engine compartment overview - 1.6L Duratec-16V Ti-VCT (Sigma).....	187
Engine compartment overview - 1.6L EcoBoost SCTi (Sigma).....	188
Engine compartment overview - 1.6L Duratorq-TDCi (DV) Diesel.....	189
Engine compartment overview - 2.0L Duratorq-TDCi (DW) Diesel.....	191
Engine oil dipstick - 1.6L Duratec-16V Ti-VCT (Sigma).....	192
Engine oil dipstick - 1.6L EcoBoost SCTi (Sigma).....	192
Engine oil dipstick - 1.6L Duratorq-TDCi (DV) Diesel/2.0L Duratorq-TDCi (DW) Diesel.....	192
Engine oil check.....	192
Engine coolant check.....	193
Brake and clutch fluid check.....	194
Washer fluid check.....	194
Technical specifications.....	195

Vehicle care

Cleaning the exterior.....	197
Cleaning the interior.....	197
Repairing minor paint damage.....	198

Vehicle battery

Using booster cables.....	199
Changing the vehicle battery.....	199
Battery connection points.....	200

Wheels and tyres

General information.....	201
Changing a road wheel.....	201

Tyre repair kit.....	206
Tyre care.....	209
Using winter tyres.....	210
Using snow chains.....	210
Tyre pressure monitoring system.....	210
Technical specifications.....	211

Vehicle identification

Vehicle identification plate.....	214
Vehicle identification number (VIN).....	214

Technical specifications

Technical specifications.....	215
-------------------------------	-----

Navigation introduction

General information.....	219
Road Safety.....	219

Navigation Quick start

Navigation Quick start.....	221
-----------------------------	-----

Navigation unit overview

Navigation unit overview.....	224
Loading the navigation data.....	229

System settings

System settings.....	230
----------------------	-----

Navigation system

Route options menu.....	233
Route displays.....	234

Traffic Message Channel

Principle of operation.....	235
Using TMC.....	235

Map updates

Map updates.....	236
------------------	-----

Table of contents

Audio introduction

Important audio information.....237

Audio unit overview

Audio unit overview.....238

Audio system security

Security code.....244

Audio unit operation

On/off control.....245

Sound button.....245

Waveband button.....245

Station tuning control.....245

Station preset buttons.....246

Autostore control.....246

Traffic information control.....246

Audio unit menus

Automatic volume control.....248

Digital signal processing (DSP).....248

News broadcasts.....248

Alternative frequencies.....248

Regional mode (REG).....249

Compact disc player

Compact disc playback.....250

Track selection.....250

Fast forward/reverse.....250

Shuffle/random.....250

Repeat compact disc tracks.....250

Compact disc track scanning.....251

MP3 file playback.....251

MP3 display options.....253

Ending compact disc playback.....253

Auxiliary input (AUX IN) socket

Auxiliary input (AUX IN) socket.....254

Audio troubleshooting

Audio troubleshooting.....255

Telephone

General information.....256

Bluetooth setup.....256

Telephone setup.....256

Telephone controls.....257

Using the telephone.....258

Voice control

Principle of operation.....260

Using voice control.....260

Audio unit commands.....261

Telephone commands.....268

Climate control commands.....273

Connectivity

General information.....276

Connecting an external device.....277

Connecting an external device -
Vehicles With: Bluetooth.....277

Using a USB device.....278

Using an iPod.....279

Appendices

Type approvals.....281

Type approvals.....281

Type approvals.....281

Type approvals.....282

Type approvals.....282

Electromagnetic compatibility.....283

Introduction

ABOUT THIS HANDBOOK

Thank you for choosing Ford. We recommend that you take some time to get to know your vehicle by reading this handbook. The more that you know about it, the greater the safety and pleasure you will get from driving it.

WARNING



Always drive with due care and attention when using and operating the controls and features on your vehicle.

Note: *This handbook describes product features and options available throughout the range, sometimes even before they are generally available. It may describe options not fitted to your vehicle.*

Note: *Always use and operate your vehicle in line with all applicable laws and regulations.*

Note: *Pass on this handbook when selling your vehicle. It is an integral part of the vehicle.*

SYMBOLS GLOSSARY

Symbols in this handbook

WARNING



You risk death or serious injury to yourself and others if you do not follow the instructions highlighted by the warning symbol.

CAUTION



You risk damaging your vehicle if you do not follow the instructions highlighted by the caution symbol.

Symbols on your vehicle



When you see these symbols, read and follow the relevant instructions in this handbook before touching or attempting adjustment of any kind.

PARTS AND ACCESSORIES

Now you can be sure that your Ford parts are Ford parts

Your Ford has been built to the highest standards using high quality Ford Original Parts. As a result, you can enjoy driving it for many years.

Should the unexpected occur and a major part needs replacing, we recommend that you accept nothing less than Ford Original Parts.

The use of Ford Original Parts ensures that your vehicle is repaired to its pre-accident condition and maintains its maximum residual value.

Ford Original Parts match Ford's stringent safety requirements and high standards of fit, finish and reliability. Quite simply, they represent the best overall repair value, including parts and labour costs.

Now it is easier to tell if you have really been given Ford Original Parts. The Ford logo is clearly visible on the following parts if they are Ford Original Parts. If your vehicle has to be repaired, look for the clearly visible Ford branding and make sure that only Ford Original Parts have been used.

Introduction

Look for the Ford logo on the following parts

Sheet metal


- Bonnet
- Doors
- Luggage compartment lid or tailgate



E132325


Bumper and radiator grille

- Radiator grille
- Front and rear bumper



E132326

Exterior mirror



E132340

Glass

- Rear window
- Side glass
- Windscreen




E132327

Introduction

Lighting

- Rear lamps
- Headlamp




E132328

Quick start

QUICK START

Front exterior overview




E133220

- A See **Locking and unlocking** (page 39). See **Keyless entry** (page 41).
- B See **Automatic main beam control** (page 55). See **Driver alert** (page 158). See **Lane departure warning** (page 160). See **Lane keeping aid** (page 162). See **Traffic sign recognition** (page 164). See **Low speed safety system** (page 166).
- C See **Changing the wiper blades** (page 52).

Quick start

- D See **Maintenance** (page 185).
- E See **Towing points** (page 183).
- F See **Changing a bulb** (page 61).
- G Tyre pressures. See **Technical specifications** (page 211).
- H See **Changing a road wheel** (page 201).

Vehicle interior overview



E133222


Quick start

- A See **Transmission** (page 131).
- B See **Locking and unlocking** (page 39).
- C See **Electric windows** (page 70). See **Electric exterior mirrors** (page 72).
- D See **Head restraints** (page 112).
- E See **Fastening the seat belts** (page 33).
- F See **Rear seats** (page 114).
- G See **Manual seats** (page 111). See **Electric seats** (page 113).
- H See **Parking brake** (page 134).
- I See **Opening and closing the bonnet** (page 185).

Quick start


Instrument panel overview

Left-hand drive



Quick start

Right-hand drive



E132739


- A Air vents. See **Air vents** (page 102).
- B Direction indicators. See **Direction indicators** (page 58). Main beam. See **Lighting control** (page 54).
- C Information display control (all vehicles except right-hand drive vehicles with voice control). See **Information displays** (page 82).
- C Information and entertainment display control (right-hand drive vehicles with voice control only).
- D Instrument cluster. See **Gauges** (page 76). See **Warning lamps and indicators** (page 78).
- E Audio control (all vehicles without voice control). See **Information displays** (page 82).

Quick start

- E Information and entertainment display control (left-hand drive vehicles with voice control only). See **Audio control** (page 48).
- E Information display control (right-hand drive vehicles with voice control only). See **Information displays** (page 82).
- F Wiper lever. See **Wipers and washers** (page 50).
- G Information and entertainment display.
- H Audio unit. See **Audio unit overview** (page 238).
- I Door lock button. See **Locking and unlocking** (page 39).
- J Hazard warning flasher switch. See **Hazard warning flashers** (page 58).
- K Parking aid switch. See **Parking aid** (page 139).
- L Active park assist switch. See **Active park assist** (page 143).
- M Start-stop switch. See **Using start-stop** (page 124).
- N Heated rear window switch. See **Heated windows and mirrors** (page 108).
- O Heated windscreen switch. See **Heated windows and mirrors** (page 108).
- P Climate controls. See **Climate control** (page 102).
- Q Start button. See **Keyless starting** (page 121).
- R Ignition switch. See **Ignition switch** (page 119).
- S Audio control. See **Audio control** (page 48). Voice control. See **Voice control** (page 49).
- T Steering wheel adjustment. See **Adjusting the steering wheel** (page 48).
- U Horn.
- V Cruise control switches. See **Using cruise control** (page 149). Adaptive cruise control (ACC) switches. See **Using ACC** (page 153). Speed limiter switches. See **Using the speed limiter** (page 157).
- W Lighting control. See **Lighting control** (page 54). Front fog lamps. See **Front fog lamps** (page 57). Rear fog lamp. See **Rear fog lamps** (page 57). Headlamp levelling control. See **Headlamp levelling** (page 57). Instrument lighting dimmer. See **Instrument lighting dimmer** (page 116).

Quick start

Rear exterior overview



E133221

- A See **Changing the wiper blades** (page 52).
- B See **Changing a bulb** (page 61).
- C See **Changing a bulb** (page 61).
- D See **Fuel filler flap** (page 128).
- E See **Changing a road wheel** (page 201).
- F Tyre pressures. See **Technical specifications** (page 211).

Quick start

- G See **Towing points** (page 183).
- H See **First aid kit** (page 173). See **Warning triangle** (page 173). See **Tyre repair kit** (page 206). Spare wheel. See **Changing a road wheel** (page 201). Jack. See **Changing a road wheel** (page 201). Wheel brace. See **Changing a road wheel** (page 201). Towing eye. See **Towing points** (page 183). Fuel funnel. See **Fuel filler flap** (page 128).

Seat belt height adjustment




E87511

Note: *Lifting the slider slightly while pressing the locking button makes it easier to release the locking mechanism.*

To raise or lower, press the locking button on the adjuster and move as necessary.

Locking and unlocking



E87379

- A Unlock
- B Lock
- C Luggage compartment lid unlock

Double locking with the key

Turn the key to the lock position twice within three seconds.

Double locking the doors and the luggage compartment lid with the remote control

Press button B twice within three seconds.

See **Locking and unlocking** (page 39).


Adjusting the steering wheel

WARNING



Never adjust the steering wheel when the vehicle is moving.

Quick start



E95178




E95179

See **Adjusting the steering wheel** (page 48).

Wipers and washers


Windscreen wipers



E128444

- A Single wipe
- B Intermittent wipe or autowipers
- C Normal wipe
- D High speed wipe

Intermittent wipe




E128445

- A Short wipe interval
- B Intermittent wipe
- C Long wipe interval

Quick start


Rear window wiper and washers



E129193

- A Intermittent wipe
- B Low speed wipe

Rear window washer




E129194

See **Wipers and washers** (page 50).

Lighting control

Lighting control positions



E132706

- A Off
- B Side and tail lamps
- C Headlamps

Headlamp flasher

Pull the lever slightly towards the steering wheel.

See **Lighting control** (page 54).

Manual climate control

Cooling the interior quickly



E129887

Quick start

Heating the interior quickly



E129884

Defrosting and demisting the windscreen



E129888

When the temperature is above 4°C (39°F), the air conditioning will switch on automatically. Make sure that the blower is on. The indicator in the switch will illuminate during defrosting and demisting.

If you move the air distribution control to a position other than windscreen, the **A/C** will remain on.

You can switch the air conditioning and recirculated air on and off while the air distribution control is set to windscreen.

See **Manual climate control** (page 103).

Automatic climate control

AUTO

Recommended settings: AUTO, 22°C


Mono mode

In mono mode, the temperature settings for both the driver's and passenger's side are linked. If you adjust the temperature using the rotary control on the driver's side, the settings will be adjusted to the same setting on the passenger's side.

See **Automatic climate control** (page 105).

Manual seats


Moving the seats backwards and forwards




E130249

Quick start

Adjusting the height of the driver's seat




Adjusting the angle of the seatback



See **Manual seats** (page 111).

Head restraints






Adjust the head restraint so that the top of it is level with the top of your head.

See **Head restraints** (page 112).

Quick start

Electric seats



E78060

Keyless starting

WARNING



The keyless starting system may not function if the key is close to metal objects or electronic devices such as mobile phones.

Quick start



E85766

Press the start button once.

Starting with automatic transmission

Note: *Releasing the brake pedal during engine start will stop the engine cranking and return to ignition on.*

1. Make sure the transmission is in **P** or **N**.
2. Fully depress the brake pedal.
3. Briefly press the start button.

Starting with manual transmission

Note: *Releasing the clutch pedal during engine start will stop the engine cranking and return to ignition on.*

1. Fully depress the clutch pedal.
2. Briefly press the start button.

Stopping the engine when the vehicle is moving

WARNING



Switching off the engine when the vehicle is still moving will result in a loss of brake and steering assistance. The steering will not be locked, but higher effort will be required. When the ignition is switched off some electrical circuits, warning lamps and indicators may also be OFF.

Press and hold the start button for two seconds, or press three times within three seconds.

See **Keyless starting** (page 121).

Child safety

CHILD SEATS








E133140





E68916

WARNINGS

-  Secure children that are less than 150 centimetres tall in a suitable, government approved child restraint, in the rear seat
-  Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an air bag in front of it!
-  Read and follow the manufacturer's instructions when you are fitting a child restraint.
-  Do not modify child restraints in any way.
-  Do not hold a child on your lap when the vehicle is moving.

WARNINGS

-  Do not leave unattended children in your vehicle.
-  If your vehicle has been involved in an accident, have the child restraints checked by properly trained technicians.

Note: *Mandatory use of child restraints varies from country to country.*

Only child restraints certified to ECE-R44.03 (or later) have been tested and approved for use in your vehicle. A choice of these are available from your Dealer.

Child restraints for different mass groups

Use the correct child restraint as follows:

Baby safety seat



E68918

Secure children that weigh less than 13 kilograms in a rearward facing baby safety seat (Group 0+) in the rear seat.

Child safety

Child safety seat



E68920

Secure children that weigh between 13 and 18 kilograms in a child safety seat (Group 1) in the rear seat

CHILD SEAT POSITIONING

WARNINGS



Please consult your Dealer for the latest details relating to Ford recommended child seats.

WARNINGS



Original text according to ECE R94.01: Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an air bag in front of it!



When using a child seat with a support leg, the support leg must rest securely on the floor.



When using a child seat with a seat belt, make sure that the seat belt is not slack or twisted.

CAUTION



The child seat must rest tightly against the vehicle seat. It may be necessary to lift or remove the head restraint. See **Head restraints** (page 112).

Note: When using a child seat on a front seat, always adjust the front passenger seat to its fully rearwards position. If it proves difficult to tighten the lap section of the seat belt without slack remaining, adjust the seatback to the fully upright position and raise the height of the seat. See **Seats** (page 111).

Seating positions	Mass group categories				
	0	0+	1	2	3
	Up to 10 kg	Up to 13 kg	9 - 18 kg	15 - 25 kg	22 - 36 kg
Front passenger seat with airbag ON	X	X	UF ¹	UF ¹	UF ¹
Front passenger seat with airbag OFF	U	U	U	U	U
Rear seats	U	U	U	U	U

X Not suitable for children in this mass group.

U Suitable for universal category child seats approved for use in this mass group.

Child safety

UF¹ Suitable for universal category forward facing child restraints approved for use in this mass group. However, we recommend that you secure children in a government approved child restraint, in the rear seat.

ISOFIX child seats

Seating positions		Mass group categories	
		O+	1
		Rear facing	Forward facing
		Up to 13 kg	9 - 18 kg
Front seat	Size class	Not ISOFIX equipped	
	Seat type		
Rear outboard seat ISOFIX	Size class	C, D, E*	A, B, B1, C, D*
	Seat type	IL**	IL, IUF***
Rear centre seat	Size class	Not ISOFIX equipped	
	Seat type		

IL Suitable for particular ISOFIX child restraints systems of the **semi-universal** category. Please consult child restraints systems suppliers' vehicle recommendation lists.

IUF Suitable for ISOFIX forward facing child restraints systems of **universal** category approved for use in this mass group and ISOFIX size class.

* The ISOFIX size class for both **universal** and **semi-universal** child restraints systems is defined by the capital letters **A** to **G**. These identification letters are displayed on ISOFIX child restraints.



** At time of publishing the recommended Group O+ ISOFIX baby safety seat is the Britax Roemer Baby Safe. Please consult your Dealer for the latest details relating to Ford recommended child seats.

*** At time of publishing the recommended Group 1 ISOFIX child seat is the Britax Roemer Duo. Please consult your Dealer for the latest details relating to Ford recommended child seats.


Child safety

BOOSTER CUSHIONS

WARNINGS

-  Do not install a booster seat or a booster cushion with only the lap strap of the seat belt.
-  Do not install a booster seat or a booster cushion with a seat belt that is slack or twisted.
-  Do not put the seat belt under your child's arm or behind its back.
-  Do not use pillows, books or towels to boost your child's height.
-  Make sure that your children sit in an upright position.
-  Secure children that weigh more than 15 kilograms but are less than 150 centimetres tall in a booster seat or a booster cushion.

CAUTION

-  When using a child seat on a rear seat, make sure that the child seat rests tightly against the vehicle seat. It may be necessary to lift or remove the head restraint. See **Head restraints** (page 112).

Booster seat (Group 2)



E70710

We recommend that you use a booster seat that combines a cushion with a backrest instead of a booster cushion only. The raised seating position will allow you to position the shoulder strap of the adult seat belt over the centre of your child's shoulder and the lap strap tightly across its hips.

Booster cushion (Group 3)




E68924

Child safety

ISOFIX ANCHOR POINTS

WARNING


 Use an anti-rotation device when using the ISOFIX system. We recommend the use of a top tether or support leg.

Note: When you are purchasing an ISOFIX restraint, make sure that you know the correct mass group and ISOFIX size class for the intended seating locations. See **Child seat positioning** (page 25).


Your vehicle is fitted with ISOFIX anchor points that accommodate universally approved ISOFIX child restraints.

The ISOFIX system comprises of two rigid attachment arms on the child restraint that attach to anchor points on the rear seats, where the cushion and backrest meet. Tether anchor points may also be fitted.

Top tether anchor points - all vehicles




Top tether anchor points - 4 door vehicles



The tether anchor points are located under a flap.


Attaching a child seat with top tethers

WARNING

 Do not attach a tether strap to anything other than the correct tether anchor point.

Note: Where applicable, remove the luggage cover to ease installation. See **Luggage covers** (page 168).

WARNING

 Make sure that the top tether strap is not slack or twisted and is properly located on the anchor point.

1. Route the tether strap to the anchor point.

Child safety



E87145

2. Push the child seat back firmly to engage the ISOFIX lower anchor points.
3. Tighten the tether strap in line with the child seat manufacturer's instructions.

CHILD SAFETY LOCKS

WARNING



You cannot open the doors from inside if you have put the child safety locks on.

Manual child safety locks

Note: On vehicles with keyless entry, use the spare key. See **Keyless entry** (page 41).



E78298

Left-hand side

Turn anti-clockwise to lock and clockwise to unlock.

Right-hand side

Turn clockwise to lock and anti-clockwise to unlock.

Electric child safety locks

Note: Pressing the switch will also disable the rear electric window switches.

Child safety



E124779

Occupant protection

PRINCIPLE OF OPERATION

Airbags

WARNINGS



Do not modify the front of your vehicle in any way. This could adversely affect deployment of the airbags.



Original text according to ECE R94.01: Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an airbag in front of it!



Wear a seat belt and keep sufficient distance between yourself and the steering wheel. Only when you use the seat belt properly, can it hold you in a position that allows the airbag to achieve its optimum effect. See **Sitting in the correct position** (page 111).



Have repairs to the steering wheel, steering column, seats, airbags and seat belts carried out by a properly trained technician.



Keep the areas in front of the airbags free from obstruction. Do not affix anything to or over the airbag covers.



Do not poke sharp objects into areas where airbags are fitted. This could damage and adversely affect deployment of the airbags.




Use seat covers designed for seats with side airbags. Have these fitted by a properly trained technician.

Note: You will hear a loud bang and see a cloud of harmless powdery residue if an airbag deploys. This is normal.

Note: Only wipe airbag covers with a damp cloth.

Driver and front passenger airbags



E74302

The driver and front passenger airbags will deploy during significant frontal collisions or collisions that are up to 30 degrees from the left or the right. The airbags will inflate within a few thousandths of a second and deflate on contact with the occupants, thus cushioning forward body movement. During minor frontal collisions, overturns, rear collisions and side collisions, the driver and front passenger airbags will not deploy.

Side airbags




E72658

Side airbags are fitted inside the seatback of the front seats. A label indicates that side airbags are fitted to your vehicle.

Occupant protection

The side airbags will deploy during significant lateral collisions. Only the airbag on the side affected by the collision will deploy. The airbags will inflate within a few thousandths of a second and deflate on contact with the occupants, thus providing protection for the chest and shoulder areas. During minor lateral collisions, overturns, front collisions and rear collisions, the side airbags will not deploy.

Curtain airbags




E75004


Curtain airbags are fitted inside the trim panels over the front and rear side windows. Moulded badges in the B-pillar trim panels indicate that curtain airbags are fitted to your vehicle.


The curtain airbags will deploy during significant lateral collisions. Only the airbag on the side affected by the collision will deploy. The airbag will inflate within a few thousandths of a second and deflate on contact with the occupants, thus providing protection for the head. During minor lateral collisions, front collisions, rear collisions, or overturns the curtain airbags will not deploy.


Seat belts


WARNINGS


 Wear a seat belt and keep sufficient distance between yourself and the steering wheel. Only when you use the seat belt properly, can it hold you in a position to achieve its optimum effect. See **Sitting in the correct position** (page 111).

 Never use a seat belt for more than one person.

 Use the correct buckle for each seat belt.

 Do not use a seat belt that is slack or twisted.


 Do not wear thick clothing. The seat belt must fit tightly around your body to achieve its optimum effect.

 Position the shoulder strap of the seat belt over the centre of your shoulder and position the lap strap tightly across your hips.

The driver and front passenger seat belt buckles are fitted with a seat belt pretensioner. Seat belt pretensioners have a lower deployment threshold than the airbags. During minor collisions, it is possible that only the seat belt pretensioners will deploy.

Status after a collision

WARNING

 Seat belts subjected to strain, as a result of an accident, should be renewed and the anchorages checked by a properly trained technician.

Occupant protection

FASTENING THE SEAT BELTS


WARNING



Insert the tongue into the buckle until you hear a distinct click. You have not fastened the seat belt properly if you do not hear a click.



E74124



E85817

Pull the belt out steadily. It may lock if you pull it sharply or if the vehicle is on a slope.

Press the red button on the buckle to release the belt. Let it retract completely and smoothly.

SEAT BELT HEIGHT ADJUSTMENT



E87511

Note: *Lifting the slider slightly while pressing the locking button makes it easier to release the locking mechanism.*

To raise or lower, press the locking button on the adjuster and move as necessary.

SEAT BELT REMINDER

WARNING



The occupant protection system will only provide optimum protection when you use the seat belt properly.



The seat belt reminder warning lamp illuminates and an audible warning will sound if the driver's or front seat passenger's seat belt has not been fastened and the vehicle exceeds a relatively low speed. It will also illuminate if the driver's or front seat passenger's seat belt is unfastened when the vehicle is moving. The audible warning and warning lamp will go off after four minutes.

Occupant protection

Rear seat belt reminder

WARNING



If multiple belts are unfastened within a few seconds of each other, only one audible chime will sound.

Note: Press the **OK** button on the steering wheel control to confirm the message.

A visual reminder of the seat belt status will be shown on the instrument display once the engine is started, and once again if any are unfastened when the vehicle is moving.


Fastened seat belts are indicated by a tick symbol.

If a belt is unfastened when the vehicle is moving, the seat belt status screen will be displayed and the relevant seats will be highlighted by an exclamation mark. An audible chime will also sound.

Deactivating the seat belt reminder

See your dealer.

USING SEAT BELTS DURING PREGNANCY



E68587

WARNING



Position the seat belt correctly for your safety and that of your unborn child. Do not use only the lap strap or the shoulder strap.

Position the lap strap comfortably across your hips and low beneath your pregnant abdomen. Position the shoulder strap between your breasts, above and to the side of your pregnant abdomen.

DISABLING THE PASSENGER AIRBAG

WARNING



Make sure that the passenger airbag is disabled when using a rearward facing child restraint on the front passenger seat.



E71313

Fitting the passenger airbag deactivation switch

WARNING




If you need to fit a child restraint on a seat protected by an operational airbag in front of it, have a passenger airbag deactivation switch fitted. Ask your dealer for further information.

Occupant protection

Note: The key switch is located in the glove compartment with an airbag deactivation lamp in the overhead console.

If the airbag warning lamp illuminates or flashes when you are driving, this indicates a malfunction. See **Warning lamps and indicators** (page 78). Remove the child restraint and have the system checked immediately.

Disabling the passenger airbag



E71312

- A Disabled
- B Enabled

Turn the switch to position **A**.

When you switch the ignition on, check that the passenger airbag deactivation warning lamp illuminates.

Enabling the passenger airbag

WARNING




Make sure that the passenger airbag is enabled when you are **not** using a child restraint on the front passenger seat.


Turn the switch to position **B**.

Keys and remote controls

GENERAL INFORMATION ON RADIO FREQUENCIES

CAUTIONS

 The radio frequency used by your remote control can also be used by other short distance radio transmissions (e.g. amateur radios, medical equipment, wireless headphones, remote controls and alarm systems). If the frequencies are jammed, you will not be able to use your remote control. You can lock and unlock the doors with the key.

 Check your vehicle is locked before leaving it unattended. This will safeguard against any potential malicious frequency blocking.

Note: *You could unlock the doors if you press the buttons on the remote control unintentionally.*

The operating range between your remote control and your vehicle varies depending on the environment.

PROGRAMMING THE REMOTE CONTROL

You can programme a maximum of eight remote controls to use with your vehicle (including any supplied with your vehicle).

Programming a new remote control

1. Insert the key in the ignition.
2. Cycle the key from position **0** to **II** and then back to **0** four times within six seconds.

3. Leave the key in position **0** and press any button on the remote control within 10 seconds. You will receive confirmation via a chime or LED that programming has been successful.

Note: *Further remote controls may be programmed at this stage.*

4. Press any button on each additional remote control within 10 seconds of each other.

Reprogramming the unlocking function

Note: *When you press the unlock button either all the doors are unlocked or only the driver's door is unlocked. Pressing the unlock button again unlocks all the doors.*

Press and hold the unlock and lock buttons on the remote key simultaneously for at least four seconds with the ignition off. The direction indicators will flash twice to confirm the change.

To return to the original unlocking function, repeat the process.


CHANGING THE REMOTE CONTROL BATTERY



Make sure that you dispose of old batteries in an environmentally friendly way. Seek advice from your local authority regarding recycling.


Keys and remote controls

Remote control with a folding key blade




E128809

1. Insert a screwdriver in the position shown and gently push the clip.
2. Press the clip down to release the battery cover.



E128810

3. Carefully remove the cover.



E128811


4. Turn the remote control over to remove the battery.
5. Install a new battery (3V CR 2032) with the + facing upwards.
6. Replace the battery cover.

Remote control without a folding key blade



E87964

1. Press and hold the pushbuttons on the edges to release the cover. Carefully remove the cover.
2. Remove the key blade.



E105362


3. Twist a flat bladed screwdriver in the position shown to separate the two halves of the remote control.

Keys and remote controls




E119190

- Carefully insert the screwdriver in the position shown to open the remote control.



E125860

CAUTION

-  Do not touch the battery contacts or the printed circuit board with the screwdriver.
-

- Carefully prise out the battery with the screwdriver.
- Install a new battery (3V CR 2032) with the + facing downwards.
- Assemble the two halves of the remote control.
- Install the key blade.

Locks

LOCKING AND UNLOCKING

Note: Do not leave your keys in the vehicle.

Locking

Locking with the key

Turn the top of the key towards the front of the vehicle.

Locking with the remote control

Note: The driver's door can be locked with the key. This needs to be used if the remote control is not functioning.

Note: Your vehicle can be locked with a rear door open. The door will be locked when it is closed.



Press the button.

Double locking

WARNING



Do not activate double locking when persons or animals are inside the vehicle. You will not be able to unlock the doors from the inside if you have double locked them.

Note: If you double lock your vehicle whilst inside, switch the ignition on to return the door locks to a single locked state.

Note: Your vehicle can be double locked with a rear door open. The door will be double locked when it is closed.

Double locking is a theft protection feature that prevents someone from opening the doors from the inside.

Double locking with the key

Turn the key to the lock position twice within three seconds.

Double locking with the remote control



Press the button twice within three seconds.

Unlocking

Unlocking with the key

Turn the top of the key towards the rear of the vehicle.

Unlocking with the remote control

Note: The driver's door can be unlocked with the key. This needs to be used if the remote control is not functioning.

Note: If the vehicle remains locked for several weeks, the remote control will be disabled. The vehicle must be unlocked and the engine started using the key. Unlocking and starting the vehicle once will enable the remote control.



Press the button.

Automatic relocking

The doors will relock automatically if you do not open a door, the luggage compartment lid, or turn on the ignition within 45 seconds of unlocking the doors with the remote control. The doors lock and the alarm will return to its previous state.

Locks

Reprogramming the unlocking function

The unlocking function may be reprogrammed so that only the driver's door is unlocked (See **Programming the remote control** (page 36).).

Locking and unlocking confirmation

Note: *If your vehicle has double locking, the direction indicators will flash once after you have activated central locking, followed by two further flashes after double locking.*

When you lock the doors, the direction indicators will flash once.

When you double lock the doors, the direction indicators will flash three times.

When you unlock the doors, the direction indicators will flash once.

Locking and unlocking the doors from inside



Press the button. For item location: See **Quick start** (page 10).

Luggage compartment lid

Opening the luggage compartment lid with the remote control



Press the button twice within three seconds.


Closing the luggage compartment lid



E133536

Locking the doors individually with the key

Note: *If the central locking function fails to operate, the doors can be individually locked using the key in the position shown.*



E112203

Left-hand side

Turn clockwise to lock.

Locks

Right-hand side

Turn anti-clockwise to lock.

Unlocking

Note: If the child safety locks have also been activated, pulling the internal lever will only deactivate the emergency locking and not the child safety lock. The doors can only be opened using the external door handle.

Note: If the doors have been unlocked using this method, the doors must be locked individually until the central locking function has been repaired.

Unlock the driver's door using the key. The other doors can be unlocked individually by pulling the interior door handles on those doors.

KEYLESS ENTRY

General information

WARNING




The keyless entry system may not function if the key is close to metal objects or electronic devices such as mobile phones.

The passive entry system will not function if:

- The vehicle battery is flat.
- The passive key frequencies are jammed.
- The passive key battery is flat.

Note: If the passive entry system does not function, you will need to use the key blade to lock and unlock your vehicle.

The keyless system allows the driver to operate the vehicle without the use of a key or remote control.




E78276

Passive locking and unlocking requires a valid passive key to be located within one of the three external detection ranges. These are located approximately one and a half metres from the driver and front passenger door handles and the luggage compartment lid.

Passive key

The vehicle can be locked and unlocked with the passive key. The passive key can also be used as a remote control. See **Locking and unlocking** (page 39).

Locking the vehicle



E87384

WARNING



The vehicle does not lock itself automatically. If the locking function is not activated, the vehicle will remain unlocked.

Locks

Touch a front door handle lock sensor to lock the vehicle.

To activate central locking and arm the alarm:

- Touch a front door handle lock sensor once.

To activate double locking and arm the alarm:

- Touch a front door handle lock sensor twice within three seconds.

Note: There must be clearance between each touch of the door handle.

Note: Once activated, the vehicle will remain locked for approximately three seconds. When the delay period is over, the doors can be opened again, provided the passive key is within the respective detection range.

Two short flashes of the direction indicators confirms that all the doors and the luggage compartment lid have been locked and that the alarm has been armed.

Luggage compartment lid


Note: The luggage compartment lid cannot be closed and, will pop back up if the passive key is located inside the vehicle with the doors locked.

Note: If a second valid passive key is located within the rear exterior detection range, the luggage compartment lid can be closed.

Unlocking the vehicle

Note: If the vehicle remains locked for longer than three days, the keyless system will enter an energy-saving mode. This is to reduce the discharge of the vehicle battery. When the vehicle is unlocked while in this mode, the reaction time of the system may be a little longer than normal. Unlocking the vehicle once will deactivate the energy-saving mode.

Note: If the vehicle remains locked for several weeks, the keyless system will be disabled. The vehicle must be unlocked using the key blade. Unlocking the vehicle once will enable the keyless system.



E87384

Open any door.

Note: A valid passive key must be located within the detection range of that door.

One long flash of the direction indicators confirms that all the doors and the luggage compartment lid have been unlocked and that the alarm has been disarmed.

Unlocking only the driver's door

If the unlocking function is reprogrammed so that only the driver's door and the luggage compartment lid are unlocked (See **Programming the remote control** (page 36).), note the following:

If the driver's door is the first door which is opened, the other doors will remain locked. All the other doors can be unlocked from inside the vehicle by pressing the unlock button on the instrument panel. For item location: See **Quick start** (page 10). Doors can be unlocked individually by pulling the interior door handles on those doors.

Locks

Disabled keys

Any keys left inside the vehicle interior when it is locked will be disabled.

A disabled key cannot be used to turn the ignition on or start the engine.

In order to use these passive keys again, they have to be enabled.

To enable all your passive keys, unlock the vehicle using a passive key or the remote control unlocking function.

All passive keys will then be enabled if the ignition is turned on or the vehicle is started using a valid key.

Locking and unlocking the doors with the key blade



E87964

1. Carefully remove the cover.
2. Remove the key blade and insert it into the lock.


Note: Only the driver's door handle is fitted with a lock cylinder.

GLOBAL OPENING AND CLOSING

You can also operate the electric windows with the ignition off via the global opening and global closing function.

Note: Global closing will only operate if you have set the memory correctly for each window. See **Electric windows** (page 70).

Global opening




E71955

To open all the windows, press and hold the remote control **unlock** button for at least three seconds. Press any remote control button again to stop the opening function.


Global closing

Vehicles without keyless entry

WARNING

 Take care when using global closing. In an emergency, press a remote control button immediately to stop.


Locks



E71956

To close all the windows, press and hold the remote control **lock** button for at least three seconds. Press any remote control button again to stop the closing function. The anti-trap function is also active during global closing.

Vehicles with keyless entry



E87384

WARNING



Take care when using global closing. In an emergency, touch a door handle lock sensor to stop.

Note: Global closing can be activated using the driver's door handle. Global opening and closing can also be activated using the buttons on the passive key.

Engine immobiliser

PRINCIPLE OF OPERATION

The engine immobiliser is a theft protection system that prevents someone from starting the engine with an incorrectly coded key.

CODED KEYS

Note: *Do not shield your keys with metal objects. This may prevent the receiver from recognising your key as a valid one.*

Note: *Have all of your remaining keys erased and recoded if you lose a key. Ask your dealer for further information. Have replacement keys recoded together with your existing keys.*

If you lose a key, you can obtain a replacement from your Ford Dealer. If possible, provide them with the key number from the tag provided with the original keys. You can also obtain additional keys from your Ford Dealer.

ARMING THE ENGINE IMMOBILISER

The engine immobiliser is armed automatically a short time after you have switched the ignition off.

DISARMING THE ENGINE IMMOBILISER

The engine immobiliser is disarmed automatically when you switch the ignition on with a correctly coded key.

Alarm

PRINCIPLE OF OPERATION

Alarm system


Your vehicle may be equipped with one of the following alarm systems:

- Perimeter alarm.
- Perimeter alarm with interior sensors.
- Category one alarm with interior sensors and battery back-up sounder.

Perimeter alarm

The perimeter alarm is a deterrent against unauthorised access to your vehicle through the doors and the bonnet. It also protects the audio unit.

Interior sensors



E129005

WARNING



The sensors in the interior lamp unit must not be covered up. Do not activate the alarm with full guard if any persons, animals or other moving objects are inside the vehicle.

The sensors act as a deterrent against unauthorised intrusion by sensing any movement within the vehicle.

Battery back-up sounder

The battery back-up sounder is an extra alarm system which will sound a siren when the alarm is triggered. It is armed directly when you lock the vehicle. The sounder has its own battery and will sound an alarm siren even if someone disconnects the vehicle battery or the battery back-up sounder itself.

Triggering the alarm

Once armed, the alarm is triggered in any of the following ways:

- If someone opens a door, the tailgate or the bonnet without a valid key or remote control.
- If someone removes the audio or navigation system.
- If the ignition is turned to position **I**, **II** or **III** without a valid key.
- If the interior sensors detect movement within the vehicle.
- On vehicles with a battery back-up sounder, if someone disconnects the vehicle battery or the battery back-up sounder itself.

If the alarm is triggered, the alarm horn will sound for 30 seconds and the hazard warning flasher will flash for five minutes.

Any further attempts to perform one of the above will trigger the alarm again.

Full and reduced guard

Full guard

Full guard is the standard setting.

In full guard, the interior sensors are activated when you arm the alarm.

Note: *This may result in false alarms if animals or moving objects are inside the vehicle.*

Alarm

Note: *False alarms can also be triggered by the auxiliary heater. See **Auxiliary heater** (page 108). If you are using the auxiliary heater, direct the air flow towards the footwell.*

Reduced guard

In reduced guard, the interior sensors are deactivated when you arm the alarm.

Note: *You can set the alarm to reduced guard for the current ignition cycle only. The next time you switch on the ignition, the alarm will be reset to full guard.*

Ask on Exit

You can set the information display to ask you each time which level of guard you wish to set.

If you select **Ask on Exit**, the message **Reduced guard?** appears in the instrument cluster display each time you switch the ignition off.

If you wish to arm the alarm with reduced guard, press the **OK** button when this message appears.

If you wish to arm the alarm with full guard, leave the vehicle without pressing the **OK** button.

Selecting full or reduced guard

Note: *Selecting **Reduced** does not set the alarm permanently to reduced guard. It sets it to reduced guard only for the current ignition cycle. If you regularly set the alarm to reduced guard, select **Ask on Exit**.*

You can select full or reduced guard using the information display. See **General information** (page 82).

Information messages

See **Information messages** (page 90).

ARMING THE ALARM

To arm the alarm, lock the vehicle. See **Locks** (page 39).

DISARMING THE ALARM

Vehicles without keyless entry

Perimeter alarm

Disarm and silence the alarm by unlocking the doors with the key and switching the ignition on with a correctly coded key, or unlocking the doors or the luggage compartment lid with the remote control.

Category one alarm

Disarm and silence the alarm by unlocking the doors with the key and switching the ignition on with a correctly coded key within 12 seconds, or unlocking the doors or the luggage compartment lid with the remote control.

Vehicles with keyless entry

Note: *A valid passive key must be located within the detection range of that door for keyless entry. See **Keyless entry** (page 41).*

Perimeter alarm

Disarm and silence the alarm by unlocking the doors and switching the ignition on, or unlocking the doors or the luggage compartment lid with the remote control.


Category one alarm

Disarm and silence the alarm by unlocking the doors and switching the ignition on within 12 seconds, or unlocking the doors or the luggage compartment lid with the remote control.


Steering wheel

ADJUSTING THE STEERING WHEEL

WARNING

 Never adjust the steering wheel when the vehicle is moving.

Note: Make sure that you are sitting in the correct position. See **Sitting in the correct position** (page 111).




E95178



E95179

WARNING


 Make sure that you fully engage the locking lever when returning it to its original position.

AUDIO CONTROL

Select the required source on the audio unit.

The following functions can be operated with the remote control:

Type 1




E129462

- A Volume up
- B Seek up
- C Volume down
- D Seek down
- E Mode

Steering wheel

Type 2



E129463

- A Volume up
- B Seek up
- C Volume down
- D Seek down

VOICE CONTROL



E129464

Pull the button to select or deselect voice control. See **Voice control** (page 260).

Mode

Press the mode button to tune the radio to the next preset station.

Press and **hold** the mode button to select the audio source.

Seek

Press the seek button to:


- tune the radio to the next station up or down the frequency band
- play the next or the previous track.

Press and **hold** the seek button to:

- tune the radio up or down the frequency band
- seek through a track.

Wipers and washers


WINDSCREEN WIPERS



E128444

- A Single wipe
- B Intermittent wipe or autowipers
- C Normal wipe
- D High speed wipe

Intermittent wipe



E128445

- A Short wipe interval
- B Intermittent wipe
- C Long wipe interval

The rotary control can be used to adjust the intermittent wipe interval.

Automatic wiper system

Some models without autowipers are fitted with a speed-dependent front screen wiper system.

When the vehicle is slowed to walking speed or is brought to a standstill, the wiper speed will automatically switch to the next lower wiper speed setting.

When the vehicle speed is increased, the wiper speed will return to the manually-chosen setting.

Moving the wiper lever when the system is operating will switch off the system.


If the vehicle is again slowed to walking speed or is brought to a standstill, the system is reactivated.

AUTOWIPERS

CAUTIONS

- ⚠ Do not switch autowipers on in dry weather conditions. The rain sensor is very sensitive and the wipers may operate if dirt, mist or flies hit the windscreen.
- ⚠ Replace the wiper blades as soon as they begin to leave bands of water and smears. If you do not replace them, the rain sensor will continue to detect water on the windscreen and the wipers will operate, even though the majority of the windscreen is dry.
- ⚠ Fully defrost the windscreen in icy conditions before you switch autowipers on.
- ⚠ Switch autowipers off before you enter a car wash.

Wipers and washers



E128445

- A High sensitivity
- B On
- C Low sensitivity

If you switch autowipers on, the wipers will not cycle until water is detected on the windscreen. The rain sensor will then continuously measure the amount of water on the windscreen and adjust the speed of the wipers automatically.

Adjust the sensitivity of the rain sensor using the rotary control. With low sensitivity, the wipers will operate when the sensor detects a lot of water on the windscreen. With high sensitivity, the wipers will operate if the sensor detects a small amount of water on the windscreen.

WINDSCREEN WASHERS



E129188

WARNING




Do not operate the washer for more than 10 seconds at a time, and never when the reservoir is empty.

Whilst the lever is pulled towards the steering wheel the washer will work in conjunction with the wipers.

After releasing the lever, the wipers operate for a short time.

REAR WINDOW WIPER AND WASHERS

Intermittent wipe



E129193

- A Intermittent wipe
- B Low speed wipe


Press the button at the end of the lever to change between off, intermittent and low speed.

Wipers and washers

Reverse gear wipe

The rear wiper will be activated automatically when selecting reverse gear if the rear wiper is not already switched on and the front wiper is operating.

Rear window washer



E129194

WARNING



Do not operate the washer for more than 10 seconds at a time, and never when the reservoir is empty.

While the lever is pushed away from the steering wheel the washer will work in conjunction with the wipers.


After releasing the lever, the wipers operate for a short time.

HEADLAMP WASHERS

The headlamp washers will operate with the windscreen washers when the headlamps are on.

Note: *To stop the washer fluid reservoir emptying quickly, the headlamp washers will not operate every time that you use the windscreen washers.*

CHECKING THE WIPER BLADES



E66644



Run the tip of your fingers over the edge of the blade to check for roughness.

Clean the wiper blade lips with water applied with a soft sponge.

CHANGING THE WIPER BLADES

Windscreen wiper blades

CAUTIONS


-  Set the windscreen wipers in the service position to change the wiper blades.
-  You can use the service position in winter to provide easier access to the wiper blades for freeing them from snow and ice. The windscreen wipers will return to their normal position as soon as you switch on the ignition so make sure that the outside of the windscreen is free from snow and ice before you switch on the ignition.

Wipers and washers

Service position



E75184




E129986

Switch off the ignition and move the wiper lever to position **A** within three seconds. Release the lever when the windscreen wipers have moved to the service position.

Changing the windscreen wiper blades

Set the windscreen wipers in the service position and lift the wiper arms.




E72899

Install in the reverse order.

Note: Make sure that the wiper blade locks into place.

Rear window wiper blade

1. Lift the wiper arm.



E86456

2. Position the wiper blade at right angles to the wiper arm.

3. Disengage the wiper blade from the wiper arm.

4. Remove the wiper blade.


Note: Make sure that the wiper blade locks into place.

5. Install in the reverse order.

Lighting

LIGHTING CONTROL

Lighting control positions




E132706

- A Off
- B Side and tail lamps
- C Headlamps

Parking lamps

CAUTION


 Prolonged use of the parking lamps will discharge the battery.

Switch off the ignition.

Both sides

Turn the lighting control switch to position **B**.

One side



E130139

- A Right-hand side
- B Left-hand side

Main and dipped beam



E130140

Push the lever forward to switch between main and dipped beam.

Headlamp flasher

Pull the lever slightly towards the steering wheel.

Lighting

Home safe lighting

Switch the ignition off and pull the direction indicator lever towards the steering wheel to switch the headlamps on. You will hear a short tone. The headlamps will go off automatically after 3 minutes with any door open, or 30 seconds after the last door has been closed.

The home safe lights can be cancelled by either pulling the direction indicator lever towards the steering wheel again or by turning the ignition switch ON.

AUTOLAMPS

WARNING



In severe weather conditions, it may be necessary to switch your headlamps on manually.



E132707

Note: If you have switched autolamps on, you can only switch the main beam on when autolamps has switched the headlamps on.

The headlamps will come on and go off automatically depending on the ambient light.

The headlamps will remain on for a period of time after you switch the ignition off. You can adjust the time delay using the information display. See **Information displays** (page 82).

AUTOMATIC MAIN BEAM CONTROL

WARNINGS



The system does not relieve you of your responsibility to drive with due care and attention. A manual override may be necessary if the system fails to switch the main beam on or off.



A manual override may be required when approaching other road users such as cyclists.



Do not use the system in fog.

CAUTIONS



In cold and severe weather conditions the system may not function. A manual override may be necessary in these cases.



Reflective road signs may be detected as oncoming traffic and the headlamps may be switched to dipped beam.



If the lights of oncoming vehicles are hidden by obstacles (for example guard rails) the system may not deactivate the main beam.



Always fit Ford Original Parts when replacing headlamp bulbs. Other bulbs may reduce system performance.



Check and replace wiper blades regularly to ensure the camera sensor has a clear view through the windscreen. Replacement wiper blades must be the correct length.

Lighting

Note: Keep the windscreen free from obstructions such as bird droppings, insects and snow or ice.

The system will automatically switch on main beam if it is dark enough and no other traffic is present. If it detects an approaching vehicle's headlamps or tail lamps, or street lighting ahead the system will switch off main beam before it can distract other road users. Dipped beams will remain on.

A camera sensor is centrally mounted behind the windscreen of the vehicle, and monitors conditions continuously to decide when to switch the main beam off and on.

Once the system is active the main beam will switch on if:

- It is dark enough to require the use of main beams and
- there is no traffic or street lighting ahead and
- vehicle speed is greater than 40 km/h (25 mph).

The main beam will switch off if:

- The ambient light is high enough that main beam is not required.
- An approaching vehicle's headlamps or tail lamps are detected.
- Street lighting is detected.
- Vehicle speed falls below 25 km/h (16 mph).
- The camera sensor is too hot or becomes blocked.

Activating the system

Switch on the system using the information display and autolamps. See **Information displays** (page 82). See **Autolamps** (page 55).



E132707

Turn the switch to the autolamps position.


Note: The system may take a short time to initialise after first switching the ignition on, especially in very dark conditions. The main beam will not automatically switch on during this period.

Setting the system sensitivity

The system has three sensitivity levels which can be accessed via the information display. See **Information displays** (page 82).

The sensitivity determines the speed at which the main beam will be restored after detected traffic leaves the field of view.

Manually overriding the system



E133632

Lighting

Push or pull the lever to switch between main and dipped beam.

Note: This is a temporary override and the system will return to automatic operation after a short period.

To permanently deactivate the system use the information display menu or turn the lighting control switch from autolamps to headlamps.

FRONT FOG LAMPS

WARNING



Only use the front fog lamps when visibility is considerably restricted by fog, snow or rain.



E132709

REAR FOG LAMPS

WARNINGS



Only use the rear fog lamps when visibility is restricted to less than 50 metres.



Do not use the rear fog lamps when it is raining or snowing and visibility is more than 50 metres.



E132710

HEADLAMP LEVELLING

Note: Vehicles with Xenon headlamps are equipped with automatic headlamp levelling.

1. Press to release the pop out button.



E132711

2. Rotate the button to the required setting.
3. Push the button to the closed position.

You can adjust the level of the headlamp beams according to the vehicle load.

Lighting

Recommended headlamp levelling switch positions

Load		Load in luggage compartment	Switch position
Front seats	Second row seats		
1-2	-	-	0
2	3	-	1
2	3	Max ¹	2
1	-	Max ¹	3


¹ See **Vehicle identification** (page 214).

HAZARD WARNING FLASHERS



For item location: See **Quick start** (page 10).

DIRECTION INDICATORS




E130141

Note: Tap the lever up or down to make the direction indicators flash only three times.

Lighting

CORNERING LAMPS



E72898

- A Headlamp beam
- B Corning lamp beam


The corning lamps illuminate the inside of a corner when you are turning.

Lighting

INTERIOR LAMPS

LED interior lighting

Driver LED lamp



E124991

- A Individual lamp on and off switch
- B All lamps on and off switch

You can control all lamps using switch **B**.

Note: Individual lamps may be switched on independently, but not off if all lamps have been switched on by the driver.

The lamps will come on when you unlock or open a door or the luggage compartment lid. If you leave a door open with the ignition switch off, all lamps will go off automatically after some time to prevent the vehicle battery from discharging. To switch them back on, switch on the ignition for a short time.

If you press and hold switch **B** for 3 seconds all lamps will stay off regardless of the doors or luggage compartment lid position. Press the switch again to reverse.

Ambient lighting

If you leave a door open with the ignition switch off, the ambient lamp will go off automatically after some time to prevent the vehicle battery from discharging.

If dark, the ambient lights are active if the ignition and headlamps are switched on.

Type 1

Illuminates the interior with a single colour. The ambient lighting can be switched on and off using the information display menu. See **General information** (page 82).

Use the instrument lighting dimmer switches to adjust to the desired brightness. See **Instrument lighting dimmer** (page 116).

Type 2



E133092

Illuminates the interior with a choice of several colours. The ambient lighting control switch is located in the overhead console.

To activate, rotate the control knob and adjust to the desired brightness. Use the left switch to cycle through the colour choices. Use the right switch to activate all ambient light areas and interior lamps.

Lighting


REMOVING A HEADLAMP

WARNING




Have Xenon bulbs changed by a trained technician. There is a risk of electric shock.

1. Open the bonnet. See **Opening and closing the bonnet** (page 185).



E133215

2. Remove the screws.
3. Pull the headlamp as far as possible towards the front of the vehicle to disengage it from the lower fixing point.
4. Lift the outer side of the headlamp and remove it.



E133750

5. Disconnect the electrical connector.
Note: When fitting the headlamp, make sure that you reconnect the electrical connector properly.
Note: When fitting the headlamp, make sure that you fully engage the headlamp in the lower fixing point.
Note: When fitting the headlamp, make sure that the screw is located in the headlamp moulding before you install it.

CHANGING A BULB

WARNINGS



Switch the lights and the ignition off.



Let the bulb cool down before removing it.



Have Xenon bulbs changed by a properly trained technician. There is a risk of electric shock.

CAUTIONS



Do not touch the glass of the bulb.

Lighting


CAUTIONS

-  Only fit bulbs of the correct specification. See **Bulb specification chart** (page 69).

Note: The following instructions describe how to remove the bulbs. Fit replacements in the reverse order unless otherwise stated.

Headlamp

Note: Remove the covers to gain access to the bulbs.




E133102

- A Side lamp
- B Headlamp dipped beam
- C Headlamp main beam
- D Direction indicator

Direction indicator

1. Remove the headlamp. See **Removing a headlamp** (page 61).




E133104


2. Remove the cover.
3. Turn the bulb holder anti-clockwise and remove it.
4. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Headlamp main beam

CAUTION

-  Do not touch the glass of the bulb.

1. Remove the headlamp. See **Removing a headlamp** (page 61).



E133105


2. Remove the cover.
3. Disconnect the electrical connector.

Lighting


4. Release the clip and remove the bulb.

Headlamp dipped beam

CAUTION

-  Do not touch the glass of the bulb.

1. Remove the headlamp. See **Removing a headlamp** (page 61).





E133106

2. Remove the cover.
3. Disconnect the electrical connector.
4. Release the clip and remove the bulb.

Side Lamp


1. Remove the headlamp. See **Removing a headlamp** (page 61).



E133103

2. Remove the cover.
3. Remove the bulb holder.
4. Remove the bulb.

Side repeater



E133426

1. Carefully remove the cover.

Lighting




E133427

2. Using a suitable implement release the retaining clip.



E133108

3. Carefully remove the side repeater.




E133109

4. Remove the bulb holder.
5. Remove the bulb.

Approach lamp

CAUTION

 When removing the mirror glass, take care not to break it.


Note: *Position the mirror glass as far inwards as possible.*



E133110

Lighting

1. Insert your fingers into the gap between the mirror housing and the mirror glass and pull gently to remove the mirror glass.



E133717

2. Remove the lamp.




E133718

3. Remove the bulb.

Front fog lamps

1. Remove the headlamp. See **Removing a headlamp** (page 61).



E133107

Note: You cannot separate the fog lamp bulb from the bulb holder.

2. Disconnect the electrical connector.
3. Turn the bulb holder anti-clockwise and remove it.


Rear lamps - 5 door



E133111


1. Remove the trim panel.

Lighting




E133112

2. Remove the wing nuts and detach the clip.
3. Remove the lamp.



E133127

4. Disconnect the electrical connector.



E133113

5. Remove the bulb holder.
 6. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.
- A. Brake lamp
B. Reversing lamp
C. Tail and fog lamp
D. Direction indicator

Rear lamps - 4 door


Direction indicator, tail and fog lamp



E133702


1. Remove the trim panel.

Lighting




E133703

2. Remove the wing nuts and detach the clip.
3. Remove the lamp.



E133713

4. Disconnect the electrical connector.



E133714

5. Remove the bulb holder.

6. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

- A. Tail and fog lamp
- B. Direction indicator


Brake and reversing lamp

1. Open the luggage compartment lid.



E133724

2. Remove the luggage compartment lid trim.



E133725


CAUTION



Unclip the outboard side first.


Lighting

3. Remove the wing nut and detach the 2 clips.
4. Remove the lamp.



E133726

5. Disconnect the electrical connector.



E133727

6. Remove the bulb holder.
 7. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.
- A. Brake lamp
B. Reversing lamp

Central high mounted brake lamp

Note: *These are not serviceable items, please consult your dealer if they fail.*


Number plate lamp

Note: *These are not serviceable items, please consult your dealer if they fail.*

Interior lamps


Vehicles with LED lamps

Note: *The LED board is not a serviceable item, please consult your dealer if this fails.*



E125092

Luggage compartment lamp, footwell lamp and tailgate lamp



E72784

1. Carefully prise out the lamp.
2. Remove the bulb.

Lighting

BULB SPECIFICATION CHART

Lamp	Specification	Power (watt)
Front direction indicator	PY21W	21
Headlamp main beam	H1	55
Headlamp dipped beam	H7	55 ¹
Cornering lamp	H1	55
Front fog lamp	H11	55
Side lamp	W5W	5
Side repeater	WY5W	5
Approach lamp	W5W	5
Rear direction indicator	PY21W	21
Brake and tail lamp	P21/5W	21/5
Tail lamp	W5W	5
Rear fog lamp	P21W	21
Reversing lamp (5 door)	W16W	16
Reversing lamp (4 door)	P21W	21
Luggage compartment lamp	W5W	5

¹Fit a replacement with the same rating as the one you have removed.

Windows and mirrors

ELECTRIC WINDOWS

WARNING



Do not operate the electric windows unless they are free from obstruction.

Note: *If you operate the switches often during a short period of time, the system might become inoperable for a certain time to prevent damage due to overheating.*


Switch on the ignition to operate the electric windows.

Global opening and closing

You can also operate the electric windows with the ignition off via the global opening and closing function. See **Locks** (page 39).

Driver's door switches

You can operate all the windows with the switches on the door trim panel of the driver's door.



E70848

Opening and closing the windows automatically

Press or lift the switch to the second action point and release it completely. Press or lift it again to stop the windows.

Safety switch for rear windows

WARNING



On some vehicles, pressing the switch will also lock the rear doors from inside. See **Child safety locks** (page 29).

Note: *You can always operate the rear windows from the driver's door.*



E70850

A switch in the driver's door disables the rear electric window switches.

The light in the switch comes on and the lights in the rear window switches go off when the rear windows are disabled.

Anti-trap function

WARNING




Careless closing of the windows can override the protection function and cause injuries.

Windows and mirrors

The electric windows will stop automatically while closing and reverse some distance if there is an obstacle in the way.

Overriding the anti-trap function

CAUTION


 While you close the window for the third time, the anti-trap function is disabled. Make sure there are no obstacles in the way of the closing window.

To override this protection function when there is a resistance, e.g. in the winter, proceed as follows:

1. Close the window twice until it reaches the resistance and let it reverse.
2. Close the window a third time to the resistance. The anti-trap function is disabled and you cannot close the window automatically. The window will override the resistance and you can close it fully.
3. If the window does not close after the third attempt, have it checked by an expert.

Resetting the memory of the electric windows

WARNING

 The anti-trap function is deactivated until you have reset the memory.


After the battery has been disconnected from the vehicle you must reset the memory separately for each window:

Note: *On vehicles with a convertible top, the roof and doors must be fully closed before carrying out the following procedure.*

1. Lift and hold the switch until the window is fully closed.
2. Release the switch.
3. Lift the switch again for one more second.
4. Push and hold the switch until the window is fully open.
5. Release the switch.
6. Lift and hold the switch until the window is fully closed.
7. Open the window and try to close it automatically.
8. Reset and repeat procedure if the window does not close automatically.

EXTERIOR MIRRORS

WARNING

 Do not overestimate the distance of the objects that you see in the convex mirror. Objects seen in convex mirrors will appear smaller and further away than they actually are.

Manual folding mirrors

Folding


Push the mirror towards the door window glass.

Unfolding

Make sure that you fully engage the mirror in its support when returning it to its original position.

Windows and mirrors


ELECTRIC EXTERIOR MIRRORS



E70846

- A Left-hand mirror
- B Off
- C Right-hand mirror

Mirror tilting positions



E70847

The electric exterior mirrors are fitted with a heating element that will defrost or demist the mirror glass. See **Heated windows and mirrors** (page 108).

Electric folding mirrors

Automatic folding and unfolding

Note: If the mirrors have been folded using the manual fold button they can only be unfolded using the manual fold button.

The mirrors will fold automatically when you lock the vehicle with the key, the remote control or a keyless entry system request. The mirrors will unfold when you unlock the vehicle with the key, the remote control, a keyless entry system request, the driver's interior door handle or starting the engine.

Manual folding and unfolding

The electric folding mirrors operate with the ignition on.

Note: You can operate the mirrors (mirror tilting and folding) for several minutes after you switch off the ignition. They will be deactivated as soon as a door is opened.



E72623


Press the button to fold or unfold the mirrors.

Windows and mirrors

If you press the switch again while the mirrors are moving, they will stop and reverse the direction of movement.

Note: *When the mirrors are operated often during a short period of time, the system may become inoperable for a period of time to prevent damage due to overheating.*

AUTO-DIMMING MIRROR



E71028

The auto-dimming mirror will adjust automatically when hit by glaring light from behind. It will not work when you have selected reverse gear.

BLIND SPOT MONITOR

Blind spot information system (BLIS)

WARNINGS




The system is not designed to prevent contact with other vehicles or objects. The system only provides a warning to assist you in detecting vehicles in the blind spot zones. The system will not detect obstacles, pedestrians, motorcyclists or cyclists.



Do not use the system as a replacement for using the side and rear view mirrors, and looking over your shoulder before changing lanes. The system is not a replacement for careful driving and is only to be used as an aid.

The system is a convenience feature that aids the driver in detecting vehicles that may have entered the blind spot zone (A). The detection area is on both sides of the vehicle extending rearwards from the exterior mirrors to approximately 3 metres (10 feet) beyond the bumper. The system will alert you if certain vehicles enter the blind spot zone whilst driving.



E124788

Using the system

The system displays a yellow indicator located in the exterior mirrors.



E124736

Note: *Both indicators will illuminate briefly when you switch the ignition on to confirm that the system is operational.*

Windows and mirrors

Note: On vehicles with automatic transmission, the system is active only in **S, D and N**.

The system is only active when you exceed 10 km/h (6 mph). The system is temporarily deactivated when you select reverse gear.

System detection and alerts


The system will trigger the alert for vehicles that enter the blind spot zone from the rear or merge from the side. Vehicles that you pass, or vehicles that enter the blind spot zone from the front, will only trigger the alert after the vehicle has remained in the blind spot zone for a short period of time.

Note: Vehicles that pass through the blind zone quickly (typically less than 2 seconds) will not trigger the alert.

The system consists of two radar sensors each located behind the rear wheels hidden behind the bumpers.

CAUTIONS

- ! Do not place items such as bumper stickers in this area.
- ! Repairs to these areas using body filler will affect the performance of the system.



E124741

Detection limitations

There may be certain instances where vehicles entering and exiting the blind spot zones may not be detected.

Instances which may cause non-detection:

- Debris build up on the rear bumper panels in the area of the sensors.
- Certain manoeuvring of vehicles entering and exiting the blind zone.
- Vehicles passing through the blind zone at high speed.
- Severe weather conditions.
- Several vehicles passing through the blind zone following each other closely.

False alerts

Note: False alerts are temporary and will self correct.

There may be certain instances when the system will alert with no vehicle present in the blind zone.

Circumstances where false alerts may occur:

- Road guardrails.
- Motorway concrete walls.
- Construction areas.
- Sharp turns around a building.
- Bushes and trees.
- Cyclists and motorcyclists.
- Coming to a stop with a vehicle directly behind but very close.

Turning the system on and off

Note: The on or off position will remain until manually changed.

You can turn the system on and off using the information display. See **Information displays** (page 82).

Windows and mirrors

When you turn the system off no further alerts will be received. The BLIS warning indicator will illuminate. See **Warning lamps and indicators** (page 78).

Detection errors

Note: *The alert indicator in the mirror will not illuminate.*

If the system senses a fault on either sensor, the system warning symbol will illuminate and remain on. The information display will confirm the fault and indicate whether the left or right side is affected.

Blocked sensor

WARNING



Prior to the system recognizing a blocked condition and issuing a warning, the number of missed objects will increase.

CAUTION



The sensors may not detect vehicles in heavy rain or other conditions that cause disruptive reflections.

Note: *Keep the rear bumper area surrounding the sensors free from dirt, ice and snow.*

If a sensor becomes blocked the system performance may degrade. A blocked sensor message may be displayed.

The system will automatically return to normal operation once two other vehicles have been detected on both sides.

Trailer towing false alerts

CAUTION




Vehicles fitted with a trailer tow module not approved by us may not correctly be detected. Switch the system off to avoid false alerts. See **Information displays** (page 82).

If the vehicle is fitted with a trailer tow module approved by us, the system will detect a connected trailer and deactivate. A confirmation message will be shown in the information display. See **Information messages** (page 90). The BLIS warning indicator will illuminate. See **Warning lamps and indicators** (page 78).

Instruments

GAUGES

Type 1




E132065

- A Information display. See **Information displays** (page 82).
- B Speedometer
- C Engine coolant temperature gauge
- D Tripmeter reset button
- E Fuel gauge
- F Tachometer

Instruments

Type 2 and 3



E130149

- A Information display. See **Information displays** (page 82).
- B Speedometer
- C Engine coolant temperature gauge
- D Fuel gauge
- E Tachometer

Engine coolant temperature gauge

All vehicles

Shows the temperature of the engine coolant. At normal operating temperature, the needle will remain in the centre section.

CAUTION

- ⚠ Do not restart the engine until the cause of overheating has been resolved.

If the needle enters the red section, the engine is overheating. Stop the engine, switch the ignition off and determine the cause **once the engine has cooled down**. See **Engine coolant check** (page 193).

Fuel gauge

The arrow adjacent to the fuel pump symbol indicates on which side of the vehicle the fuel filler cap is located.

Instruments

WARNING LAMPS AND INDICATORS

The following warning lamps and indicators illuminate when the ignition is switched on:

- Airbag
- ABS
- Stability control (ESP)
- Low fuel
- Brake system
- Frost
- ESP off

If a warning or indicator lamp does not illuminate when the ignition is switched on, it indicates a malfunction. Have the system checked by properly trained technician.

ABS warning lamp



If it illuminates when you are driving, this indicates a malfunction. You will continue to have normal braking (without ABS). Have the system checked by a properly trained technician as soon as possible.

Airbag warning lamp



If it illuminates when you are driving, this indicates a malfunction. Have the system checked by a properly trained technician.

Blind spot monitor indicator



It will illuminate when this feature is deactivated or in conjunction with a message. See **Blind spot monitor** (page 73). See **Information messages** (page 90).

Brake system lamp



It illuminates when the parking brake is engaged.

WARNING



Reduce your speed gradually and stop your vehicle as soon as it is safe to do so. Use your brakes with care.

If it illuminates when you are driving, check that the parking brake is not engaged. If the parking brake is not engaged, this indicates a malfunction. Have the system checked by a properly trained technician immediately.

Cruise control indicator



It will illuminate when you have set a speed using the cruise control system. See **Using cruise control** (page 149).

Direction indicators



Flashes during operation. A sudden increase in the rate of flashing warns of a failed indicator bulb. See **Changing a bulb** (page 61).


Engine warning lamp




If it illuminates with the engine running, this indicates a malfunction. If it flashes when you are driving, **reduce the speed of your vehicle immediately**. If it continues to flash, avoid heavy acceleration or deceleration. Have the system checked by a properly trained technician immediately.

Instruments

CAUTION

 If the engine warning lamp illuminates in conjunction with a message, have the system checked as soon as possible.

Forward alert warning indicator


 It will illuminate when this feature is switched off or in conjunction with a message. See **Forward alert function** (page 155).


Front fog lamp indicator

 It will illuminate when you switch the front fog lamps on.


Frost warning lamp

WARNING


 Even if the temperature rises to above +4°C there is no guarantee that the road is free of hazards caused by inclement weather.

 It will illuminate and glow amber when the outside air temperature is between +4°C (39°F) and 0°C (32°F). It will glow red when the temperature is below 0°C (32°F).

Glow plug indicator

 See **Starting a diesel engine** (page 121).

Headlamp indicator

 It will illuminate when you switch the headlamp dipped beam or the side and tail lamps on.

Ignition warning lamp



If it illuminates when you are driving, this indicates a malfunction. Switch off all unnecessary electrical equipment. Have the system checked by a properly trained technician immediately.

Lane departure warning indicator



It will illuminate when this feature is switched off or in conjunction with a message. See **Lane departure warning** (page 160).

Low fuel level warning lamp



If it illuminates, refuel as soon as possible.

Main beam indicator



It will illuminate when you switch the headlamp main beam on. It will flash when you use the headlamp flasher.

Message indicator



It will illuminate when a new message is stored in the information display. See **Information messages** (page 90).

Oil pressure warning lamp

CAUTION



Do not resume your journey if it illuminates despite the level being correct. Have the system checked by a properly trained technician immediately.

Instruments



If it stays on after starting or illuminates when driving, this indicates a malfunction. Stop your vehicle as soon as it is safe to do so and switch the engine off. Check the engine oil level. See **Engine oil check** (page 192).

Rear fog lamp indicator



It will illuminate when you switch the rear fog lamps on.

Seat belt reminder



See **Seat belt reminder** (page 33).

Stability control (ESP) indicator



While driving, it flashes during activation of the system. After switching on the ignition, if it does not illuminate or illuminates continuously while driving, this indicates a malfunction. During a malfunction, the system switches off. Have the system checked by a properly trained technician as soon as possible.



If you switch ESP off, the warning lamp will illuminate. The lamp will go out when you switch the system back on or when you switch the ignition off.

Start-stop indicator



It will illuminate to inform you when the engine shuts down or in conjunction with a message. See **Using start-stop** (page 124). See **Information messages** (page 90).

AUDIBLE WARNINGS AND INDICATORS

Switching the chimes on and off

You can deactivate certain chimes in the Information display using the steering wheel control. For item location: See **Quick start** (page 10).

To set which chimes should sound:

1. Press the left arrow button on the steering wheel to enter the main menu.
2. Highlight **Settings** with the up and down arrow buttons and press the right arrow button.
3. Highlight **Chimes** and press the right arrow button.
4. Highlight **Information or Warning** and press the **OK** button to switch the chime on and off.
5. Press the left arrow button to exit the menu. Press and hold the left arrow button to return to the main menu display.

Automatic transmission

If position **P** is not selected, a warning chime will sound when the driver's door is opened.

Frost

WARNING



Even if the temperature rises to above +4°C (39°F) there is no guarantee that the road is free of hazards caused by inclement weather.

Instruments

A warning chime will sound in the following conditions:

- +4°C (39°F) or lower: frost warning
- 0°C (32°F) or lower: danger of icy roads.

Key outside car

Vehicles with keyless entry

If the engine is running and a passive key is no longer detected within the vehicle interior, a warning chime will sound.

Door open

A warning chime will sound when any door is opened if the vehicle exceeds a relatively low speed.

Lights on

A warning chime will sound if the driver's door is opened with the exterior lights switched on and the ignition switched off.

Low fuel

A warning chime will sound when the remaining fuel is less than approximately 6 litres (1.3 gallons).

Seat belt reminder

See **Seat belt reminder** (page 33).

Information displays

GENERAL INFORMATION

Note: *The information display will remain on for several minutes after you switch off the ignition.*

Various systems on your vehicle can be controlled using the information display controls on the steering column. Corresponding information is displayed in the information display.

For detailed instructions on navigation, refer to the appropriate manual.

Device list

The icon changes to show the current function in use.



CD



Radio



Auxiliary input



Phone



Settings

Controls

Press the **up** and **down** arrow buttons to scroll through and highlight the options within a menu.

Press the **right** arrow button to enter a sub-menu.

Press the **left** arrow button to exit a menu.

Hold the **left** arrow button pressed at any time to return to the main menu display (escape button).


Press the **OK** button to choose and confirm a setting.

Menu structure - information display

All vehicles


You can access the menu using the Information display control. For item location: See **Quick start** (page 10).

Information displays



E133367

Information displays




E133368

Information displays

Menu structure - information and entertainment display

You can access the menu using the buttons on the audio or navigation unit.

All vehicles



E130532


Information displays

Menu structure - information and entertainment display


You can access the menu using the Information and entertainment display control. For item location: See **Quick start** (page 10).

Information displays

Vehicles with navigation system




Information displays



E130535

Information displays



E130536

TRIP COMPUTER

Trip Odometer

Registers the mileage of individual journeys.

Distance to empty

Indicates the approximate distance the vehicle will travel on the fuel remaining in the tank. Changes in driving pattern may cause the value to vary.

Instantaneous fuel consumption

Indicates the current average fuel consumption.

Average fuel consumption

Indicates the average fuel consumption since the function was last reset.

Average speed

Indicates the average speed calculated since the function was last reset.

Outside air temperature

Shows the outside air temperature.

Odometer

Registers the total mileage of the vehicle.

Resetting the trip computer

To reset a particular display:

1. Highlight **Trip Computer** with the up and down arrow buttons and press the right arrow button.
2. Highlight the function to be reset.
3. Hold the **OK** button pressed.

PERSONALISED SETTINGS

Language setting

A choice of eleven languages are available:

English, German, Italian, French, Spanish, Turkish, Russian, Dutch, Polish, Swedish and Portuguese.

Information displays

Measure units

To toggle between metric and imperial units, scroll to this display and press the **OK** button.

Toggling the units of measure using this display will affect the following displays:

- Distance to empty.
- Average fuel consumption.
- Instantaneous fuel consumption.
- Average speed.

Temperature units

To toggle between metric and imperial units, scroll to this display and press the **OK** button.

Toggling the temperature units using this display will affect the following displays:

- Outside air temperature.
- The temperature display in the automatic climate control.

Chime deactivation

The following chimes can be deactivated:

- Warning messages.
- Information messages.

INFORMATION MESSAGES

Note: *Certain messages may be abbreviated or shortened depending upon which cluster type you have.*

Airbag

Message	Message indicator	Action
Airbag malfunction service now	amber	Have the system checked by a properly trained technician as soon as possible.




E130248

Press the **OK** button to acknowledge and remove some messages from the information display. Other messages will be removed automatically after a short time.

Certain messages need to be confirmed before you can access the menus.

Message indicator

 The message indicator illuminates to supplement some messages. It will be red or amber depending on the severity of the message and will remain on until the cause of the message has been rectified.

Some messages will be supplemented by a system specific symbol with a message indicator.

Information displays

Alarm

Message	Message indicator	Action
Alarm triggered check vehicle	amber	See Alarm (page 46).
Alarm malfunction service required	-	Have the system checked by a properly trained technician.

Automatic main beam control

Message	Indicator	Action
Front camera low visibility Clean screen	amber	The front camera sensor has reduced visibility. Clean the windscreen.
Front camera malfunction Service required	amber	The front camera sensor has malfunctioned. Have this checked as soon as possible.

Battery and charging system

Message	Message indicator	Action
Electrical system over voltage stop safely	red	Stop your vehicle as soon as it is safe to do so and switch off the ignition. Have the system checked by a properly trained technician as soon as possible.
Battery low check handbook	amber	Have the system checked by a properly trained technician as soon as possible.

Information displays

Blind spot monitor

Message	Message indicator	Action
BLIS sensor blocked check handbook	amber	See Blind spot monitor (page 73).
BLIS: right sensor fault service required	amber	Have the system checked by a properly trained technician as soon as possible.
BLIS: left sensor fault service required	amber	Have the system checked by a properly trained technician as soon as possible.
BLIS not available trailer attached	amber	See Blind spot monitor (page 73).

Child power lock

Message	Message indicator	Action
Child lock malfunction service required	amber	Have the system checked by a properly trained technician as soon as possible.

Climate control

Message	Indicator	Action
Auxiliary Heater on	amber	See Auxiliary heater (page 108).
Auxiliary Heater off	-	See Auxiliary heater (page 108).

Cruise control and Adaptive cruise control (ACC)

Message	Indicator	Action
Front radar sensor blocked Clean grill	amber	See Adaptive cruise control (ACC) (page 151).
Forward Alert not available	amber	See Adaptive cruise control (ACC) (page 151).
ACC not available	amber	See Adaptive cruise control (ACC) (page 151).

Information displays

Doors open

Message	Message indicator	Action
Driver door open	red	Vehicle is moving. Stop the vehicle as soon as safely possible and close.
Driver side rear door open	red	Vehicle is moving. Stop the vehicle as soon as safely possible and close.
Passenger door open	red	Vehicle is moving. Stop the vehicle as soon as safely possible and close.
Passenger side rear door open	red	Vehicle is moving. Stop the vehicle as soon as safely possible and close.
Luggage compartment lid open	red	Vehicle is moving. Stop the vehicle as soon as safely possible and close.
Bonnet open	red	Vehicle is moving. Stop the vehicle as soon as safely possible and close. See Opening and closing the bonnet (page 185).
Driver door open	-	Vehicle not moving. Close.
Driver side rear door open	-	Vehicle not moving. Close.
Passenger door open	-	Vehicle not moving. Close.
Passenger side rear door open	-	Vehicle not moving. Close.
Luggage compartment lid open	-	Vehicle not moving. Close.
Bonnet open	-	Vehicle not moving. Close. See Opening and closing the bonnet (page 185).

Driver alert

Message	Indicator	Action
Driver fatigue warning Rest now	red	Stop and rest as soon as it is safe to do so.
Driver fatigue warning Rest suggested	amber	Take a rest break soon.

Information displays

Engine immobiliser

Message	Message indicator	Action
Immobiliser active check handbook	amber	Your key has not been recognised. Remove the key and try again.
Immobiliser malfunction service required	amber	Have the system checked by a properly trained technician as soon as possible.

Hill start assist

Message	Message indicator	Action
Hill start assist not available	amber	Have the system checked by a properly trained technician.

Keyless system

Message	Message indicator	Action
Steering malfunction stop safely	red	Stop your vehicle as soon as it is safe to do so and switch off the ignition. Have the system checked by a properly trained technician as soon as possible.
Ford KeyFree switch ignition off press POWER	red	See Keyless starting (page 121).
Ford KeyFree key not inside car	red	See Keyless entry (page 41).
Ford KeyFree key inside vehicle	amber	Keyless system.
Steering malfunction service now	amber	Have the system checked by a properly trained technician.
Ford KeyFree Place key in key holder	-	See Keyless entry (page 41).
Ford KeyFree no key detected	-	See Keyless entry (page 41).

Information displays

Message	Message indicator	Action
Ford KeyFree press brake to start	-	See Keyless entry (page 41).
Ford KeyFree press clutch to start	-	See Keyless starting (page 121).
Ford KeyFree press brake and clutch	-	See Keyless starting (page 121).
Key battery low replace soon	-	See Changing the remote control battery (page 36).
Steering lock engaged turn steering wheel	-	See Steering wheel lock (page 119).

Lane keeping aid

Message	Indicator	Action
Lane keeping aid malfunction Service required	amber	The system has malfunctioned. Have this checked as soon as possible.

Lighting

Message	Message indicator	Action
Headlamp malfunction service required	amber	Have the system checked by a properly trained technician as soon as possible.
Brake lamp bulb fault	-	One or both of the brake lamp bulbs have blown. Check the brake lamp bulbs. See Changing a bulb (page 61).
Park lamp bulb fault	-	
Rear fog lamp bulb fault	-	One or both of the rear fog lamp bulbs have blown. Check the rear fog lamp bulbs. See Changing a bulb (page 61).
Dipped beam bulb fault	-	One or both of the headlamp dipped beam bulbs have blown. Check the headlamp dipped beam bulbs. See Changing a bulb (page 61).

Information displays

Message	Message indicator	Action
Trailer brake lamp bulb fault	-	One or both of the brake lamp bulbs on your trailer have blown. Check the brake lamp bulbs on your trailer.
Trailer turn lamp bulb fault	-	One or both of the direction indicator bulbs on your trailer have blown. Check the direction indicator bulbs on your trailer.

Low speed safety system

Message	Indicator	Action
LS Safety Sys Sensor blocked Clean screen	amber	See Using the low speed safety system (page 166).
Low Speed Safety System not available	amber	See Using the low speed safety system (page 166).
LS Safety Sys Auto braking	-	See Using the low speed safety system (page 166).

Maintenance

Message	Message indicator	Action
High engine temperature stop safely	red	Stop your vehicle as soon as it is safe to do so and switch off the ignition. Have the system checked by a properly trained technician as soon as possible.
Brake fluid level low service now	red	Check the brake fluid level. See Brake and clutch fluid check (page 194).
Brake system malfunction stop safely	red	Stop the vehicle as soon as safely possible. Have the system checked by a properly trained technician immediately.
Engine malfunction service now	red	Stop the vehicle as soon as safely possible and switch off the engine immediately. Have the system checked by a properly trained technician immediately.

Information displays

Message	Message indicator	Action
Water detected in fuel service required	amber	Have the system checked by a properly trained technician as soon as possible.
Engine malfunction service now	amber	Have the system checked by a properly trained technician as soon as possible.
Washer fluid level low	-	Check the washer fluid level. See Washer fluid check (page 194).
Engine oil change due	-	Service Indication

Occupant protection

Message	Indicator	Action
Service Beltminder	-	Have the system checked by a properly trained technician as soon as possible.

Parking aid

Message	Indicator	Action
Parking aid malfunction Service required	amber	Have the system checked by a properly trained technician as soon as possible.

Parking brake

Message	Indicator	Action
Park brake applied	red	See Parking brake (page 134).
Park brake applied	amber	See Parking brake (page 134).

Information displays

Power steering

Message	Message indicator	Action
Steering loss stop safely	red	Stop your vehicle as soon as it is safe to do so and switch off the ignition. Have the system checked by a properly trained technician as soon as possible.
Steering assist malfunction service required	amber	Power steering. Full steering will be maintained but you will need to exert greater force on the steering wheel. Have the system checked by a properly trained technician as soon as possible.
Steering malfunction service now	amber	Have the system checked by a properly trained technician.

Stability control (ESP)

Message	Indicator	Action
Traction control off	amber	See General information (page 82).

Starting the engine

Message	Message indicator	Action
Engine preheating	-	See Starting a diesel engine (page 121).
Drive to clean exhaust filter check handbook	Amber	See Diesel particulate filter (DPF) (page 123).
Cleaning exhaust filter	-	See Diesel particulate filter (DPF) (page 123).
Filter cleaning complete	-	See Diesel particulate filter (DPF) (page 123).
Exhaust filter full service now	Amber	See Diesel particulate filter (DPF) (page 123).
Engine malfunction service now	Amber	See Diesel particulate filter (DPF) (page 123).

Information displays

Start stop

Message	Message indicator	Action
Auto StartStop malfunction service required	amber	Have the system checked by a properly trained technician.
Auto StartStop Press clutch to start engine	-	The engine needs to be restarted, press the clutch pedal to start. See Using start-stop (page 124).
Auto StartStop Switch ignition off	red	Switch the ignition off before leaving the vehicle if the system has shut down the engine. See Using start-stop (page 124).
Auto StartStop Select neutral	-	Select neutral for the system to restart the engine. See Using start-stop (page 124).
Auto StartStop Manual Start required	-	The system is not functioning. A manual restart is required.

Transmission

Message	Message indicator	Action
Transmission too hot press brake	red	Under certain driving conditions it is possible that the clutches in the transmission can overheat. In these circumstances it is necessary to press the brake pedal and stop the vehicle to prevent further overheating. Select N (NEUTRAL) or P (PARK) and apply the foot brake and parking brake until the transmission has cooled and the message disappears from the display. If the vehicle is driven with this message active you may experience vehicle judder as a further over-heat warning.
Transmission malfunction service now	red	Have the system checked by a properly trained technician as soon as possible.

Information displays

Message	Message indicator	Action
Transmission over-heating stop safely	red	The transmission is too hot. In these extreme conditions the transmission will disengage drive in order to prevent damage due to overheating. You will not be able to drive until the transmission has cooled. Select N (NEUTRAL) or P (PARK) and apply the foot brake and parking brake until the transmission has cooled and the message disappears from the display.
Transmission too hot press brake	amber	Under certain driving conditions it is possible that the clutches in the transmission can overheat. In these circumstances it is necessary to press the brake pedal and stop the vehicle to prevent further overheating. Select N (NEUTRAL) or P (PARK) and apply the foot brake and parking brake until the transmission has cooled and the message disappears from the display. If the vehicle is driven with this message active you may experience vehicle judder as a further over-heat warning.
Transmission limited function check handbook	amber	Some gears may not be available. Have the system checked by a properly trained technician as soon as possible.
Transmission warming up please wait	-	At low outside temperatures, after starting the engine, it may take the transmission several seconds to engage R (REVERSE) or D (DRIVE) . Keep the brake pedal depressed until these messages disappear from the display.
Transmission not in Park select P	-	See Automatic transmission (page 131). See Starting the engine (page 119).
To start press brake pedal	-	See Automatic transmission (page 131). See Starting the engine (page 119).
Press brake pedal	-	See Automatic transmission (page 131).

Information displays

Tyre pressure monitoring system

Message	Message indicator	Action
Check tyre pressures	amber	The pressure in one or more tyres has dropped. Check as soon as possible.
Tyre pressure sys malfunction service required	amber	Permanent malfunction. Have your vehicle checked by a properly trained technician.

Climate control

PRINCIPLE OF OPERATION

Outside air

Keep the air intakes forward of the windscreen free from obstruction (snow, leaves etc.) to allow the climate control system to function effectively.

Recirculated air

CAUTION

⚠ Prolonged use of recirculated air may cause the windows to mist up. If the windows mist up, follow the settings for defrosting and demisting the windscreen.

The air currently in the passenger compartment will be recirculated. Outside air will not enter the vehicle.

Heating

Heating performance depends on the temperature of the engine coolant.

Air conditioning

Note: *The air conditioning operates only when the temperature is above 4°C (39°F).*

Note: *If you use the air conditioning, the fuel consumption of your vehicle will be higher.*

Air is directed through the evaporator where it is cooled. Humidity is extracted from the air to help keep the windows free of mist. The resulting condensation is directed to the outside of the vehicle and it is therefore normal if you see a small pool of water under your vehicle.

General information on controlling the interior climate

Fully close all the windows.

Warming the interior


Direct the air towards your feet. In cold or humid weather conditions, direct some of the air towards the windscreen and the door windows.

Cooling the interior

Direct the air towards your face.

AIR VENTS


Centre air vents



E132995

Climate control


Side air vent



E132996

MANUAL CLIMATE CONTROL

Air distribution control




E74660

- A Face level
- B Face level and footwell
- C Footwell
- D Footwell and windscreen
- E Windscreen

You can set the air distribution control to any position between the symbols.

Climate control

Blower



E75470

A Off

Note: If you switch the blower off, the windscreen may mist up.

Recirculated air



Press the button to toggle between outside air and recirculated air.

Heating the interior quickly



E129884

Ventilation



E129885

Set the air distribution control, blower and air vents to suit your requirements.

Air conditioning

Switching the air conditioning on and off



If you turn the blower off, the air conditioning will turn off. When you turn the blower on again, the air conditioning will come on automatically.

Cooling with outside air



E129886

Cooling the interior quickly



E129887

Climate control

With the heater control in this position, the air conditioning and recirculated air will switch on automatically.

You can switch the air conditioning and recirculated air on and off.

Defrosting and demisting the windscreen



E129888

When the temperature is above 4°C (39°F), the air conditioning will switch on automatically. Make sure that the blower is on. The indicator in the switch will illuminate during defrosting and demisting.

If you move the air distribution control to a position other than **E**, the **A/C** will remain on.

You can switch the air conditioning and recirculated air on and off while the air distribution control is set to position **E**.

If necessary, switch the heated windows on. See **Heated windows and mirrors** (page 108).

Reducing interior air humidity



E129889

AUTOMATIC CLIMATE CONTROL



E133114

The system controls the temperature, amount and distribution of the air flow automatically and adjusts them according to the driving and weather conditions. Pressing the **AUTO** button once switches on the auto mode.

The system in your vehicle is dual-zone automatic climate control. When the system is in mono mode, all the temperature zones are linked to the driver's zone. When you switch mono mode off, the dual-zone system allows you to set different temperatures for the driver's and front passenger's side.

Climate control

Note: Avoid adjusting the settings when the vehicle interior is extremely hot or cold. The automatic climate control adjusts to the current circumstances automatically. For the system to function properly, the side and centre vents should be fully open.

Note: The sunload sensor is located on top of the instrument panel. Do not cover the sensor with any objects.

Note: At low outside temperatures, when the system is in auto mode, the air stream will be directed to the windscreen and the side windows as long as the engine is cold.

Setting the temperature



E133115

You can set the temperature between 15.5°C (60°F) and 29.5°C (85°F) in steps of 0.5°C (1°F). In position **LO**, 15°C (59°F), the system will switch to permanent cooling. In position **HI**, 30°C (86°F), the system will switch to permanent heating.

Note: If either position **LO** or **HI** is selected, the system will not regulate a stable temperature.

Mono mode

In mono mode, the temperature settings for both the driver's and passenger's side are linked. If you adjust the temperature using the rotary control on the driver's side, the settings will be adjusted to the same setting on the passenger's side. In mono mode, **MONO** appears in the display.

To switch mono mode off

Select a temperature for the passenger's side with the rotary control on the passenger's side. Mono mode will switch off and **MONO** disappears from the display. The temperature for the driver's side will remain unchanged. You can now adjust the driver and passenger side temperatures independently of each other. The temperature settings for each side are shown in the display. You can set a temperature difference of up to 4°C (7°F).

Note: If you set a temperature difference of greater than 4°C (7°F), the temperature on the other side will be adjusted so that the difference remains 4°C (7°F).

Note: If you set one of the sides to **HI** or **LO**, both sides will be set to **HI** or **LO**.

To switch mono mode back on



To switch mono mode back on, press and hold the **AUTO** button. **MONO** reappears in the display and the passenger's side temperature will be adjusted to the driver's side temperature.

Blower



Climate control


Use the buttons to adjust the blower speed.

The blower setting is indicated in the display.

To return to auto mode, press the **AUTO** button.

Air distribution

To adjust air distribution, press the desired button. Any combination of settings can be selected simultaneously.



E70308

- A Footwell
- B Face level
- C Windscreen

When you select windscreen defrosting and demisting, **A**, **B** and **C** switch off automatically and the air conditioning switches on. Outside air will flow into the vehicle. You cannot select recirculated air.

Cooling the interior quickly



E133122

Windscreen defrosting and demisting



Press the windscreen defrosting and demisting button. Outside air will flow into the vehicle. Air conditioning is automatically selected. As long as the air distribution is set to this position, you cannot select recirculated air.

The blower speed and the temperature control operate automatically and cannot be adjusted manually. The blower is set to high speed and the temperature to **HI**.

When you select windscreen defrosting and demisting, the heated screens switch on automatically and switch off after a short time.

To return to auto mode, press the **AUTO** button.

Switching the air conditioning on and off



Press the **A/C** button to switch the air conditioning on and off. **A/C OFF** appears in the display when the air conditioning is switched off.

A/C ON appears in the display when the air conditioning is switched on.

Recirculated air



Press the recirculated air button to toggle between outside air and recirculated air.

Climate control

Note: When the system is in auto mode and the interior and exterior temperatures are quite hot, the system selects recirculated air automatically to maximise cooling of the interior. Once the selected temperature is reached, the system will reselect outside air automatically.

Switching off the automatic climate control



Press the button.

When switched off, the heating, ventilation and air conditioning system is switched off and recirculated air is selected.

HEATED WINDOWS AND MIRRORS

Heated windows

Use the heated windows to defrost or demist the windscreen or rear window.

Note: The heated windows operate only when the engine is running.

Heated windscreen



Heated rear window



Vehicles without auxiliary heater

If the ambient temperature is below 5°C (41°F) and the engine coolant is below 65°C (149°F), the heated windscreen and heated rear window will switch on automatically. They will switch off automatically after a short time.

Heated exterior mirrors

Electric exterior mirrors are fitted with a heating element that will defrost or demist the mirror glass. They will switch on automatically when you switch the heated rear window on.

AUXILIARY HEATER

Parking heater

WARNINGS



The parking heater must not be operated at filling stations, near sources of combustible vapours or dust or in enclosed spaces.



The parking heater should be switched on for approximately 10 minutes at least once a month all year round. This prevents the water pump and heater motor from seizing.

Note: The parking heater will only operate if there is at least 7.5 litres (1.6 gallons) of fuel in the fuel tank and the ambient temperature is below 15°C (59°F). The heater will not operate if the battery is low.

Note: The heating depends on the outside air temperature.

Note: When the parking heater is activated, exhaust fumes may come from under the sides of the vehicle. This is normal.

Climate control

Note: On vehicles with manual climate control the heating of the vehicle interior is dependent on the temperature, air distribution and blower control settings.

The parking heater operates independently of the vehicle heater by heating the engine's coolant circuit. It is fed from the vehicle fuel tank. You can also use it while the vehicle is in motion to help the vehicle heater warm up the interior more quickly.

Used properly, the parking heater provides the following benefits:

- It preheats the interior of the vehicle.
- It keeps the windows clear of ice in the event of frost and prevents condensation.
- It avoids cold starts and allows the engine to reach operating temperature sooner.

To prevent the battery from discharging:

- Once the parking heater has performed one heating cycle, the next programmed heating cycle will only be carried out if you have started the vehicle's engine in between.
- After a heating cycle, drive the vehicle for at least the period of the heating cycle.

Programming the parking heater


Note: The programmed time is the time at which you wish the vehicle to be warm and ready to drive, not the time at which the heater switches on.

Note: You must programme the times at least 70 minutes in advance of the time you wish to set.

Note: You must set the time and date correctly. See **Clock** (page 116).

To programme the heating times:

1. Use the arrow buttons on the steering wheel to enter the main menu. See **Information displays** (page 82).
2. Select the park heater option.



E74467

- The two time functions allow you to programme up to two heating cycles for each day of the week. These times will remain stored and the heater will warm up the vehicle at these times on these days every week.
- The function **once** allows you to programme one heating cycle for one specific day.
- The function **Heat now** automatically switches on the heater.

Climate control

Programming the functions Program 1 and Program 2

Program 1	
[07:55]	>
<input type="checkbox"/> Monday	
<input type="checkbox"/> Tuesday	
<input checked="" type="checkbox"/> Wednesday	
<input type="checkbox"/> Thursday	
<input type="checkbox"/> Friday	∨

E74468

1. Use the arrow buttons on the steering wheel to enter the main menu.
2. Select the first programme time list.
3. Highlight the day on which the heater should warm up the vehicle.
4. Press the **OK** button.
5. Continue in the same way to select all the days on which the heater should warm up the vehicle.
6. To set the time at which the vehicle should be warmed up, highlight the time at the top of the display and press the **OK** button. The hours start to flash.
7. Adjust the hours and minutes as necessary.


You can use the second programme time list to set a second cycle, for example different times on different days or twice on the same day. The programming procedure is the same as for the first programme timer..

Diesel auxiliary heater (depending on country)

The diesel auxiliary heater (PTC electrical heater) aids in warming the engine and the vehicle interior on vehicles with a diesel engine. It is switched on or off automatically depending on the outside air temperature, the coolant temperature and the alternator load.

Seats

SITTING IN THE CORRECT POSITION



E68595

WARNINGS



Do not adjust the seats when the vehicle is moving.



Only when you use the seat belt properly, can it hold you in a position that allows the airbag to achieve its optimum effect.

When you use them properly, the seat, head restraint, seat belt and airbags will provide optimum protection in the event of a collision. We recommend that you:


- sit in an upright position with the base of your spine as far back as possible.
- do not recline the seatback more than 30 degrees.
- adjust the head restraint so that the top of it is level with the top of your head and as far forwards as possible, remaining comfortable.
- keep sufficient distance between yourself and the steering wheel. We recommend a minimum of 250 millimetres (10 inches) between your breastbone and the airbag cover.

- hold the steering wheel with your arms slightly bent.
- bend your legs slightly so that you can press the pedals fully.
- position the shoulder strap of the seat belt over the centre of your shoulder and position the lap strap tightly across your hips.

Make sure that your driving position is comfortable and that you can maintain full control of your vehicle.

MANUAL SEATS

Moving the seats backwards and forwards




WARNING



Rock the seat backwards and forwards after releasing the lever to make sure that it is fully engaged in its catch.


Seats

Adjusting the lumbar support




E78058

Adjusting the height of the driver's seat



E70730

Adjusting the angle of the seatback






E130250

HEAD RESTRAINTS

Adjusting the head restraint

WARNINGS

-  Raise the rear head restraint when the rear seat is occupied by a passenger.
-  When using a forward facing child restraint on a rear seat, always remove the head restraint from that seat.



E66539




Adjust the head restraint so that the top of it is level with the top of your head.

Seats

Removing the head restraint

Press the locking buttons and remove the head restraint.

ELECTRIC SEATS



E78060

Seats

REAR SEATS

WARNINGS



When folding the seatbacks down, take care not to get your fingers caught between the seatback and seat frame.




Make sure that the seats and the seatbacks are secure and fully engaged in their catches.

Folding the rear seatbacks forwards

CAUTION



Lower the head restraints. See **Head restraints** (page 112).



E78819

1. Insert the seatbelt tongues into the retaining slots.



E78820

2. Press and hold the unlock buttons.
3. Push the seatback forwards.

Folding the seat cushions and the rear seatbacks forwards

WARNING



Make sure the red indicator is not showing when you engage the seat in the catches.

CAUTIONS




Lower the head restraints. See **Head restraints** (page 112).



When inserting your fingers between the seat cushion and seatback, take care not to get your fingers caught on the ISOFIX anchor points and bracket. See **ISOFIX anchor points** (page 28).

Seats



E78819

1. Insert the seatbelt tongues into the retaining slots.



E78821

2. Insert your fingers between the seat cushion and seatback and fold the seat cushion forwards.

Note: Hold the cushion edge to avoid the ISOFIX anchor points and brackets.

3. Press and hold the unlock buttons.
4. Push the seatback forwards.

Folding the seatbacks up

WARNING




When folding the seatbacks up, make sure that the belts are visible to an occupant and not caught behind the seat.

HEATED SEATS

CAUTION



Operating this function with the engine off will drain the battery.



E130471

The maximum temperature is reached after five or six minutes. It is regulated thermostatically.

The seat heating will operate only when the ignition is on.

Convenience features

INSTRUMENT LIGHTING DIMMER



E132712

Press repeatedly or press and hold until the desired level is reached.



Note: If the battery is disconnected, discharged, or a new battery is installed, the dimmer will set the illuminated components to the maximum setting automatically.

CLOCK


See **Information displays** (page 82).

CIGAR LIGHTER

CAUTIONS

-  If you use the socket when the engine is not running, the battery may discharge.
-  Do not hold the cigar lighter element pressed in.

Note: You can use the socket to power 12 volt appliances that have a maximum current rating of 10 Amperes. Use only Ford accessory connectors or connectors specified for use with SAE standard sockets.




E132415

Press the element in to use the cigar lighter. It will pop out automatically.

AUXILIARY POWER SOCKETS

CAUTION

-  If you use the socket when the engine is not running, the battery may discharge.

Note: You can use the socket to power 12 volt appliances that have a maximum current rating of 10 Amperes. Use only Ford accessory connectors or connectors specified for use with SAE standard sockets.

Convenience features



E78056

Auxiliary power sockets are located in the centre console and in the luggage compartment.

CUP HOLDERS

WARNING




Do not place hot drinks in the cup holders when the vehicle is moving.

Rear seat armrest




E132505

GLASSES HOLDER




E75193



E91508

Convenience features


AUXILIARY INPUT (AUX IN) SOCKET



E132422

See **Auxiliary input (AUX IN) socket** (page 254).

USB PORT




E132423

See **Connectivity** (page 276).

SATELLITE NAVIGATION UNIT HOLDER

Adjusting the holder




E112711

1. Unlock.
2. Adjust the holder to the desired position.
3. Lock.

Note: Make sure that the navigation unit holder is locked in position.

FLOOR MATS

WARNING

 When using the floor mats, always make sure the floor mat is properly secured using the appropriate fixings and positioned so that it does not interfere with the operation of the pedals.

Starting the engine

GENERAL INFORMATION

General points on starting

If the battery has been disconnected the vehicle may exhibit some unusual driving characteristics for approx. 8 kilometres (5 miles) after reconnecting the battery.

This is because the engine management system must realign itself with the engine. Any unusual driving characteristics during this period may be disregarded.

Starting the engine by towing or pushing

WARNING



To prevent damage you must not push or tow start your vehicle. Use booster cables and a booster battery. See **Using booster cables** (page 199).

IGNITION SWITCH

WARNING



Never return the key to position **O** or **I** when the vehicle is in motion.



E72128

O The ignition is off.

I The ignition and all main electrical circuits are disabled.

Note: Do not leave the ignition key in this position for too long to avoid discharging the battery.

II The ignition is switched on. All electrical circuits are operational. Warning lamps and indicators illuminate. This is the key position when driving. You must also select it when being towed.

III The starter motor is activated. Release the key as soon as the engine starts.

STEERING WHEEL LOCK

WARNING



Always check that the steering is unlocked before attempting to move your vehicle.

Vehicles without keyless starting

To activate the steering wheel lock;

1. Remove the key from the ignition switch.
2. Turn the steering wheel.

Vehicles with keyless starting

Note: The steering wheel lock will not activate when the ignition is on or the vehicle is moving.

Your vehicle has an electronically controlled steering wheel lock. This operates automatically.

The steering wheel lock will activate after a short period of time once you have parked your vehicle and the passive key is outside of the vehicle, or when you lock the vehicle. See **Keyless entry** (page 41).

Deactivating the steering wheel lock

Switch the ignition on, or:

Vehicles with automatic transmission

- Press the brake pedal.

Starting the engine

Vehicles with manual transmission

- Press the clutch pedal.

STARTING A PETROL ENGINE

Note: *You can only operate the starter for a maximum of 30 seconds at a time.*

Cold or hot engine

All vehicles

CAUTION



When the temperature is below -20°C (-4°F), switch the ignition on for at least one second before starting the engine. This will make sure that the maximum fuel pressure is established for starting the engine.

Vehicles with manual transmission

Note: *Do not touch the accelerator pedal.*

1. Fully depress the clutch pedal.
2. Start the engine.
3. If the engine does not start, fully depress the brake and clutch pedals.

Vehicles with automatic transmission

Note: *Do not touch the accelerator pedal.*

1. Select park or neutral.
2. Fully depress the brake pedal.
3. Start the engine.

All vehicles

If the engine does not start within 15 seconds, wait for a short period and try again.

If the engine does not start after **three** attempts, wait 10 seconds and follow the **Flooded engine** procedure.

If you have difficulty starting the engine when the temperature is below -25°C (-13°F), press the accelerator pedal between 1/4 to 1/2 of its travel and try again.

Flooded engine

Vehicles with manual transmission

1. Fully depress the clutch pedal.
2. Fully depress the accelerator pedal and hold it there.
3. Start the engine.

Vehicles with automatic transmission

1. Select park or neutral.
2. Fully depress the accelerator pedal and hold it there.
3. Fully depress the brake pedal.
4. Start the engine.

All vehicles

If the engine does not start, repeat the **Cold or hot engine** procedure.

Engine idle speed after starting

The speed at which the engine idles immediately after starting will vary depending on the engine temperature.

If the engine is cold then the idle speed will automatically be increased in order to heat the catalytic converter as quickly as possible. This ensures that vehicle emissions are kept to an absolute minimum.

The idle speed will slowly decrease to the normal level as the catalytic converter warms up.

Starting the engine

STARTING A DIESEL ENGINE

Cold or hot engine

All vehicles

Note: When the temperature is below -15°C (5°F), you may need to crank the engine for up to 25 seconds. If you consistently operate the vehicle in such temperatures, we recommend that you have an engine block heater fitted.

Note: Continue cranking the engine until it starts.

Note: You can only operate the starter for a maximum of 30 seconds at a time.



Switch the ignition on and wait until the glow plug indicator goes off.

Vehicles with manual transmission

Note: Do not touch the accelerator pedal.

1. Fully depress the clutch pedal.
2. Start the engine.
3. If the engine does not start, fully depress the brake and clutch pedals.

Vehicles with automatic transmission

1. Select park or neutral.
2. Fully depress the brake pedal.
3. Start the engine.

KEYLESS STARTING

WARNINGS



The keyless starting system may not function if the key is close to metal objects or electronic devices such as mobile phones.

WARNINGS



Always check that the steering wheel lock is deactivated before attempting to move your vehicle. See **Steering wheel lock** (page 119).

Note: A valid passive key must be located inside the vehicle to switch the ignition on and start the engine.

Note: To start your engine you must also fully depress the brake or clutch pedal, depending on the transmission fitted.



E85766

Ignition on

Press the start button once. All electrical circuits are operational, warning lamps and indicators illuminate.

Starting with automatic transmission

Note: Releasing the brake pedal during engine start will stop the engine cranking and return to ignition on.

1. Make sure the transmission is in **P** or **N**.
2. Fully depress the brake pedal.
3. Press the start button.

Starting with manual transmission

Note: Releasing the clutch pedal during engine start will stop the engine cranking and return to ignition on.

1. Fully depress the clutch pedal.

Starting the engine

2. Press the start button.

Starting a diesel engine

Note: *Engine cranking may not commence until the engine glow plug cycle has been completed. This may take several seconds in extremely cold conditions.*


Note: *Continue to press the clutch or brake pedal until engine cranking begins.*

Failure to start

The passive starting system will not function if:


- The passive key frequencies are jammed.
- The passive key battery is flat.

If you are unable to start your vehicle carry out the following procedure.



E87381

1. Carefully prise out the cover.



E85767

2. Insert the key into the key holder.
3. With the key in this position you can use the start button to switch the ignition on and start your vehicle.

Stopping the engine with the vehicle stationary

Note: *The ignition, all electrical circuits, warning lamps and indicators will be switched off.*

Manual transmission

Press the start button.

Automatic transmission

1. Move the selector lever to position **P**.
2. Press the start button.

Stopping the engine when the vehicle is moving

WARNING



Switching off the engine when the vehicle is still moving will result in a loss of brake and steering assistance. The steering will not be locked, but higher effort will be required. When the ignition is switched off some electrical circuits, warning lamps and indicators may also be OFF.

Starting the engine

Press and hold the start button for two seconds, or press two times within two seconds.

DIESEL PARTICULATE FILTER (DPF)

The DPF forms part of the emissions reduction systems fitted to your vehicle. It filters harmful diesel particulates (soot) from the exhaust gas.

Regeneration

WARNING



Do not park or idle your vehicle over dry leaves, dry grass or other combustible materials. The DPF regeneration process creates very high exhaust gas temperatures and the exhaust will radiate a considerable amount of heat during and after DPF regeneration, and after you have switched the engine off. This is a potential fire hazard.

CAUTION



Avoid running out of fuel.

Note: *After you have switched your engine off the fans may continue to run for a short period of time.*

Unlike a normal filter which requires periodic replacement, the DPF has been designed to regenerate, or clean itself to maintain operating efficiency. The regeneration process takes place automatically. However, some driving conditions mean that you may need to support the regeneration process.

If you drive only short distances or your journeys contain frequent stopping and starting, where there is increased acceleration and deceleration, occasional trips with the following conditions will assist the regeneration process:

- Drive your vehicle at a constant speed, preferably on a main road or motorway, for up to 20 minutes.
- Avoid prolonged idling and always observe speed limits and road conditions.
- Do not switch off the ignition.
- Use a lower gear than normal to maintain a higher engine speed during this journey, where appropriate.

SWITCHING OFF THE ENGINE

Vehicles with a turbocharger

CAUTION



Do not switch the engine off when it is running at high speed. If you do, the turbocharger will continue running after the engine oil pressure has dropped to zero. This will lead to premature turbocharger bearing wear.

Release the accelerator pedal. Wait until the engine has reached idle speed and then switch it off.

Start-stop

PRINCIPLE OF OPERATION

CAUTION



For vehicles with Start-stop the battery requirement is different. It must be replaced by one of exactly the same specification as the original.

The system reduces fuel consumption and CO₂ emissions by shutting down the engine when the vehicle is idling, for example at traffic lights. The engine will automatically restart when the driver presses the clutch pedal or when required by a vehicle system, for example to recharge the battery.

To obtain maximum benefit from the system, move the gear lever to the neutral position and release the clutch pedal during any stop of longer than 2 seconds.

USING START-STOP

WARNINGS



The engine may restart automatically if required by the system. See **Principle of operation** (page 124).



Switch the ignition off before opening the bonnet or carrying out any maintenance.



Always switch the ignition off before leaving your vehicle, as the system may have shut down the engine but the ignition will still be live.

Note: The system only operates when the engine is warm and the outside temperature is between 0°C (32°F) and 30°C (86°F).

Note: The system is on by default. To switch the system off, press the switch in the instrument panel. The system will only be de-activated for the current ignition cycle. To turn it on, press the switch again. For item location. See **Quick start** (page 10).

Note: The Start-stop indicator will illuminate green when the engine shuts down. See **Warning lamps and indicators** (page 78).

Note: The Start-stop indicator will flash amber, requiring you to select neutral or depress the clutch pedal. In conjunction a message will be shown in the display.

Note: If the system detects a malfunction, it is deactivated. Have the system checked by a properly trained technician.

Note: If you have switched the system off, the switch will be illuminated.

Note: If you stall the engine, and then depress the clutch pedal within a couple of seconds, the system will automatically restart the engine.

To stop the engine

Note: The vehicle must be stationary.

Note: If the system does not shut down the engine the condition will be shown in the information display. See **Information messages** (page 90).

1. Stop the vehicle.
2. Move the gear lever to the neutral position.
3. Release the clutch pedal.
4. Release the accelerator pedal.

The system may not shut down the engine under certain conditions, for example:

- To maintain the interior climate.
- Low battery voltage.

Start-stop

- The outside temperature is too low or too high.
- The driver's door has been opened.
- Low engine operating temperature.
- Low brake system vacuum.
- If a road speed of 10 kph (6 mph) has not been exceeded.

To re-start the engine

Note: *The gear lever must be in the neutral position.*

Depress the clutch pedal.

The system may automatically restart the engine under certain conditions, for example:

- Low battery voltage.
- To maintain the interior climate.

Eco mode

PRINCIPLE OF OPERATION


The system assists the driver to drive more efficiently by constantly monitoring characteristics of gear changing, anticipation of traffic conditions and speeds on motorways and open roads.

Note: *These efficiency values do not result in a defined fuel consumption figure. It might vary as it is not only related to these driving disciplines but also influenced by many other factors such as short journeys and cold starts.*

Note: *Frequent short journeys, where the engine does not fully warm up, will also increase fuel consumption.*

The value of these characteristics is represented by petals shown in the display, with five petals being the most efficient. The more efficiently you drive, the better the rating, and the better your overall fuel consumption.

Type 1



E121813

- A Gear shifting
- B Anticipation
- C Efficient speed

Gear shifting

Using the highest drivable gear appropriate for the road conditions will improve fuel consumption.

Anticipation

Adjusting your vehicle speed and the distance to other vehicles without the need for heavy braking or acceleration will improve fuel consumption.

Efficient speed

Higher speeds use more fuel. Reducing your cruising speed on open roads will improve fuel consumption.

Type 2 and 3

The relevant information will be shown in the display.

USING ECO MODE

The system is accessed using the relevant information display menu. See **Information displays** (page 82).

Resetting Eco mode

Reset the average fuel consumption.

Note: *New values may take a short time to calculate.*

Fuel and refuelling

SAFETY PRECAUTIONS

WARNINGS



Stop refuelling after the fuel nozzle stops the second time. Additional fuel will fill the expansion space in the fuel tank which could lead to fuel overflowing. Fuel spillage could be hazardous to other road users.



Do not use any kind of flames or heat near the fuel system. The fuel system is under pressure. There is a risk of injury if the fuel system is leaking.

FUEL QUALITY - PETROL

CAUTION



Do not use leaded petrol or petrol with additives containing other metallic compounds (e.g. manganese-based). They could damage the emission system.

Note: We recommend that you use only high quality fuel without additives or other engine treatments.

Use **minimum 95 octane unleaded** petrol that meets the specification defined by **EN 228**, or equivalent.

FUEL QUALITY - DIESEL

WARNING



Do not mix diesel with oil, petrol or other liquids. This could cause a chemical reaction.

CAUTIONS



Do not add kerosene, paraffin or petrol to diesel. This could cause damage to the fuel system.

CAUTIONS



Use diesel that meets the specification defined by **EN 590**, or the relevant national specification.

Note: We recommend that you use only high quality fuel.

Note: The use of additives or other engine treatments not approved by Ford is not recommended.

Note: We do not recommend the prolonged use of additives intended to prevent fuel waxing.

Long-term storage

Most diesel fuels contain bio-diesel, it is recommended to fill the tank with purely mineral diesel (where available) or add an anti-oxidant prior to long-term storage of your vehicle exceeding two months. Your dealer can help you with a suitable anti-oxidant.

CATALYTIC CONVERTER

WARNING



Do not park or idle your vehicle over dry leaves, dry grass or other combustible materials. The exhaust will radiate a considerable amount of heat during use, and after you have switched the engine off. This is a potential fire hazard.

Driving with a catalytic converter

CAUTIONS



Avoid running out of fuel.



Do not crank the engine for long periods.

Fuel and refuelling

CAUTIONS

- ⚠ Do not run the engine when a spark plug lead is disconnected.
- ⚠ Do not push-start or tow-start your vehicle. Use booster cables. See **Using booster cables** (page 199).
- ⚠ Do not switch the ignition off when driving.


FUEL FILLER FLAP

WARNINGS

- ⚠ Take care when refuelling to avoid spilling any residual fuel from the fuel nozzle.
- ⚠ Do not use any kind of flames or heat near the fuel system. The fuel system is under pressure. There is a risk of injury if the fuel system is leaking.

CAUTION

- ⚠ If you use a high pressure spray to wash your vehicle, only spray the fuel filler flap briefly from a distance not less than 20 centimetres (8 inches).




E86613

Press the flap to open it. Open the flap fully until it engages.

When you insert the fuel nozzle, a spring loaded inhibitor will open if the correct size nozzle is detected. This helps to avoid filling up with the wrong fuel.

WARNING

- ⚠ Stop refuelling after the fuel nozzle stops the second time. Additional fuel will fill the expansion space in the fuel tank which could lead to fuel overflowing. Fuel spillage could be hazardous to other road users.




E119080

Insert the fuel nozzle up to and including the first notch on the nozzle. Keep it resting on the cover of the fuel pipe opening.

WARNING

- ⚠ We recommend that you wait at least 10 seconds before slowly removing the fuel nozzle to allow any residual fuel to drain into the fuel tank.

Fuel and refuelling




E119081

Slightly raise the fuel nozzle to remove it.
A funnel is located in the glove box. Use this when refilling with a fuel can.

REFUELLING

CAUTION

 Do not attempt to start the engine if you have filled the fuel tank with the incorrect fuel. This could damage the engine. Have the system checked by a properly trained technician immediately.

TECHNICAL SPECIFICATIONS

Focus

Fuel consumption figures

Variant	Urban	Extra-urban	Combined	CO ₂ emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
1.6L Duratec- 16V Ti- VCT (Sigma) Stage V, 5-door	8 (35.3)	4.7 (60.1)	5.9 (47.9)	136
1.6L Duratec- 16V Ti- VCT (Sigma) Stage V, 4-door	8.1 (34.9)	4.8 (58.9)	6 (47.1)	139
1.6L EcoBoost SCTi (Sigma) without start-stop	8.3 (34)	5 (56.5)	6.2 (45.6)	144

FUEL CONSUMPTION

The CO₂ and fuel consumption figures are derived from laboratory tests according to EEC Directive 80/1268/EEC and subsequent amendments and are carried out by all vehicle manufacturers.

They are intended as a comparison between makes and models of vehicles. They are not intended to represent the real world fuel consumption you may get from your vehicle. Real world fuel consumption is governed by many factors including; driving style, high speed driving, stop/start driving, air conditioning usage, the accessories fitted and towing etc.

Your Ford dealer can give you advice on improving your fuel consumption.

Fuel and refuelling

Variant	Urban	Extra-urban	Combined	CO2 emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
1.6L EcoBoost SCTi (Sigma) with start-stop	7.7 (36.7)	5 (56.5)	6 (47.1)	139
1.6L Duratorq- TDCi (DV) Diesel Stage V without start-stop	5.7 (49.6)	3.7 (76.3)	4.5 (62.8)	117
1.6L Duratorq- TDCi (DV) Diesel Stage V with start-stop	5.1 (55.4)	3.7 (76.3)	4.2 (67.3)	109
2.0L Duratorq- TDCi (DW) Diesel Stage V, manual transmission	6.3 (44.8)	4.2 (67.3)	5 (56.5)	129
2.0L Duratorq- TDCi (DW) Diesel Stage V, automatic transmission	6.8 (41.5)	4.4 (64.2)	5.3 (53.3)	139


Transmission

MANUAL TRANSMISSION

Selecting reverse gear

CAUTION

- ⚠ Do not engage reverse gear when the vehicle is moving. This can cause damage to the transmission.



E99067

On some vehicles it is necessary to raise the collar whilst selecting reverse gear.

Vehicles with 5-speed transmission

CAUTION

- ⚠ Fully depress the clutch pedal and wait for three seconds before you select reverse gear.

AUTOMATIC TRANSMISSION

Selector lever positions



E133124

- P Park
- R Reverse
- N Neutral
- D Drive
- S Sport mode and manual shifting
- + Manual shift up
- Manual shift down

WARNING

- ⚠ Apply the brakes before moving the selector lever and keep them applied until you are ready to move off.

Press the button on the selector lever to change to each position.

The selector lever position will be shown in the information display.

Park

WARNINGS

- ⚠ Select park only when your vehicle is stationary.

Transmission

WARNINGS



Apply the parking brake and select park before leaving your vehicle. Make sure that the selector lever is latched in position.

The selector lever is latched in position.

Note: An audible warning will sound if you open the driver's door and you have not selected park.

In this position, power is not transmitted to the drive wheels and the transmission is locked. You can start the engine with the selector lever in this position.

Reverse

WARNINGS



Select reverse only when your vehicle is stationary and the engine is at idle speed.



Always come to a complete stop before shifting out of reverse.

Select reverse to allow the vehicle to move backwards.

Neutral

In this position, power is not transmitted to the drive wheels but the transmission is not locked. You can start the engine with the selector lever in this position.

Drive

Note: A shift will occur only when the vehicle speed and the engine speed are appropriate.

Note: You may temporarily override the current gear selected using the + and - buttons.

Select drive to shift automatically through the forward gears.

The transmission will select the appropriate gear for optimum performance based on ambient temperature, road gradient, vehicle load and driver input.

Sport mode and manual shifting

Sport Mode

Note: In **Sport** mode the transmission operates as normal but gears are selected more quickly and at higher engine speeds.

Note: In **Sport** mode **S** will be displayed on the instrument panel.

Activate **Sport** mode by moving the selector lever to position **S**. **Sport** mode will remain active until either you shift manually up or down the gears using + and -, or return the selector lever to position **D**.

Manual shifting

WARNING



Do not hold the buttons permanently in - or +.

CAUTION



The transmission will automatically downshift when the engine speed is too low.

Press the - button to shift down and press the + button to shift up.

Gears may be skipped by pressing the buttons repeatedly at short intervals.

Manual mode also provides a kickdown function. See **Kickdown**.

Transmission

Hints on driving with an automatic transmission

CAUTION

- ! Do not idle the engine for long periods of time in drive with the brakes applied.

Moving off

1. Release the parking brake.
2. Release the brake pedal and press the accelerator pedal.

Stopping


1. Release the accelerator pedal and press the brake pedal.
2. Apply the parking brake.
3. Select neutral or park.

Kickdown


Press the accelerator pedal fully with the selector lever in the drive position to select the next lowest gear for optimum performance. Release the accelerator pedal when you no longer require kickdown.

Emergency park position release lever

Use the lever to move the selector lever from the park position in the event of an electrical malfunction or if your vehicle has a flat battery.



1. Carefully remove the cover.
2. Remove the retaining clip.
3. Remove the centre console side panel.



Note: *The lever is white.*

4. Apply the brake pedal. Using a suitable tool press and hold the lever forward while pulling the selector lever out of the park position and into the neutral position.

Brakes

PRINCIPLE OF OPERATION

Note: Depending on applicable laws and regulations in the country for which your vehicle was originally built, the brake lamps may flash if you brake heavily.

Disc brakes

Wet brake discs result in reduced braking efficiency. Dab the brake pedal when driving from a car wash to remove the film of water.

ABS

WARNING



The ABS does not relieve you of your responsibility to drive with due care and attention.

The ABS helps you to maintain full steering and directional stability when you brake heavily in an emergency, by preventing the road wheels from locking.

HINTS ON DRIVING WITH ABS

When the ABS is operating, the brake pedal will pulse. This is normal. Maintain pressure on the brake pedal.

The ABS will not eliminate the dangers inherent when:

- you drive too close to the vehicle in front of you.
- the vehicle is aquaplaning.
- you take corners too fast.
- the road surface is poor.

PARKING BRAKE

All vehicles

WARNING



Vehicles with an automatic transmission should always be left with the selector lever in position **P**.

- Press the foot brake pedal firmly.
- Pull the parking brake lever up smartly to its fullest extent.
- Do not press the release button while pulling the lever up.
- If your vehicle is parked on a hill and facing uphill, select first gear and turn the steering wheel away from the kerb.
- If your vehicle is parked on a hill and facing downhill, select reverse gear and turn the steering wheel towards the kerb.

To release the parking brake, press the brake pedal firmly, pull the lever up slightly, depress the release button and push the lever down.

Stability control


PRINCIPLE OF OPERATION

Electronic stability programme (ESP)

WARNING



ESP does not relieve you of your responsibility to drive with due care and attention.



E72903

- A without ESP
- B with ESP

The ESP supports stability when the vehicle starts to slide away from your intended path. This is performed by braking individual wheels and reducing engine torque as needed.

The system also provides an enhanced traction control function by reducing engine torque if the wheels spin when you accelerate. This improves your ability to pull away on slippery roads or loose surfaces, and improves comfort by limiting wheel spin in hairpin bends.

Stability control (ESP) warning lamp

The ESP warning lamp will flash when the system is operating. See **Warning lamps and indicators** (page 78).

Emergency brake assist

WARNING



Emergency brake assist does not relieve you of your responsibility to drive with due care and attention.

Emergency brake assist will detect when you brake heavily by measuring the rate at which you press the brake pedal. It will provide maximum braking efficiency as long as you press the pedal. Emergency brake assist can reduce stopping distances in critical situations.

Trailer stability control

WARNINGS



Trailer stability control does not relieve you of your responsibility to tow with due care and attention.



Disabling ESP will turn off the system.

Trailer stability control is an enhanced feature of ESP, and automatically detects when an attached trailer starts to sway.

If this situation occurs, the system will automatically brake individual wheels to stabilise the trailer and vehicle. In case a very severe sway is detected, the engine torque will be reduced and the vehicle will be slowed automatically.

USING STABILITY CONTROL

Note: The system will be switched on automatically every time you switch the ignition on.

Stability control

To turn the system off and on. See **Information displays** (page 82).

Hill start assist

PRINCIPLE OF OPERATION

The system makes it easier to pull away when the vehicle is on a slope without the need to use the parking brake.

When the system is active, the vehicle will remain stationary on the slope for a short time after you release the brake pedal. During this time, you have time to move your foot from the brake to the accelerator pedal and pull away. The brakes are released automatically once the engine has developed sufficient drive to prevent the vehicle from rolling down the slope. This is an advantage when pulling away on a slope, for example from a car park ramp, traffic lights or when reversing uphill into a parking space.

WARNING



The system does not replace the parking brake. When you leave the vehicle, always apply the parking brake and select first or reverse gear.

USING HILL START ASSIST

The system is activated automatically when you stop your vehicle on a slope greater than 3%. The system operates with the vehicle facing downhill if reverse gear is selected and with the vehicle facing uphill if any forward gear is selected.

Vehicles with manual transmission only

The system can be switched on and off using the information display. See **General information** (page 82).

Activating the system

WARNINGS



You must remain in the vehicle once you have activated the system.

WARNINGS



At all times you are responsible for controlling the vehicle, supervising the system and intervening, if required.



If a malfunction is detected when the system is active, the system will be deactivated and a message will be shown in the display. See **Information messages** (page 90).

You can activate the system only if the following conditions have been met:

- The engine is running.
- The system is switched on.
- On vehicles with manual transmission, the clutch pedal is pressed.
- No failure mode is present.

To activate the system:

1. Press the brake pedal to bring the vehicle to a complete standstill. Keep the brake pedal depressed.
2. If the sensors detect that the vehicle is on a slope the system will be activated automatically.
3. When you remove your foot from the brake pedal, the vehicle will remain on the slope without rolling away for a short time. This hold time will automatically be extended if you are in the process of driving off.
4. Drive off in the normal manner. The brakes will be released automatically.

Deactivating the system

To deactivate the system, perform **one** of the following:

Hill start assist

- Wait for a short time until the system deactivates automatically.
- If a forward gear was selected when the system became active, select reverse gear.
- If reverse gear was selected when the system became active, select a forward gear.

Parking aid

PRINCIPLE OF OPERATION

WARNING



The parking aid does not relieve you of your responsibility to drive with due care and attention.

CAUTIONS



Vehicles fitted with a trailer tow module not approved by us may not correctly detect obstacles.



The sensors may not detect objects in heavy rain or other conditions that cause disruptive reflections.



The sensors may not detect objects with surfaces that absorb ultrasonic waves.



The parking aid does not detect obstacles moving away from the vehicle. They will only be detected shortly after they start to move towards the vehicle again.



If you use a high pressure spray to wash your vehicle, only spray the sensors briefly from a distance not less than 20 centimetres (8 inches).



Parking aid sends tones via the audio system fitted and approved by us. If this is not working the parking aid system will not work.

Note: On vehicles fitted with a tow ball arm, the rear parking aid is deactivated automatically when any trailer lamps (or lighting boards) are connected to the 13-pin socket via a trailer tow module we have approved.

Note: Keep the sensors free from dirt, ice and snow. Do not clean with sharp objects.

Note: The parking aid may emit false tones if it detects a signal using the same frequency as the sensors or if the vehicle is fully laden.


Note: The outer sensors may detect the side walls of a garage. If the distance between the outer sensor and the side wall remains constant for three seconds, the tone will switch off. As you continue, the inner sensors will detect rearward objects.

USING THE PARKING AID - VEHICLES WITH: REAR PARKING AID

WARNING



The parking aid does not relieve you of your responsibility to drive with due care and attention.




E77927

The parking aid is automatically activated when you select reverse gear with the ignition switched on.

You will hear an intermittent tone at a distance of approximately 150 centimetres (59 inches) between the obstacle and rear bumper and approximately 50 centimetres (20 inches) to the side. Decreasing the distance accelerates the intermittent tone.

Parking aid



E130178

A Distance Indicator.

As the distance decreases the indicator moves towards the vehicle.

A continuous tone will start at a distance of less than 30 centimetres (11 inches) to the rear bumper.

Note: *On Vehicles with a tow bar fitted and approved by us the continuous tone will start at a distance of 45 centimetres (18 inches) from the rear bumper.*



E130179

A Malfunction indicator.

Note: *If a malfunction is indicated the system will be disabled. Have the system checked by a properly trained technician.*



E130180

A trailer symbol indicates there is a trailer attached and the system is disabled.

USING THE PARKING AID - VEHICLES WITH: FRONT AND REAR PARKING AID

WARNING



The parking aid does not relieve you of your responsibility to drive with due care and attention.

Switching the parking aid on and off


The parking aid is per default off. To switch the parking aid on, select reverse gear or press the switch in the instrument panel. For item location: See **Quick start** (page 10).

The light in the switch illuminates when the parking aid is activated.

To turn it off, press the switch again.

Parking aid

Manoeuvring with the parking aid




E130381

- 1 Reverse gear selected
- 2 Neutral or forward gear selected
- A Display and tone
- B Display and tone
- C Display only
- D Display and tone

You will hear an intermittent tone at a distance of approximately 150 centimetres (59 inches) between the obstacle and rear bumper, approximately 80 centimetres (31 inches) between the obstacle and front bumper and approximately 50 centimetres (20 inches) to the side. Decreasing the distance accelerates the intermittent tone. A continuous tone will start at a distance of less than 30 centimetres (11 inches) to the front or rear bumper.

Note: On vehicles with a tow bar fitted and approved by us the continuous tone will start at a distance of 45 centimetres (18 inches) from the rear bumper.


You will hear an alternating tone from the front and rear if obstacles are closer than 30 centimetres (11 inches) to the front and rear bumpers.



E130382

- A Distance Indicator.

As the distance decreases the indicator moves towards the vehicle.



E130383

- A Malfunction indicator.

Note: If a malfunction is indicated the system will be disabled. Have the system checked by a properly trained technician.

Parking aid



E130180

A trailer symbol indicates there is a trailer attached and the rear sensors are disabled.

Active park assist

PRINCIPLE OF OPERATION

WARNINGS



Active park assist does not relieve you of your responsibility to drive with due care and attention.



You must observe that the selected space remains clear of obstructions at all times in the manoeuvre.



Vehicles with overhanging loads, street furniture and other items may not be detected by active park assist. You must ensure the selected space is suitable for parking.



Do not use active park assist if a trailer is attached to the vehicle.



Do not use active park assist if a bike rack is attached to the back of the vehicle.



Do not use active park assist if an over hanging item is attached to the roof.



If the manoeuvre is interrupted before completion, active park assist will be cancelled. The steering wheel position will not indicate the true position of the steering and you will have to take control of the vehicle.



Ensure loose clothing, your hands or your arms do not get caught in the rotating steering wheel.

Active park assist detects a suitable parallel parking space and steers the vehicle into the space. The system controls the steering while the driver controls the accelerator, transmission and brakes. The manoeuvre can be stopped by holding the steering wheel or pressing the active park assist control switch.

Active park assist will visually and audibly instruct the driver throughout the procedure to safely park the vehicle.

USING ACTIVE PARK ASSIST

CAUTIONS



The sensors may not detect objects in heavy rain or other conditions that cause disruptive reflections.



The sensors may not detect objects with surfaces that absorb ultrasonic waves.



The sensors may not detect the kerb.

Note: *If the traction control system is disabled active park assist will not be available. See **General information** (page 82).*


Active park assist will not align the vehicle correctly if:

- a spare tyre, or a tyre worn significantly more than the other tyres is used
- the factory installed tyre size is not used on the vehicle
- the tyres skid
- you allow the vehicle to roll
- the weather conditions are poor (heavy rain, snow, fog, etc).

Move forwards at a maximum speed of 30 kph (18 mph). Press the active park assist control switch. See **Quick start** (page 10). Use the direction indicator lever to select searching either to the left-hand side or right-hand side of the vehicle.

Note: *If no selection is made via the direction indicator lever active park assist will default to the passenger side of the vehicle.*

Active park assist




E130107

Note: To disable the chimes: See **Personalised settings** (page 89).

The information and entertainment display will inform you and a chime will be heard when a suitable space is found. To park the vehicle, follow the instructions on the information and entertainment display.

Note: The arrow symbols or graphics in the display indicate on which side of the vehicle the system will park. The display will also advise you when to select reverse gear.

Drive slowly to position **A**, then follow the system instructions.



E130108

WARNING




If a speed of 10 km/h (6 mph) is exceeded the system will be disabled and you will need to take full control of the vehicle.

Move the vehicle backwards cautiously using the accelerator and brake pedals to control the vehicle. Parking aid warning tones will sound. Stop the vehicle when you hear a continuous tone.

You can take control of the manoeuvre by holding the steering wheel. A message may appear that active park assist can be resumed. To accept this message press the active park assist switch. See **Quick start** (page 10).

Active park assist



E130109

Move the vehicle forwards. Stop the vehicle when you hear a continuous tone.

Repeat the above steps until the vehicle is satisfactory parked. The message centre will indicate when active park assist has finished the manoeuvre.

Rear view camera

PRINCIPLE OF OPERATION

The camera is a visual aid for use when reversing.

WARNING



The camera does not relieve you of your responsibility to drive with due care and attention.

CAUTIONS



If you use a high pressure spray to wash your vehicle, only spray the camera briefly from a distance not less than 20 centimetres (8 inches).



Do not apply pressure to the camera.

Note: *Keep the camera free from dirt, ice and snow. Do not clean with sharp objects, degreaser, wax or organic products. Use only a soft cloth.*

During operation, guide lines appear in the display which represent your vehicle's path and approximate distance from rearward objects.

USING THE REAR VIEW CAMERA

WARNINGS



The operation of the camera may vary depending on the ambient temperature, vehicle and road conditions.



The distances shown in the display may differ from the actual distance.



Do not place objects in front of the camera.

The camera is located on the luggage compartment lid near the handle.



E99105

Activating the rear view camera

CAUTION



The camera may not detect objects that are close to the vehicle.

With the ignition and the audio unit switched on:

1. Press the parking aid switch in the instrument panel. For item location: See **Quick start** (page 10). Or,
2. Engage reverse gear.

The image is displayed on the screen.

The lamp in the switch illuminates when the system is activated.

The camera may not operate correctly in the following conditions:

- Dark areas.
- Intense light.
- If the ambient temperature increases or decreases rapidly.
- If the camera is wet, for example in rain or high humidity.
- If the camera's view is obstructed, for example by mud.


Rear view camera

Using the display

CAUTIONS

- ⚠ Obstacles above the camera position will not be shown. Inspect the area behind your vehicle if necessary.
- ⚠ Marks are for general guidance only, and are calculated for vehicles in maximum load conditions on an even road surface.

The lines show a projected vehicle path (based on the current steering wheel angle) and the distance from the exterior mirrors and rear bumper.



E99458

- A Exterior mirror clearance - 0.1 metre (4 inches)
- B Red - 0.3 metre (12 inches)
- C Yellow - 0.6 metre (24 inches)
- D Green - 0.9 to 3.2 metres (35 to 126 inches)

Rear view camera

Note: *When reversing with a trailer, the lines on the screen are not shown.*

Deactivating the rear view camera

Note: *Disengage reverse gear. The display will stay on for a short period before switching off.*

Note: *The system will automatically switch off once the vehicle speed has reached approximately 15 km/h (9 mph).*

Press the parking aid switch in the instrument panel. For item location: See

Quick start (page 10).

Vehicles with parking aid

The display will additionally show a coloured distance bar. This guide indicates the distance from the rear bumper to the detected obstacle.

These are colour coded as follows:

- Green - 0.6 to 1.8 metres (24 to 71 inches).
- Yellow - 0.3 to 0.6 metre (12 to 24 inches).
- Red - 0.3 metre (12 inches) or less.

Cruise control

PRINCIPLE OF OPERATION

Cruise control allows you to control your speed using the switches on the steering wheel. You can use cruise control when you exceed approximately 30 km/h (20 mph).

USING CRUISE CONTROL

WARNING



Do not use cruise control in heavy traffic, on twisty roads or when the road surface is slippery.

Switching cruise control on



E130072

Note: The system is ready for you to set a speed.

Setting a speed

Press the **SET+** switch or the **SET-** switch to store and maintain your current speed. The cruise control indicator will illuminate. See **Warning lamps and indicators** (page 78).


Changing the set speed

WARNING



When you are going downhill, your speed may increase above the set speed. The system will not apply the brakes. Change down a gear and press the **SET-** switch to assist the system in maintaining the set speed.

Note: If you accelerate by pressing the accelerator pedal, the set speed will not change. When you release the accelerator pedal, you will return to the speed that you previously set.



E130073

- A Accelerate
- B Decelerate

Cancelling the set speed

Press the brake pedal or the **CAN** switch.

Note: The system will no longer control your speed. The cruise control indicator will not illuminate but the system will retain the speed that you previously set.

Resuming the set speed

Press the **RES** switch.

Cruise control

The cruise control indicator will illuminate and the system will attempt to resume the speed that you previously set.

Switching cruise control off



E130072

The system will not retain the speed that you previously set. The cruise control indicator will not illuminate.

Adaptive cruise control (ACC)

PRINCIPLE OF OPERATION

WARNINGS



The system is not a collision warning or avoidance system. The separate forward alert function provides a collision warning and mitigation feature. See **Forward alert function** (page 155). You must intervene if the system does not detect a vehicle in front.



When driving you are responsible for maintaining the correct distance and speed, even when adaptive cruise control is used. You must always pay attention to the traffic conditions and intervene when adaptive cruise control is not maintaining a suitable speed or suitable distance.



The system does not relieve you of your responsibility to drive with due care and attention.



The system does not brake for slow or stationary vehicles, pedestrians, objects in the road, oncoming and crossing vehicles.

Note: When adaptive cruise control is activated, you may hear some unusual sounds during automatic braking. This is normal and caused by the automatic braking system.

Note: Keep the front of the vehicle free from dirt, metal badges or objects, including vehicle front protectors and additional lights which may prevent the sensor from operating.

The system is designed to help you maintain a gap from the vehicle ahead or a set road speed if there is no slower vehicle ahead. The system is intended to provide enhanced operation of the vehicle when following other vehicles which are in the same lane and travelling in the same direction.

The system is based on the use of a radar sensor which projects a beam directly forward of the vehicle. This beam will detect any vehicle ahead within the system's range.

The radar sensor is mounted behind the front grille.

CAUTIONS



Only use adaptive cruise control when conditions are favourable, for example on motorways and main roads with steady free flowing traffic.



Do not use in poor visibility, specifically fog, heavy rain, spray or snow.



Do not use on icy or slippery roads.



Do not use the system when entering or leaving a motorway.




The radar sensor has a limited field of vision. In some situations it may detect a vehicle other than the one expected or not detect any vehicle at all.


Adaptive cruise control (ACC)

Detection beam issues


A



B



C



E71621

Detection issues can occur:

- With vehicles that edge into your lane that can only be detected once they have moved fully into your lane (**A**). Motorcycles may be detected late, or not at all. (**B**)
- With vehicles in front when going into and coming out of a bend (**C**). The detection beam will not follow sharp curves in the road.

In these cases the system may brake late or unexpectedly. You should stay alert and intervene if necessary.

Automatic braking with ACC

WARNINGS



You must take immediate action once alerted, as the adaptive cruise control braking will not be sufficient to keep a safe distance to the vehicle in front.



In some cases there may be no warning or the warning may be delayed. You should always apply the brakes when necessary.




When following a vehicle in front of you, adaptive cruise control will not automatically decelerate to a stop.

The system will automatically brake for you, if required to maintain the set gap between your vehicle and the one detected in front. This braking capacity is limited to approximately 30% of the total manual braking capacity to ensure smooth and comfortable cruising. If the car needs to brake more heavily than this, and you do not intervene by braking manually, an alarm will sound and a warning symbol will be displayed in the cluster.

Adaptive cruise control (ACC)

USING ACC

The system is operated by adjustment controls mounted on the steering wheel.



E133195

- A Set speed increase
- B Speed limiter on/off
- C Set speed decrease
- D ACC on/off
- E ACC gap increase
- F ACC gap decrease
- G ACC cancel/resume

Switching the system on

Press switch **D**. The system is set to standby mode.

Setting a speed

Note: The system must be in standby mode.

Press switch **A** or switch **C** to select your desired cruise speed. The speed is displayed in the information display and stored as the set speed.

Changing the set speed

Note: Vehicle speed may be increased and decreased at intervals of 5 km/h or 5 mph.

Note: If the system does not react to these changes the reason may be that the gap interval to the vehicle in front prevents an increase in speed.

Press switch **A** to increase or switch **C** to decrease the set speed until the desired set speed is shown in the information display. The vehicle speed will gradually change to the selected speed.

Setting the vehicle gap

CAUTION




Use the appropriate gap setting in accordance with local traffic regulations.

Note: The gap setting is time dependent and therefore the distance will automatically adjust with your speed. For example on a gap setting of four bars, the time gap is 1.8 seconds. This will mean that at a speed of 100 km/h (62 mph), the distance to the vehicle in front will be maintained at 50 metres (164 feet).

Note: If the accelerator is depressed for a short period, for example when overtaking, the system is temporarily deactivated and then reactivated when the accelerator pedal is released. A message is displayed in the information display.

Note: The gap setting will remain unchanged during ignition cycles.

Adaptive cruise control (ACC)




E82311

The distance between you and the vehicle detected in front is maintained by a variable setting. There are five steps which are represented by horizontal bars displayed in the information display. One bar indicates the smallest gap and five bars indicates the largest gap. These bars are shown empty when in standby mode and filled when in active mode.

If no vehicle is detected in front, then only your vehicle is displayed in the information display below the bars. The system will maintain the set speed when conditions permit. The set gap is maintained and displayed.

If a vehicle is detected by the sensor, the display will show another vehicle above the horizontal bars:



E82312

This is a follow mode, and the system will accelerate or decelerate as necessary to maintain the set gap.

Press switch **F** to decrease the gap or switch **E** to increase the gap. The gap selected will be represented by the number of bars in the display.

Note: The recommended gap setting is four or five bars.

Temporarily deactivating the system

Note: The system is cancelled when the gear lever is moved to a neutral position or if the accelerator pedal or clutch is depressed for a long period of time

Press either the brake or switch **G** to cancel the system. The system will return to standby mode allowing you full manual control of the vehicle. The set speed and gap setting are retained in the memory.

Press switch **G** again to resume. The system will resume with the previously set speed and vehicle gap setting if conditions permit.

Switching the system off

Press switch **D** to turn the system off.

Note: When deactivating the system by pressing switch **D**, the stored speed is not retained.

Automatic deactivation

Note: If the engine speed drops too low, a message is displayed in the information display instructing you to change down a gear (manual transmission only). If you do not follow this recommendation then the system will go into automatic deactivation mode.

Note: The system will not operate if the electronic stability programme (ESP) has been manually switched off.

The system is dependent on various other safety systems, for example ABS and ESP. If any of these systems are malfunctioning or reacting to an emergency, the system is automatically deactivated.

Adaptive cruise control (ACC)

In the event of automatic deactivation a signal will sound and the message is displayed in the information display. See **Information messages** (page 90). You must then intervene and adapt your driving and speed to vehicles in front.

An automatic deactivation can be due to the:

- vehicle speed falling below 30 km/h (20 mph)
- wheels losing traction
- brake temperature being too high, for example when driving on mountainous or hilly roads
- engine speed being too low
- radar sensor being covered
- parking brake being applied.

FORWARD ALERT FUNCTION

WARNINGS



Never wait for a collision warning. When driving you are responsible for maintaining the correct distance and speed, even when the system is used.



The system will only react to vehicles in front travelling in the same direction and will not react to slow or stationary vehicles.



Never drive in a manner to provoke the system. The system is designed to assist in emergencies only.

CAUTIONS



Warnings may be triggered late, be absent or triggered unnecessarily due to detection beam issues. See **Principle of operation** (page 151).

CAUTIONS



The system uses the same radar sensors as adaptive cruise control and therefore has the same limitations. See **Principle of operation** (page 151).

Note: *The brake support system only reduces the collision speed if you brake immediately once alerted.*

Note: *If the brake pedal is depressed sufficiently quickly then braking is implemented with full brake function, even if the force on the pedal is light.*

Note: *Brake support prepares the brake system for rapid braking and the brakes are applied gently, which may be noticed as a slight jerk.*

Note: *The collision alerts will only occur if the system is switched on, however the brake support is always on and cannot be turned off.*

Note: *The system may be used with or without the Adaptive cruise control system being activated.*

The system assists you by warning of the risk of a collision with a vehicle in front.

The system alerts you by warning chimes and a visual warning in the information display. See **Information messages** (page 90).

Brake support is activated to enable full braking effectiveness, and reduce the severity of a collision with the vehicle in front.

Switching the system on and off

Note: *When the system is switched off, a warning indicator will remain illuminated in the information display. See **Warning lamps and indicators** (page 78).*

Adaptive cruise control (ACC)

Note: *The system status and settings will remain unchanged during ignition cycles.*

The system can be switched on and off using the information display. See

General information (page 82).

Adjusting the warning sensitivity

You may adjust the system warning sensitivity using the buttons on the steering wheel. See **General information** (page 82). This controls how early the visual and audible warning is activated.

Speed limiter

PRINCIPLE OF OPERATION

WARNING



When you are going downhill, your speed may increase above the set speed. The system will not apply the brakes but a warning will be given.

The system allows you to set a speed, to which the vehicle then becomes limited. The set speed will become the effective maximum speed of the vehicle, but with the option to temporarily exceed this limit if required.

USING THE SPEED LIMITER

Note: *The set speed limit can be intentionally exceeded for a short period if required, for example when overtaking.*

The system is operated by adjustment controls mounted on the steering wheel.



E133198

- A Set speed increase
- B Speed limiter on/off
- C Set speed decrease
- D Speed limiter cancel/resume

Switching the system on and off

Press switch **B**. The information display will prompt for a speed to be set.

Setting the speed limit

Use the cruise control switches to alter the maximum speed setting.

Press switch **A** or switch **C** to select your desired speed limit. The speed is displayed in the information display and stored as the set speed.

Press switch **D** to cancel the limiter and place it in standby mode. The information display will confirm deactivation by showing the set speed crossed out.

Press switch **D** again to resume the limiter. The information display will confirm the system is active by showing the set speed again.

Intentionally exceeding the set speed limit

Depress the accelerator fully to temporarily deactivate the system. The system will reactivate once the vehicle speed drops below the set speed.

System warnings

If the set limit is accidentally exceeded, for example driving downhill, the information display will show the set speed flashing together with an audible warning chime.

If the set limit is intentionally exceeded the information display will show the set speed crossed out.

Driver alert

PRINCIPLE OF OPERATION

WARNINGS



The system does not relieve you of your responsibility to drive with due care and attention.



At all times you are responsible for controlling the vehicle, supervising the system and intervening if required.



If the sensor becomes blocked the system may not function.



Take regular rest breaks as required and do not wait for the system to warn you if you feel tired.



Take rest breaks only where it is safe to do so.



Certain driving styles and behaviour may result in the system issuing a warning even if you are not feeling tired.

CAUTIONS



In cold and severe weather conditions the system may not function. Rain, snow, spray and large contrasts in lighting can all influence the sensor.



The system will not operate if the sensor cannot track the road lane markings.



The system may not operate in areas during roadworks construction.



The system may not operate on roads with sharp bends or narrow lanes.



Do not carry out windscreen repairs in the immediate area surrounding the sensor.

CAUTIONS



If your vehicle is fitted with a suspension kit not approved by us, the system may not function correctly.

Note: *Keep the windscreen free from obstructions such as bird droppings, insects and snow or ice.*

Note: *The system is intended as a driver aid when driving on fast main roads and motorways.*

Note: *The system calculates an alertness level at vehicle speeds above approximately 65 km/h (40 mph).*

The system automatically monitors your driving behaviour using various inputs including the front camera sensor.

If the system detects that you are becoming drowsy or there is a deterioration in your driving, the system will alert you.

USING DRIVER ALERT

Switching the system on and off

Note: *The system status will remain unchanged during ignition cycles.*

Activate the system using the information display. See **Information displays** (page 82).

Once activated the system will calculate your alertness level based upon your driving behaviour in relation to the lane markings, and other factors.

System warnings

Note: *The system will not issue warnings below approximately 65 km/h (40 mph).*

Driver alert

The warning system is in two stages. At first the system issues a temporary warning that a rest should be taken. This message will only appear for a short time. If a rest is not then taken a further warning may be issued which will remain in the information display until cancelled.


Press **OK** on the steering wheel control to remove the warning.

System display

When active the system will run automatically in the background and only issue warnings if required. You can view the status at any time using the information display.


Select **Information** then **Driver Alert** to show the status screen in the information display.

The alertness level is shown by six steps as a coloured bar.



E131358

Alertness level is fine, no rest required.



E131359

Alertness level is critical, indicating that a rest should be taken as soon as safely possible.

The status bar will travel from left to right as the calculated alertness level decreases. As the rest icon is approached the colour turns from green to yellow and then finally red when a rest break must be taken.

- Green - No rest required.
- Yellow - First (temporary) warning.
- Red - Second warning.

Note: *The alertness level will be shown in grey if the camera sensor cannot track the road lane markings or if the vehicle speed drops below approximately 65 km/h (40 mph).*

Resetting the system

You can reset the system by either:

- Switching the ignition off and on.
- Stopping the vehicle and then opening and closing the driver's door.

Lane departure warning

PRINCIPLE OF OPERATION

WARNINGS



The system does not relieve you of your responsibility to drive with due care and attention.



At all times you are responsible for controlling the vehicle, supervising the system and intervening if required.



If the sensor becomes blocked the system may not function.



Lane markings may not always be properly tracked by the sensor. Other structures or objects may sometimes be incorrectly detected as a lane marking, resulting in a false or missed warning.

CAUTIONS



In cold and severe weather conditions the system may not function. Rain, snow, spray and large contrasts in lighting can all influence the sensor.



The system will not operate if the sensor cannot track the road lane markings.



The system may not operate in areas during roadworks construction.



The system may not operate on roads with sharp bends or narrow lanes.



Do not carry out windscreen repairs in the immediate area surrounding the sensor.



If your vehicle is fitted with a suspension kit not approved by us, the system may not function correctly.

Note: Keep the windscreen free from obstructions such as bird droppings, insects and snow or ice.

Note: The system is intended as a driver aid when driving on fast main roads and motorways.

Note: The system may not operate during hard braking or acceleration and, when you are intentionally steering the vehicle.

Note: The system will operate with a minimum of one tracked lane marking.

Note: The system will only operate above vehicle speeds of approximately 65 km/h (40 mph).

A sensor is mounted behind the interior rear view mirror. It continuously monitors conditions to alert you of unintentional lane drifting at high speeds.

The system will automatically detect and track the lane markings on the road. If it detects that the vehicle is unintentionally drifting towards the lane boundaries then a visual warning will be displayed in the information display. There is also a warning given in the form of a vibration felt through the steering wheel.

USING LANE DEPARTURE WARNING

Switching the system on and off

Note: When the system is switched off, a warning indicator will remain illuminated in the information display. See **Warning lamps and indicators** (page 78).

Note: The system status and settings will remain unchanged during ignition cycles.

Lane departure warning



E132099

Activate and deactivate the system using the button on the indicator stalk.

Press the button to turn the system off. Press the button twice to turn the system on.

Setting the steering wheel vibration level

The system has three intensity levels which can be set using the information display. See **General information** (page 82).

Setting the system sensitivity

You can adjust how quickly the system warns you of a dangerous situation. The system has two sensitivity levels which can be set using the information display. See **General information** (page 82).

System warnings



E132651

A column of lane markings is displayed either side of the vehicle graphic.

The lane markings are colour coded as follows:

- Green - The system is ready to warn you of any unintentional lane departure.
- Red - The vehicle is approaching or is too close to the detected lane boundary. Take immediate safe action to reposition the vehicle.
- Grey - The relevant lane boundary will be suppressed.

Instances where a lane boundary may be suppressed:

- Lane markings on the road may not be detected by the sensor.
- The direction indicator for that side of the vehicle is on.
- During hard acceleration and braking, or if direct steering is applied.
- Vehicle speed is outside the operating limits
- If there is an ABS or Stability Control (ESP) intervention.
- Narrow lane width.

If the lane markings turn red or a vibration is felt through the steering wheel you must take immediate and safe action to align the vehicle and correct any unintended lane drift.

Lane keeping aid

PRINCIPLE OF OPERATION

WARNINGS



The system does not relieve you of your responsibility to drive with due care and attention.



At all times you are responsible for controlling the vehicle, supervising the system and intervening if required.



If the sensor becomes blocked the system may not function.



Lane markings may not always be properly tracked by the sensor. Other structures or objects may sometimes be incorrectly detected as a lane marking, resulting in a false or missed warning in conjunction with a false or missed steering intervention.



Always have your hands on the steering wheel in case you need to overrule the system.

CAUTIONS



In cold and severe weather conditions the system may not function. Rain, snow, spray and large contrasts in lighting can all influence the sensor.



The system will not operate if the sensor cannot track the road lane markings.



The system may not operate in areas during roadworks construction.



The system may not operate on roads with sharp bends or narrow lanes.



Do not carry out windscreen repairs in the immediate area surrounding the sensor.

CAUTIONS



If your vehicle is fitted with a suspension kit not approved by us, the system may not function correctly.

Note: *Keep the windscreen free from obstructions such as bird droppings, insects and snow or ice.*

Note: *The system is intended as a driver aid when driving on fast main roads and motorways.*

Note: *The system may not operate during hard braking or acceleration and when you are intentionally steering the vehicle.*

Note: *The system will operate with a minimum of one tracked lane marking.*

Note: *The system will only operate between vehicle speeds of approximately 65 km/h (40 mph) and 180 km/h (112 mph).*

Note: *If the system does not detect an active steering input by the driver it will be temporarily deactivated until you resume control. The system alerts you with a warning chime and a message in the display.*

A sensor is mounted behind the interior rear view mirror. It continuously monitors conditions to alert you of unintentional lane drifting at high speeds.

The system will automatically detect and track the lane markings on the road. If it detects that the vehicle is unintentionally drifting towards the lane boundaries then a visual warning will be displayed in the information display. The system will also automatically apply a steering torque to correct the vehicle path. If the system is unable to correct the vehicle path a lane departure warning will be given. See **Using lane departure warning** (page 160).

Lane keeping aid

USING THE LANE KEEPING AID

Switching the system on and off

Note: The system is per default off.

Note: When the system has been switched on, lane departure warning is per default on.



E132099

Activate and deactivate the system using the button on the indicator stalk.

Press the button three times to switch the system on. Press the button again to turn the system off.

System warnings



E132651

A column of lane markings is displayed either side of the vehicle graphic.

The lane markings are colour coded as follows:

- Green - The system is ready to intervene if an unintentional lane departure may occur.
- Yellow - The system will automatically apply a steering torque to align the vehicle path and correct any unintended lane drift.
- Red - The vehicle is approaching or is too close to the detected lane boundary. A warning is given in the form of a vibration felt through the steering wheel. Take immediate safe action to reposition the vehicle.
- Grey - The relevant lane boundary will be suppressed.

Instances where a lane boundary may be suppressed:

- Lane markings on the road may not be detected by the sensor.
- The direction indicator for that side of the vehicle is on.
- During hard acceleration and braking, or if direct steering is applied.
- Vehicle speed is outside the operating limits
- If there is an ABS or Stability Control (ESP) intervention.
- Narrow lane width.

Note: The system can be overridden at any time during its operation by turning the steering wheel.

Traffic sign recognition

PRINCIPLE OF OPERATION

WARNINGS



The system does not relieve you of your responsibility to drive with due care and attention.



At all times you are responsible for controlling the vehicle, supervising the system and intervening if required.



If the sensor becomes blocked the system may not function.

CAUTIONS



In cold and severe weather conditions the system may not function. Rain, snow, spray and large contrasts in lighting can all influence the sensor.



Do not carry out windscreen repairs in the immediate area surrounding the sensor.



If your vehicle is fitted with a suspension kit not approved by us, the system may not function correctly.



Always fit Ford Original Parts when replacing headlamp bulbs. Other bulbs may reduce system performance.

Note: *Keep the windscreen free from obstructions such as bird droppings, insects and snow or ice.*

Note: *The system may not detect all traffic signs.*

Note: *The system is designed to read signs meeting the Vienna convention.*

A sensor is mounted behind the interior rear view mirror. It continuously monitors road signs to alert you of the current legal speed limit and overtaking regulations.

The system will automatically detect recognizable traffic signs, for example speed limit signs, no overtaking signs and speed limit cancellation signs.

USING TRAFFIC SIGN RECOGNITION

Switching the system on and off

Note: *The system status and settings will remain unchanged during ignition cycles.*

The system can be switched on and off using the information display. See **General information** (page 82).

Setting the system speed warning

The system has a number of speed warning levels which can be set using the information display. See **General information** (page 82).

System display



E132994

The system can display two traffic signs in parallel.

You can view the status at any time using the information display.

Traffic sign recognition

The system display is in four stages as follows:










1. All new recognisable traffic signs will appear brighter than the other warning signs in the display.
2. After a predetermined time they will be shown normally.
3. After a predetermined distance they will be shown greyed out.
4. After another predetermined distance they will be deleted.

If a supplementary traffic sign is detected, for example a reduced speed limit in wet road conditions sign, it will not be shown but will appear as an empty box underneath the respective sign.





Low speed safety system

PRINCIPLE OF OPERATION

WARNINGS

-  The system does not relieve you of your responsibility to drive with due care and attention.
-  At all times you are responsible for controlling the vehicle, supervising the system and intervening if required.
-  Never look directly into the sensor with any type of object, there is a risk of eye injury.
-  If the sensor becomes blocked the system may not function.
-  The system performance may vary depending on the vehicle and road conditions.
-  The system will not react to vehicles driving in a different direction.
-  The system will not react to bicycles, motorcycles, people or animals.
-  When the ignition is on the sensor will constantly transmit a laser beam.
-  The system will not operate during harsh acceleration.

CAUTIONS

-  In cold and severe weather conditions the system may not function. Rain, snow, spray and ice can all influence the sensor.
-  Do not carry out windscreen repairs in the immediate area surrounding the sensor.
-  If your vehicle is fitted with a windscreen not approved by us, the system may not function correctly.
-  If the engine stops after the system has been activated, the hazard warning flashers will be activated.

Note: *Keep the windscreen free from obstructions such as bird droppings, insects and snow or ice.*

Note: *Keep the bonnet free of ice and snow, otherwise the system may not function correctly.*

A sensor is mounted behind the interior rear view mirror. It continuously monitors conditions to decide when to intervene.

The system is designed to help you reduce low speed collisions into the rear of another vehicle. It will also help you reduce the impact damage or potentially avoid the collision completely.

The system operates at speeds below approximately 30 kph (19 mph) by applying the brakes when the sensor detects that a collision is likely.


You must depress the brake pedal to obtain full braking force.

When the system is braking or has automatically applied the brakes, a message will be shown in the display.

For laser sensor information and data: See **Type approvals** (page 281).

USING THE LOW SPEED SAFETY SYSTEM

WARNING

-  Never look directly into the sensor with any type of object, there is a risk of eye injury.

Switching the system on and off

Note: *The system is per default on.*

Note: *In certain situations, it may be advisable to disable the system, for example driving off road when objects may cover the windscreen.*







Low speed safety system


Activate and deactivate the system using the information display. See **General information** (page 82).

Load carrying

GENERAL INFORMATION

WARNINGS

-  Use load securing straps to an approved standard, e.g. DIN.
-  Make sure that you secure all loose items properly.
-  Place luggage and other loads as low and as far forward as possible within the luggage or loadspace.
-  Do not drive with the tailgate or rear door open. Exhaust fumes may enter the vehicle.
-  Do not exceed the maximum front and rear axle loads for your vehicle. See **Vehicle identification** (page 214).
-  Heavy loads, when placed in the passenger compartment, should be on folded rear seats as shown. See **Rear seats** (page 114).



E97377

LUGGAGE ANCHORPOINTS



E132901


Lift the flap to access the anchor point.

LUGGAGE COVERS

WARNING

-  Do not place objects on the luggage cover.


Load carrying



E72969

Pull out the cover and secure it in the retaining points.

Release it from the retaining points and let it roll back into the case. Clip the retaining hook onto the case.



E72970

To remove or install the cover, push either end of the case inwards.


CARGO NETS

Cargo retention net

To install the cargo retention net cassette:
Remove the luggage cover.

Push the sliders on the cassette towards each other and insert the telescopic bar into the holes on the sidewall behind the rear seatbacks.

Ensure that the end caps with the anti-rotation pin are correctly fitted in the side trim.




E78834

Pull up the net and insert the ends of the bar into the retainers on the roof.

Ensure that the bar is pushed forwards into the narrow section of the retainers.

WARNING


 After installing the cassette, press the front edge of the luggage cover back down into its original position (forwards) to prevent vision out of the rear screen being obscured.

Reinstall the luggage cover.

Remove in the reverse order.

Load carrying

Cargo net



E78835

- A With retaining rings
- B Without retaining rings

The cargo net can be used to prevent objects sliding around.

Attach the hooks at each corner of the net to the four retaining points on the load floor.

Towing

TOWING A TRAILER

Change down a gear before you reach a steep downhill gradient.

WARNINGS



Do not exceed 100 km/h (62 mph).



The rear tyre pressures must be increased by 0.2 bar (3 psi) above specification. See **Technical specifications** (page 211).



Do not exceed the maximum gross train weight stated on the vehicle identification plate. See **Vehicle identification** (page 214).

CAUTION



Do not exceed the maximum permissible nose weight, i.e. vertical weight on the tow ball, of 75 kilogrammes (165 pounds).

Note: *Not all vehicles are suitable or approved to have tow bars fitted. Check with your dealer first.*

Place loads as low and central to the axle(s) of the trailer as possible. If you are towing with an unladen vehicle, the load in the trailer should be placed toward the nose, within the maximum nose load, as this gives the best stability.

The stability of the vehicle to trailer combination is very much dependant on the quality of the trailer.

In high altitude regions above 1 000 metres (3 281 feet), the stipulated maximum permitted gross train weight must be reduced by 10% for every additional 1 000 metres (3 281 feet).

Steep gradients

WARNING



The overrun brake on a trailer is not controlled by ABS.

Driving hints

RUNNING-IN

Tyres

WARNING



New tyres need to be run-in for approximately 500 kilometres (300 miles). During this time, you may experience different driving characteristics.

Brakes and clutch

WARNING



Avoid heavy use of the brakes and clutch if possible for the first 150 kilometres (100 miles) in town and for the first 1 500 kilometres (1 000 miles) on motorways.

Engine

CAUTION



Avoid driving too fast during the first 1 500 kilometres (1 000 miles). Vary your speed frequently and change up through the gears early. Do not labour the engine.

COLD WEATHER PRECAUTIONS

The functional operation of some components and systems can be affected at temperatures below -30°C (-22°F).

DRIVING THROUGH WATER

Driving through water

CAUTIONS



Drive through water in an emergency only, and not as part of normal driving.



Engine damage can occur if water enters the air filter.

In an emergency, the vehicle can be driven through water to a maximum depth of 200 mm and at a maximum speed of 10 km/h (6 mph). Extra caution should be exercised when driving through flowing water.

When driving in water, maintain a low speed and do not stop the vehicle. After driving through water, and as soon as it is safe to do so:

- Depress the brake pedal lightly and check that full brake function is achieved.
- Check that the horn works.
- Check that the vehicle's lights are fully operational.
- Check the power assistance of the steering system.

Emergency equipment

FIRST AID KIT

Space is provided in the luggage compartment.

WARNING TRIANGLE

Space is provided in the luggage compartment.


Fuses

FUSE BOX LOCATIONS


Engine compartment fuse box

This fuse box is located in the engine compartment. See **Maintenance** (page 185).

Passenger compartment fuse box



E130170




E130171

1. Pinch the retaining clips to release the cover.
2. Lower the fuse box cover and pull it towards you.

Install in the reverse order.


Load compartment fuse box




E130147


CHANGING A FUSE

WARNINGS

 Do not modify the electrical system of your vehicle in any way. Have repairs to the electrical system and the replacement of relays and high current fuses carried out by a properly trained technician.

 Switch the ignition and all electrical equipment off before touching or attempting to change a fuse.

CAUTION

 Fit a replacement fuse with the same rating as the one you have removed.

Note: You can identify a blown fuse by a break in the filament.


Note: All fuses, except high current fuses, are a push fit.

Note: A fuse puller is located in the engine compartment fuse box.

Fuses

FUSE SPECIFICATION CHART

Engine compartment fuse box



E129925

Fuse	Ampere rating	Circuits protected
7	40	ABS pump, Electronic Stability Program (ESP) pump
8	30	Electronic Stability Program (ESP) valve
9	30	Heated rear window
10	40	Heater blower
11	30	Voltage quality module
12	30	Engine Control Relay
13	30	Starter relay
14	40	Heated windscreen (right-hand side)
15	-	Not used

Fuses



Fuse	Ampere rating	Circuits protected
16	40	Heated windscreen (left-hand side)
17	20	Fuel operated heater
18	20	Windscreen wipers
19	5	ABS, Electronic Stability Program (ESP) module
20	15	Horn
21	5	Stop lamp switch
22	15	Battery monitoring system
23	5	Relay coils, light switch module
24	20	Rear power outlet
25	10	Electric exterior mirrors
26	15	Transmission control module
27	15	Air conditioning clutch
28	5	Forward looking radar
29	20	Headlamp washer
30	5	Engine control module
31	15	Intercooler fan - 1.6L Duratorq TDCi
32	10	EGR Valve, swirl control valves, HEGO sensor (engine management)
33	10	Ignition Coils
34	10	Injectors
35	15	Diesel filter heater, active grille shutters
36	10	Engine control module
37	5	ABS
38	15	Engine control module, transmission control module
39	5	Headlamp control module
40	5	Electric power assisted steering
41	20	Body Control Module

Fuses

Fuse	Ampere rating	Circuits protected
42	15	Rear window wiper
43	15	Headlamp levelling
44	5	Forward looking radar (FLR), forward sensing module (FSM), adaptive cruise control module
45	10	Heated washer jets
46	25	Power windows (front)
47	7.5	Heated exterior mirrors
48	15	Vapouriser - 2.0L Duratorq TDCi

Fuses

Passenger compartment fuse box



E129926


Fuses

Fuse	Ampere rating	Circuits protected
56	20	Fuel pump supply
57	-	Not used
58	-	Not used
59	5	Passive anti theft system (PATS) supply
60	10	Interior lamp, driver's door switch pack, glove box, OHCSB
61	20	Cigar lighter, rear power outlet
62	5	Rain sensor module, humidity sensor, interior mirror
63	10	Forward sensing module (adaptive cruise control)
64	-	Not used
65	10	Liftgate release
66	20	Driver's door lock, double locking
67	7.5	Multi function display, GPS, BVC
68	15	Steering column lock
69	5	Instrument cluster
70	20	Central locking
71	10	Air conditioning
72	7.5	Steering wheel control module
73	5	Battery backup sounder (alarm system), OBD II (board computer diagnostics)
74	15	Main beam
75	15	Front fog lamps
76	10	Reversing lamp
77	20	Washer pump
78	5	Ignition switch or start button
79	15	Radio, hazard and door lock buttons
80	20	Power sunroof, power sunblind

Fuses

Fuse	Ampere rating	Circuits protected
81	5	Interior motion sensor, RF receiver
82	20	Washer pump ground
83	20	Central locking ground
84	20	Driver's door lock and double locking ground
85	7.5	PTC heater, passenger airbag deactivation switch, heated seats switch, parking heater, manual air conditioning heater module
86	10	Restraint system, passenger airbag deactivation
87	-	Not used
88	-	Not used
89	-	Not used

Load compartment fuse box



E129927

Fuse	Ampere rating	Circuits protected
1	-	Not used
2	10	Keyless vehicle module
3	5	Keyless vehicle door handles

Fuses

Fuse	Ampere rating	Circuits protected
4	25	Door module (left-hand front) (power windows, central locking, electric folding exterior mirror, heated exterior mirror)
5	25	Door module (right-hand front) (window up/down, central locking, electric folding mirror, heated mirror)
6	25	Door module (left-hand rear) (window up/down)
7	25	Door module (right-hand rear) (window up/down)
8	10	Security Horn
9	25	Electric driver's seat
10	-	Not used
11	-	Not used
12	10	Air conditioning module (with voltage quality module)
13	5	Instrument cluster (with voltage quality module)
14	7.5	Multi function display, GPS module (with voltage quality module)
15	15	Audio unit, audio unit control panel (with voltage quality module)
16	-	Not used
17	-	Not used
18	-	Not used
19	-	Not used
20	-	Not used
21	-	Not used
22	-	Not used
23	-	Not used
24	-	Not used
25	-	Not used
26	40	Accessories, trailer module

Fuses

Fuse	Ampere rating	Circuits protected
27	-	Not used
28	-	Not used
29	5	Blind spot information system, forward looking camera, rear view camera (without Voltage Quality Module)
30	5	Park aid module
31	-	Not used
32	-	Not used
33	-	Not used
34	15	Heated driver's seat
35	15	Heated front passenger seat
36	-	Not used
37	5	Power sunroof
38	-	Not used
39	-	Not used
40	-	Not used
41	-	Not used
42	-	Not used
43	-	Not used
44	-	Not used
45	-	Not used
46	10	Blind spot information system, forward looking camera, rear view camera (with voltage quality module)

Vehicle recovery

TOWING POINTS


Towing eye location

The screw-in towing eye is located in the spare wheel well.

The towing eye must **always** be carried in the vehicle.

Installing the towing eye

CAUTION

 The screw-in towing eye has a **left-hand thread**. Turn it **anti-clockwise** to install it. Make sure that the towing eye is fully tightened.

Note: *On vehicles with a tow bar, the towing eye cannot be installed at the rear of the vehicle. Use the tow bar to tow a vehicle.*

Front towing eye



E78367

Rear towing eye



E78368


Insert a suitable object into the hole on the underside of the cover and prise off the cover.


Install the towing eye.

TOWING THE VEHICLE ON FOUR WHEELS

All vehicles




WARNINGS

 Switch the ignition on when your vehicle is being towed. The steering lock will engage and the direction indicators and brake lamps will not work if you do not.

 The brake and steering assistance will not operate unless the engine is running. Press the brake pedal harder and allow for increased stopping distances and heavier steering.

Vehicle recovery

CAUTIONS

-  Too much tension in the tow rope could cause damage to your vehicle or the vehicle that is towing.
 -  Select neutral when your vehicle is being towed.
 -  In the event of a breakdown or mechanical failure **do not** use individual axle carriers. Your vehicle must be recovered with either **ALL** wheels on the ground or transported with **ALL** wheels lifted clear of the ground on a level platform.
-

Drive off slowly and smoothly without jerking the vehicle that is towing.

Vehicles with automatic transmission

CAUTIONS

-  If a speed of 20 km/h (12 mph) and a distance of 20 kilometres (12 miles) is to be exceeded **ALL** wheels must be lifted clear of the ground.
 -  It is recommended not to tow with the drive wheels on the ground. However, if it is required to move the vehicle from a dangerous location, do not tow your vehicle faster than 20 km/h (12 mph) or further than 20 kilometres (12 miles).
 -  Do not tow your vehicle backwards.
 -  In the event of a mechanical failure of the transmission **do not** use individual axle carriers. **ALL** wheels must be lifted clear of the ground on a level platform.
 -  Do not tow your vehicle if the ambient temperature is below 0°C (32°F).
-

Maintenance

GENERAL INFORMATION

Have your vehicle serviced regularly to help maintain its roadworthiness and resale value. There is a large network of Ford Authorised Repairers that are there to help you with their professional servicing expertise. We believe that their specially trained technicians are best qualified to service your vehicle properly and expertly. They are supported by a wide range of highly specialised tools developed specifically for servicing your vehicle.

In addition to regular servicing, we recommend that you carry out the following additional checks.

WARNINGS



Switch the ignition off before touching or attempting adjustment of any kind.



Do not touch the electronic ignition system parts after you have switched the ignition on or when the engine is running. The system operates at high voltage.



Keep your hands and clothing clear of the engine cooling fan. Under certain conditions, the fan may continue to run for several minutes after you have switched the engine off.

CAUTION



When carrying out maintenance checks, make sure that filler caps are fitted securely.

Daily checks

- Exterior lamps.
- Interior lamps.
- Warning lamps and indicators.

Check when refuelling

- Engine oil level. See **Engine oil check** (page 192).
- Brake fluid level. See **Brake and clutch fluid check** (page 194).
- Washer fluid level. See **Washer fluid check** (page 194).
- Tyre pressures (when cold). See **Technical specifications** (page 211).
- Tyre condition. See **Wheels and tyres** (page 201).

Monthly checks


- Engine coolant level (engine cold). See **Engine coolant check** (page 193).
- Pipes, hoses and reservoirs for leaks.
- Air conditioning operation.
- Parking brake operation.
- Horn operation.
- Tightness of wheel nuts. See **Technical specifications** (page 211).

OPENING AND CLOSING THE BONNET

Opening the bonnet




Maintenance



E133239

Move the yellow catch to the right.



E87786

Open the bonnet and support it with the strut.

Closing the bonnet

WARNING




Make sure that the bonnet is closed properly.

Lower the bonnet and allow it to drop from under its own weight for the last 20 – 30 centimetres (8 - 11 inches).

Maintenance

ENGINE COMPARTMENT OVERVIEW - 1.6L DURATEC-16V TI-VCT (SIGMA)



E130030

- A Engine coolant reservoir*: See **Engine coolant check** (page 193).
- B Brake and clutch fluid reservoir (right-hand drive)*: See **Brake and clutch fluid check** (page 194).
- C Engine oil filler cap*: See **Engine oil check** (page 192).
- D Brake and clutch fluid reservoir (left-hand drive)*: See **Brake and clutch fluid check** (page 194).
- E Battery: See **Vehicle battery** (page 199).
- F Engine compartment fuse box: See **Fuses** (page 174).
- G Air cleaner: No maintenance necessary.


Maintenance

H Engine oil dipstick*: See **Engine oil check** (page 192).

I Screen washer fluid reservoir*: See **Washer fluid check** (page 194).

*For easy identification, filler caps and the engine oil dipstick are marked in colour.

ENGINE COMPARTMENT OVERVIEW - 1.6L ECOBOOST SCTI (SIGMA)



E132729

A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 194).


B Engine oil filler cap¹. See **Engine oil check** (page 192).

Maintenance

- C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 194).
- D Battery. See **Vehicle battery** (page 199).
- E Engine compartment fuse box. See **Fuses** (page 174).
- F Air cleaner. No maintenance necessary.
- G Engine oil dipstick¹. See **Engine oil check** (page 192).
- H Screen washer fluid reservoir. See **Washer fluid check** (page 194).
- I Engine coolant reservoir. See **Engine coolant check** (page 193).

¹The filler caps and the engine oil dipstick are coloured for easy identification.

ENGINE COMPARTMENT OVERVIEW - 1.6L DURATORQ-TDCI (DV) DIESEL




E130031

Maintenance

- A Engine coolant reservoir^{*}: See **Engine coolant check** (page 193).
 - B Brake and clutch fluid reservoir (right-hand drive)^{*}: See **Brake and clutch fluid check** (page 194).
 - C Engine oil filler cap^{*}: See **Engine oil check** (page 192).
 - D Brake and clutch fluid reservoir (left-hand drive)^{*}: See **Brake and clutch fluid check** (page 194).
 - E Battery: See **Vehicle battery** (page 199).
 - F Engine compartment fuse box: See **Fuses** (page 174).
 - G Air cleaner: No maintenance necessary.
 - H Engine oil dipstick^{*}: See **Engine oil check** (page 192).
 - I Screen washer fluid reservoir^{*}: See **Washer fluid check** (page 194).
- ^{*}For easy identification, filler caps and the engine oil dipstick are marked in colour.

Maintenance

ENGINE COMPARTMENT OVERVIEW - 2.0L DURATORQ-TDCI (DW) DIESEL



E130032

- A Engine coolant reservoir^{*}: See **Engine coolant check** (page 193).
- B Brake and clutch fluid reservoir (right-hand drive)^{*}: See **Brake and clutch fluid check** (page 194).
- C Engine oil dipstick^{*}: See **Engine oil check** (page 192).
- D Brake and clutch fluid reservoir (left-hand drive)^{*}: See **Brake and clutch fluid check** (page 194).
- E Battery: See **Vehicle battery** (page 199).
- F Engine compartment fuse box: See **Fuses** (page 174).
- G Air cleaner: No maintenance necessary.


Maintenance

H Engine oil filler cap*: See **Engine oil check** (page 192).

I Screen washer fluid reservoir*: See **Washer fluid check** (page 194).

*For easy identification, filler caps and the engine oil dipstick are marked in colour.

ENGINE OIL DIPSTICK - 1.6L DURATEC-16V TI-VCT (SIGMA)




E95540

A MIN

B MAX

ENGINE OIL DIPSTICK - 1.6L ECOBOOST SCTI (SIGMA)




E134114

A MIN

B MAX

ENGINE OIL DIPSTICK - 1.6L DURATORQ-TDCI (DV) DIESEL/2.0L DURATORQ-TDCI (DW) DIESEL



E95543

A MIN

B MAX

ENGINE OIL CHECK

CAUTION

! Do not use oil additives or other engine treatments. Under certain conditions, they could damage the engine.

Note: The oil consumption of new engines reaches its normal level after approximately 5 000 kilometres (3 000 miles).

Checking the oil level

CAUTION

! Make sure that the level is between the **MIN** and the **MAX** marks.

Maintenance

Note: Check the level before starting the engine.

Note: Make sure that your vehicle is on level ground.

Note: Oil expands when it is hot. The level may therefore extend a few millimetres beyond the **MAX** mark.

Remove the dipstick and wipe it with a clean, lint free cloth. Replace the dipstick and remove it again to check the oil level.

If the level is at the **MIN** mark, top up immediately.

Topping up

WARNINGS



Only top up when the engine is cold. If the engine is hot, wait 10 minutes for the engine to cool down.



Do not remove the filler cap when the engine is running.

Remove the filler cap.

CAUTION



Do not top up further than the **MAX** mark.

Top up with fluid that meets the Ford specification. See **Technical specifications** (page 195).

Replace the filler cap. Turn it until you feel a strong resistance.

ENGINE COOLANT CHECK

Checking the coolant level

WARNING



Do not allow the fluid to touch your skin or eyes. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.

CAUTION



Make sure that the level is between the **MIN** and the **MAX** marks.

Note: Coolant expands when it is hot. The level may therefore extend beyond the **MAX** mark.

If the level is at the **MIN** mark, top up immediately.

Topping up

WARNINGS



Only top up when the engine is cold. If the engine is hot, wait 10 minutes for the engine to cool down.



Do not remove the filler cap when the engine is running.



Do not remove the filler cap when the engine is hot. Wait for the engine to cool down.



Undiluted coolant is flammable and may ignite if spilt on a hot exhaust.

CAUTIONS



In an emergency, you can add just water to the cooling system to reach a vehicle service station. Have the system checked by a properly trained technician as soon as possible.



Prolonged use of incorrect dilution of the coolant can cause engine damage from corrosion, overheating or freezing.

Unscrew the cap **slowly**. Any pressure will escape slowly as you unscrew the cap.

CAUTION



Do not top up further than the **MAX** mark.

Maintenance

Top up with a 50/50 mixture of coolant and water using fluid that meets the Ford specification. See **Technical specifications** (page 195).

BRAKE AND CLUTCH FLUID CHECK

WARNINGS



Do not allow the fluid to touch your skin or eyes. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.



If the level is at the **MIN** mark, have the system checked by a properly trained technician as soon as possible.

Note: Contamination with dirt, water, petroleum products or other materials may result in brake failure or costly repairs.

Note: The brake and the clutch systems are supplied from the same reservoir.

Top up with fluid that meets the Ford specification. See **Technical specifications** (page 195).

WASHER FLUID CHECK

Note: The front and rear washer systems are supplied from the same reservoir.

When topping up, use a mixture of washer fluid and water to help prevent freezing in cold weather and improve the cleaning capability. We recommend that you use only high quality washer fluid.

For information on fluid dilution, refer to the product instructions.

Maintenance

TECHNICAL SPECIFICATIONS

Vehicle fluids

CAUTION



Do not use fluids which do not meet the specifications or requirements defined. Use of unsuitable fluids may lead to damage which is not covered by your Warranty.

Item	Recommended fluid	Specification
Engine oil - petrol and diesel engines	Castrol or Ford Engine Oil	WSS-M2C913-C
Alternative engine oil - petrol engines only	Castrol Engine Oil	WSS-M2C925-B
Antifreeze	Motorcraft SuperPlus Anti-freeze	WSS-M97B44-D
Brake fluid	Ford or Motorcraft Super DOT 4 Brake Fluid	WSS-M6C57-A2

Your engine has been designed to be used with Castrol and Ford Engine Oil, which gives a fuel economy benefit whilst maintaining the durability of your engine.

For petrol engines only, Ford and Castrol have developed a low friction **SAE-5W-20** oil which offers further fuel economy benefits over the standard **SAE-5W-30** oil. If this oil is not available, we recommend that you service with oil to specification **WSS-M2C913-C**.

Topping up the oil: If you are unable to find an oil that meets the specification defined by **WSS-M2C913-C** or **WSS-M2C925-B** (petrol engines only), you must use **SAE 5W-30** that meets the specification defined by **ACEA A5/B5**.

Using topping up oils other than the one specified can result in longer engine cranking periods, reduced engine performance, reduced fuel economy and increased emission levels.

Castrol engine oil recommended.



Maintenance

Capacities

Variant	Item	Capacity in litres (gallons)
Vehicles with a petrol engine	Fuel tank	55 (12.1)
1.6L Duratorq-TDCi	Fuel tank	53 (11.7)
2.0L Duratorq-TDCi	Fuel tank	60 (13.2)
All	Windscreen washer system - with headlamp washers	4.5 (1)
All	Windscreen washer system - without headlamp washers	3 (0.7)
1.6L Duratec-16V Ti-VCT	Engine oil - with filter	4.1 (0.9)
1.6L Duratec-16V Ti-VCT	Engine oil - without filter	3.75 (0.8)
1.6L Duratec-16V Ti-VCT	Cooling system	approx. 5.8 (1.3)
1.6L EcoBoost SCTi	Engine oil - with filter	4.1 (0.9)
1.6L EcoBoost SCTi	Engine oil - without filter	3.75 (0.8)
1.6L EcoBoost SCTi	Cooling system	approx. 6.3 (1.4)
1.6L Duratorq-TDCi	Engine oil - with filter	3.8 (0.8)
1.6L Duratorq-TDCi	Engine oil - without filter	3.5 (0.8)
1.6L Duratorq-TDCi	Cooling system	approx. 7.3 (1.6)
2.0L Duratorq-TDCi	Engine oil - with filter	5.7 (1.3)
2.0L Duratorq-TDCi	Engine oil - without filter	5.4 (1.2)
2.0L Duratorq-TDCi	Cooling system	approx. 8.5 (1.9)

Engine oil top up capacities

Engine	Capacity in litres (gallons)
1.6L Duratec-16V Ti-VCT	0.8 (0.2)
1.6L EcoBoost SCTi	0.8 (0.2)
1.6L Duratorq-TDCi	1.6 (0.4)
2.0L Duratorq-TDCi	1.8 (0.4)

Vehicle care

CLEANING THE EXTERIOR

WARNING



If you use a car wash with a waxing cycle, make sure that you remove the wax from the windscreen.

CAUTIONS



Prior to using a car wash facility check the suitability of it for your vehicle.



Some car wash installations use water at high pressure. This could damage certain parts of your vehicle.



Remove the aerial before using an automatic car wash.



Switch the heater blower off to prevent contamination of the fresh air filter.

We recommend that you wash your vehicle with a sponge and lukewarm water containing a car shampoo.

Cleaning the headlamps

CAUTIONS



Do not scrape the headlamp lenses or use abrasives, alcoholic solvents or chemical solvents to clean them.



Do not wipe the headlamps when they are dry.

Cleaning the rear window

CAUTION



Do not scrape the inside of the rear window or use abrasives or chemical solvents to clean it.

Use a clean, lint free cloth or a damp chamois leather to clean the inside of the rear window.

Cleaning the chrome trim

CAUTION



Do not use abrasives or chemical solvents. Use soapy water.

Body paintwork preservation

CAUTIONS



Do not polish your vehicle in strong sunshine.



Do not allow polish to touch plastic surfaces. It could be difficult to remove.



Do not apply polish to the windscreen or rear window. This could cause the wipers to become noisy and they may not clear the window properly.

We recommend that you wax the paintwork once or twice a year.

CLEANING THE INTERIOR

Seat belts

WARNINGS



Do not use abrasives, or chemical solvents to clean them.



Do not allow moisture to penetrate the seat belt retractor mechanism.

Clean the seat belts with interior cleaner or water applied with a soft sponge. Let the seat belts dry naturally, away from artificial heat.

Vehicle care

Instrument cluster screens, LCD screens, radio screens

WARNING



Do not use abrasives, alcoholic solvents or chemical solvents to clean them.

REPAIRING MINOR PAINT DAMAGE

CAUTION



Remove apparently harmless looking substances from the paintwork immediately (e.g. bird droppings, tree resins, insect remains, tar spots, road salt and industrial fall out).

You should repair paintwork damage caused by stones from the road or minor scratches as soon as possible. A choice of products is available from your Ford Dealer. Read and follow the manufacturer's instructions.


Vehicle battery

USING BOOSTER CABLES

CAUTIONS

- ⚠ Connect batteries with only the same nominal voltage.
- ⚠ Always use booster cables with insulated clamps and adequate size cable.
- ⚠ Do not disconnect the battery from the vehicle's electrical system.

To connect the booster cables



E102925

- A Flat battery vehicle
- B Booster battery vehicle
- C Positive connection cable
- D Negative connection cable

1. Position the vehicles so that they do not touch one another.
2. Switch off the engine and any electrical equipment.
3. Connect the positive (+) terminal of vehicle **B** with the positive (+) terminal of vehicle **A** (cable **C**).
4. Connect the negative (-) terminal of vehicle **B** to the ground connection of vehicle **A** (cable **D**). See **Battery connection points** (page 200).

CAUTIONS

- ⚠ **Do not connect to the negative (-) terminal of the flat battery.**
- ⚠ Make sure that the cables are clear of any moving parts.

To start the engine

1. Run the engine of vehicle **B** at moderately high speed.
2. Start the engine of vehicle **A**.
3. Run both vehicles for a minimum of three minutes before disconnecting the cables.

CAUTION

- ⚠ Do not switch on the headlamps when disconnecting the cables. The peak voltage could blow the bulbs.

Disconnect the cables in the reverse order.

CHANGING THE VEHICLE BATTERY

CAUTION

- ⚠ For vehicles with Start-stop the battery requirement is different. It must be replaced by one of exactly the same specification as the original.

Vehicle battery


Note: Where applicable, the audio system must be reprogrammed with the keycode.

The battery is located in the engine compartment. See **Maintenance** (page 185).

BATTERY CONNECTION POINTS

CAUTION

! Do not connect to the negative (-) terminal of the flat battery.



E130431


The ground connection point is located to the right of the battery near the engine compartment fuse box.

Wheels and tyres

GENERAL INFORMATION

CAUTIONS

 Use only approved wheel and tyre sizes. Using other sizes could damage the vehicle and will make the National Type Approval invalid.

 If you change the diameter of the tyres from that fitted at the factory, the speedometer may not display the correct speed. Take the vehicle to your dealer to have the engine management system reprogrammed.

A decal with tyre pressure data is located in the driver's door opening at the B-pillar.

Check and set the tyre pressure at the ambient temperature in which you are intending to drive the vehicle and when the tyres are cold.


CHANGING A ROAD WHEEL


Locking wheel nuts


You can obtain a replacement locking wheel nut key and replacement locking wheel nuts from your dealer using the reference number certificate.


Vehicles with a temporary spare wheel

WARNINGS

 If the spare wheel differs from the other fitted wheels, these rules must be followed:


 Do not exceed 80 km/h (50 mph).


 Drive the shortest possible distances.

 Do not fit more than one spare wheel on your vehicle at any one time.


WARNINGS

 Do not use snow chains on this type of wheel.

 Do not drive through an automatic car wash.

 Do not carry out any tyre repairs on a temporary spare wheel.


CAUTION


 The ground clearance of your vehicle will be reduced. Take care when parking next to a kerb.


Note: *Your vehicle may exhibit some unusual driving characteristics.*

Vehicle jack

WARNINGS

 The vehicle jack supplied with your vehicle should only be used when changing a wheel in emergency situations.

 Before using the vehicle jack, check that it is not damaged or deformed and that the thread is lubricated and free from foreign matter.

 Never place anything between the jack and the ground, or the jack and the vehicle.

Note: *Vehicles with a tyre repair kit are not equipped with a vehicle jack or a wheel brace.*

It is recommended to use a workshop type hydraulic jack for changing between summer and winter tyres.

Note: *Use a jack with a minimum lifting capacity of 1.5 tonnes and a lifting plate with a minimum diameter of 80 millimetres (3.1 inches).*

Wheels and tyres



Vehicles without tyre repair kit

Your vehicle jack, wheel brace, screw-in towing eye and wheel trim remover are located in the spare wheel well.

Jacking and lifting points

CAUTION


! Use only the specified jacking points. If you use other positions, you may damage the body, steering, suspension, engine, braking system or the fuel lines.



E92658

- A Emergency use only
- B Maintenance

Wheels and tyres




E93302

Small arrow-shaped marks on the sills **A** show the location of the jacking points.



E92932



E93020

Assembling the wheel brace

Type one

WARNING



When returning the wheel brace extension to its original position, take care not to get your fingers caught.

Note: Make sure that the wheel brace is fully extended.



E122546


Extend the wheel brace.

Type two

CAUTION



The screw-in towing eye has a **left-hand thread**. Turn it anti-clockwise to install it. Make sure that the towing eye is fully tightened.



E122502

Insert the screw-in towing eye into the wheel brace.


Wheels and tyres

Removing the wheel trim

Type one

Insert the flat end of the wheel brace between the rim and the trim and carefully remove the trim.

Type two







E122314

1. Insert the wheel trim remover.
2. Remove the wheel trim.







Note: Make sure that you pull the wheel trim remover at right angles to the trim.

Removing a road wheel


WARNINGS

-  Park your vehicle in such a position that neither the traffic nor you are hindered or endangered.
-  Set up a warning triangle.
-  Make sure that the vehicle is on firm, level ground with the wheels pointing straight ahead.
-  Switch off the ignition and apply the parking brake.

WARNINGS

-  If your vehicle has a manual transmission, select first or reverse gear. If it has an automatic transmission, select park.
-  Have the passengers leave the vehicle.
-  Secure the diagonally opposite wheel with an appropriate block or wheel chock.
-  Make sure that the arrows on directional tyres point in the direction of rotation when the vehicle is moving forwards. If you have to fit a spare wheel with the arrows pointing in the opposite direction, have the tyre refitted in the correct direction by a properly trained technician.
-  Do not work underneath the vehicle when it is supported only by a jack.
-  Make sure that the jack is vertical to the jacking point and the base is flat on the ground.


CAUTION

-  Do not lay alloy wheels face down on the ground, this will damage the paint.

Note: The spare wheel is located under the floor cover in the luggage compartment.

1. Install the locking wheel nut key.

Wheels and tyres




E121887

2. Slacken the wheel nuts.
3. Jack up the vehicle until the tyre is clear of the ground.
4. Remove the wheel nuts and the wheel.


Installing a road wheel

WARNINGS

 Use only approved wheel and tyre sizes. Using other sizes could damage the vehicle and will make the National Type Approval invalid. See **Technical specifications** (page 211).

 Do not fit run flat tyres on vehicles that were not originally fitted with them. Please contact your dealer for more details regarding compatibility.

CAUTION


 Do not install alloy wheels using wheel nuts designed for use with steel wheels.

Note: The wheel nuts of alloy wheels and spoked steel wheels can also be used for the steel spare wheel for a short time (maximum two weeks).

Note: Make sure the wheel and hub contact surfaces are free from foreign matter.

Note: Make sure that the cones on the wheel nuts are against the wheel.

1. Install the wheel.
2. Install the wheel nuts finger tight.
3. Install the locking wheel nut key.



E75442

4. Partially tighten the wheel nuts in the sequence shown.
5. Lower the vehicle and remove the jack.
6. Fully tighten the wheel nuts in the sequence shown. See **Technical specifications** (page 211).
7. Install the wheel trim using the ball of your hand.

Wheels and tyres

WARNING



Have the wheel nuts checked for tightness and the tyre pressure checked as soon as possible.

TYRE REPAIR KIT

Your vehicle may not have a spare tyre. In this case it will have an emergency tyre repair kit that can be used to repair **one** flat tyre.

The tyre repair kit is located in the spare wheel well.

General information

WARNINGS



Depending on the type and extent of tyre damage, some tyres can only be partially sealed or not sealed at all. Loss of tyre pressure can affect vehicle handling, leading to loss of vehicle control.



Do not use the tyre repair kit if the tyre has already been damaged as a result of being driven under inflated.



Do not use the tyre repair kit on run flat tyres.



Do not try to seal damage other than that located within the visible tread of the tyre.



Do not try to seal damage to the tyre's sidewall.

The tyre repair kit seals most tyre punctures [with a diameter of up to six millimetres (1/4 inch)] to temporarily restore mobility.

Observe the following rules when using the kit:

- **Drive with caution and avoid making sudden steering or driving manoeuvres**, especially if the vehicle is heavily loaded or you are towing a trailer.
- The kit will provide you with an emergency temporary repair, enabling you to continue your journey to the next vehicle or tyre dealer, or to drive a maximum distance of 200 kilometres (125 miles).
- Do not exceed a **maximum speed of 80 km/h (50 mph)**.
- Keep the kit out of the reach of children.
- Only use the kit when the ambient temperature is between -30°C (-22°F) and $+70^{\circ}\text{C}$ ($+158^{\circ}\text{F}$).

Using the tyre repair kit

WARNINGS



Compressed air can act as an explosive or propellant.



Never leave the tyre repair kit unattended while in use.

CAUTION



Do not keep the compressor operating for more than 10 minutes.

Note: Use the tyre repair kit only for the vehicle with which it was supplied.

- Park your vehicle at the roadside so that you do not obstruct the flow of traffic and so that you are able to use the kit without being in danger.
- Apply the parking brake, even if you have parked on a level road, to make sure that the vehicle will not move.
- Do not attempt to remove foreign objects like nails or screws penetrating the tyre.

Wheels and tyres

- Leave the engine running while the kit is in use, but not if the vehicle is in an enclosed or poorly ventilated area (for example, inside a building). In these circumstances, switch the compressor on with the engine turned off.
- Replace the sealant bottle with a new one before the expiry date (see top of bottle) is reached.
- Inform all other users of the vehicle that the tyre has been temporarily sealed with the tyre repair kit and make them aware of the special driving conditions to be observed.


Inflating the tyre

WARNINGS

- ⚠ Check the sidewall of the tyre prior to inflation. If there are any cracks, bumps or similar damage, do not attempt to inflate the tyre.
- ⚠ Do not stand directly beside the tyre while the compressor is pumping.
- ⚠ Watch the sidewall of the tyre. If any cracks, bumps or similar damage appear, turn off the compressor and let the air out by means of the pressure relief valve **B**. Do not continue driving with this tyre.
- ⚠ The sealant contains natural rubber latex. Avoid contact with skin and clothing. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.
- ⚠ If the tyre inflation pressure does not reach 1.8 bar (26 psi) within seven minutes, the tyre may have suffered excessive damage, making a temporary repair impossible. In this case, do not continue driving with this tyre.

CAUTION

- ⚠ Screwing the bottle onto the bottle holder will pierce the seal of the bottle. Do not unscrew the bottle from the holder as the sealant will escape.



- A Protective cap
- B Pressure relief valve
- C Hose
- D Orange cap
- E Bottle holder
- F Pressure gauge

Wheels and tyres

- G Power plug with cable
- H Compressor switch
- I Label
- J Bottle lid
- K Sealant bottle

1. Open the lid of the tyre repair kit.
2. Peel off the label **I** showing the maximum permissible speed of 80 km/h (50 mph) from the casing and attach it to the instrument panel in the driver's field of view. Make sure the label does not obscure anything important.
3. Take the hose **C** and the power plug with cable **G** out of the kit.
4. Unscrew the orange cap **D** and the bottle lid **J**.
5. Screw the sealant bottle **K** clockwise into the bottle holder **E** fully tight.
6. Remove the valve cap from the damaged tyre.
7. Detach the protective cap **A** from the hose **C** and screw the hose **C** firmly onto the valve of the damaged tyre.
8. Make sure that the compressor switch **H** is in position **O**.
9. Insert the power plug **G** into the cigar lighter socket or auxiliary power socket. See **Cigar lighter** (page 116). See **Auxiliary power sockets** (page 116).
10. Start the engine.
11. Move the compressor switch **H** to position **1**.
12. Inflate the tyre for no longer than seven minutes to an inflation pressure of minimum 1.8 bar (26 psi) and a maximum of 3.5 bar (51 psi). Move the compressor switch **H** to position **O** and check the current tyre pressure with pressure gauge **F**.

13. Remove the power plug **G** from the cigar lighter socket or auxiliary power socket.
14. Quickly unscrew the hose **C** from the tyre valve and replace the protective cap **A**. Fasten the valve cap again.
15. Leave the sealant bottle **K** in the bottle holder **E**.
16. Make sure the kit, the bottle lid and the orange cap are stored safely, but still easily accessible in the vehicle. The kit will be required again when you check the tyre pressure.
17. Immediately drive approximately three kilometres (two miles) so that the sealant can seal the damaged area.

Note: When pumping in the sealant through the tyre valve, the pressure may rise up to 6 bar (87 psi) but will drop again after about 30 seconds.

WARNING



If you experience heavy vibrations, unsteady steering behaviour or noises while driving, reduce your speed and drive with caution to a place where it is safe for you to stop the vehicle. Recheck the tyre and its pressure. If the tyre pressure is less than 1.3 bar (19 psi) or if there are any cracks, bumps or similar damage visible, do not continue driving with this tyre.

Checking the tyre pressure

1. Stop the vehicle after driving approximately three kilometres (two miles). Check, and where necessary, adjust the pressure of the damaged tyre.
2. Attach the kit and read the tyre pressure from the pressure gauge **F**.

Wheels and tyres

- If the pressure of the sealant-filled tyre is 1.3 bar (19 psi) or more, adjust it to the specified pressure. See **Technical specifications** (page 211).
- Follow the inflation procedure once again to top up the tyre.
- Check the tyre pressure again from the pressure gauge **F**. If the tyre pressure is too high, deflate the tyre to the specified pressure using the pressure relief valve **B**.
- Once you have inflated the tyre to its correct tyre pressure, move the compressor switch **H** to position **O**, remove the power plug **G** from the socket, unscrew the hose **C**, fasten the valve cap and replace the protective cap **A**.
- Leave the sealant bottle **K** in the bottle holder **E** and store the kit away safely in its original location.
- Drive to the nearest tyre specialist to get the damaged tyre replaced. Before the tyre is removed from the rim, inform your tyre dealer that the tyre contains sealant. Renew the kit as soon as possible after it has been used once.

Note: Remember that emergency roadside tyre repair kits only provide temporary mobility. Regulations concerning tyre repair after usage of tyre repair kit may differ from country to country. You should consult a tyre specialist for advice.

WARNING



Before driving, make sure the tyre is adjusted to the recommended inflation pressure. See **Technical specifications** (page 211). Monitor the tyre pressure until the sealed tyre is replaced.

Empty sealant bottles can be disposed of together with normal household waste. Return remains of sealant to your dealer or dispose of it in compliance with local waste disposal regulations.

TYRE CARE



E70415

To make sure the front and rear tyres of your vehicle wear evenly and last longer, we recommend that you swap the tyres from front to rear and vice versa at regular intervals of between 5 000 and 10 000 km (3 000 and 6 000 miles).

CAUTION



Do not scrub the sidewalls of the tyres when you are parking.

If you have to mount a kerb, do so slowly and approach it with the wheels at right-angles to the kerb.


Examine the tyres regularly for cuts, foreign objects and uneven wear of the tread. Uneven wear could mean that the wheel alignment is outside specification.

Check the tyre pressures (including the spare) when cold, every two weeks.

Wheels and tyres

USING WINTER TYRES

CAUTION

-  Make sure that you use the correct wheel nuts for the type of wheel the winter tyres are fitted to.


If winter tyres are used, make sure that the tyre pressures are correct. See **Technical specifications** (page 211).

USING SNOW CHAINS

WARNINGS

-  Do not exceed 50 km/h (30 mph).
-  Do not use snow chains on snow-free roads.
-  Only fit snow chains to specified tyres. See **Technical specifications** (page 211).

CAUTION

-  If your vehicle is fitted with wheel trims, remove them before fitting snow chains.

Note: *The ABS will continue to operate normally.*

Only use small link snow chains.




Only use snow chains on the front wheels.

Vehicles with stability control (ESP)



Vehicles with stability control (ESP) may exhibit some unusual driving characteristics which can be avoided by switching the system off. See **Using stability control** (page 135).

TYRE PRESSURE MONITORING SYSTEM

WARNINGS

-  The system does not relieve you of your responsibility to regularly check the tyre pressures.
-  The system will only provide a low tyre pressure warning. It will not inflate the tyres.
-  Do not drive on significantly under-inflated tyres. This may cause the tyres to overheat and fail.
- Under-inflation reduces fuel efficiency, tyre tread life and may also affect your ability to drive the vehicle safely.

CAUTIONS

-  Do not bend or damage the valves when you are inflating the tyres.
-  Have tyres installed by properly trained technicians.

The Deflation Detection System will alert you if there is a change of air pressure in any tyre. It does this by using the ABS sensors to detect the rolling circumference of the wheels. When the circumference changes, this indicates low pressure in a tyre, a warning message is displayed in the information display and the message indicator will illuminate. See **Information messages** (page 90).

Apart from a too low tyre pressure or a damaged tyre, the following situations can affect the rolling circumference:

- Vehicle load is uneven.
- When using a trailer or travelling up and down an incline.
- Using snow chains.
- Driving on soft surfaces such as snow or mud.

Wheels and tyres

Note: *The system will still function correctly, but there may be an increased detection time.*

If a low pressure warning message is displayed in the information display, check the tyre pressures as soon as possible and inflate them to the recommended pressure. See **Technical specifications** (page 211).

If this happens frequently, have the cause determined and rectified as soon as possible.

System reset

Note: *Do not reset the system when the vehicle is moving.*

Note: *You should reset the system following any adjustment to the tyre pressures or any changing of tyres.*

Note: *Turn the ignition on.*

1. Using the information display control, navigate to **Information > Deflat detect**
2. Press and hold the **OK** button until confirmation appears.

TECHNICAL SPECIFICATIONS

Wheel nut torque

Wheel type	Nm (lb-ft)
All	130 (96)

Tyre pressures (cold tyres)

Up to 80 km/h (50 mph)

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
All	T125/80 R 16	4.2 (61)	4.2 (61)	4.2 (61)	4.2 (61)
All	T125/90 R 16	4.2 (61)	4.2 (61)	4.2 (61)	4.2 (61)

Wheels and tyres

Up to 160 km/h (100 mph)

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (psi)	bar (psi)	bar (psi)	bar (psi)
All	205/55 R 16*	2.1 (31)	2.1 (31)	2.4 (35)	2.8 (41)
Vehicles with a petrol engine and 1.6L Duratorq-TDCi (DV) Diesel	215/55 R 16*	2.1 (31)	2.1 (31)	2.4 (35)	2.8 (41)
2.0L Duratorq-TDCi (DW) Diesel	215/55 R 16*	2.3 (33)	2.1 (31)	2.4 (35)	2.8 (41)
Vehicles with a petrol engine and 1.6L Duratorq-TDCi (DV) Diesel	215/50 R 17	2.1 (31)	2.1 (31)	2.4 (35)	2.8 (41)
2.0L Duratorq-TDCi (DW) Diesel	215/50 R 17	2.3 (33)	2.1 (31)	2.4 (35)	2.8 (41)
Vehicles with a petrol engine and 1.6L Duratorq-TDCi (DV) Diesel	235/40 R 18	2.1 (31)	2.1 (31)	2.4 (35)	2.8 (41)
2.0L Duratorq-TDCi (DW) Diesel	235/40 R 18	2.3 (33)	2.1 (31)	2.4 (35)	2.8 (41)

* Only fit snow chains to specified tyres.

Continuous speed in excess of 160 km/h (100 mph)

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (psi)	bar (psi)	bar (psi)	bar (psi)
1.6L Duratec-Ti-VCT (Sigma) and 1.6L Duratorq-TDCi (DV) Diesel	205/55 R 16	2.1 (31)	2.1 (31)	2.4 (35)	2.8 (41)

Wheels and tyres


Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (psi)	bar (psi)	bar (psi)	bar (psi)
1.6L EcoBoost SCTi (Sigma)	205/55 R 16	2.2 (32)	2.1 (31)	2.4 (35)	2.8 (41)
Vehicles with a petrol engine and 1.6L Duratorq-TDCi (DV) Diesel	215/55 R 16	2.1 (31)	2.1 (31)	2.4 (35)	2.8 (41)
2.0L Duratorq-TDCi (DW) Diesel	215/55 R 16	2.3 (33)	2.1 (31)	2.6 (38)	2.8 (41)
Vehicles with a petrol engine and 1.6L Duratorq-TDCi (DV) Diesel	215/50 R 17	2.1 (31)	2.1 (31)	2.4 (35)	2.8 (41)
2.0L Duratorq-TDCi (DW) Diesel	215/50 R 17	2.3 (33)	2.1 (31)	2.6 (38)	2.8 (41)
Vehicles with a petrol engine and 1.6L Duratorq-TDCi (DV) Diesel	235/40 R 18	2.1 (31)	2.1 (31)	2.4 (35)	2.8 (41)
2.0L Duratorq-TDCi (DW) Diesel	235/40 R 18	2.3 (33)	2.1 (31)	2.6 (38)	2.8 (41)

Vehicle identification

VEHICLE IDENTIFICATION PLATE

Note: The vehicle identification plate design may vary to that shown.

Note: The information shown on the vehicle identification plate is dependant upon market requirements.




E85610

- A Vehicle identification number
- B Gross vehicle weight
- C Gross train weight
- D Maximum front axle weight
- E Maximum rear axle weight

The vehicle identification number and maximum weights are shown on a plate located on the lock side of the right-hand front door aperture at the bottom.

VEHICLE IDENTIFICATION NUMBER (VIN)




E87496

The vehicle identification number is stamped into the floor panel on the right-hand side, beside the front seat. It is also shown on the left-hand side of the instrument panel.

Technical specifications

TECHNICAL SPECIFICATIONS

Vehicle dimensions



E132736

Technical specifications

4-door


Item	Dimension description	Dimension in mm (inches)
A	Maximum length	4 534 (178.5)
B	Overall width including exterior mirrors	2 010 (79.1)
C	Overall height - EC kerb weight	1 451 - 1 484 (57.1 - 58.4)
D	Wheelbase	2 648 (104.3)
E	Front track	1 544 - 1 559 (60.8 - 61.4)
E	Rear track	1 534 - 1 549 (60.4 - 61)

5-door

Item	Dimension description	Dimension in mm (inches)
A	Maximum length	4 358 - 4 362 (171.6 - 171.7)
B	Overall width including exterior mirrors	2 010 (79.1)
C	Overall height - EC kerb weight	1 451 - 1 484 (57.1 - 58.4)
D	Wheelbase	2 648 (104.3)
E	Front track	1 544 - 1 559 (60.8 - 61.4)
E	Rear track	1 534 - 1 549 (60.4 - 61)

Technical specifications

Towing equipment dimensions



E132737

Technical specifications

4-door

Item	Dimension description	Dimension in mm (inches)
A	Bumper – centre of tow ball	77 - 80 (3 - 3.1)
B	Attachment point – centre of tow ball	5 (0.2)
C	Wheel centre – centre of tow ball	1 068 - 1 071 (42 - 42.2)
D	Centre of tow ball – side member	518 (20.4)
E	Distance between side members	1 037 (40.8)
F	Centre of tow ball – centre 1. attachment point	450 (17.7)
G	Centre of tow ball – centre 2. attachment point	750 (29.5)

5-door

Item	Dimension description	Dimension in mm (inches)
A	Bumper – centre of tow ball	81 - 83 (3.2 - 3.3)
B	Attachment point – centre of tow ball	5 (0.2)
C	Wheel centre – centre of tow ball	896 - 898 (35.3 - 35.4)
D	Centre of tow ball – side member	518 (20.4)
E	Distance between side members	1 036 (40.8)
F	Centre of tow ball – centre 1. attachment point	420 (16.5)
G	Centre of tow ball – centre 2. attachment point	720 (28.3)

Navigation introduction

GENERAL INFORMATION


Press the relevant button on the unit bezel to access the system functions. This will take you into the selected mode.


One hour mode

To conserve battery power, the system can be operated in one hour mode. If the ignition is off, press the ON/OFF button to switch the system on. The system will automatically switch off after one hour.


System notes


WARNINGS

 The front glass on the liquid crystal display may break if hit with a hard object. If the glass breaks, do not touch the liquid crystalline material. In case of contact with the skin, wash immediately with soap and water.

 The unit is a highgrade laser product which uses an invisible laser beam. If this is handled incorrectly it can emit dangerous rays. Do not attempt to look through any openings in the unit.

CAUTIONS


 Irregular shaped CDs and CDs with a scratch protection film or self adhesive labels attached should not be used. Warranty claims, where this type of disc is found to be inside an audio unit returned for repair, will not be accepted.


 Do not clean the unit with solvents or aerosol cleaning agents. Use only a damp cloth.


 Do not insert foreign objects into any of the unit disc drives or media card slots.

 Do not insert more than one disc into the unit disc drive.

CAUTIONS

 Use only 12 cm (4.7 inches) discs or 8 cm (3.1 inches) discs with a suitable adaptor.

 Do not attempt to open the unit. If the unit malfunctions consult your dealer.


 Improper use of settings and connections, other than those explained in this handbook, can damage the unit.

 Do not turn the ignition key or attempt to start the engine while the software is updating.


The system is recommended for use when the ignition key is turned to the accessory position or when the engine is running. If the system is used extensively when the engine is not running, care needs to be taken to avoid draining the battery.


ROAD SAFETY


WARNINGS

 The system provides you with information designed to help you reach your destination quickly and safely.

 For reasons of safety, the driver should only program the system when the vehicle is stationary.

 The system provides no assistance with respect to stop signs, traffic lights, areas under construction or other important safety information.

 Do not use the system until you have familiarised yourself with its operation.

 Only view the system display when driving conditions permit.

Navigation introduction

Safety information

Read and follow all stated safety precautions. Failure to do so may increase your risk of collision and personal injury. Ford Motor Company shall not be liable for any damages of any type arising from failure to follow these guidelines.

If detailed viewing of route instructions is necessary, pull off the road when it is safe to do so and park your vehicle.

Do not use the navigation system to locate emergency services.

To use the system as effectively and safely as possible, always use the latest navigation information. Your dealer will be able to assist with this.

Navigation Quick start

NAVIGATION QUICK START

Vehicles with mobile navigation system

CAUTION

 Using the system with the engine off will drain the battery.

Note: You will be charged when sending and receiving text messages.


Note: Refer to your phone handbook for all phone functions and operation.

Note: Keep the activation code (printed on the installation guide) in a safe place.

Note: Retain the activation text message in your mobile phone inbox.


Compatibility of phones

CAUTION

 As no common agreement exists, mobile phone manufacturers are able to implement a variety of profiles in their Bluetooth devices. Because of this, an incompatibility can occur between the phone and hands-free system, which in some cases may significantly degrade the system performance. To avoid this situation, only recommended phones should be used.

Please visit the website www.ford-mobile-connectivity.com for full details.

Installing the micro SD card



E114212

1. Remove the micro SD card from the adaptor.
2. Insert the micro SD card into the mobile phone.

Activating the mobile phone navigation system

Note: The radio must be switched on before connecting the mobile phone to the in-car GPS receiver.

Note: The Ford Mobile Navigation must be installed and activated on your mobile phone.

Note: It is possible to activate up to a **maximum** of three phones.

Note: Detailed instructions are available on the micro SD card and at www.ford-mobile-connectivity.com.

To connect the device to the system follow the same procedure as for Bluetooth hands free phones. See **Bluetooth setup** (page 256).

1. Switch the radio on.

Navigation Quick start



E114213

2. Switch your mobile phone on and start the "Ford Mobile Navigation".
3. Choose "Select Destination".
4. Choose "Enter Address".
5. Change route options if necessary and start the route guidance.
6. The vehicle display will show the turn information. Voice instructions are heard via the vehicle speakers.

Note: *Your mobile phone will display your current position.*

7. You are able to exit the application and continue your route guidance after restarting the application.

Vehicles with CD-SD navigation system or Sony CD-SD navigation system

The system has a large range of features, yet is easy and intuitive to use. Route guidance is shown on the display screen. The screen provides full information for operating the system through the use of menus, text screens and map displays. Screen selections are made by scrolling through the menus using the up, down, left and right arrow buttons and pressing the **OK** button to activate the desired setting.

Basic operation

1. Press either the **NAV** or **MENU** button to enter the menu structure.

2. Use the up, down, left and right arrow buttons and scroll through the various selection lists.
3. Press the **OK** button to activate your selection.

Selection lists

Various screens are presented which offer a selection list of available options.

1. Select the option you require, or if it is not shown on the screen use the up and down arrow buttons to view the remainder of the selection list.
2. Press the **OK** button to confirm your selection.

Alphanumeric keypad entry

When it is necessary to enter an address, a keypad will appear prompting you to enter a postcode, city, or street.

1. Use the up, down, left and right arrow buttons to select the letter or number that you require.

Note: *As you spell the entry the results will appear in the display.*

Note: *The system will limit your entries to only those characters which spell a valid entry.*

2. Press the **OK** button to activate your selection.

Route setting example

Navigation main screen

- To select the navigation system, press the **NAV** button. The road safety caution will be displayed. To use the system, read the caution and press the **OK** button.

Navigation Quick start

Destination input screen

- Use the up and down arrow buttons and scroll to **Destination input**.
- Press the OK button to activate your selection.

Note: *A list with several options is shown.*


- Starting from the top, select the country followed by either the postcode if available or city and street name.
- Use the alphanumeric keypad and selection lists to select your address details.
- Once sufficient information has been entered, scroll to **Start guidance** and press the **OK** button to activate your selection.

Note: *If you only need to navigate to a city centre for example, full address details are not required.*

- The route is now calculated and the screen returns to the main navigation screen with instructions on how to proceed.
- Follow the screen information and voice prompts to reach your destination.

Navigation unit overview

NAVIGATION UNIT OVERVIEW




E104157

A Descriptions for function buttons 1-4

Function buttons 1 to 4 are context dependent, and change according to the current unit mode. Descriptions for the functions are shown at the bottom of the screen display.

Navigation unit overview

Vehicles with CD-SD navigation system



E129241


- A CD eject.
- B Navigation arrows.
- C CD aperture.
- D OK.
- E Information.
- F Map select. See **Route displays** (page 234).
- G Menu select. See **System settings** (page 230).
- H Telephone keypad and station presets. See **Audio unit operation** (page 245). See **Audio unit menus** (page 248). See **Telephone** (page 256).
- I Clock. See **System settings** (page 230).
- J Traffic announcement. See **Traffic Message Channel** (page 235).
- K Function 4.

Navigation unit overview

- L Function 3.
- M Seek up. CD track selection. See **Station tuning control** (page 245). See **Track selection** (page 250).
- N On/off and volume control. See **On/off control** (page 245).
- O Seek down. CD track selection. See **Station tuning control** (page 245). See **Track selection** (page 250).
- P Function 2.
- Q Function 1.
- R Phone select. See **Telephone** (page 256).
- S Auxiliary select. See **Auxiliary input (AUX IN) socket** (page 254).
- T Radio select. See **Audio unit operation** (page 245). See **Audio unit menus** (page 248).
- U CD select. See **Compact disc player** (page 250).
- V Navigation select. See **System settings** (page 230).

Navigation unit overview

Vehicles with Sony CD-SD navigation system



E129242

- A On/off control. See **On/off control** (page 245).
- B Navigation select. See **System settings** (page 230).
- C Telephone keypad and station presets. See **Audio unit operation** (page 245). See **Audio unit menus** (page 248). See **Telephone** (page 256).
- D CD aperture.
- E Navigation arrows.
- F Map select. See **Route displays** (page 234).
- G CD eject.
- H Information.
- I Clock. See **System settings** (page 230).

Navigation unit overview

- J Seek up. CD track selection. end call. See **Station tuning control** (page 245). See **Track selection** (page 250). See **Using the telephone** (page 258).
- K Home select. See **System settings** (page 230).
- L Traffic announcement. See **Traffic Message Channel** (page 235).
- M Function 4.
- N Sound select. See **Sound button** (page 245).
- O Function 3.
- P OK.
- Q Function 2.
- R Menu select. See **System settings** (page 230).
- S Function 1.
- T Phone select. See **Telephone** (page 256).
- U Auxiliary select. See **Auxiliary input (AUX IN) socket** (page 254).
- V Seek down. CD track selection. accept call. See **Station tuning control** (page 245). See **Track selection** (page 250). See **Using the telephone** (page 258).
- W Radio select. See **Audio unit operation** (page 245). See **Audio unit menus** (page 248).
- X CD select. See **Compact disc player** (page 250).
- Y Volume control.

Navigation unit overview

LOADING THE NAVIGATION DATA

Loading the navigation data



E129900

1. Load the navigation SD card into the aperture.
2. Press the NAV button. The road safety warning will be shown in the display.
3. Use the up and down arrow buttons to select the required feature.
4. Press the OK button to confirm your selection.

For map updates and system upgrades please refer to your dealer.

System settings

SYSTEM SETTINGS

Most of the important settings for your navigation unit can be accessed via the **MENU** or **NAV** button. The following section describes the various options and how to use them.

For menu structures: See **Information displays** (page 82).

Menu structure - Information and entertainment display - Vehicles with navigation system

Route

This feature allows you to customise the route to your specific journey requirements (for example continue route guidance, block specific sections of your route or select specific sections of a route).

Destination input

This feature allows you to enter your destination details (for example enter city names, enter street names or pick a place from a map).

Traffic

This feature allows you to customise how you receive traffic information (for example review and sort traffic messages, review your route or block parts of your route).

Home address

This feature allows you to start the route guidance to your home address or change the details of your home address.

Note: *On Vehicles with a Sony CD-SD navigation system, press the **HOME** button and the system will automatically start route guidance to the listed home address.*

Last destinations

This feature allows quick access to a history of previous destinations entered in the system. A detailed display will show the complete stored information including an overview map. Select the required repeat destination from the list.

Favourites

This feature allows you to customize a personal destination address book and assign user defined names to addresses and locations. A detailed display will show the complete stored information including an overview map. Select the required repeat destination from the list.

Points of interest

This feature allows you to customise the route to your specific journey requirements (for example select a museum on route or a specific point of interest near your destination).

Tour planning

This feature allows you to enter a number of different destinations and select the order in which you wish to visit them. You can also modify an existing tour or recall a previous tour. The system will automatically calculate and display your chosen journey.

Store position

This feature allows you to store and name your current position.

Route options

This feature allows you to customise the route to your specific journey requirements (for example select the fastest or most economical route or select a route that will avoid tunnels, seasonal roads and toll roads).

System settings

Special functions

This feature allows you to select GPS and system information or a demonstration of the system functionality.

Map display

This feature allows you to change the way the map screen is displayed (for example clean 2D and clean 3D view) and to customise display information for your journey (for example time to arrival and lane guidance).

Assistance options

This feature allows you to customise display information for your journey (for example signs, lanes and speed limits).

Personal data

This feature allows you to edit and delete personal data (for example your home address).

Reset all settings

This feature allows you to reset the navigation settings.

Menu structure - Information and entertainment display - All vehicles

Audio settings

Adaptive volume

This feature allows you to adjust the volume level to compensate for engine and road speed noise. You can turn this on and off.

Sound

This feature allows you to adjust the sound settings (for example bass and treble).

Nav audio mixing

This feature allows you to adjust the volume mix between the navigation voice output and audio source.

DSP settings

This feature allows you to customise speaker output relevant to seat positions.

DSP equaliser

This feature allows you to select the music category that most suits your listening preference. The audio output will change to enhance the particular style of music chosen.

News

This feature allows you to receive news bulletins from stations on the FM waveband or radio data system (RDS) and enhanced other network (EON) linked stations, in the same way as traffic information is provided. You can turn this on and off.

Alternative frequencies

This feature will search for and switch to the strongest station signal when moving from one transmission area to another.

RDS regional

This feature controls the behaviour of AF switching between regionally related networks of a parent broadcaster.

DAB service link

This feature allows you to select stations that are broadcast on the DAB channels.

Bluetooth

This feature allows you to switch Bluetooth on or off.

System settings

Clock settings

Set time

This feature allows you to manually adjust the time.

Set date

This feature allows you to manually adjust the date, month and year.

GPS time

This feature allows you to, if in a suitable coverage area, automatically adjust the date and time using GPS.

Set time zone

This feature allows you select a specific time zone.

Summertime

This feature allows you set the system to adjust for seasonal time differences.

Note: *GPS time must be selected.*

24-hour mode

This feature allows you to adjust the system between 12 and 24-hour mode.

Navigation system

ROUTE OPTIONS MENU

You can set a number of options which alter the way a route is planned.

Using the up, down, left and right arrow buttons, you can select from the list which road features are to be avoided or included in the route by turning the feature on or off.

Route

Eco

This option will prioritise the most economical route to the destination.

Fast

This option will prioritise the fastest route to the destination.

Short

This option will prioritise the shortest route to the destination.

Always ask

Use this feature to make sure that you are always given the choice of route type selection for your journey.

Driver

Leisurely

This option will prioritise the route for a leisurely driver to the destination.

Normal

This option will prioritise the route for a normal driver to the destination.

Fast

This option will prioritise the route for a fast driver to the destination.

Eco settings

Trailer

Use this feature to change the economy settings of your journey relating to whether or not you are towing a trailer and if so the size of trailer being towed.

Roof box

Use this feature to change the economy settings of your journey relating to the use of a roof box.

Dynamic

When switched on, and if the unit is receiving a valid traffic message channel (TMC) signal, the route will be automatically updated to take into account real time traffic incidents or congestion.

Note: *This feature can be useful in avoiding delays or hold ups on journeys.*

Motorway

When switched on the system will look for motorways on your route and automatically update your route distance and timings.

Note: *This feature can be useful in avoiding delays or hold ups on journeys.*

Ferry/motorail

When switched on the system will look for ferry crossings and motorail facilities on your route and automatically update your route distance and timings.

Toll

When switched on the system will look for toll roads on your route and automatically update your route distance and timings.

Navigation system

Seasonal roads

When switched on the system will look for seasonal roads on your route and automatically update your route distance and timings.

Note: *This feature can be useful in avoiding delays or hold ups on journeys.*

Toll sticker

When switched on the system will automatically select toll roads and update your route distance and timings.

ROUTE DISPLAYS

Map display

Press the **MAP** button for a map view.

This view will show your current location with your vehicle in the centre shown as an arrow surrounded by a circle. The arrow will face in the direction of travel.

The information on the top line gives the name of the current road, or the next road to take if a turn is approaching.

You can change the way the map is displayed by altering the zoom and orientation settings. Press the relevant function buttons to change the map scale and using the left and right arrow buttons zoom in or out. The current map scale is shown on the display.

Map scale settings may be set between 50 m to 500 km or 0.05 miles to 500 miles, with an auto setting to the far left. The auto setting continuously changes the map scale according to the road type being driven.

Junction zoom

This feature will automatically increase the zoom on the map display at times when you are required to make a turn, or perform more complex manoeuvres. Shortly after the zoom scale will return to the previous level.

Select AUTO to activate junction zoom.

Navigation display

After commencing a navigation route, the default screen is the main navigation screen:

Once an active route is underway, guidance will be given by on-screen information and voice prompts. Whichever audio source you wish to leave the unit in, basic turn by turn and distance information will remain on the screen in the form of a graphic inset. You do not need to leave the unit on the main navigation screen when you are navigating a route. Slightly more detailed information on your route may be available via the main navigation screen if required.

WARNING



Do not rely on the screen prompts when navigating. Always listen to the navigation voice and take care not to be distracted from the road ahead.

Traffic Message Channel

PRINCIPLE OF OPERATION

Traffic message channel (TMC) stations are broadcast on the FM waveband. TMC is a feature that receives traffic alerts which can be used to plan alternative routes and avoid hold ups.

Select the required item to display a list of TMC messages. This is only an overview display which gives very basic information. Select the message you require further information on and another screen will be displayed giving full message details on incident location etc.

USING TMC

Press the **TA** or **TRAFFIC** button to show the traffic menu page.

Traffic announcement

Traffic announcement (TA) can be turned on or off via this menu. If switched on a **TA** indicator is shown in the information border of the status bar.

Stations which broadcast on the FM waveband and carry traffic programme (TP) information are identified by **TP** shown in the screen display. With TA switched on the unit will respond to these announcements and interrupt music playback. After the announcement has ended music playback will resume.

Ending traffic announcements

The unit will return to normal operation at the end of each traffic announcement. To end the announcement prematurely, press the **TA** or **TRAFFIC** button during the announcement.

Using TMC messages

To review TMC messages, you may either select a view which shows messages only affecting your programmed route, or a view which shows all messages received.

Map updates

MAP UPDATES

The road network is constantly changing due to new roads, changes in road classification, etc. Therefore, it is not always possible to exactly match the map data in the system to the current road network.

Map information is regularly updated, but all areas are not necessarily covered to the same level of detail. Some roads, in particular private roads, may not be included on the database. To help with accuracy, always use the latest version navigation disc. Your dealer will be able to provide this.

Audio introduction

IMPORTANT AUDIO INFORMATION

WARNINGS



Due to technical incompatibility, recordable (CD-R) and rewritable (CD-RW) discs may not function correctly.



These CD radio units will play compact discs that conform to the International Red Book standard audio specification. Copy protected CDs from some manufacturers do not conform to this standard and playback cannot be guaranteed.



Dual format, dual sided discs (DVD Plus, CD-DVD format), adopted by the music industry, are thicker than normal CDs and consequently playback cannot be guaranteed, and jamming could occur. Irregular shaped CDs and CDs with a scratch protection film or self adhesive labels attached should not be used. Warranty claims, where this type of disc is found to be inside an audio unit returned for repair, will not be accepted.



All CD units are designed to play commercially pressed 12 cm audio compact discs only.



The audio unit may be damaged if unsuitable items like credit cards or coins are pushed inside the CD aperture.

CAUTION—INVISIBLE LASER RADIATION WHEN OPEN
DO NOT STARE INTO BEAM OR
VIEW DIRECTLY WITH OPTICAL INSTRUMENTS

Disc labels

Audio CD



MP3



Audio unit labels


CLASS 1
LASER PRODUCT

Audio unit overview

AUDIO UNIT OVERVIEW

Note: Units have an integrated multi function display situated above the CD aperture. This shows important information regarding control of your audio unit. Additionally, there are various icons placed around the display screen which light up when a function is active (for example CD, Radio or Aux.)

Type 1




E130324

- A CD eject. See **Compact disc player** (page 250).
- B Navigation arrows.
- C CD aperture. See **Compact disc player** (page 250).
- D OK.
- E Information.
- F Traffic announcement. See **Traffic information control** (page 246).
- G Station presets. See **Station preset buttons** (page 246).

Audio unit overview

- H Seek up. CD track selection. See **Station tuning control** (page 245). See **Track selection** (page 250).
- I On/off and volume control.
- J Seek down. CD track selection. See **Station tuning control** (page 245). See **Track selection** (page 250).
- K Menu select.
- L Sound button. See **Sound button** (page 245).
- M Auxiliary select. See **Auxiliary input (AUX IN) socket** (page 118). See **Auxiliary input (AUX IN) socket** (page 254).
- N Radio and waveband select. See **Audio unit operation** (page 245).
- O CD select. See **Compact disc player** (page 250).


Type 2



E104157

- A Descriptions for function buttons 1-4

Audio unit overview



E130142


- A CD eject. See **Compact disc player** (page 250).
- B Navigation arrows.
- C CD aperture. See **Compact disc player** (page 250).
- D OK.
- E Information.
- F Traffic announcement. See **Traffic information control** (page 246).
- G Sound button. See **Sound button** (page 245).
- H Telephone keypad and station presets. See **Using the telephone** (page 258). See **Station preset buttons** (page 246).
- I Function 4.
- J Function 3.
- K Seek up. CD track selection. See **Station tuning control** (page 245). See **Track selection** (page 250).

Audio unit overview

- L On/off and volume control.
- M Seek down. CD track selection. See **Station tuning control** (page 245). See **Track selection** (page 250).
- N Function 2.
- O Function 1.
- P Menu select.
- Q Phone menu. See **Telephone** (page 256).
- R Auxiliary, USB and iPod select. See **Auxiliary input (AUX IN) socket** (page 118). See **Auxiliary input (AUX IN) socket** (page 254). See **Connectivity** (page 276).
- S Radio and waveband select. See **Audio unit operation** (page 245).
- T CD select. See **Compact disc player** (page 250).


Function buttons 1 to 4 are context dependent, and change according to the current unit mode. Descriptions for the functions are shown at the bottom of the screen display.

Type 3



- A Descriptions for function buttons 1-4

Audio unit overview



E129074

- A On/off control.
- B Display select.
- C Telephone keypad and station presets. See **Using the telephone** (page 258). See **Station preset buttons** (page 246).
- D CD aperture. See **Compact disc player** (page 250).
- E Navigation arrows.
- F DSP select. See **Digital signal processing (DSP)** (page 248).
- G CD eject. See **Compact disc player** (page 250).
- H Information.
- I Clock.
- J Seek up. CD track selection. End call. See **Station tuning control** (page 245). See **Track selection** (page 250). See **Using the telephone** (page 258).

Audio unit overview

- K Mute.
- L Traffic announcement. See **Traffic information control** (page 246).
- M Function 4.
- N Sound button. See **Sound button** (page 245).
- O Function 3.
- P OK.
- Q Function 2.
- R Menu select.
- S Function 1.
- T Phone menu. See **Telephone** (page 256).
- U Auxiliary select. See **Auxiliary input (AUX IN) socket** (page 118). See **Auxiliary input (AUX IN) socket** (page 254).
- V Seek down. CD track selection. Accept call. See **Station tuning control** (page 245). See **Track selection** (page 250). See **Using the telephone** (page 258).
- W Radio and waveband select. See **Audio unit operation** (page 245).
- X CD select. See **Compact disc player** (page 250).
- Y Volume control.

Function buttons 1 to 4 are context dependent, and change according to the current unit mode. Descriptions for the functions are shown at the bottom of the screen display.

Audio system security

SECURITY CODE

Each unit incorporates a unique code that is linked to the vehicle identification number (VIN). The system will automatically check that the audio unit and vehicle match before allowing operation.

If a security code message appears, please see your dealer.

Audio unit operation

ON/OFF CONTROL

Press the on/off control. This will also operate the unit for up to one hour with the ignition turned off.

The radio will switch off automatically after one hour.

SOUND BUTTON

This will allow you to adjust the sound settings (for example bass and treble).

1. Press the sound button.
2. Use the up and down arrow buttons to select the required setting.
3. Use the left and right arrow buttons to make the necessary adjustment. The display indicates the level selected.
4. Press the **OK** button to confirm the new settings.

WAVEBAND BUTTON

Press the RADIO button to select from the wavebands available.

The selector can also be used to return to radio reception when you have been listening to another source.

Alternatively, press the left arrow button to display the available wavebands. Scroll to the required waveband and press OK.

STATION TUNING CONTROL

Seek tuning

Select a waveband and briefly press one of the seek buttons. The unit will stop at the first station it finds in the direction you have chosen.

Manual tuning

Type 1

1. Press the MENU button.
2. Select RADIO mode and then MANUAL TUNE.
3. Use the left and right arrow buttons to tune down or up the waveband in small increments or press and hold to increment quickly, until you find a station you want to listen to.
4. Press OK to continue listening to a station.

Type 2 and 3

1. Press function button 2.
2. Use the left and right arrow buttons to tune down or up the waveband in small increments or press and hold to increment quickly, until you find a station you want to listen to.
3. Press OK to continue listening to a station.

Scan tuning

Scan allows you to listen to a few seconds of each station detected.

Type 1

1. Press the MENU button.
2. Select RADIO mode and then SCAN.
3. Use the seek buttons to scan up or down the selected waveband.
4. Press OK to continue listening to a station.

Type 2 and 3

1. Press function button 3.
2. Use the seek buttons to scan up or down the selected waveband.
3. Press function button 3 again or OK to continue listening to a station.

Audio unit operation

STATION PRESET BUTTONS

This feature allows you to store your favourite stations so that they can be recalled by selecting the appropriate waveband and pressing one of the preset buttons.

1. Select a waveband.
2. Tune to the station required.
3. Press and hold one of the preset buttons. A progress bar and message will appear. When the progress bar completes the station has been stored. The audio unit will also mute momentarily as confirmation.

This can be repeated on each waveband and for each preset button.

Whilst in radio mode, stored stations can also be selected by pressing the arrow up, down, right or OK buttons. Then scroll to the desired preset station and press OK.

Note: *When you drive to another part of the country, FM stations that broadcast on alternative frequencies, and are stored on preset buttons, may be updated with the correct frequency for that area.*

AUTOSTORE CONTROL

Note: *This will store up to a maximum of the 10 strongest signals available, either from the AM or the FM waveband, and overwrite the previously stored stations. It can also be used to store stations manually in the same way as other wavebands.*

Note: *On type 3 you must select either FM AST or AM AST to use this function.*

- Press and hold function button 1 or the RADIO button.
- When the search is complete, sound is restored and the strongest signals are stored on the Autostore presets.

TRAFFIC INFORMATION CONTROL

Many stations that broadcast on the FM waveband have a TP code to signify that they carry traffic programme information.

Activating traffic announcements

Before you can receive traffic announcements, you must press either the TA or TRAFFIC button. A 'TA' display will appear to show the feature is switched on.

If you are already tuned to a station that broadcasts traffic information, 'TP' will also be displayed. Otherwise the unit will search for a traffic programme.

When traffic information is broadcast, it will automatically interrupt normal radio or CD playback and 'Traffic announcement (TA)' will appear in the display.

If a non-traffic station is selected or recalled using a preset button, the audio unit will remain on that station unless TA or TRAFFIC is turned off, then on again.

Note: *If TA is on and you select a preset or manual tune to a non TA station no traffic announcement will be heard.*

Note: *When you are listening to a non TA station and turn TA off and on again a TP seek will occur.*

Audio unit operation

Traffic announcement volume

Traffic announcements interrupt normal broadcasts at a preset minimum level that is usually louder than normal listening volumes.

To adjust the preset volume:

- Use the volume control to make the necessary adjustment during an incoming TA broadcast. The display will show the level selected.

Ending traffic announcements

The audio unit will return to normal operation at the end of each traffic announcement. To end the announcement prematurely, press TA or TRAFFIC during the announcement.

Note: *If you press TA or TRAFFIC at any other time it will switch all announcements off.*

Audio unit menus

AUTOMATIC VOLUME CONTROL

When available, automatic volume control (AVC) adjusts the volume level to compensate for engine noise and road speed noise.

1. Press the MENU button and select AUDIO.
2. Select AVC LEVEL or ADAPTIVE VOL.
3. Use the left or right arrow button to adjust the setting.
4. Press the OK button to confirm your selection.
5. Press the MENU button to return.

DIGITAL SIGNAL PROCESSING (DSP)

DSP occupancy

This feature takes into account the differences in distance from the various speakers in the vehicle to each seat. Select the sitting position for which the audio is to be correctly enhanced.

DSP equaliser

Select the music category that most suits your listening preference. The audio output will change to enhance the particular style of music chosen.

Changing the DSP settings

1. Press the MENU button.
2. Select AUDIO or AUDIO SETTINGS.
3. Scroll to the required DSP function.
4. Use the up and down arrow buttons to select the required setting.
5. Press the OK button to confirm your selection.
6. Press the MENU button to return.

NEWS BROADCASTS

Some audio units interrupt normal reception to broadcast news bulletins from stations on the FM waveband or radio data system (RDS) and enhanced other network (EON) linked stations, in the same way as traffic information is provided.

During news broadcasts, the display will indicate there is an incoming announcement. News interrupts are broadcast at the same preset volume level as traffic announcements.

1. Press the MENU button.
2. Select AUDIO or AUDIO SETTINGS.
3. Scroll to NEWS and turn on or off with the OK button.
4. Press the MENU button to return.

ALTERNATIVE FREQUENCIES

Many programmes that broadcast on the FM waveband have a programme identification (PI) code, which can be recognised by audio units.

If your radio has alternative frequencies (AF) tuning switched on and you move from one transmission area to another, this facility will search for and switch to a stronger station signal, if one can be found.

Under certain conditions, however, AF tuning may temporarily disrupt normal reception.

Audio unit menus

When selected, the unit continually evaluates signal strength and, if a better signal becomes available, the unit will switch to that alternative. It mutes while it checks a list of alternative frequencies and, if necessary, it will search once across the selected waveband for a genuine alternative frequency.

It will restore radio reception when it finds one or, if one is not found, the unit will return to the original stored frequency.

When selected, 'AF' will be shown in the display.

1. Press the MENU button.
 2. Select AUDIO or AUDIO SETTINGS.
 3. Scroll to RDS REGIONAL and turn on or off with the OK button.
 4. Press the MENU button to return.
1. Press the MENU button.
 2. Select AUDIO or AUDIO MENU.
 3. Scroll to ALTERNAT FREQ. or ALTERNATIVE FREQ. and turn on or off with the OK button.
 4. Press the MENU button to return.

REGIONAL MODE (REG)

Regional mode (REG) controls the behaviour of AF switching between regionally related networks of a parent broadcaster. A broadcaster may run a fairly large network across a large part of the country. At various times of the day this large network may be broken down into a number of smaller regional networks, typically centred on major towns or cities. When the network is not split into regional variants, the whole network carries the same programming.

Regional mode ON: This prevents 'random' AF switches when neighbouring regional networks are not carrying the same programming.

Regional mode OFF: This allows a larger coverage area if neighbouring regional networks are carrying the same programming, but can cause 'random' AF switches if they are not.

Compact disc player

COMPACT DISC PLAYBACK

Note: During playback, the display indicates the disc, track and time that has elapsed since the start of the track.

During radio reception, press the CD button once to start CD playback.

Playback will start immediately after a disc is loaded.

TRACK SELECTION

- Press the seek up button once to move to the next track or press it repeatedly to access later tracks.
- Press the seek down button once to replay the current track. If pressed within two seconds of the start of a track, the previous track will be selected.
- Press the seek down button repeatedly to select previous tracks.
- Press the up or down arrow buttons, and using the OK button, select the required track.

Type 2 and 3

The desired track number may be entered using the numeric keypad. Dial the required track number until complete (for example 1 then 2 for track 12), or dial the number and directly press OK.

FAST FORWARD/REVERSE

Press and hold the seek down or up buttons to search backwards or forwards within the tracks on the disc.

SHUFFLE/RANDOM

Random track playback, also known as shuffle, plays all tracks on the CD in random order.

Type 1

1. Press the MENU button and select CD MODE.
2. Select SHUFFLE, which then enables the function to be selected on or off.

When an MP3 CD is playing, options include SHUFFLE for the whole CD, or to play all the tracks in the folder in a random order.

Type 2 and 3

Press function button 2.

Note: When an MP3 CD is playing, options include SHUFFLE for the whole CD, or to play all the tracks in the folder in a random order. Repeat presses of function button 2 will toggle these options.

Use the seek up or down button to select the next track to shuffle if required.

REPEAT COMPACT DISC TRACKS

Type 1

1. Press the MENU button and select CD MODE.
2. Select REPEAT, which then enables the function to be selected on or off. The track will replay once ended.

When an MP3 CD is playing, options include REPEAT for the track, or to repeat all the tracks in the folder.

Type 2 and 3

Press function button 1.

Compact disc player

When an MP3 CD is playing, options include REPEAT for the track, or to repeat all the tracks in the folder. Repeat presses of function button 1 will toggle these options.

COMPACT DISC TRACK SCANNING

The SCAN function allows you to preview each track for approximately 5 seconds.

Type 1

Various scan modes are possible, according to the type of CD currently playing.

1. Press the MENU button and select CD MODE.
2. Select SCAN, which then enables the function to be selected on or off.

Note: *When an MP3 CD is playing, options include SCAN for the CD, or just the tracks in the folder.*

3. Press the OK button to stop the scan mode.

Type 2 and 3

1. Press function button 3.

Note: *When an MP3 CD is playing, options include SCAN for the CD, or just the tracks in the folder. Repeat presses of function button 3 will toggle these options.*

2. Press function button 3 again to stop the scan mode.

MP3 FILE PLAYBACK

MP3 (MPEG 1 Audio Layer-3) is a standard technology and format for compressing audio data. This allows a more efficient use of the media.

You can play MP3 files recorded on CD-ROMs, CD-Rs, and CD-RWs. The disc must be in the ISO 9660 level 1 or level 2 format, or Joliet or Romeo in the expansion format. You can also use a disc recorded in Multi Session.

ISO 9660 format

This is the most common international standard for the logical format of files and folders on a CD-ROM.

There are several specification levels. In Level 1, file names must be in the 8.3 format (no more than 8 characters in the name, no more than 3 characters in the extension ".MP3") and in capital letters.

Folder names can be no longer than 8 characters. There can be no more than 8 folder levels (trees). Level 2 specifications allow file names up to 31 characters long.

Each folder can have up to 8 trees.

For Joliet or Romeo in the expansion format, please consider these restrictions when configuring your CD writing software.

Multi session

This is a recording method that enables adding of data using the Track-At-Once method.

Conventional CDs begin at a CD control area called the Lead-in and end at an area called Lead-out. A Multi Session CD is a CD having multiple sessions, with each segment from Lead-in to Lead-out regarded as a single session.

- CD-Extra: The format that records audio (audio CD data) as tracks on session 1, and records data as tracks on session 2.
- Mixed CD: In this format, data is recorded as track 1, and audio (audio CD data) is recorded as track 2.

Compact disc player

File formats

- With formats other than ISO 9660 level 1 and level 2, folder names or file names may not be displayed correctly.
- When naming, be sure to add the file extension “.MP3” to the file name.
- If you put the extension “.MP3” to a file other than MP3, the unit cannot recognize the file properly and will generate random noise that could damage your speakers.
- The following discs take a longer time to start playback.
 - a disc recorded with complicated tree structure.
 - a disc recorded in Multi Session.
 - a non-finalised disc to which data can be added.

Playing a multi session disc

When the first track of the first session is audio CD data

Only audio CD data of the first session is played back. Non-audio CD data/MP3 file information (track number, time, etc.) is displayed with no sound.

When the first track of the first session is not audio CD data


- If an MP3 file is in the disc, only MP3 file(s) play back and other data is skipped. (Audio CD data is not recognised.)
- If no MP3 file is in the disc, nothing is played back. (Audio CD data is not recognised.)

MP3 files playback order

The playback order of the folders and files is as shown.

Note: A folder that does not include an MP3 file is skipped.

Playback tip: To specify a desired playback order, before the folder or file name, input the order by number (e.g., “01,” “02”), then record contents onto a disc. (The order differs depending on the writing software.)



E104206

ID3 Tag Version 2

The following occurs when an MP3 file containing ID3 tag ver.2 is played:

- When skipping a portion of ID3 tag ver.2 (at the beginning of the track), sound is not output. Skip time changes depending ID3 tag ver.2 capacity. Example: At 64 kbytes, it is about 2 seconds (with RealJukebox).
- The displayed elapsed playing time when skipping a portion of ID3 tag ver.2 is inaccurate. For MP3 files of a bit rate other than 128 kbps, time is not displayed accurately during playback.
- When an MP3 file is created with MP3 conversion software (e.g. RealJukebox - a registered trademark of RealNetworks Inc), ID3 ver.2 will automatically be written.

Compact disc player

MP3 navigation

MP3 tracks may be recorded on the CD in several ways. They can all be placed in the root directory like a conventional audio CD, or they can be placed in folders that may represent, for example, an album, an artist, or a genre.

The normal playing sequence on CDs with multiple folders is to play the tracks within the root (top level) first, then the tracks in any folder(s) within the root, then move onto the second folder, and so forth.

- Press the up or down arrow buttons to enter the track list.
- Navigate the hierarchy using the arrow buttons to select another folder or track (file).
- Press OK to select a highlighted track.

MP3 DISPLAY OPTIONS

Note: *Type 1 units may require repeated button presses of the INFO button to display all the available track information.*

When an MP3 disc is playing, certain information encoded in each track can be displayed. Such information will normally include:

- The file name
- The folder name
- ID3 information which might be the album or artist's name

The unit will normally show the file name that is playing. To select one of the other items of information:

- Press the INFO button.

CD text display options

When an audio disc with CD text is playing, limited information encoded in each track can be displayed. Such information will normally include:

- The disc name
- The artist name
- The track name

These display options are selected in the same way as MP3 displays.

ENDING COMPACT DISC PLAYBACK

To restore radio reception on all units:

- Press the RADIO button.

Note: *This will not eject the CD; the disc will merely pause at the point where radio reception was restored.*

To resume CD playback, press the CD button again.

Auxiliary input (AUX IN) socket

AUXILIARY INPUT (AUX IN) SOCKET

Note: *For optimum performance when using any auxiliary device set the volume on the device high. This will reduce audio interference when charging the device via the vehicle power supply socket.*

When fitted the Auxiliary input (AUX IN) socket permits an auxiliary device, such as an MP3 player, to be linked into the vehicle audio system. Output can be played through the vehicle speakers.

To connect an auxiliary device, plug it into the AUX IN socket using a 3.5 mm conventional audio jack connector.

Select the auxiliary input via the AUX button and playback will be heard through the vehicle speakers. LINE IN or LINE IN ACTIVE will appear in the vehicle audio unit display. Volume, treble and bass can be adjusted on the vehicle audio unit as normal.

The vehicle audio unit buttons can also be used to restore playback from the vehicle audio unit, while the auxiliary device remains connected.

Audio troubleshooting


AUDIO TROUBLESHOOTING

Audio unit display	Rectification
PLEASE CHECK CD	General error message for CD fault conditions, such as cannot read the CD, data-CD inserted, etc. Ensure disc is loaded correct way up. Clean and re-try, or replace disc with known music disc. If error persists contact your dealer.
CD DRIVE MALFUNCTION	General error message for CD fault conditions such as possible mechanism fault.
CD DRIVE HIGH TEMP	Ambient temperature too hot – unit will not work until it has cooled down.
IPOD ERROR READING DEVICE	General error message for iPod fault conditions, such as cannot read the data. Ensure iPod is inserted correctly. If error persists contact your dealer.

Telephone

GENERAL INFORMATION

CAUTION


 Using the system with the engine off will drain the battery.

This section describes the functions and features of the Bluetooth mobile phone hands free system.

The Bluetooth mobile phone part of the system provides interaction with the audio or navigation system and your mobile phone. It allows you to use the audio or navigation system to make and receive calls without having to hold your mobile phone.

Compatibility of phones

CAUTION

 As no common agreement exists, mobile phone manufacturers are able to implement a variety of profiles in their Bluetooth devices. Because of this, an incompatibility can occur between the phone and hands-free system, which in some cases may significantly degrade the system performance. To avoid this situation, only recommended phones should be used.

Please visit the website www.ford-mobile-connectivity.com for full details.

BLUETOOTH SETUP

Before you can use your telephone with your vehicle it must be bonded to the vehicle telephone system.

Handling of phones

Up to six Bluetooth devices can be bonded to the vehicle system.

Note: *If there is an ongoing call when the phone in use is selected as the new active phone, the call is transferred to the vehicle audio system.*

Note: *Even if connected to the car system, your phone can still be used in the usual way.*

Requirements for Bluetooth connection

The following are required before a Bluetooth phone connection can be made.

1. The Bluetooth feature must be activated on the phone and on the audio unit. Make sure the Bluetooth menu option in the audio unit is set to **ON**. For information on phone settings, refer to your phone user guide.
2. In the Bluetooth menu on your phone, search for **Ford Audio** and select it.
3. Enter the code number shown on the vehicle display using the phone keypad. If no code number is shown on the display, enter the Bluetooth PIN number 0000 using the phone keypad. Now enter the Bluetooth PIN number shown on the vehicle display.
4. If your mobile phone asks you to authorize the automatic connection, select **YES**.

Note: *A phone call will be disconnected if the audio unit is switched off. If the ignition key is turned to the off position the phone call will remain in progress.*

TELEPHONE SETUP

Phonebook

Note: *It may be necessary to confirm phonebook access to the Bluetooth system via the mobile phone.*

Telephone

After start up access to the phonebook list can be delayed for several minutes, depending upon the size.

Phonebook categories

The category is indicated as an icon:



Phone



Mobile



Home



Office

Making a phone an active phone

Note: If there is an ongoing call when the phone in use is selected as the new active phone, the call is transferred to the vehicle audio system.

When using the system for the first time, no phone is connected to the system.

After switching on the ignition and the audio unit, the Bluetooth phone must be bonded to the system. See **Bluetooth setup** (page 256).

After bonding a Bluetooth phone to the system, this becomes the active phone. For further information refer to the phone menu.

Select the phone from the active phone menu.

Turning the ignition and radio back on again, the last active phone is picked up by the system.

Note: In some cases the Bluetooth connection must also be confirmed on the phone.

Bond another Bluetooth phone


Bond a new Bluetooth phone as described in the requirements for a Bluetooth connection.

Phones stored in the system are accessible by using the phone list on the audio unit.

Note: A maximum of six devices may be bonded. If six Bluetooth devices have already been bonded, one of these has to be debonded in order to bond a new device.

TELEPHONE CONTROLS

Remote control



E129649

- A Volume up
- B Voice button
- C End call
- D Volume down
- E Receive call

Telephone

USING THE TELEPHONE

Note: Refer to your audio guide for details of the controls. See **Audio unit overview** (page 238).

Note: You can exit the phone menu by pressing any source button **CD**, **RADIO** or **AUX**.

Note: When referred to, the use of the up/down arrow buttons, seek up and seek down buttons, and the **OK** button can be used on either the steering wheel or the audio unit.

This chapter describes the phone functions of the audio unit.

An active phone must be present.

Even if connected to the audio unit, your phone can still be used in the usual way.

Making a call

Dialling a number using voice control

Phone numbers can be dialled using voice control. See **Telephone commands** (page 268).

Dialling a number using the address book

1. Press the **PHONE** button.
2. Press the up/down arrow buttons until **PHONEBOOK** is shown.
3. Press the **OK** button.

Note: You can also use the telephone keypad to select the first letter of the entry you are looking for. Press the relevant number that corresponds to the letter repeatedly until the required letter is displayed.

4. Press the up/down arrow buttons to select the desired phone number.

Note: Press and hold the up/down arrow buttons to search forwards or backwards within the phonebook.

5. Press the **OK** button to dial the selected phone number.

Dialling a number using the telephone keypad

1. Press the **PHONE** button.
2. Dial the number using the telephone keypad on the audio unit.
3. Press the **OK** button.

Note: If you enter an incorrect digit whilst entering a phone number, press function button 3 to erase the last digit. A long press will erase the complete string of digits.

Ending a call

Calls can be ended by:

- pressing the seek up button
- pressing the **OK** button
- pressing function button 4.

Redialling a number

1. Press the **PHONE** button.
2. Press the up/down arrow buttons until **CALL LISTS** is displayed.
3. Press the **OK** button.

Note: If the active phone does not provide a call out list, the last outgoing call number/entry can be redialled.

4. Press the up/down buttons to select the desired call list.
5. Press the **OK** button.
6. Press the up/down buttons to select the desired phone number.
7. Press the **OK** button.

Redialling the last dialled number

1. Press the **PHONE** button.

Telephone

2. Press the up/down arrow buttons until **REDIAL** is displayed.
3. Press the **OK** button.

Receiving an incoming call

Accepting an incoming call

Incoming calls can be accepted by pressing the seek down button, or by pressing the **OK** button.

Rejecting an incoming call

Incoming calls can be rejected by:

- pressing the seek up button, or
- pressing the arrow down button to highlight **REJECT** and then pressing the **OK** button.

Receiving a second incoming call

Note: *The second incoming call function must be activated in your phone.*

If there is an incoming call whilst there is an ongoing call, a beep will be heard and you will have the option to end the active call and to accept the incoming call.

Accepting a second incoming call

Note: *The first incoming call will be disconnected and replaced by the second incoming call.*

Second incoming calls can be accepted by pressing the seek down button on the steering wheel or on the audio unit, or by pressing the **OK** button on the audio unit.

Rejecting a second incoming call

Second incoming calls can be rejected by:

- pressing the seek up button, or
- pressing the arrow down button to highlight **REJECT** and then pressing the **OK** button.

Second incoming calls can be rejected by pressing function button 4.

Muting the microphone

Note: *During a call, it is possible to mute the microphone. Whilst muted, confirmation will appear in the display.*

Press function button 1. Press the button once again to turn this function off.

Changing the active phone

Note: *Phones must be bonded to the system before they can be made active.*

Note: *After bonding a phone to the system, this becomes the active phone.*

1. Press the **PHONE** button.
2. Press the up/down buttons until **SELECT PHONE** is shown.
3. Press the **OK** button.
4. Scroll through the different stored phones by using the up/down buttons to display the bonded phones.
5. Press the **OK** button to select the phone which is to be the active phone.

Debonding a bonded phone

A bonded phone can be deleted from the system at any time, unless a phone call is in progress.

1. Press the **PHONE** button.
2. Press the up/down buttons until **SELECT PHONE** is shown.
3. Press the **OK** button.
4. Press the up/down buttons to highlight the required phone.
5. Press function button 1.

Voice control

PRINCIPLE OF OPERATION

CAUTION

 Using the system with the engine off will drain the battery.

Voice recognition enables operation of the system without the need to divert your attention from the road ahead in order to change settings, or receive feedback from the system.

Whenever you issue one of the defined commands with the system active, the voice recognition system converts your command into a control signal for the system. Your inputs take the form of dialogues or commands. You are guided through these dialogues by announcements or questions.

Please familiarise yourself with the functions of the system before using voice recognition.

Supported commands

The voice control system allows you to control the following vehicle functions:

- Bluetooth phone
- radio
- CD Player
- external device (USB)
- external device (iPod)
- automatic climate control

System response

As you work through a voice session the system will prompt you with a beep tone each time the system is ready to proceed.

Do not try to give any commands until the beep tone has been heard. The voice control system will repeat each spoken command back to you.

If you are not sure how to continue say "HELP" for assistance or "CANCEL" if you do not wish to continue.

The "HELP" function provides only a subset of the available voice commands. Detailed explanations of all possible voice commands can be found on the following pages.

Voice commands

All voice commands should be given using a natural speaking voice, as if speaking to a passenger or on the phone. Your voice level should be dependant on the surrounding noise level inside or outside the vehicle but do not shout.

USING VOICE CONTROL

System operation

The order and content of the voice controls are given in the following lists. The tables show the sequence of user voice commands and system responses for each available function.

<> indicates a number or stored name tag to be inserted by the user.

Short cuts

There are a number of voice command short cuts available, which allow you to control some vehicle features without having to follow the complete command menu. These are:

- phone: "MOBILE NAME", "DIAL NUMBER", "DIAL NAME", and "REDIAL"
- automatic climate control: "TEMPERATURE", "AUTO MODE", "DEFROSTING/DEMISTING ON" and "DEFROSTING/DEMISTING OFF"
- radio: "TUNE NAME"

Voice control

- external device (USB): "TRACK"
- external device (iPod): "TRACK"

Start communicating with the system

Before you can start talking to the system you first have to press the **VOICE** button for each operation and wait until the system answers with a beep. See **Voice control** (page 49).

Press the button again to cancel the voice session.

Name tag

The name tag functionality can support the phone, audio and navigation features by using the "STORE NAME" function. You can assign name tags to items such as favourite radio stations and personal phone contacts. See **Audio unit commands** (page 261). See **Telephone commands** (page 268).

- Store up to 20 name tags per function.
- The average recording time for each name tag is approximately 2-3 seconds.

AUDIO UNIT COMMANDS

CD Player

You can control playback directly by voice control.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu in selected examples.

"CD PLAYER"
"HELP"
"PLAY"
"TRACK"*
"SHUFFLE ALL "
"SHUFFLE FOLDER"**
"SHUFFLE OFF"
"REPEAT FOLDER"**
"REPEAT TRACK"
"REPEAT OFF"

* Can be used as a shortcut.

** Only available if the CD contains audio data files like MP3.

Voice control

Track

You can choose a track on your CD directly.

Steps	User says	System answer
1	"CD PLAYER"	"CD PLAYER"
2	"TRACK"*	"TRACK NUMBER PLEASE"
3	"<a number between 1 and 99>"**	"TRACK <number>"

* Can be used as a shortcut.

** Additionally, numbers can be spoken as up to four single digits (for example "2", "4", "5" for track 245)

Shuffle all

To set random playback.

Steps	User says	System answer
1	"CD PLAYER"	"CD PLAYER"
2	"SHUFFLE ALL"	

Radio

The radio voice commands support the functionality of the radio and allow you to tune radio stations by voice control.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu.

"RADIO"
"HELP"
"AM"
"FM"
"TUNE NAME"*
"DELETE NAME"
"DELETE DIRECTORY"
"PLAY DIRECTORY"

Voice control

"RADIO"
"STORE NAME"
"PLAY"

* Can be used as a shortcut.

Tune frequency

This function allows you to tune your radio by voice commands.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"AM"	"AM FREQUENCY PLEASE"
	"FM"	"FM FREQUENCY PLEASE"
3	"<frequency>"*	"TUNE <frequency>"

* The frequency may be entered in a variety of ways. Refer below for representative examples.

FM band: 87.5 - 108.0 in increments of 0.1

- "Eighty nine point nine" (89.9)
- "Ninety" (90.0)
- "One hundred point five" (100.5)
- "One zero one point one" (101.1)
- "One zero eight" (108.0)

AM/MW band: 531 - 1602 in increments of 9

AM/LW band: 153 - 281 in increments of 1

- "Five thirty one" (531)
- "Nine hundred" (900)
- "Fourteen forty" (1440)
- "Fifteen zero three" (1503)
- "Ten eighty" (1080)

Store name

If you have tuned a radio station, you can store it with a name in the directory.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"STORE NAME"	"STORE NAME" "NAME PLEASE"
3	"<name>"	"REPEAT NAME PLEASE"

Voice control

Steps	User says	System answer
4	"<name>"	"STORING NAME" "<name> STORED"

Tune name

This function allows you to call up a stored radio station.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"TUNE NAME"*	"NAME PLEASE"
3	"<name>"	"TUNE <name>"

* Can be used as a shortcut.

Delete name

This function allows you to delete a stored radio station.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"DELETE NAME"	"NAME PLEASE"
3	"<name>"	"DELETE <name>" "CONFIRM YES OR NO"
4	"YES"	"DELETED"
	"NO"	"COMMAND CANCELLED"

Play directory

This function allows you to let the system tell you all of the stored radio stations.

Steps	User says	System answer
1	"RADIO"	"RADIO"

Voice control

Steps	User says	System answer
2	"PLAY DIRECTORY"	"PLAY <DIRECTORY>"

Delete directory

This function allows you to delete all stored radio stations at once.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"DELETE DIRECTORY"	"DELETE DIRECTORY" "CONFIRM YES OR NO"
3	"YES"	"RADIO DIRECTORY DELETED"
	"NO"	"COMMAND CANCELLED"

Play

This function switches the audio source to the radio mode.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"PLAY"	

Auxiliary input

This function allows you to switch the audio source to the attached auxiliary input device.

Steps	User says	System answer
1	"EXTERNAL DEVICE"	"EXTERNAL DEVICE"
2	"LINE IN"	"LINE IN"

Voice control

External devices - USB

These voice commands support the functionality of an external USB device which may be connected to the audio unit.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu in selected examples.

"EXTERNAL DEVICE", "USB"
"HELP"
"PLAY"
"TRACK"*
"PLAYLIST"**
"FOLDER"**
"SHUFFLE ALL"
"SHUFFLE FOLDER"
"SHUFFLE PLAYLIST"
"SHUFFLE OFF"
"REPEAT TRACK"
"REPEAT FOLDER"
"REPEAT OFF"

* Can be used as a shortcut.

** Playlists and folders activated by voice control must be assigned special filenames. See **General information** (page 276).

USB play

This function allows you to switch the audio source to the attached USB device.

Steps	User says	System answer
1	"EXTERNAL DEVICE"	"EXTERNAL DEVICE"
2	"USB"	"USB"
3	"PLAY"	

Voice control

USB Track

You can choose a track on your USB device directly.

Steps	User says	System answer
1	"EXTERNAL DEVICE"	"EXTERNAL DEVICE"
2	"USB"	"USB"
3	"TRACK"	"TRACK NUMBER PLEASE"
4	"<a number between 1 and 99>"*	"TRACK <number>"

* Additionally, numbers can be spoken as up to four single digits (for example "2", "4", "5" for track 245)

External devices - iPod

These voice commands support the functionality of an iPod which may be connected to the audio unit.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu in selected examples.

"EXTERNAL DEVICE", "IPOD"
"HELP"
"PLAY"
"TRACK"*
"PLAYLIST"**
"SHUFFLE ALL"
"SHUFFLE PLAYLIST"
"SHUFFLE OFF"
"REPEAT TRACK"
"REPEAT OFF"

* Can be used as a shortcut.

** Playlists activated by voice control must be assigned special filenames. See **General information** (page 276).

Voice control

iPod Track

You can choose a track off the all titles list of your iPod directly.

Steps	User says	System answer
1	"EXTERNAL DEVICE"	"EXTERNAL DEVICE"
2	"IPOD"	"IPOD"
3	"TRACK"*	"TRACK NUMBER PLEASE"
4	"<a number between 1 and 99>"**	"TRACK <number>"

* Can be used as a shortcut.

** Additionally, numbers can be spoken as up to five single digits (for example "5", "2", "4", "5", "3" for track 52453), to a limit of 65535.

iPod playlist

You can choose a playlist from your iPod directly.

Steps	User says	System answer
1	"EXTERNAL DEVICE"	"EXTERNAL DEVICE"
2	"IPOD"	"IPOD"
3	"PLAYLIST"*	"PLAYLIST NUMBER PLEASE"
4	"<a number between 1 and 10>"	"PLAYLIST <number>"

* Playlists activated by voice control must be assigned special filenames. See **General information** (page 276).

TELEPHONE COMMANDS

Phone

Your phone system allows you to create an additional phonebook. The stored entries can be dialed by voice control. Phone numbers stored by using voice control are stored on the vehicle system and not in your phone.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu in selected examples.

Voice control

"PHONE"
"HELP"
"MOBILE NAME"*
"DIAL NUMBER"*
"DIAL NAME"*
"DELETE NAME"
"DELETE DIRECTORY"
"PLAY DIRECTORY"
"STORE NAME"
"REDIAL"*
"ACCEPT CALLS"
"REJECT CALLS"

* Can be used as a shortcut.

Phone functions

Dial number

Phone numbers can be dialled after giving the name tag voice command.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DIAL NUMBER"*	"NUMBER PLEASE"
3	"<phone number>"	"<phone number> CONTINUE?"
4	"DIAL"	"DIALLING"
	"CORRECTION"	"<repeat last part of number> CONTINUE?"

* Can be used as a shortcut.

Voice control

Dial name

Phone numbers can be dialled after giving the name tag voice command.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DIAL NAME"*	"NAME PLEASE"
3	"<name>"	"DIAL <name>" "CONFIRM YES OR NO"
4	"YES"	"DIALLING"
	"NO"	"COMMAND CANCELLED"

* Can be used as a shortcut.

Redial

This function allows you to redial the last dialled phone number.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"REDIAL"*	"REDIAL" "CONFIRM YES OR NO"
3	"YES"	"DIALLING"
	"NO"	"COMMAND CANCELLED"

* Can be used as a shortcut.

Mobile name

This function allows you to access phone numbers stored with a name tag in your mobile phone.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"MOBILE NAME"*	"MOBILE NAME" "<phone dependent dialogue>"

* Can be used as a shortcut.

Voice control

DTMF (Tone dialling)

This function transfers spoken numbers into DTMF tones. For example, to make a remote enquiry to your home answering machine or to enter a PIN number etc.

Note: DTMF can only be used during an ongoing call. Press the VOICE button and wait for the system prompt.

Can only be used with vehicles installed with a dedicated VOICE button.

Steps	User says	System answer
1		"NUMBER PLEASE"
2	"<numbers 1 to 9, zero, hash, star>"	

Create a phonebook

Store name

New entries can be stored with the "STORE NAME" command. This feature can be used to dial a number by calling up the name instead of the full phone number.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"STORE NAME"	"STORE NAME" "NAME PLEASE"
3	"<name>"	"REPEAT NAME PLEASE"
4	"<name>"	"STORING NAME" "<name> STORED" "NUMBER PLEASE"
5	"<phone number>"	"<phone number>"
6	"STORE"	"STORING NUMBER" "<phone number>" "NUMBER STORED"

Delete name

Stored names can also be deleted from the directory.

Voice control

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DELETE NAME"	"NAME PLEASE"
3	"<name>"	"DELETE <name>" "CONFIRM YES OR NO"
4	"YES"	"<name> DELETED"
	"NO"	"COMMAND CANCELLED"

Play directory

Use this function to let the system tell you all stored entries.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"PLAY DIRECTORY"	"PLAY DIRECTORY"

Delete directory

This function allows you to delete all entries in one go.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DELETE DIRECTORY"	"DELETE DIRECTORY" "CONFIRM YES OR NO"
3	"YES"	"DIRECTORY DELETED"
	"NO"	"COMMAND CANCELLED"

Main settings

Reject calls

Calls can be set to be automatically rejected using voice control.

Voice control

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"REJECT CALLS"	"REJECT CALLS"
	"ACCEPT CALLS"*	"ACCEPT CALLS"

* use this command to turn the reject mode off

CLIMATE CONTROL COMMANDS

Climate

The climate voice commands supports the functionality of the fan speed, temperature and mode settings. Not all functions are available on all vehicles.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu in selected examples.

"CLIMATE"
"HELP"
"FAN"*
"DEFROSTING/DEMISTING ON"*
"DEFROSTING/DEMISTING OFF"*
"TEMPERATURE"*
"AUTO MODE"*

* Can be used as a shortcut. On vehicles fitted with an English language module the "FAN" shortcut is not available.

Fan

This function allows you to adjust the fan speed.

Voice control

Steps	User says	System answer
1	"CLIMATE"	"CLIMATE"
2	"FAN"*	"FAN SPEED PLEASE"
3	"MINIMUM"	"FAN MINIMUM"
	"<a number between 1 and 7>"	"FAN <number>"
	"MAXIMUM"	"FAN MAXIMUM"

* Can be used as a shortcut. On vehicles fitted with an English language module the "FAN" shortcut is not available.

Defrosting/Demisting

Steps	User says	System answer
1	"CLIMATE"	"CLIMATE"
2	"DEFROSTING ON/DEMISTING ON"*	"DEFROSTING ON/DEMISTING ON"
	"DEFROSTING OFF/DEMISTING OFF"*	"DEFROSTING OFF/DEMISTING OFF"

* Can be used as a shortcut.

Temperature

This function allows you to adjust the temperature.

Steps	User says	System answer
1	"CLIMATE"	"CLIMATE"
2	"TEMPERATURE"*	"TEMPERATURE PLEASE"
3	"MINIMUM"	"TEMPERATURE MINIMUM"
	"<a number between 15 and 29 °C with 0.5 increments>" or "<a number between 59 and 84 °F>"	"TEMPERATURE <number>"

Voice control

Steps	User says	System answer
	"MAXIMUM"	"TEMPERATURE MAXIMUM"

* Can be used as a shortcut.

Auto mode


Steps	User says	System answer
1	"CLIMATE"	"CLIMATE"
2	"AUTO MODE"*	"AUTO MODE"


* Can be used as a shortcut. Can be deactivated by selecting a different temperature or fan speed.

Connectivity


GENERAL INFORMATION


CAUTIONS

 Take care when handling external devices with exposed electrical connectors (such as the USB plug). Always replace the protective cap/shield when possible. There may be a risk of electrostatic discharge causing damage to the device.

 Do not touch or handle the USB socket in the vehicle. Cover the socket when not in use.

 Only use USB Mass-Storage device compliant devices.

 Always switch your audio unit to a different source (for example the radio) before unplugging the USB device.

 Do not install or connect USB hubs or splitters.

Note: *The system is only designed to recognize and read suitable audio files from a USB device that conforms to the USB Mass-Storage device class or an iPod. Not all available USB devices can be guaranteed to function with the system.*

Note: *It is possible to connect compatible devices with a trailing USB lead as well as those that plug into the vehicle USB socket directly (for example USB memory sticks and pen drives).*

Note: *Some USB devices with a higher power consumption may not be compatible (for example some larger hard drives).*

Note: *Access time to read the files on the external device will vary depending upon factors such as the file structure, size and device content.*

The system supports a range of external devices, to fully integrate with your audio unit via the USB and auxiliary input sockets. Once connected, control of the external device is possible via the audio unit.

A list of typical compatible devices are shown below:

- USB memory sticks
- USB portable hard drives
- Some MP3 players with USB connection
- iPod media players (refer to **www.ford-mobile-connectivity.com** for latest compatibility list).

The system is USB 2.0 full speed compatible, USB 1.1 host compliant and supports FAT 16/32 file systems.

Information on audio file structures for external devices

USB

Create only a single partition on the USB device.

If playlists are created, they must contain correct file paths referenced to the USB device. It is recommended to create the playlist after the audio files have been transferred to the USB device.

Playlists must be created in .m3u format.

Audio files must be in .mp3 format.

Do not exceed the following limits:

- 1000 items per folder (files, folders and playlists)
- 5000 folders per USB device (including playlists)
- 8 subfolder levels.

Connectivity

To enable voice control for custom playlists and folders, follow the procedure below:

- Create folders named with the structure "**Ford<*>**" where <*> is a number 1-10. For example "**Ford3**" without an extension.
- Create playlists named with the structure "**Ford<*>.m3u**" where <*> is a number 1-10. For example "**Ford5.m3u**" without any space between "**Ford**" and the number.

Thereafter, custom folders and playlists will be selectable with voice control. See **Audio unit commands** (page 261).

iPod

To enable voice control for custom playlists, create playlists named with the structure "**Ford<*>**" where <*> is a number 1-10. For example "**Ford7**" without any space between "**Ford**" and the number.

Thereafter, playlists will be selectable with voice control. See **Audio unit commands** (page 261).

CONNECTING AN EXTERNAL DEVICE

WARNING



Make sure the external device is securely mounted within the vehicle, and that trailing connections do not obstruct any of the driving controls.

External devices may be connected using the auxiliary input socket and the USB port. See **Auxiliary input (AUX IN) socket** (page 118). See **USB port** (page 118).

Connection

Plug in the device, and if necessary secure it to prevent movement within the vehicle.

Connecting an iPod

For optimum convenience and audio quality, we recommend that you purchase a dedicated single connection lead available from your dealer.

Alternatively, it is possible to connect your iPod using the standard iPod USB cable and a separate 3.5mm audio jack lead. If using this method preset the iPod volume to maximum and turn off any equalizer settings before making the connections:

- Connect the headphone output of the iPod to the AUX IN socket.
- Connect the USB cable from the iPod to the vehicle USB socket.

CONNECTING AN EXTERNAL DEVICE - VEHICLES WITH: BLUETOOTH

Connecting a Bluetooth audio device

CAUTION



As various standards exist, manufacturers are able to implement a variety of profiles in their Bluetooth devices. Because of this, an incompatibility can occur between the Bluetooth device and the system, which in some cases may limit system functionality. To avoid this situation, only recommended devices should be used.

Please visit the website www.ford-mobile-connectivity.com for full details.

Connectivity

Bonding the device

To connect the device to the system follow the same procedure as for Bluetooth hands free phones. See **Bluetooth setup** (page 256).

Operating the device

Note: *The seek buttons and file information will only work on certain phones and devices.*

Select Bluetooth audio as the active source.

1. Select **AUX**.
2. Press the up and down arrow buttons to select the desired function.
3. Press the **OK** button.

Tracks can be accessed by skipping forwards and backwards using the steering wheel controls, or directly from the audio unit controls.

Audio control

Press the seek up and down keys to skip backwards and forwards through tracks.

Press and hold the seek keys to enable fast rewind/fast forward through track content.

Press the **INFO** button or function button 4 to display the following:

- Title.
- Artist.
- Album.
- File name.

USING A USB DEVICE

Various icons are used to identify types of audio file, folders etc.



USB device is the active source



Folder



Playlist



Album



Artist



Filename



Track title



Information not available

Operation

Select the USB device as the audio source by repeatedly pressing the **AUX** button until the USB screen appears in the display. After first connecting the USB device, the first track within the first folder will start to play automatically. Subsequently, following audio source switching, the position of playback on the USB device is remembered.

To browse the device contents, press the up/down arrow key or the **OK** button once.

Connectivity

The display will show the track information, together with other important information described below:

- A vertical scroll bar on the right side of the display shows the current position of the folder view.
- ">" after an entry indicates a further level down is readable (for example a folder named after an album, with individual album tracks within that folder).
- "<" before the list indicates that a further level up is readable.
- Icons to the left of track/folder text indicate the type of file/folder. Refer to the list for an explanation of these icons.

To navigate the USB device contents, use the up/down arrow keys to scroll through lists, and the left/right keys to move up or down within the folder hierarchy. Once your desired track, playlist or folder is highlighted, press the **OK** button to select playback.

Note: *If you wish to jump to the top level of the USB device contents, press and hold the left arrow key.*

Audio control

Press the seek up and down keys to skip backwards and forwards through tracks.

Press and hold the seek keys to enable fast rewind/fast forward through track content.

Use the function buttons to enable shuffle, repeat and scan with respect to the whole device, folders and playlists.

Press the **INFO** button or function button 4 to display the following:

- title
- artist
- album

- folder name
- file name.

USING AN IPOD

Various icons are used to identify types of audio file, folders etc.



iPod is the active source



iPod playlist



iPod artist



iPod album



iPod genre



iPod song



iPod generic category



iPod generic media file

Operation

Connect the iPod. See **Connecting an external device** (page 277).

Select the iPod as the audio source by repeatedly pressing the **AUX** button until the iPod screen appears in the display.

Connectivity

The iPod menu list for browsing contents will be available through the radio display. Navigation of the contents follows the same principles as for iPod standalone use (for example search by artist, title, etc.). To browse the iPod contents, press the up/down arrow key or the OK button once.

The display will show the track information, together with other important information described below:

- A vertical scroll bar on the right side of the display shows the current position of the list view.
- ">" after an entry indicates a further level down is readable (for example all albums by a particular artist).
- "<" before the list indicates that a further level up is readable.
- An icon on the left side indicates the type of the currently displayed list (for example list of albums). Refer to the list for an explanation of these icons.

To navigate the iPod contents, use the up/down arrow keys to scroll through lists, and the left/right keys to move up or down within the hierarchy. Once your desired track, playlist, album, artist or genre is highlighted, press the OK button to select playback.

Note: *If you wish to jump to the top level of the iPod contents, press and hold the left arrow key.*

Audio control

Press the seek up and down keys to skip backwards and forwards through tracks.

Press and hold the seek keys to enable fast rewind/fast forward through track content.

Use the function buttons to enable shuffle and repeat with respect to playlists.

Press function button 3 to scan the whole device or a playlist if it is in operation.

Press the **INFO** button or function button 4 to display the following:

- title
- artist
- album.

Appendices

TYPE APPROVALS

FCC/INDUSTRY CANADA NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: WJLRX-42

IC: 7847A-RX42

Changes or modifications to your device not expressly approved by the party responsible for compliance can void the user's authority to operate the equipment.

RX-42 - declaration of conformity

We, the party responsible for compliance, declare under our sole responsibility that the Handset Integration product RX-42 is in conformity with the provisions of the following Council Directive: 1999/5/EC. A copy of the Declaration of Conformity can be found at:

www.novero.com/declaration_of_conformity

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Ford Motor Company is under license. Other trademarks and trade names are those of their respective owners.

TYPE APPROVALS

iPod is a trademark of Apple Inc.

TYPE APPROVALS



© 2008 NAVTEQ B.V. All rights reserved.

Appendices

(AT)	"© Bundesamt für Eich- und Vermessungswesen"
(PL)	"© EuroGeographics"
(FR)	"source: Géoroute® IGN France & BD Carto® IGN France"
(DE)	"Die Grundlagendaten wurden mit Genehmigung der zuständigen Behörden entnommen"
(GB)	"Based upon Crown Copyright material."
(GR)	"Copyright Geomatics Ltd."
(IT)	"La Banca Dati Italiana è stata prodotta usando quale riferimento anche cartografia numerica ed al tratto prodotta e fornita dalla Regione Toscana."
(NO)	"Copyright © 2000; Norwegian Mapping Authority"
(PT)	"Source: IgeoE – Portugal"
(ES)	"Información geográfica propiedad del CNIG"
(SE)	"Based upon electronic data © National Land Survey Sweden."
(CH)	"Topografische Grundlage: © Bundesamt für Landestopographie"


TYPE APPROVALS



SD Logo is a trademark.

TYPE APPROVALS

Laser sensor



Appendices

WARNINGS



Invisible laser radiation. Do not view directly with optical instruments (magnifiers). Class 1M laser product.

WARNINGS



IEC 60825-1: 1993 + A2:2001.
Complies with FDA performance standards for laser products except for deviation pursuant to Laser Notice No. 50, dated July 26th, 2001.

Item	Specification
Max average power	45mW
Pulse duration	33ns
Wavelength	905nm

ELECTROMAGNETIC COMPATIBILITY

WARNINGS



Your vehicle has been tested and certified to legislations relating to electromagnetic compatibility (72/245/EEC, UN ECE Regulation 10 or other applicable local requirements). It is your responsibility to ensure that any equipment you have fitted complies with applicable local legislations. Have any equipment fitted by properly trained technicians.

WARNINGS



Radio frequency (RF) transmitter equipment (e.g. cellular telephones, amateur radio transmitters etc.) may only be fitted to your vehicle if they comply with the parameters shown in the table below. There are no special provisions or conditions for installations or use.



Do not mount any transceiver, microphones, speakers, or any other item in the deployment path of the airbag system.




Do not fasten antenna cables to original vehicle wiring, fuel pipes and brake pipes.



Keep antenna and power cables at least 100mm from any electronic modules and airbags.

Appendices



E85998

Frequency Band MHz	Maximum output power Watt (Peak RMS)	Antenna Positions
1 – 30	50 W	3, 4
30 – 54	50 W	1, 2, 3
68 – 87.5	50 W	1, 2, 3
142 – 176	50 W	1, 2, 3
380 – 512	50 W	1, 2, 3
806 – 940	10 W	1, 2, 3
1200 – 1400	10 W	1, 2, 3
1710 – 1885	10 W	1, 2, 3
1885 – 2025	10 W	1, 2, 3

Note: After the installation of RF transmitters, check for disturbances from and to all electrical equipment in the vehicle, both in the standby and transmit modes.

Check all electrical equipment:

- with the ignition **ON**
- with the engine running
- during a road test at various speeds.

Check that electromagnetic fields generated inside the vehicle cabin by the transmitter installed do not exceed applicable human exposure requirements.

Index

A

- A/C
See: Climate control.....102
- About this handbook.....7
- ABS
See: Brakes.....134
- ABS driving hints
See: Hints on driving with ABS.....134
- ACC
See: Adaptive cruise control (ACC).....151
- Accessories
See: Parts and accessories.....7
See: Using ACC.....153
- Active park assist.....143
Principle of operation.....143
- Adaptive cruise control (ACC).....151
Principle of operation.....151
- Adaptive cruise control (ACC)
See: Using ACC.....153
- Adjusting the steering wheel.....48
- Air conditioning
See: Climate control.....102
- Air vents.....102
Centre air vents.....102
Side air vent.....103
- Alarm.....46
Principle of operation.....46
- Alternative frequencies.....248
- Appendices.....281
- Arming the alarm.....47
- Arming the engine immobiliser.....45
- Audible warnings and indicators.....80
Automatic transmission.....80
Door open.....81
Frost.....80
Key outside car.....81
Lights on.....81
Low fuel.....81
Seat belt reminder.....81
Switching the chimes on and off.....80
- Audio control.....48
Type 1.....48
Type 2.....49
- Audio introduction.....237
- Audio system security.....244
- Audio troubleshooting.....255
- Audio unit commands.....261
Auxiliary input.....265
CD Player.....261
External devices - iPod.....267
External devices - USB.....266
Radio.....262
- Audio unit menus.....248
- Audio unit operation.....245
- Audio unit overview.....238
- Auto-dimming mirror.....73
- Autolamps.....55
- Automatic climate control.....105
Air distribution.....107
Blower.....106
Cooling the interior quickly.....107
Mono mode.....106
Recirculated air.....107
Setting the temperature.....106
Switching off the automatic climate control.....108
Switching the air conditioning on and off.....107
To switch mono mode back on.....106
To switch mono mode off.....106
- Windscreen defrosting and demisting.....107
- Automatic main beam control.....55
Activating the system.....56
Manually overriding the system.....56
Setting the system sensitivity.....56
- Automatic transmission.....131
Emergency park position release lever.....133
Hints on driving with an automatic transmission.....133
Selector lever positions.....131
Sport mode and manual shifting.....132
- Automatic volume control.....248
- Autostore control.....246
- Autowipers.....50
- Auxiliary heater.....108
Diesel auxiliary heater (depending on country).....110
Parking heater.....108
- Auxiliary input (AUX IN) socket.....118
- Auxiliary power sockets.....116

Index

- B**
- Battery connection points.....200
 - Blind spot monitor.....73
 - Blind spot information system (BLIS).....73
 - Detection errors.....75
 - System detection and alerts.....74
 - Turning the system on and off.....74
 - Using the system.....73
 - Bluetooth setup.....256
 - Handling of phones.....256
 - Requirements for Bluetooth connection.....256
 - Bonnet lock
 - See: Opening and closing the bonnet....185
 - Booster cables
 - See: Using booster cables.....199
 - Booster cushions.....27
 - Booster cushion (Group 3).....27
 - Booster seat (Group 2).....27
 - Brake and clutch fluid check.....194
 - Brakes.....134
 - Principle of operation.....134
 - Bulb changing
 - See: Changing a bulb.....61
 - Bulb specification chart.....69
- C**
- Cargo nets.....169
 - Cargo net.....170
 - Cargo retention net.....169
 - Car wash
 - See: Cleaning the exterior.....197
 - Catalytic converter.....127
 - Driving with a catalytic converter.....127
 - Changing a bulb.....61
 - Approach lamp.....64
 - Central high mounted brake lamp.....68
 - Front fog lamps.....65
 - Headlamp.....62
 - Interior lamps.....68
 - Luggage compartment lamp, footwell lamp and tailgate lamp.....68
 - Number plate lamp.....68
 - Rear lamps - 4 door.....66
 - Rear lamps - 5 door.....65
 - Side repeater.....63
 - Changing a fuse.....174
 - Changing a road wheel.....201
 - Assembling the wheel brace.....203
 - Installing a road wheel.....205
 - Jacking and lifting points.....202
 - Locking wheel nuts.....201
 - Removing a road wheel.....204
 - Removing the wheel trim.....204
 - Vehicle jack.....201
 - Vehicles with a temporary spare wheel.....201
 - Changing the remote control battery.....36
 - Remote control with a folding key blade.....37
 - Remote control without a folding key blade.....37
 - Changing the vehicle battery.....199
 - Changing the wiper blades.....52
 - Rear window wiper blade.....53
 - Windscreen wiper blades.....52
 - Checking the wiper blades.....52
 - Child safety.....24
 - Child safety locks.....29
 - Electric child safety locks.....29
 - Manual child safety locks.....29
 - Child seat positioning.....25
 - Child seats.....24
 - Child restraints for different mass groups.....24
 - Cigar lighter.....116
 - Cleaning the exterior.....197
 - Body paintwork preservation.....197
 - Cleaning the chrome trim.....197
 - Cleaning the headlamps.....197
 - Cleaning the rear window.....197
 - Cleaning the interior.....197
 - Instrument cluster screens, LCD screens, radio screens.....198
 - Seat belts.....197
 - Climate control.....102
 - Principle of operation.....102
 - Climate control commands.....273
 - Climate.....273
 - Clock.....116
 - Coded keys.....45
 - Cold weather precautions.....172
 - Compact disc playback.....250

Index

Compact disc player.....	250
Compact disc track scanning.....	251
Type 1.....	251
Type 2 and 3.....	251
Connecting an external device.....	277
Connection.....	277
Connecting an external device - Vehicles With: Bluetooth.....	277
Connecting a Bluetooth audio device.....	277
Connectivity.....	276
General information.....	276
Convenience features.....	116
Coolant check See: Engine coolant check.....	193
Cornering lamps.....	59
Cruise control.....	149
Principle of operation.....	149
Cruise control See: Using cruise control.....	149
Cup holders.....	117
Rear seat armrest.....	117

D

Diesel particulate filter (DPF).....	123
Regeneration.....	123
Digital signal processing (DSP).....	248
Changing the DSP settings.....	248
DSP equaliser.....	248
DSP occupancy.....	248
Direction indicators.....	58
Disabling the passenger airbag.....	34
Disabling the passenger airbag.....	35
Enabling the passenger airbag.....	35
Fitting the passenger airbag deactivation switch.....	34
Disarming the alarm.....	47
Vehicles with keyless entry.....	47
Vehicles without keyless entry.....	47
Disarming the engine immobiliser.....	45
DPF See: Diesel particulate filter (DPF).....	123
Driver alert.....	158
Principle of operation.....	158
Driving hints.....	172
Driving through water.....	172
Driving through water	172

E

Eco mode.....	126
Principle of operation.....	126
Electric exterior mirrors.....	72
Electric folding mirrors.....	72
Mirror tilting positions.....	72
Electric seats.....	113
Electric windows.....	70
Anti-trap function.....	70
Driver's door switches.....	70
Global opening and closing.....	70
Opening and closing the windows automatically.....	70
Resetting the memory of the electric windows.....	71
Safety switch for rear windows.....	70
Electromagnetic compatibility.....	283
Emergency equipment.....	173
Ending compact disc playback.....	253
Engine compartment overview - 1.6L Duratec-16V Ti-VCT (Sigma).....	187
Engine compartment overview - 1.6L Duratorq-TDCi (DV) Diesel.....	189
Engine compartment overview - 1.6L EcoBoost SCTi (Sigma).....	188
Engine compartment overview - 2.0L Duratorq-TDCi (DW) Diesel.....	191
Engine coolant check.....	193
Checking the coolant level.....	193
Topping up.....	193
Engine immobiliser.....	45
Principle of operation.....	45
Engine oil check.....	192
Checking the oil level.....	192
Topping up.....	193
Engine oil dipstick - 1.6L Duratec-16V Ti-VCT (Sigma).....	192
Engine oil dipstick - 1.6L Duratorq-TDCi (DV) Diesel/2.0L Duratorq-TDCi (DW) Diesel.....	192
Engine oil dipstick - 1.6L EcoBoost SCTi (Sigma).....	192
Exterior mirrors.....	71
Manual folding mirrors.....	71

Index

F

Fastening the seat belts.....	33
Fast forward/reverse.....	250
First aid kit.....	173
Floor mats.....	118
Fog lamp	
See: Front fog lamps.....	57
Forward alert function.....	155
Adjusting the warning sensitivity.....	156
Switching the system on and off.....	155
Front fog lamps.....	57
Fuel and refuelling.....	127
Technical specifications.....	129
Fuel burning heater	
See: Auxiliary heater.....	108
Fuel consumption.....	129
Fuel consumption	
See: Technical specifications.....	129
Fuel filler flap.....	128
Fuel quality - Diesel.....	127
Long-term storage.....	127
Fuel quality - Petrol.....	127
Fuse box locations.....	174
Engine compartment fuse box.....	174
Load compartment fuse box.....	174
Passenger compartment fuse box.....	174
Fuses.....	174
Fuse specification chart.....	175
Engine compartment fuse box.....	175
Load compartment fuse box.....	180
Passenger compartment fuse box.....	178

G

Gauges.....	76
Engine coolant temperature gauge.....	77
Fuel gauge.....	77
Gearbox	
See: Transmission.....	131
General information on radio	
frequencies.....	36
Glasses holder.....	117
Global opening and closing.....	43
Global closing.....	43
Global opening.....	43

H

Handbrake	
See: Parking brake.....	134
Hazard warning flashers.....	58
Headlamp levelling.....	57
Recommended headlamp levelling switch	
positions.....	58
Headlamp washers.....	52
Head restraints.....	112
Adjusting the head restraint.....	112
Removing the head restraint.....	113
Heated seats.....	115
Heated windows and mirrors.....	108
Heated exterior mirrors.....	108
Heated windows.....	108
Heating	
See: Climate control.....	102
Hill launch assist (HLA)	
See: Using hill start assist.....	137
Hill start assist.....	137
Principle of operation.....	137
Hints on driving with ABS.....	134
HLA	
See: Hill start assist.....	137
See: Using hill start assist.....	137

I

Ignition switch.....	119
Immobiliser	
See: Engine immobiliser.....	45
Important audio information.....	237
Audio unit labels.....	237
Disc labels.....	237
Information displays.....	82
General information.....	82

Index

Information messages.....	90
Airbag.....	90
Alarm.....	91
Automatic main beam control.....	91
Battery and charging system.....	91
Blind spot monitor.....	92
Child power lock.....	92
Climate control.....	92
Cruise control and Adaptive cruise control (ACC).....	92
Doors open.....	93
Driver alert.....	93
Engine immobiliser.....	94
Hill start assist.....	94
Keyless system.....	94
Lane keeping aid.....	95
Lighting.....	95
Low speed safety system.....	96
Maintenance.....	96
Message indicator.....	90
Occupant protection.....	97
Parking aid.....	97
Parking brake.....	97
Power steering.....	98
Stability control (ESP).....	98
Starting the engine.....	98
Start stop.....	99
Transmission.....	99
Tyre pressure monitoring system.....	101
Instrument lighting dimmer.....	116
Instruments.....	76
Interior lamps.....	60
Ambient lighting.....	60
LED interior lighting.....	60
Introduction.....	7
iPod connection	
See: Connecting an external device.....	277
See: Connecting an external device - Vehicles With: Bluetooth.....	277
iPod	
See: Using an iPod.....	279
ISOFIX anchor points.....	28
Attaching a child seat with top tethers.....	28
Top tether anchor points - 4 door vehicles.....	28
Top tether anchor points - all vehicles.....	28
J	
Jump starting	
See: Using booster cables.....	199
K	
Keyless entry.....	41
Disabled keys.....	43
General information.....	41
Locking and unlocking the doors with the key blade.....	43
Locking the vehicle.....	41
Passive key.....	41
Unlocking the vehicle.....	42
Keyless starting.....	121
Failure to start.....	122
Ignition on.....	121
Starting a diesel engine.....	122
Starting with automatic transmission.....	121
Starting with manual transmission.....	121
Stopping the engine when the vehicle is moving.....	122
Stopping the engine with the vehicle stationary.....	122
Keys and remote controls.....	36
L	
Lane departure warning.....	160
Principle of operation.....	160
Lane keeping aid.....	162
Principle of operation.....	162
Lighting control.....	54
Headlamp flasher.....	54
Home safe lighting.....	55
Lighting control positions.....	54
Main and dipped beam.....	54
Parking lamps.....	54
Lighting.....	54
Load carrying.....	168
General information.....	168
Loading the navigation data.....	229
Loading the navigation data.....	229

Index

- Locking and unlocking.....39
 Double locking.....39
 Locking.....39
 Locking and unlocking confirmation.....40
 Locking and unlocking the doors from
 inside.....40
 Locking the doors individually with the
 key.....40
 Luggage compartment lid.....40
 Unlocking.....39
Locks.....39
Low speed safety system.....166
 Principle of operation.....166
Luggage anchor points.....168
Luggage covers.....168
- ## M
- Maintenance.....185
 General information.....185
 Technical specifications.....195
Manual climate control.....103
 Air conditioning.....104
 Air distribution control.....103
 Blower.....104
 Heating the interior quickly.....104
 Recirculated air.....104
 Ventilation.....104
Manual seats.....111
 Adjusting the angle of the seatback.....112
 Adjusting the height of the driver's
 seat.....112
 Adjusting the lumbar support.....112
 Moving the seats backwards and
 forwards.....111
Manual transmission.....131
 Selecting reverse gear.....131
Map updates.....236
Message centre
 See: Information displays.....82
Mirrors
 See: Heated windows and mirrors.....108
 See: Windows and mirrors.....70
MP3 connection
 See: Connecting an external device.....277
 See: Connecting an external device -
 Vehicles With: Bluetooth.....277
MP3 display options.....253
 CD text display options.....253
MP3 file playback.....251
 File formats.....252
 ID3 Tag Version 2.....252
 ISO 9660 format.....251
 MP3 files playback order.....252
 MP3 navigation.....253
 Multi session.....251
 Playing a multi session disc.....252
- ## N
- Navigation introduction.....219
 General information.....219
Navigation Quick start.....221
 Vehicles with CD-SD navigation system or
 Sony CD-SD navigation system.....222
 Vehicles with mobile navigation
 system.....221
 Navigation system.....233
 Navigation unit overview.....224
 Vehicles with CD-SD navigation
 system.....225
 Vehicles with Sony CD-SD navigation
 system.....227
News broadcasts.....248
- ## O
- Occupant protection.....31
 Principle of operation.....31
Oil check
 See: Engine oil check.....192
On/off control.....245
 See: Opening and closing the bonnet.....185
- ## O
- Opening and closing the bonnet.....185
 Closing the bonnet.....186
 Opening the bonnet.....185
- ## P
- Parking aid.....139
 Principle of operation.....139

Index

- Parking aid
See: Using the parking aid - Vehicles With:
Front and Rear Parking Aid.....140
See: Using the parking aid - Vehicles With:
Rear Parking Aid.....139
- Parking brake.....134
All vehicles.....134
- Parts and accessories.....7
Look for the Ford logo on the following
parts8
Now you can be sure that your Ford parts
are Ford parts.....7
- Personalised settings.....89
Chime deactivation.....90
Language setting.....89
Measure units.....90
Temperature units.....90
- Programming the remote control.....36
Programming a new remote control.....36
Reprogramming the unlocking
function.....36
- ## Q
- Quick start.....10
Adjusting the steering wheel.....17
Automatic climate control.....20
Electric seats.....22
Front exterior overview.....10
Head restraints.....21
Instrument panel overview.....13
Keyless starting.....22
Lighting control.....19
Locking and unlocking.....17
Manual climate control.....19
Manual seats.....20
Rear exterior overview.....16
Seat belt height adjustment.....17
Vehicle interior overview.....11
Wipers and washers.....18
- ## R
- Rear fog lamps.....57
- Rear seats.....114
Folding the rear seatbacks forwards.....114
Folding the seatbacks up.....115
Folding the seat cushions and the rear
seatbacks forwards.....114
- Rear view camera.....146
Principle of operation.....146
- Rear window wiper and washers.....51
Intermittent wipe.....51
Rear window washer.....52
Reverse gear wipe.....52
- Refuelling.....129
- Regional mode (REG).....249
- Remote control battery
See: Changing the remote control
battery.....36
- Remote control programming
See: Programming the remote control.....36
- Removing a headlamp.....61
- Repairing minor paint damage.....198
- Repeat compact disc tracks.....250
Type 1.....250
Type 2 and 3.....250
- Road Safety.....219
Safety information.....220
- Route displays.....234
Junction zoom.....234
Map display.....234
Navigation display.....234
- Route options menu.....233
Driver.....233
Dynamic.....233
Eco settings.....233
Ferry/motorail.....233
Motorway.....233
Route.....233
Seasonal roads.....234
Toll.....233
Toll sticker.....234
- Running-in.....172
Brakes and clutch.....172
Engine.....172
Tyres.....172
- ## S
- Safety precautions.....127

Index

- Satellite navigation unit holder.....118
Adjusting the holder.....118
Seat belt height adjustment.....33
Seat belt reminder.....33
Deactivating the seat belt reminder.....34
Rear seat belt reminder.....34
Seat belts
See: Fastening the seat belts.....33
Seats.....111
Security code.....244
Shuffle/random.....250
Type 1.....250
Type 2 and 3.....250
Sitting in the correct position.....111
Snow chains
See: Using snow chains.....210
Sound button.....245
Speed control
See: Cruise control.....149
Speed limiter.....157
Principle of operation.....157
Stability control.....135
Principle of operation.....135
Stability control
See: Using stability control.....135
Starter switch
See: Ignition switch.....119
Starting a diesel engine.....121
Cold or hot engine.....121
Starting a petrol engine.....120
Cold or hot engine.....120
Engine idle speed after starting.....120
Flooded engine.....120
Starting the engine.....119
General information.....119
Start-stop.....124
Principle of operation.....124
Station preset buttons.....246
Station tuning control.....245
Manual tuning.....245
Scan tuning.....245
Seek tuning.....245
Steering wheel lock.....119
Vehicles with keyless starting.....119
Vehicles without keyless starting.....119
Steering wheel.....48
Switching off the engine.....123
Vehicles with a turbocharger.....123
Symbols glossary.....7
Symbols in this handbook.....7
Symbols on your vehicle.....7
System settings.....230
Audio settings.....231
Clock settings.....232
Menu structure - Information and entertainment display - All vehicles.....231
Menu structure - Information and entertainment display - Vehicles with navigation system.....230
- ## T
- Technical specifications.....215
Technical specifications.....215
Telephone commands.....268
Create a phonebook.....271
Main settings.....272
Phone.....268
Phone functions.....269
Telephone controls.....257
Remote control.....257
Telephone setup.....256
Bond another Bluetooth phone.....257
Making a phone an active phone.....257
Phonebook.....256
Phonebook categories.....257
Telephone.....256
General information.....256
Telephone
See: Using the telephone.....258
Towing a trailer.....171
Steep gradients.....171
Towing points.....183
Installing the towing eye.....183
Towing eye location.....183
Towing the vehicle on four wheels.....183
All vehicles.....183
Vehicles with automatic transmission.....184
Towing.....171
Track selection.....250
Type 2 and 3.....250

Index

- Traffic information control.....246
 Activating traffic announcements.....246
 Ending traffic announcements.....247
 Traffic announcement volume.....247
- Traffic Message Channel.....235
 Principle of operation.....235
- Traffic sign recognition.....164
 Principle of operation.....164
- Transmission.....131
- Trip computer.....89
 Average fuel consumption.....89
 Average speed.....89
 Distance to empty.....89
 Instantaneous fuel consumption.....89
 Odometer.....89
 Outside air temperature.....89
 Resetting the trip computer.....89
 Trip Odometer.....89
- Type approvals.....281
 FCC/INDUSTRY CANADA NOTICE.....281
 Laser sensor.....282
 RX-42 - declaration of conformity.....281
- Tyre care.....209
- Tyre pressure monitoring system.....210
 System reset.....211
- Tyre pressures
 See: Technical specifications.....211
- Tyre repair kit.....206
 Checking the tyre pressure.....208
 General information.....206
 Inflating the tyre.....207
 Using the tyre repair kit.....206
- Tyres
 See: Wheels and tyres.....201
- U**
- USB port.....118
- USB
 See: Using a USB device.....278
- Using ACC.....153
 Automatic deactivation.....154
 Changing the set speed.....153
 Setting a speed.....153
 Setting the vehicle gap.....153
 Switching the system off.....154
 Switching the system on.....153
 Temporarily deactivating the system.....154
- Using active park assist.....143
- Using an iPod.....279
 Audio control.....280
 Operation.....279
- Using a USB device.....278
 Audio control.....279
 Operation.....278
- Using booster cables.....199
 To connect the booster cables.....199
 To start the engine.....199
- Using cruise control.....149
 Cancelling the set speed.....149
 Changing the set speed.....149
 Resuming the set speed.....149
 Setting a speed.....149
 Switching cruise control off.....150
 Switching cruise control on.....149
- Using driver alert.....158
 Resetting the system.....159
 Switching the system on and off.....158
 System display.....159
 System warnings.....158
- Using Eco mode.....126
 Resetting Eco mode.....126
- Using hill start assist.....137
 Activating the system.....137
 Deactivating the system.....137
 Vehicles with manual transmission only.....137
- Using lane departure warning.....160
 Setting the steering wheel vibration level.....161
 Setting the system sensitivity.....161
 Switching the system on and off.....160
 System warnings.....161
- Using seat belts during pregnancy.....34
- Using snow chains.....210
 Vehicles with stability control (ESP).....210
- Using stability control.....135

Index

Using start-stop.....	124
To re-start the engine.....	125
To stop the engine.....	124
Using the lane keeping aid.....	163
Switching the system on and off.....	163
System warnings.....	163
Using the low speed safety system.....	166
Switching the system on and off.....	166
Using the parking aid - Vehicles With:	
Front and Rear Parking Aid.....	140
Manoeuvring with the parking aid.....	141
Switching the parking aid on and off.....	140
Using the parking aid - Vehicles With:	
Rear Parking Aid.....	139
Using the rear view camera.....	146
Activating the rear view camera.....	146
Deactivating the rear view camera.....	148
Using the display.....	147
Vehicles with parking aid.....	148
Using the speed limiter.....	157
Intentionally exceeding the set speed limit.....	157
Setting the speed limit.....	157
Switching the system on and off.....	157
System warnings.....	157
Using the telephone.....	258
Changing the active phone.....	259
Debonding a bonded phone.....	259
Making a call.....	258
Muting the microphone.....	259
Receiving an incoming call.....	259
Receiving a second incoming call.....	259
Using TMC.....	235
Ending traffic announcements.....	235
Traffic announcement.....	235
Using TMC messages.....	235
Using traffic sign recognition.....	164
Setting the system speed warning.....	164
Switching the system on and off.....	164
System display.....	164
Using voice control.....	260
Name tag.....	261
System operation.....	260
Using winter tyres.....	210

V

Vehicle battery.....	199
Vehicle care.....	197
Vehicle identification number (VIN).....	214
Vehicle identification plate.....	214
Vehicle identification.....	214
Vehicle recovery.....	183
Ventilation	
See: Climate control.....	102
Vents	
See: Air vents.....	102
VIN	
See: Vehicle identification number (VIN).....	214
Voice control.....	49
Principle of operation.....	260

W

Warning lamps and indicators.....	78
ABS warning lamp.....	78
Airbag warning lamp.....	78
Blind spot monitor indicator.....	78
Brake system lamp.....	78
Cruise control indicator.....	78
Direction indicators.....	78
Engine warning lamp.....	78
Forward alert warning indicator.....	79
Front fog lamp indicator.....	79
Frost warning lamp.....	79
Glow plug indicator.....	79
Headlamp indicator.....	79
Ignition warning lamp.....	79
Lane departure warning indicator.....	79
Low fuel level warning lamp.....	79
Main beam indicator.....	79
Message indicator.....	79
Oil pressure warning lamp.....	79
Rear fog lamp indicator.....	80
Seat belt reminder.....	80
Stability control (ESP) indicator.....	80
Start-stop indicator.....	80
Warning triangle.....	173
Washer fluid check.....	194
Washers	
See: Wipers and washers.....	50

Index

Washing	
See: Cleaning the exterior.....	197
Waveband button.....	245
Wheels and tyres.....	201
General information.....	201
Technical specifications.....	211
Windows and mirrors.....	70
Windscreen washers.....	51
Windscreen wipers.....	50
Automatic wiper system.....	50
Intermittent wipe.....	50
Winter tyres	
See: Using winter tyres.....	210
Wipers and washers.....	50

Feel the difference

