

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your occupants. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Lincoln dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

Lincoln Customer
Relationship Center

U.S. 1-800-521-4140
(TDD for the hearing
impaired 1-800-232-5952)
lincolnowner.com

Ford of Canada's Lincoln
Customer Relationship Centre

Canada 1-800-387-9333
lincolncanada.com



lincolnowner.com



lincolncanada.com

LEARN MORE ABOUT YOUR NEW LINCOLN NAVIGATOR
lincolnowner.com (U.S.) / lincolncanada.com (Canada)

LEARN HOW TO SYNC YOUR RIDE: SYNC is a voice-activated technology personalized by you. It is a hands-free, voice recognition system used for entertainment, information and communication.

SyncMyRide.com (U.S.) / **SyncMyRide.ca** (Canada)

WARNING

Driving while distracted can result in loss of vehicle control, accident and injury. Ford Motor Company strongly recommends that drivers use extreme caution when using any device or feature that may take their focus off the road. Your primary responsibility is the safe operation of the vehicle. We recommend against the use of any hand-held device while driving, encourage the use of voice-operated systems when possible and that you become aware of applicable state and local laws that may affect the use of electronic devices while driving.



NAVIGATOR
July 2012
First Printing
Quick Reference Guide
Litho in USA

DL7J 19G217 AA



2013 QUICK REFERENCE GUIDE



LINCOLN NAVIGATOR




NAVIGATOR COMMONLY USED VOICE COMMANDS

SYNC® ...Say the Word.


TABLE OF CONTENTS



Touch the  button on the right-hand side of your steering wheel, and then say:

-  **Basic Commands**
 - ▶ What can I say?
 - ▶ List of commands
 - ▶ Main menu
 - ▶ Previous
 - ▶ Next
 - ▶ Go back
 - ▶ Exit
 - ▶ Help
 - ▶ Vehicle health
 - ▶ Pair my phone
-  **Phone**
 - ▶ Phone list of commands
 - ▶ Dial
 - ▶ Call <name> on cell/at home/at work
 - ▶ Call voicemail
 - ▶ Do not disturb<On/Off>
 - ▶ Listen to text message (phone-dependent feature)
-  **SYNC Services**

Must say “Services” first, and then “What can I say?”

 - ▶ Traffic
 - ▶ Directions
 - ▶ Business search
 - ▶ Operator (for direction or business search)
 - ▶ Favorites
 - ▶ News, sports, weather, horoscopes, stock quotes, movies or travel
 - ▶ Help
-  **Entertainment**
 - ▶ Audio list of commands
 - You can also get detailed lists of commands for radio, USB, Bluetooth® audio, Sirius and SD Card
 - ▶ Audio <On/Off>
 - ▶ Radio
 - FM <87.7-107.9>
 - FM preset <#>
 - ▶ CD
 - Play track <1-152>
 - Shuffle <On/Off>
 - ▶ USB
 - Play song <name>
 - Play album <name>
 - ▶ SiriusXM
 - <channel name>
 - Preset <#>

INSTRUMENT PANEL	4-5
VEHICLE STABILITY	6-7
SYNC	8-9
COMFORT & CONVENIENCE	10-11
ESSENTIAL INFORMATION	12-13
FUNCTION	14-15

THE LUXURY OF
VERSATILITY

For more complete information, refer to your **Owner's Manual**, visit the website or call the toll-free number.
For U.S. customers: visit SyncMyRide.com or call 1-800-392-3673 (select Option 1 or 2 for language, then Option 3).
For Canadian customers: visit SyncMyRide.ca or call 1-800-565-3673 (select Option 1 or 2 for language, then Option 3).



INSTRUMENT PANEL

{ LINCOLN NAVIGATOR

1 HEADLAMPS CONTROLS:

ⓘ: Turns the headlamps off.

P: Turns on the parking lamps.

☞: Turns on the headlamps.

☞: Autolamps: Automatically turns the exterior lamps on/off based on available daylight.

☞: Turns on fog lamps by pulling the control toward you.

2 PARKING BRAKE

3 MULTI-FUNCTION/ WINDSHIELD WIPER LEVER:

Rotate the end of the control stalk up/down to increase/decrease the speed of the wipers.

Push the end of the stalk:

► Quickly for a single swipe without fluid.

► Hold briefly for three swipes with washer fluid.

► Hold for a longer wash cycle.

To operate your rear window wiper:

Turn the rear wiper control to 1 (intermittent speed), 2 (normal speed) or O (off). For a rear wash cycle, rotate and

hold the rear wiper control to either ☞ position.

Note: For optimal wiper performance, clean your blades and glass regularly. Refer to your Owner's Manual for more information.

4 SPEED CONTROL

To set the speed:

1. Press **ON**.

2. Accelerate to the desired speed.

3. Press **SET + / SET -** and take your foot off the accelerator.

► To set a higher or lower speed, press and hold **SET + / SET -** or press either button repeatedly until the desired speed is reached.

► To return to a previously set speed, press **RESUME**.

► To turn off, press **OFF** or turn off the ignition.

5 INFORMATION DISPLAY

shows important vehicle information through a constant monitor of vehicle systems. The display will notify you of potential vehicle problems by showing system warnings followed by a long indicator chime. For more details about your information display functions, please see your *Owner's Manual*.

6 SERVICE ENGINE SOON LIGHT:

The service engine soon light ☞ illuminates briefly when the ignition is turned on. If it remains on or is blinking after the engine is started, the on-board diagnostics system (OBD-II) has detected a malfunction. Drive in a moderate fashion and contact your authorized dealer as soon as possible.

7 HAZARD FLASHER CONTROL

* if equipped

OVERDRIVE CONTROL WITH TOW/HAUL FEATURE: The tow/haul feature improves transmission operation when towing a trailer or a heavy load. To activate tow/haul, press the button on the side of the gearshift lever. The **TOW HAUL** indicator light will illuminate in the instrument cluster. To deactivate, press the button again. Drive with the vehicle in D (overdrive) with tow/haul off for the best fuel economy. Refer to the *Transmission* chapter of your *Owner's Manual* for more information.


CONTROL TRAC® FOUR-WHEEL DRIVE (4X4) OPERATION*

4X2 (2WD): delivers power to the rear wheels only. This is appropriate for normal, on-road driving on dry pavement.

4X4 AUTO: provides electronic control four-wheel drive with power delivered to all four wheels, as required, for increased traction. The information display will show **"4X4 AUTO"** when this position is selected. This mode is appropriate for all on-road driving conditions, such as dry road surfaces, wet pavement, snow and gravel.

4X4: provides electronically locked four-wheel drive power to all four wheels. The information display will show **"4X4"** when this position is selected. This position is not recommended for use on dry pavement. This position is only intended for severe winter or off-road conditions, such as deep snow, ice or shallow sand. Refer to the Using *Four-Wheel Drive (4WD)* chapter in your *Owner's Manual* for more information including shifting instructions.

ADVANCETRAC® WITH RSC® (ROLL STABILITY CONTROL™)*: The AdvanceTrac® stability system helps you to maintain stability and steer-ability of your vehicle during a variety of road conditions. If your vehicle becomes stuck in the snow, mud or sand, try turning off the AdvanceTrac® system to allow wheel spin and help increase momentum to dig the vehicle out. The system defaults to **ON** and the control will illuminate when turned off. Refer to your *Stability Control* chapter in your *Owner's Manual* for safety information and more details.

TRAILER SWAY CONTROL*: This control uses the vehicle's AdvanceTrac® system to detect and help reduce trailer sway by applying brake force at individual wheels and, if necessary, reducing engine power. If this happens, **"TRAILER SWAY REDUCE SPEED"** will display in the instrument cluster with the AdvanceTrac® icon . For more information, please refer to the *Towing* chapter in your *Owner's Manual*.



GETTING STARTED WITH YOUR SYNC SYSTEM:

SYNC is a hands-free, voice recognition system used for entertainment, information and communication.

SYNC...Say the word.


GENERAL TIPS:

- ▶ Press RETURN to exit a menu.
- ▶ For additional support, refer to your **Owner's Manual**, visit the website or call the toll-free number. See the inside front cover of this guide for details.

Before you get started:


1. Set up your owner account by visiting **SyncMyRide.com** (U.S.) or **SyncMyRide.ca** (Canada). Follow the on-screen instructions.

Note: Your account gives you even more SYNC capabilities, including personalization features and software updates.

2. SYNC uses a wireless connection called Bluetooth®  to communicate with your phone. Turn Bluetooth mode on in your phone's menu options. This lets your phone find SYNC. For more details on setting up your phone with SYNC, visit **SyncMyRide.com** (U.S.) or **SyncMyRide.ca** (Canada), or your phone manufacturer's website.

PAIRING YOUR PHONE WITH SYNC:

Pair your phone to use many of the features of SYNC. To pair your phone for the first time:

1. Make sure that your vehicle is in (P) park and both your ignition and radio are turned on.
2. Press the phone button . When the display indicates no phone is paired, press **OK**.

3. When **Find SYNC** appears in the display, press **OK**.

4. Put your phone into Bluetooth discovery mode. Refer to your phone's user guide if necessary.

5. When prompted on your phone's display, enter the six-digit PIN provided by SYNC in the radio display.

6. The display indicates when the pairing is successful.

Note: The system may prompt you to:

- ▶ Set your phone as the primary/favorite (the primary phone will receive messages and voice mails).
- ▶ Download your phone book (this is required to use the full set of voice commands).
- ▶ Turn on 911 Assist®.

TIPS:


- ▶ Make sure you accept SYNC's request to access your phone.
- ▶ To pair subsequent phones or to learn more about your SYNC system, please refer to Pairing Subsequent Phones in the SYNC chapter of your **Owner's Manual**.



USING MY PHONE WITH SYNC:

Note: You must download your phone book to make phone calls with voice commands by name. Contacts listed in all caps will require you to spell them (i.e. JAKE, will be J-A-K-E).

Making a phone call: Use SYNC to make a phone call to anyone in your phone book by pressing the voice button and when prompted, give a voice command:

For example, you could say, **"Call Jake Smith at home"**. When the system confirms the number, say **"Dial"** again to initiate the call.

Note: You can also make phone calls by pressing the voice button . When prompted, give the voice command, **"Dial,"** then verbally say the phone number.


Answering incoming calls: Whenever you have an incoming call, you will be able to see the name and number of the person calling in your display. Press the phone button  to answer an incoming call. You can hang up at any time by pressing and holding the phone button .

Do not disturb mode: This feature blocks incoming calls and text messages, and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command **"Do not disturb on"** to enable and **"Do not disturb off"** to disable.

USING SYNC® TO ACCESS DIGITAL MEDIA:

SYNC has a media hub with multiple inputs allowing you to access personal media from your digital devices. Plug in your USB media devices such as phones and MP3 players and use SYNC to play all of your favorite music. SYNC indexes all of your music. The more music that is stored on your device, the longer it takes SYNC to index.

Using voice commands to play music:

1. Plug your media player into your USB port.
2. Press the voice button . When prompted say **"USB"**, then follow-up saying one of the following voice commands.
3. You will hear the command repeated back to you and the selected item will play.

SYNC APPLINK™

SYNC AppLink allows voice access to select mobile applications that you already have or can download to your Android™, BlackBerry® or iPhone®.

Current apps available include Pandora Internet Radio®, Stitcher Smart Radio™, Open Beak (BlackBerry exclusive), iHeartRadio, Slacker, NPR News and SYNC Destinations and more.


For more information on SYNC, visit the website or call the toll-free number. See the inside front cover of this guide for details.



RAIN-SENSING WIPERS:

If activated, your wipers will automatically turn on when moisture is present on the windshield. The wiper speed will vary based on the amount of moisture detected and the sensitivity setting. To deactivate, turn your wiper controls off.

Note: Make sure that this feature is turned off before entering a car wash.

MYKEY®: MyKey allows you to program certain driving restrictions in order to promote good driving habits. You can program things such as speed restrictions and limited volume levels. For complete information, refer to the **MyKey** chapter in your **Owner's Manual**.

POWER LIFTGATE: Press  to open or close the power liftgate. For added convenience, there are three more ways to activate your power liftgate's capabilities:

1. Remote entry transmitter: Press  twice within three seconds to open or close your power liftgate.
2. To open using the liftgate control button in the liftgate handle: Unlock the doors using either the remote entry transmitter or the power door unlock control, and press the control.
3. To close using the rear cargo area button: Press and release the  control located on the left rear quarter panel. This button is automatically disabled when the liftgate is latched.

Note: Keep clear of the liftgate when operating the rear switch. Your power liftgate is equipped with an obstacle detection feature which will either stop or revert to a full open position if it encounters a solid object. For complete information, see the **Liftgate** section within the **Locks** chapter of your **Owner's Manual**.



POWER-ADJUSTABLE FOOT PEDALS: Located on the left-hand side of your steering column, your power-adjustable pedal control lets you move your brake and accelerator

pedals closer. Press the ► arrow to move the pedals closer to you or the ◀ arrow to move the pedals further away from you. The pedals should only be adjusted when the vehicle is stopped and in Park (P).

SECURICODE™ KEYLESS ENTRY KEYPAD: Lock or unlock the doors or release the liftgate glass without using a key. The keypad can be operated with the factory-set, 5-digit entry code; this code is located on the owner's wallet card in the glove box. You can also create up to five of your own 5-digit personal entry codes. To lock all of the doors and liftgate, press and hold **7•8** and **9•0** at the same time. For complete information, refer to the **Locks** chapter of your **Owner's Manual**.



POWERFOLD® THIRD-ROW SEAT*: 60/40 split-folding bench seat uses a power-activated seat back release. Fold one side down or both for more flexibility.



The controls are located on the right-hand quarter trim panel that is accessible from the liftgate area. **Note:** Make sure all seatbelts are unfastened.



To lower:

1. Make sure that the head restraints are folded down first.
2. Press **"FOLD"** on the button.
3. To return the seat back to its original position, press **"UP"** on the button.

Note: The power-folding seats will operate for 10 minutes after the ignition switch is turned off. The transmission must be in P (park) and the liftgate or liftglass must be open.







FRONT HEATED AND COOLED SEATS: Press the heated seat symbol  or the cooled seat symbol  to cycle through the various settings and off. Higher settings are indicated by more indicator lights.

SECOND-ROW HEATED SEATS: Your vehicle is equipped with heated second-row seats. The controls are located on the rear of the center console. Press the indicated side of the control  for maximum heat. Press again to deactivate. Press the indicated side of the control  for minimum heat. Press again to deactivate.

Note: The heated seats reset at every ignition run cycle. They will turn off automatically when the engine is turned off.

MEMORY SEAT FEATURE:

The memory function allows a **"one touch"** recall of personalized memory features (i.e., the positions of the driver seat, power mirrors, steering column and power-adjustable foot pedals). Use the memory controls located on the side of the driver's seat   to program and then recall memory positions.

To program position 1, press and hold the **1** button  until you hear a chime. Use this same procedure to set the second position using the **2** button . You can now use these controls to recall the set memory positions.

* if equipped



EASY FUEL® SYSTEM: Your vehicle's fuel system allows you to simply open the fuel filler door, insert the nozzle and start fueling. Wait 10 seconds from the time the refueling nozzle is shut off until you remove the nozzle from the vehicle to allow residual fuel in the nozzle to drain into the tank. The Easy Fuel® System is self-sealing and therefore protected against dust, dirt, water, snow and ice. If you need to fill your fuel tank with a portable fuel container, use the fuel funnel which is attached to the underside of the spare tire cover or is included with the tire changing tools. Slowly insert the funnel into the Easy Fuel® system and fill the tank with fuel from

the container. When done, clean the funnel or properly dispose of it. Extra funnels can be purchased from your authorized dealer. **Do not** use aftermarket funnels as they will not work with the Easy Fuel® system and may cause damage.


FUEL-EFFICIENT TRANSMISSION: Your vehicle has been designed to improve fuel economy by reducing fuel usage while coasting or decelerating. This may be perceived as a light to medium braking sensation when removing your foot from the accelerator pedal.

FUEL TYPE AND FUEL TANK CAPACITY: Depending on your vehicle, your fuel tank has a capacity of either 28 gallons (106L) or 33.5 gallons (126.8L).

Your vehicle is a **Flex Fuel** vehicle. Flex Fuel vehicles


have a yellow ring around the top of the fuel filler inlet (tube). They are designed to use only **E85 FUEL ETHANOL, UNLEADED FUEL** "Regular" unleaded gasoline or any mixture of the two fuels. It is best not to alternate repeatedly between gasoline and E85. If you do switch fuels, it is recommended that you add as much fuel as possible—at least half a tank. If you use E85 fuel exclusively, it is recommended to fill the fuel tank with regular unleaded gasoline at each scheduled oil change. See your **Owner's Manual** for more specific information and E85 details.



TIRE PRESSURE MONITORING SYSTEM: Your vehicle is equipped with a Tire Pressure Monitoring System (TPMS) that illuminates a  low tire pressure warning light when one or more of your tires is significantly under-inflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the **Inflating Your Tires** section in the **Wheels and Tires** chapter of your **Owner's Manual** for more information.

ROADSIDE ASSISTANCE: Your new Lincoln Navigator comes with the assurance and support of 24-hour emergency roadside assistance. To receive roadside assistance in the United States, call 1 (800) 241-3673. In Canada, call 1 (800) 665-2006.

LOCATION OF SPARE TIRE AND TOOLS: Your vehicle is equipped with a temporary spare tire located under the vehicle, just forward of the rear bumper. The temporary spare is designed for emergency use only and should be replaced as soon as possible. The jack and tools are located in the access panel on the floor behind the third-row seat. Ensure that you turn off the deployable running boards (if equipped) as well as the air suspension system (if equipped) prior to jacking, hoisting or towing your vehicle. For complete details on how to change your tire, refer to the **Roadside Emergencies** chapter in your **Owner's Manual**.

SOS POST-CRASH ALERT SYSTEM™: The SOS Post-Crash Alert System™ provides audible and visual alarms in the event of a crash which causes the deployment of airbags or the activation of the safety belt pretensioners. The turn signals will flash and the horn will sound. To deactivate the system, press the hazard flasher control, or you can press  on your remote transmitter.



REARVIEW CAMERA: The rearview camera system is located on the liftgate and provides a visual display of the area behind the vehicle. The display will automatically appear on the navigation system screen (if equipped) or in the rearview mirror whenever the vehicle is in R (Reverse) and uses colors (green, yellow and red) to alert you of your proximity to objects.

Note: Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your **Owner's Manual** for safety information, more detail and limitations.



FORWARD AND REVERSE SENSING SYSTEMS: Your vehicle is equipped with forward and reverse sensing systems which may warn you if there is an object in front of or behind the vehicle. The system will sound a warning tone that increases in frequency as the object gets closer and will sound continuously when the object is less than 10 inches away.



MOONROOF*
Your moonroof is equipped with a one-touch, express opening and closing feature. To open, press and release the **SLIDE** control, the sunscreen will open. To fully open the moonroof, press and release the **SLIDE** control again. To close, pull and release the **SLIDE** control. Press and release the **TILT** control to vent the moonroof. Pull and hold the **TILT** control to close the moonroof. The sliding shade can be manually opened or closed when the moonroof is closed. Pull the shade toward the front of the vehicle to close it.



NAVIGATION SYSTEM: Set your destination by using your touch screen or voice commands. To program a destination using the touch screen:

1. Press the **DEST** button and "**Accept**" when the "**Terms of Use**" screen appears.
2. Select from the following:

- a. **Quick:** Allows you to cancel the route, access emergency destinations (such as police stations or hospitals), save your favorite destinations to presets for quick access, find the nearest point of interest (POI), and recall a previous destination or entry from your address book to set as a current destination.

b. **Standard:** Allows you to set a destination using any of the following:

- i. Address Book
- ii. Previous Destination
- iii. Phone Number
- iv. Map
- v. Street Address
- vi. POI
- vii. Freeway Exit/Entrance or Intersection

c. **Edit Route:** Allows you to make any adjustments to the currently selected navigation route such as:

- i. Cancel
- ii. Detour
- iii. View Route
- iv. Edit Route Preferences
- v. Edit Traffic Preferences
- vi. Edit Destination/Way Points
- vii. Edit Turn List

Note: Periodic map updates are available at an additional cost. Call 1-800-NAVMAPS (in Mexico, call 01-800-557-5539) or visit www.navigation.com/ford.