

GE5J 19G217 EA  
March 2015  
First Printing  
Quick Reference Guide  
Fusion Hybrid  
Litho in U.S.A.

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Ford dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.



### United States

Ford Customer Relationship Center  
**1-800-392-3673 (FORD)**  
(TDD for the hearing impaired: **1-800-232-5952**)  
**fordowner.com**

 **@FordService**

### Canada

Ford Customer Relationship Centre  
**1-800-565-3673 (FORD)**  
**ford.ca**

 **@FordServiceCA**

### WARNING

Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.



# FUSION HYBRID

TWO THOUSAND SIXTEEN

## Quick Reference Guide

# COMMONLY USED SYNC® VOICE COMMANDS

Press the voice button  on your steering wheel and then say:



## Basic Commands

- What can I say?
- List of commands
- Main menu
- Previous
- Next
- Go back
- Exit
- Help
- Pair my phone



## Phone

- Phone list of commands
- Dial
- Call <name> on cell/  
at home/at work
- Call voicemail
- Do not disturb <On/Off>
- Listen to text message  
(phone-dependent feature)



## Climate\*

- Climate control list of commands
- Climate <On/Off>
- Climate my temperature
- Climate temperature



## Entertainment

- Audio list of commands:  
You can also get detailed lists of commands for radio, USB, *Bluetooth*® audio, SiriusXM\* and SD card\*\*
- Radio
  - On/Off
  - FM <87.9-107.9>
  - FM preset <#>
- CD
  - Play track <1-512>
  - Shuffle <On/Off>
- USB
  - Play song <name>
  - Play album <name>
- SiriusXM
  - <Channel name>
  - Preset <#>



## Navigation\*

- Navigation list of commands
- Destination street address <number, name, city>
- Destination home
- Navigation voice <On/Off>
- Navigation voice volume <increase/decrease>
- Repeat instruction
- Show <map/north-up/  
heading-up/3-D>
- Travel Link list of commands
- Traffic
- Weather
- Movie listings
- Fuel prices
- Sports <headlines/  
scores/schedule>

*\*available only with MyFord Touch*

*\*\*if equipped*

*Some features may not be available in your area. Refer to your Owner's Manual, visit the website or call the toll-free*

*number for more information. For U.S. customers: visit [SyncMyRide.com](http://SyncMyRide.com) or call 1-800-392-3673 (select Option 1 or 2 for language, then Option 3).*

*For Canadian customers: visit [SyncMyRide.ca](http://SyncMyRide.ca) or call 1-800-565-3673 (select Option 1 or 2 for language, then Option 3).*

## Learn More About Your New Vehicle

Scan the country-appropriate QR code with your smartphone (make sure you have a scanner app installed) and you can access even more information about your vehicle.



[fordowner.com](http://fordowner.com)  
(U.S.)



[ford.ca](http://ford.ca)  
(Canada)



- 4–5 **Instrument Panel**
- 6 **Quick Tips**
- 7 **Energy Saving Tips**
- 8–9 **Getting Started with Your SYNC System**
- 10–12 **SYNC with MyFord Touch**
- 13 **Fusion Hybrid Features**
- 14–15 **Comfort**
- 16–17 **Function**
- 18–19 **Essential Information**

## Left Vehicle Info Display

Using the left steering-wheel-mounted controls, press the up and down arrow buttons to scroll through and highlight the options; use the right arrow button to enter a sub-menu.

» The Display/Trip Mode provides hybrid-specific information through the following screens:

• Engage • Empower • MyView • Trip

- MyView lets you choose what information you wish to display. Select **Change MyView** in the Options menu to scroll through choices.

» The **Brake Coach** appears after the vehicle has come to a stop. It coaches you to brake in a manner that maximizes the amount of energy returned through the regenerative braking system. The displayed percentage indicates your regenerative braking efficiency, with 100% representing the maximum amount of energy recovery. You can switch this feature ON and OFF in the information display.

## Steering Wheel Controls

### Audio Controls

Press **VOL +** or **-** to increase/decrease volume levels.  
Press **⏮** **⏭** to access the next or previous radio station preset, CD track or preset satellite radio channel\*.


### Voice Controls

Press  to access voice recognition.  
Press  to answer call.  
Press  to exit phone mode or end a call.

## Tilt and Telescope Steering Column

Unlock the steering wheel by pulling the lever down.  
Adjust the steering wheel to your desired position.  
Push the lever up to lock the steering wheel in place.

*\*if equipped*



# INSTRUMENT PANEL



## Service Engine Soon Light

 Lights briefly when you switch the ignition on. If it remains on or blinks after you start your vehicle, the On-Board Diagnostics (OBD-II) system has detected a problem. Drive in a moderate fashion and contact your authorized dealer as soon as possible.

## Right Vehicle Info Display

Use the right steering-wheel-mounted controls to access a variety of features:

- » **Fuel Economy** provides ways you can monitor your energy use:
  - **Efficiency Leaves** • **Fuel History** • **Coach**
- » **Entertainment, Phone and Navigation\*** information is also available. Refer to the *MyFord Touch* chapter in your *Owner's Manual* for more information.

## Electric Parking Brake

The operating switch (P) replaces the conventional handbrake. It is on the console, to the left of the gearshift.

To use, pull the control up. The brake system warning lamp flashes for approximately 2 seconds, then stays lit to confirm that you applied the electric parking brake.

You can release the electric parking brake manually by switching on the ignition, pressing the brake pedal and then pressing the electric parking brake control down. See the *Brakes* chapter of your *Owner's Manual* for more details.

\*if equipped

# QUICK TIPS

*The Brake Coach appears in the display after the vehicle has come to a stop, and coaches you to maximize the amount of energy that can be returned through the regenerative braking system.*

## SmartGauge® with EcoGuide

Delivers specific information about various systems on your vehicle using menus that build on previous data. Use your left-hand, 5-way steering controls to scroll through your menu choices:

**Engage:** Adds gas and electric power-split information.

**Empower:** Adds an engine on and off threshold to the power demand gauge. See how much power you request based on how far you press the accelerator pedal.

**MyView:** Lets you customize your menu options, allowing you to select key information and combine it into one screen.

**EcoGuide:** Displays leaf graphics within the right-hand cluster, showing you when you're driving efficiently. More leaves equal better driving habits!



# ENERGY SAVING TIPS

## Help Maximize Your Fuel Economy by Utilizing These Few Tips

1. **Use smooth acceleration and braking.** According to the United States Department of Energy, aggressive driving can lower your gas mileage by up to 33 percent at highway speeds and 5 percent in the city.
2. **Carry the bare essentials.** The Department of Energy estimates that an extra 100 pounds (45.4 kilograms) in your vehicle could reduce your fuel economy by up to two percent.
3. **Seasonal fuel makes a difference.** Winter fuel contains slightly less energy than summer fuel, so the fuel blend you fill up with can impact your efficiency.
4. **Idling burns fuel, too.** You can burn up to half a gallon (1.9 liters) of fuel per hour while idling. Minimize your morning warm-up and parking lot waits to get the most out of filling your tank.
5. **Avoid extreme temperatures.** Find a shady or sheltered spot to help keep your lithium-ion battery operating efficiently, and minimize the amount of energy required to heat or cool your cabin.
6. **Use accessories wisely.** Heated seats, the rear defroster, the air conditioner and other power features draw electrical energy. When you operate your accessories, you may notice that the gasoline engine needs to start. Choose "Accessory Power" when configuring your MyView screen to see how much electricity you are using to power your vehicle's accessories.

7. **Check your tires.** Proper tire inflation can help you improve your fuel economy by up to 3.3 percent, according to the Department of Energy, while under-inflation could lower your fuel economy by 0.3 percent for every 1 psi drop in pressure of all four tires. Check your vehicle's door sticker for recommended cold tire inflation pressure.

## Fuel History and Coach

Within the information displays, you'll be able to see how your driving style directly impacts your fuel economy.

**Fuel history** provides instant fuel economy, plus your recent fuel economy averaged over selectable intervals of 1, 2 or 6 minutes.

**Coach** can teach you how to improve your fuel economy by providing feedback on your recent acceleration, braking and cruising behavior.

Efficiency Leaves show your recent driving efficiency measured over the last few minutes. More leaves mean better fuel economy!

## Eco Cruise Control

This feature saves vehicle energy by relaxing acceleration compared to standard cruise control. For example, your vehicle may temporarily lose speed when going uphill. **ECO** will appear in the information display when you activate ECO cruise control. You can switch it on or off in the information display, through the Driver Assist section of the Settings menu.

# GETTING STARTED WITH YOUR SYNC® SYSTEM

SYNC Is a Hands-free,  
Voice Recognition System  
Used for Entertainment,  
Information and  
Communication.  
SYNC. Say the Word.

## Before You Get Started

1. Set up your owner account at [SyncMyRide.com](http://SyncMyRide.com) (U.S.) or [SyncMyRide.ca](http://SyncMyRide.ca) (Canada). Register and you will see which complimentary services you are eligible for.
2. SYNC uses a wireless connection called  *Bluetooth*® to communicate with your phone. Switch *Bluetooth* mode on in your phone's menu options. This lets your phone find SYNC. For more details on setting up your phone with SYNC, visit [SyncMyRide.com](http://SyncMyRide.com) (U.S.) or [SyncMyRide.ca](http://SyncMyRide.ca) (Canada), or your phone manufacturer's website.

## Pairing Your Cell Phone with SYNC

In order to use many of the features of SYNC, such as making a phone call or receiving a text, you must first connect or pair your phone with SYNC.

### To Pair Your Cell Phone for the First Time

1. Make sure that your vehicle is in park (P), then switch your ignition and radio on.
2. Press the phone button . When the display indicates there is no phone paired, press **OK**.
3. Put your phone into *Bluetooth* discovery mode. See your phone's manual, if necessary.
4. When prompted on your phone's display, enter the six-digit PIN provided by SYNC into your phone.
5. The display indicates when the pairing is successful.

### The System May Prompt You to

- » Set your phone as the *primary or favorite* (the primary phone receives messages and voicemail).
- » Download your phone book (a requirement to use the full set of voice commands).
- » Switch on 911 Assist®.

### TIPS

- » Make sure you accept the request from SYNC to access your phone.
- » To pair subsequent phones, please refer to *Pairing Subsequent Cell Phones* in the SYNC chapter of your *Owner's Manual*.
- » If you experience pairing problems, try performing a clean pairing by deleting your services from SYNC, deleting your phone pairing from SYNC, and then repeating the Pairing Your Cell Phone with SYNC process.

## Why Do You Need a SYNC Owner Account?

A SYNC owner account provides you with the latest software updates and, if you have questions, free customer support.

**NOTE** Your SYNC system may offer advanced features. Visit the website or call the toll-free number for more information. See the inside front cover of this guide for details.

## Using Your Cell Phone with SYNC

**NOTE** You must download your phone book to make phone calls with voice commands by name.

### *Making a Phone Call*

Use SYNC to make a phone call to anyone in your phone book by pressing the voice button . When prompted, say a voice command.

For example, you could say **“Call Jake Smith at home”**. When the system confirms the number, say **“Dial”** again to initiate the call.

**NOTE** You can also make phone calls by pressing the voice button  and when prompted, give the voice command **“Dial”**, then verbally say the phone number.

### *Answering Incoming Calls*

Whenever you have an incoming call, the name and number of the person calling appears in the display. Press the phone button  to answer an incoming call. You can hang up at any time by pressing and holding the phone button .

### *Do Not Disturb Mode*

This feature blocks incoming calls and text messages and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command **“Do not disturb on”** to enable and **“Do not disturb off”** to disable.

## Using SYNC to Access Digital Media

Plug in your USB media devices such as phones and MP3 players, and use SYNC to play all of your favorite music.

### *Using Voice Commands to Play Music*

1. Plug your media player into your USB port.
2. Press the voice button . When prompted, say **“USB”**, then follow-up by saying a voice command.

# SYNC® WITH MYFORD TOUCH®\*



**Phone**  
Press this corner to access the phone functions.

**Navigation**  
Press this corner to access navigation maps or directions.

**Entertainment**  
Press this corner to access all available music/media sources.

**Climate**  
Press this corner to access all available climate functions, including one-touch access to heated seats (if equipped).

**Information**  
Press this to access SiriusXM Travel Link and Traffic.

**Home**  
Press this to return to the home screen.

**EV Info**  
Press this to access information about your Electric Vehicle.

**Settings**  
Press this to access personalized system settings.

## EV Info

- » Your system has hybrid-specific screens that display your vehicle power settings.
- » Press the **EV Info** button to view the Power Flow screen. This shows you where your vehicle power is coming from and where it is being used.



## A Revolutionary Way to Connect with Your Vehicle

Use the four-corner, four-color touchscreen to explore and interact with your vehicle. The touchscreen works the same way as traditional controls, knobs and buttons do. Press the various corners on your touchscreen to personalize the many features and settings of your vehicle all in one place.

### General Tips

- » Press the home icon  at any time to return to your home screen.
- » Refer to your *Owner's Manual*, visit the website or call the toll-free number for more information. See the inside front cover of this guide for details.

### Before You Get Started

- » Pair your phone to SYNC before using MyFord Touch (see the *Getting Started with Your SYNC System* section for instructions).
- » Make sure you insert your navigation SD card\* into the media port (located in the center console) or your navigation features cannot work.

\*if equipped

## Get in Touch Using Your Four-corner Touchscreen

Phone, Navigation\*, Climate and Entertainment are the four main features of SYNC® with MyFord Touch®. Each feature has its own corner represented by its own color.



### Phone

Voice-control your phone for hands-free calling with your phone securely put away. With SYNC, you do not even need to know the phone number. Just say the name of the person you want from your contacts.

#### *Your Cell Phone Connects You with Many Other Features*

- » Listen to text messages (phone-dependent feature).
- » Transfer calls seamlessly from SYNC to phone as you get in or out of your vehicle.

**NOTE** Your cell phone allows you to connect automatically with a 911 Operator in the event of an accident (you must switch the system on prior to the event).

Refer to the *MyFord Touch* chapter of your *Owner's Manual* for complete details.



### Navigation\*

Press the upper-right, green corner to access features within your available, voice-activated navigation system:

- » SiriusXM Traffic
- » SiriusXM Travel Link
- » GPS (Global Positioning System) technology
- » 3-D mapping
- » Turn-by-turn navigation


Some features require activation. Refer to the *MyFord Touch* chapter of your *Owner's Manual* for complete details.

#### *Set a Destination*

Set a destination through your touchscreen by using a street address, a city center, a place on the map or a point of interest (POI). The easiest way, however, is by voice.

1. Press the voice button  .  
When prompted, say **“Destination street address”**.
2. The system asks you to say the full address and displays an example on screen.

3. You can then speak the address naturally, such as: **One two three Main Street, Anytown.**



You can also use the touchscreen to enter a destination and narrow your choices by city or street as you type.

You can choose from up to three different types of routes:

- » **Fastest:** Uses the fastest moving roads possible.
- » **Shortest:** Uses the shortest distance possible.
- » **Eco (EcoRoute):** Uses the most fuel efficient route.

\*if equipped

# SYNC® WITH MYFORD TOUCH®\*



## Climate

SYNC with MyFord Touch controls the temperature, airflow direction, fan speed, and activates other climate features like heated front seats for you and your passenger.

### Set Your Temperature

- » Touch the lower-right, blue corner on your touchscreen.
- » Set your exact, desired temperature using the **+** or **-** buttons.

You can also use voice commands to operate the climate. Say a voice command like **“Climate set temperature 72 degrees”** and MyFord Touch makes that adjustment.



## Entertainment

No matter how you store your music, SYNC makes it yours to enjoy when you're behind the wheel. Just press the lower-left red corner of the touchscreen. From here, you can easily go between AM/FM, SiriusXM and other media sources.

### Set Your Radio Presets

- » Touch the Entertainment corner on the touchscreen.
- » Touch **FM**.
- » Enter the desired station and touch **Enter**.
- » Touch **Presets** and then touch and hold one of the memory preset buttons to save it. The sound mutes briefly and then returns once the system saves the station.



### Bring in Your Own Music

Gain access to any audio source by voice and even control how each operates, like changing radio stations, CD tracks or music on one of the following devices:

- » Smart-charging USB
- » **Bluetooth®** streaming
- » SD card\*



Refer to the *MyFord Touch* chapter in your *Owner's Manual*, visit the website or call the toll-free number for more information. See the inside front cover of this guide for details.


\*if equipped

# FUSION HYBRID FEATURES

## Silent Key Start

When starting your vehicle, you may not hear your engine because your hybrid-electric vehicle is equipped with silent key start. This fuel-saving feature allows your vehicle to be ready to drive without requiring your gas engine to be running.

Look for the 'ready to drive' indicator light in your information display. When the light displays, your vehicle has started and is ready to drive.



## ECOSelect

This feature is designed to offer the best possible fuel economy with only a slight impact to vehicle performance and comfort. To activate ECOSelect, press the  button on the center console and a graphic shows on your information display.

With ECOSelect active, you may notice:

- » Less aggressive heating and cooling.
- » Softer acceleration and changes in engine, braking and cruise control behavior.

See the *Unique Driving Characteristics* chapter in your *Owner's Manual* for more information.

## Unique Driving Characteristics

This hybrid vehicle combines electric and gasoline propulsion to provide breakthrough performance and improved efficiency. Familiarizing yourself with these unique characteristics will provide an optimal driving experience from your new vehicle.

**Conditions that may cause the engine to start up or remain running include:** considerable vehicle acceleration, vehicle speed above 85 mph (137 km/h) (although this may vary during certain climate or road conditions), ascending a hill and the engine is not warm enough to provide a requested cabin temperature.

**Driving:** The gas engine automatically starts and stops to provide power when needed and to save fuel when not needed. While coasting at low speeds, coming to a stop, or standing, the gas engine normally shuts down and the vehicle operates in electric-only mode.

**Braking:** Your hybrid is equipped with standard hydraulic braking and regenerative braking. Regenerative braking is performed by your transmission and it captures brake energy and stores it in your high voltage battery.

**Stopping:** The gas engine may shut off to conserve fuel as you come to a stop. Restarting the vehicle is not required. Simply step on the accelerator when you are ready to drive.

## EV+ Mode

Your vehicle recognizes your frequent destinations and allows for more EV driving as you approach them. For example, when nearing your home it should be easier to stay in electric mode. The EV indicator displays **EV+** when this mode is active. You should see this about 1/8 mile (200 m) from a frequent destination.

You can clear your frequent destinations with a Driving History reset through the Settings menu. You can also switch the EV+ feature off through the Driver Assist section of the Settings menu. See the *Information Display* chapter in your *Owner's Manual* for details.

# COMFORT

## Intelligent Access\*

**NOTE** Your intelligent access transmitter must be within 3 feet (1 meter) of the vehicle for intelligent access to function properly.

This system operates the power locks.

To unlock a door, pull the exterior door handle. Make sure not to touch the lock sensor on top of the handle. To unlock and open the luggage compartment, press the exterior release button hidden above the license plate.

To lock the doors, touch the lock sensor on top of the door handle. The transmitter also contains a mechanical key blade to unlock the driver's door, if necessary.

**NOTE** You must have a valid transmitter inside the vehicle to switch on the ignition and start the engine.

## Memory Function\*

Use the memory controls located on the driver's door to program and then recall memory positions. Move the seats and mirrors to the desired positions. To program up to 3 positions, press and hold the desired pre-set button until you hear a single tone. You can now use these controls to recall the set positions.

You can also program your memory seats to your transmitter. That way, when you unlock your door with the transmitter, your memory features automatically move into your saved position. See the *Seats* chapter in your *Owner's Manual* for more details.

## Remote Start\*

Remote start allows you to start the engine from outside your vehicle using your remote transmitter.

To start, press  and then press  twice within three seconds. Once inside, apply the brake while pressing the **START STOP** button. Shift into drive (D) and go.

If you have the integrated keyhead transmitter, insert the key into the ignition and switch on the ignition as you normally would before driving. To switch off the engine from outside the vehicle after using your remote start, press  once.



\*if equipped

## Driver Seat with Easy Entry and Exit\*

With the easy entry and exit feature enabled in the information display, your driver seat automatically moves rearward up to two inches (five centimeters) when you switch the ignition off. The driver seat returns to the previous position when you switch the ignition on. See the *Information Display* chapter in your *Owner's Manual* for more details.

## Climate Controlled Front Seats\*

For heated seats, press  repeatedly to cycle through the various settings and off. More indicator lights mean warmer settings. For cooled seats, press  repeatedly to cycle through the various settings and off. More indicator lights mean cooler settings.

## Moonroof\*

Your moonroof controls are located on the overhead console and have a one-touch open and close feature. To open the moonroof, press . It stops short of the fully opened position to help reduce wind noise. To close, press . To use the venting feature, press .



## Tilting Head Restraints



Your vehicle's front head restraints have a tilting feature for extra comfort.

### To Tilt the Head Restraint

Adjust the seatback to an upright driving or riding position. Pivot the head restraint forward toward your head to the desired position. Once it is in the forward-most position, tilting it forward once more releases it to the upright position.

**NOTE** Do not attempt to force the head restraint backward after tilting it. Instead, continue tilting it forward until the head restraint releases to the upright position.

## Ambient Lighting\*

Lights various places, such as the footwells, with a choice of colors.

### Access Using Your Touchscreen and Make Your Adjustments

1. Press the **Settings** icon > **Vehicle** > **Ambient Lighting**.
2. Touch the desired color.
3. Use the scroll bar to increase or decrease the intensity.

To switch off this feature, press the power button.

# FUNCTION

## Lane Keeping System\*

Notifies you to stay in your lane through the steering system and the instrument cluster display when the front camera detects an unintentional drift out of your lane is likely to occur. The system automatically detects and tracks the road lane markings using a camera mounted behind the interior rear view mirror.

Press the button located on the left steering wheel lever to switch the system on or off.

**NOTE** The system stores the on or off setting until you manually change it, unless the system detects a MyKey. Set your preferred system settings by Mode and Intensity through your information display screen. Refer to the *Information Displays* chapter in your *Owner's Manual* for more details on how to change your settings. Refer to the *Driving Aids* chapter in your *Owner's Manual* for more information on the Lane Keeping System.

## Driver Alert\*



Automatically monitors your driving behavior using various inputs including the front camera sensor. If the system detects that your driving alertness level reduces below a certain threshold, then the system alerts you with a tone and a message in the cluster display. Press OK on the steering wheel to clear the warning.

## Pre-Collision Assist Warning System\*

This system alerts you of certain collision risks. The system's sensor detects your vehicle's rapid approach to other vehicles traveling

in the same direction as your vehicle. When your vehicle rapidly approaches another vehicle, a red warning light flashes and a tone sounds.

The brake support system assists you in reducing any collision speed by pre-charging the brakes. If the risk of collision continues to increase after the audiovisual warning, the brake support prepares the brake system for rapid braking. The system does not automatically activate the brakes, but if you press the brake pedal lightly, the brakes apply full stopping power. Refer to the *Driving Aids* chapter in your *Owner's Manual* for more details.

You can adjust the warning system's sensitivity through your information display. Refer to the *Information Displays* chapter in your *Owner's Manual* for more details.

## BLIS® (Blind Spot Information System) with Cross Traffic Alert\*

BLIS is designed to aid you in detecting vehicles that may have entered into your blind spot zone. Cross traffic alert warns you of vehicles approaching from the sides when the transmission is in reverse (R). BLIS and cross traffic turn on a yellow indicator light in the exterior mirror on the side of the vehicle the approaching vehicle is coming from. Refer to the *Driving Aids* chapter in your *Owner's Manual* for more information.

**NOTE** NEVER use BLIS or cross traffic alert as a replacement for using the interior and exterior mirrors and looking over your shoulder before changing lanes. The systems are not replacements for careful driving. Use both systems only as an assist.

\*if equipped

## Configurable Daytime Running Lamps\*

When you switch the feature on in the information display, daytime running lamps turn on when you are driving, the lighting control is in the autolamps position  and the headlamps are off. You can switch the Configurable Daytime Running Lamps feature ON or OFF using the information display controls. See the *Lighting* chapter in your *Owner's Manual* for complete information.

## Rear View Camera

Provides a video image of the area behind the vehicle. The display automatically appears in the touchscreen or the rearview mirror when the vehicle is in reverse (R) and uses green, yellow and red guides to alert you of your proximity to objects.

## Front and Rear Parking Aids\*

Sounds a warning tone if there is an obstacle near either bumper. The warning tone increases in frequency as the object gets closer. The front sensors are active when the gearshift is in any position other than park (P) or neutral (N) and the vehicle speed is below 7 mph (12 km/h). The rear sensors activate when the vehicle is in reverse (R) and is traveling less than 3 mph (5 km/h).

**NOTE** Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your *Owner's Manual* for safety information, more details and system limitations.

## Active Park Assist\*

The system detects an available parallel parking space and automatically steers the vehicle into the space (hands-free) while you control the accelerator, gearshift and brakes.

- » Press the  button on the center console near the gearshift lever. The touchscreen displays a message and a corresponding graphic to indicate it is searching for a parking space.
- » Use the direction indicator to indicate which side of your vehicle you want the system to search. If the direction indicator is off, the system automatically searches on the passenger side of the vehicle.
- » When the system locates a suitable space, the touchscreen displays a message and a tone sounds. Bring your vehicle to a complete stop, approximately even with the vehicle in front of where you wish to park, then follow the instructions on the touchscreen.

**NOTE** The driver is always responsible for controlling the vehicle, supervising the system and intervening, if required.



\*if equipped



# ESSENTIAL INFORMATION

## Fuel Tank Capacity/Fuel Info

Your vehicle has a fuel tank capacity of 13.5 gallons (51.1 liters). Use only **UNLEADED** fuel or **UNLEADED** fuel blended with a maximum of 15% ethanol. **Do not use ethanol (E85), diesel, fuel-methanol, leaded fuel or any other fuel because it could damage or impair the emission control system.**

## Low Fuel Reminder

A low fuel reminder triggers when the distance to empty is about 50 miles (80 km) to empty.

## Hybrid Transmission

Your hybrid's transmission is designed to do its work seamlessly, so you may not feel shift changes as you normally would in a

gasoline-powered vehicle. You may feel the transition when the system changes from electric vehicle (EV) mode to gas mode. This is normal. Since your engine speed is controlled by the transmission, it may seem elevated at times. This is also normal hybrid operation as it helps deliver fuel efficiency and performance.

## Easy Fuel<sup>®</sup> System

Put your vehicle into park (P) and switch the ignition off. Open the fuel release door. Slowly insert the fuel filler nozzle into the fuel system, and leave the nozzle fully inserted until you stop pumping fuel. Allow about five to ten seconds after pumping fuel before removing the fuel filler nozzle. Slowly remove the fuel filler nozzle.



**NOTE** When using a portable fuel container, slowly insert the fuel funnel (located under the luggage compartment floor covering), and pour the fuel into the funnel. When done, clean the funnel or properly dispose of it. Do not use aftermarket funnels as they do not work with the Easy Fuel system and may cause damage. You can purchase extra funnels from your authorized dealer. Refer to the *Refueling* section in the *Fuel and Refueling* chapter of your *Owner's Manual* for warnings and additional information.

## Open Window Buffeting

You may hear a pulsing noise when just one of the windows are open. Lower the opposite window slightly to reduce this noise.



## Roadside Assistance

Your new Ford vehicle comes with the assurance and support of 24-hour emergency roadside assistance.

To receive roadside assistance in the United States, call **1-800-241-3673**.

In Canada, call **1-800-665-2006**.

## Tire Pressure Monitoring System

Your vehicle illuminates a low tire pressure warning light (⚠️) in your instrument cluster when one or more of your tires are significantly under-inflated. If this happens, stop and check your tires as soon as possible, then inflate them to the proper pressure. Refer to the *Tire Pressure Monitoring* section in the *Wheels and Tires* chapter of your *Owner's Manual* for more information.

## Temporary Mobility Kit

The kit is in under the load floor of the luggage compartment. It consists of an air compressor to reinflate the tire and a sealing compound in a canister that seals most punctures caused by nails or similar objects. Refer to the *Wheels and Tires* chapter of your *Owner's Manual* for more details.

## Towing Your Fusion Hybrid

Towing your vehicle behind an RV or any other vehicle may be limited. Refer to *Towing the Vehicle on Four Wheels* in the *Towing* chapter of your *Owner's Manual*.

## Automatic Shutdown\*

In vehicles equipped with intelligent access\*, this feature automatically shuts down the vehicle if it has been idling for an extended period. The ignition also turns off in order to save battery power. Before the engine shuts down, a message appears in the information display, allowing you to override the shutdown feature temporarily.

**NOTE** You cannot permanently switch off the automatic shutdown feature. When you switch it off temporarily, it turns on at the next ignition cycle. See *Starting and Stopping the Engine* chapter of your *Owner's Manual* for more details.

\*if equipped