





focus



Cassette/CD Radio Basic Operation *(If equipped)*
 To eject a cassette, simultaneously press FF and REW all the way in. To adjust the Bass/Treble and Fade/Balance, press the appropriate button once/twice, and then adjust using the volume control knob.




Temperature Controls


Turning Air Conditioning On/Off *(If equipped)*
 Don't lose your cool. To turn the air conditioning system ON, the fan speed must be set to "1" or higher, and the A/C button must be ON. Cool enough? To turn the air conditioner OFF, simply set the fan speed to "0" or press the A/C button. You may experience air coming through your register even though your blower is set at zero. If this is not preferred, turn your Recirculation button ON. (Green light)



MAX A/C Activation *(If equipped)*
 When you want to chill out fast. Push both the A/C and Recirculation buttons on the instrument panel. Note: MAX A/C shuts off when the vehicle is turned off. The Recirculation button must be pressed again when the vehicle is restarted to reactivate MAX A/C. Please refer to owner's manual for A/C performance at high engine demands.



Defroster Performance *(A/C equipped only)*
 Need a clearer view? In the Defrost mode, the A/C will automatically come ON and the Recirculation control will turn OFF for optimal Defrost and Defog function. Be aware that the A/C will not come on if outside temperatures fall below 40° F (4° C).



Mode Selector Control
 Put the air where you want it, when you want it. A turn of the dial controls the direction of the airflow inside the vehicle. Selecting a position partway between modes will divide the airflow between the modes selected.

7543-196217-AA




focus

Get To Know Your Focus


Congratulations! You're the owner of a 2001 Ford Focus. Smart decision. You probably won't have time to sit out on the road. But take a minute to get acquainted, make yourself comfortable (it's not hard in the roomy Focus interior). Here's a quick rundown of some standard and optional features available on your new Focus. We know you'll read your Owner Guide, but Focus has so many great features that we couldn't wait to tell you about them. If you want to know more, the Owner Guide has all of the nitty-gritty details.




Driver's Seat with Manual Height Adjustment
 While you're getting comfortable, check out the standard driver's-seat manual height adjustment knob, located on the front lower right portion of the seat. Separate controls let you adjust the seat forward and backward.



Tilt and Telescoping Steering Wheel *(If equipped)*
 Here's another way Focus adjusts to you — not the other way around. Pull the locking lever (on the underside of the steering column) down, allowing the steering column to move. Adjust the steering column up or down, as well as toward or away from you, to find the driving position you like best.
WARNING: Never adjust the steering wheel while the vehicle is moving.



Overdrive Cancel Button
(Standard on Focus models with automatic transaxle) Focus lets you be in charge. If you're towing or driving in the mountains, you may want to switch the Overdrive OFF. Find the button on the shifter handle, below the thumb button. A light on the instrument cluster indicates when Overdrive is OFF. Overdrive defaults to ON when you turn the ignition OFF and then ON again.



Manual Transaxle Reverse Gear Lockout
(Standard on Focus models equipped with the Zetec engine and the manual transaxle ONLY) The gearshift lever has a collar under the shift knob that must be lifted to shift into Reverse.




focus




Power Mirror Switch *(If equipped)*

Personalize Focus to the settings you want. The power mirror switch can be swiveled and turned to adjust the outside mirrors. Turning the switch counterclockwise will operate the driver's-side mirror; turning the switch clockwise will operate the passenger's-side mirror.



One-Touch-Down Driver's-Side Window Operation *(If equipped)*

This makes fast-food drive-thru windows and ATM machines a breeze. To make the driver's-side window open fully without holding the window button, press the driver's-side window button completely down momentarily and release. Press again to stop window operation.




Luggage Compartment Button

Does Focus make life easier, or what? To open the luggage compartment without getting out of the car, press the button located to the left of the instrument cluster. A word of caution: Don't try this when the car is moving.



Remote Keyless Entry *(If equipped)*

To open the driver's door, press the UNLOCK button once. Push the button twice in succession to open all doors. To lock all doors, press the LOCK button once. To open the trunk, press the TRUNK button once. Press the PANIC button once to activate the alarm. Press the button again to deactivate.




Fog Lamp Control *(If equipped)*

Nothing could be simpler. The fog lamp control is incorporated into the headlamp switch. To operate, turn on the headlamps and gently pull the switch toward you.


Rear Window Wiper/Washer Switch

(Wagon and 3-door ZX3 models only) To operate the rear window wiper, pull the wiper control toward you for intermittent wiping. To operate the rear window washer, pull the lever toward you.




Folding Rear Seatback

1. Lift the lower seat cushion and flip it forward.
2. *(Wagon and 3-door ZX3 models only)* Push the unlocking control on the rear seatback and fold the rear seatback forward. *(Sedan models.)* Pull one or both of the unlocking controls in the luggage compartment and fold the rear seatback forward.
3. Remove the head restraints and lay the seatback down. Note: Remember to install the head restraints once the seatback is flipped up.



Rear-Door Child-Safety Locks

(Sedan and Wagon models only) The child-safety locks are located on the rear edge of each rear door. To set the locks, insert the vehicle key into the opening and turn to the lock position (vertical). Turn the key toward the center of the vehicle to disengage the child-safety locks.



Audio System Features

We know your tunes are important to you, so listen up. Your audio system may include a removable **Anti-Theft Protection Panel**, which helps protect against would-be thieves. It must be fastened securely for the radio to operate. **Automatic Volume Control** changes the volume to compensate for road noise. **Keep Alive Power** allows for one hour of radio operation with the vehicle off and the key out of the ignition.



Clock Features

To set the clock, with the radio on press the CLK button and hold until the hour digit flashes. Then use the volume control knob to adjust. Press CLK again to adjust the minutes. Pressing CLK a third time will return the system to normal operation.

