

This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Ford dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.



fordowner.com (U.S.)



ford.ca (Canada)



Ford Motor Company Customer
Relationship Center

U.S. • 1-800-392-3673 (FORD)
(TDD for the hearing impaired: 1-800-232-5952)
fordowner.com

Ford of Canada's Customer Relationship Centre
Canada • 1-800-565-3673 (FORD)
ford.ca


Learn more about your **SUPER DUTY**

To put QR tags to work for you, use your mobile phone's browser or App store link to download a QR tag reader. Then follow the directions to scan the QR tag and see your vehicle's features come to life.

Learn how to **SYNC** your ride

SYNC is a voice-activated technology personalized by you. It is a hands-free, voice recognition system used for entertainment, information and communication.

SyncMyRide.com (U.S.)
SyncMyRide.ca (Canada)



September 2012 • First Printing
Quick Reference Guide • **SUPER DUTY**
Litho in USA • **DC3J 196217 AA**

WARNING: Driving while distracted can result in loss of vehicle control, accident and injury. Ford Motor Company strongly recommends that drivers use extreme caution when using any device or feature that may take their focus off the road. Your primary responsibility is the safe operation of the vehicle. We recommend against the use of any hand-held device while driving, encourage the use of voice-operated systems when possible and that you become aware of applicable state and local laws that may affect use of electronic devices while driving.

SUPER DUTY

2013

QUICK REFERENCE GUIDE



SUPER DUTY COMMONLY USED VOICE COMMANDS

SYNC...Say the Word Touch the  button on the right-hand side of your steering wheel, and then say:

- Basic Commands**
 - What can I say?
 - List of commands
 - Main menu
 - Previous
 - Next
 - Go back
 - Exit
 - Help
 - Vehicle health
 - Pair my phone
- Entertainment**
 - Audio list of commands
 - You can also get detailed lists of commands for radio, USB, Bluetooth® audio, Sirius and SD Card
 - Audio <On/Off>
 - Radio
 - FM <87.7-107.9>
 - FM preset <#>
 - CD
 - Play track <1-152>
 - Shuffle <On/Off>
 - USB
 - Play song <name>
 - Play album <name>
- Phone**
 - Phone list of commands
 - Dial
 - Call <name> on cell/at home/at work
 - Call voicemail
 - Do not disturb
 - Listen to text messages (phone-dependent feature)
- Climate***
 - Climate control list of commands
 - Climate <On/Off>
 - Climate my temperature
 - Climate temperature <60-85>degrees
- SYNC Services**
 - Say "Services" first, and then, "What can I say?"
 - Traffic
 - Directions
 - Business search
 - Operator (for direction or business search)
 - Favorites
 - SiriusXM
 - <channel name>
 - Preset <#>
 - News, sports, weather, horoscopes, stock quotes, movies or travel
 - Help
- Navigation***
 - Navigation list of commands (if equipped)
 - Destination street address <number, name, city>
 - Destination home
 - Navigation voice <On/Off>
 - Navigation volume <increase/decrease>
 - Repeat instruction
 - Show <map/north-up/heading-up/3D>
 - Travel Link list of commands
 - Traffic
 - Weather
 - Movie Listings
 - Fuel prices
 - Sports <headlines/scores/schedule>

* Available only with MyFord Touch.

Some services may not be available in your area. Refer to your Owner's Manual, visit the website or call the toll-free number for more information.

For U.S. customers: visit SyncMyRide.com or call **1-800-392-3673** (select Option 1 or 2 for language, then Option 3).

For Canadian customers: visit SyncMyRide.ca or call **1-800-565-3673** (select Option 1 or 2 for language, then Option 3).



TABLE OF CONTENTS

4-5	INSTRUMENT PANEL
6-8	SYNC
9-13	SYNC WITH MYFORD TOUCH
14-15	COMFORT & CONVENIENCE
16-17	ESSENTIAL INFORMATION
18-19	FUNCTION

INSTRUMENT



PANEL

1 STEERING WHEEL CONTROLS*

Use the controls to adjust frequently accessed features. Press **Set +** or **Set -**, RSM and OFF to set and adjust the cruise control speed*.

Use the left-hand controls to scroll through and make selections from within your information display. Use the right-hand controls to adjust audio volume and media selection, and to activate voice controls*.

2 POWER-ADJUSTABLE PEDALS*

Located on the left side of the steering column, press the **◀** arrow to move the accelerator and brake pedals farther away from you; press the **▶** arrow to move the pedals closer.

Note: Adjust the pedals only when the vehicle is in (P) park.

3 INFORMATION DISPLAY*

Monitor vehicle systems, receive alerts, and program and configure certain vehicle features. Use your steering wheel controls to scroll, make selections and adjustments that will appear in the message center within the instrument cluster.

The LCD productivity screen displays features such as Gauge Mode with diesel-specific engine oil temperature and exhaust filter information along with transmission temperature and compass data.

A and B trip odometers also include trip time, fuel used and average fuel economy.

Instant fuel economy also provides fuel history in select increments and saves your last five resets.

Truck apps (if equipped) include details about trailers and off-road features.

The Settings menu delivers Driver Assist features such as rear park aid, rear camera, and more. Refer to your *Owner's Manual* for more information.

4 SELECTSHIFT AUTOMATIC® TRANSMISSION

Change gears without a clutch. Put the gearshift into **M** (manual) and press **+** to upshift and **-** to downshift. To lock gears, put the gearshift lever into **D** (Overdrive) and press **-** to lock out the gears. Only the available gears will be displayed. Press **+** to unlock the gears.

5 TOW/HAUL MODE

Activate the Tow/Haul mode to eliminate excessive transmission shifting when traveling on a grade. When equipped with exhaust braking (diesel only), this feature also helps slow the vehicle and assist the driver while descending a grade.



6 ELECTRONIC SHIFT-ON-THE-FLY 4X4 SYSTEM*

Rotate the knob and shift from 2WD to 4x4 High or Low:

2H (2WD) provides power to the rear wheels only. This is appropriate for normal, on-road driving on dry pavement, providing optimal smoothness and fuel economy at high speeds.

4H (4WD HIGH) delivers extra gearing for maximum power to all four wheels at reduced speeds. This is intended for use in situations such as deep sand, steep grades or pulling heavy objects.

4L (4WD LOW) mechanically locks into four-wheel drive when extra power at reduced speeds is required. Use this setting for off-road, low-speed operation such as climbing steep grades, going through deep sand or pulling a boat out of the water.

Note: Do not use 4H or 4L on dry, hard-surfaced roads. Doing so can produce extra noise and increase tire wear. For more complete details, refer to the Four-Wheel Drive chapter of your *Owner's Manual*.

7 MEDIA HUB

8 HILL DESCENT CONTROL*

While traveling at low speeds (between 2 mph [3 km/h] and 12 mph [20 km/h]), activate to help maintain vehicle speed while descending steep grades in a variety of road conditions. To enable, press the hill descent button. A light in the cluster will illuminate  and a chime will sound.

To increase descent speed, press the accelerator pedal until the desired speed is reached.

To decrease speed, press the brake pedal until the desired speed is reached.

Note: Hill descent control requires a cooling down interval after sustained use. The amount of time that the feature can remain active before cooling varies with conditions. The system will provide a warning in the information display and a chime will sound when the system is about to disengage for cooling. At this time, manually apply the brakes as needed to maintain descent speed.

9 TRAILER BRAKE CONTROLLER*

The fully integrated trailer brake controller (TBC) synchronizes vehicle and trailer brakes for seamless braking (even with the heaviest loads) to provide added driving control and confidence. Use the GAIN adjustment buttons to increase or decrease the braking feature's power output to the trailer. Refer to the *Towing* section of your *Owner's Manual* for more details.

10 LARGE CONTROLS FOR EASY HANDLING

Even when you are wearing gloves, the audio, climate and other system controls are easy to adjust.



11 UPFITTER SWITCHES*

The four switches can be customized to control additional functions, with 8, 12 or 20 amps of electrical battery power.

*IF EQUIPPED

GETTING STARTED WITH YOUR SYNC SYSTEM

SYNC is a hands-free, voice recognition system used for entertainment, information and communication. SYNC...Say the word.

BEFORE YOU GET STARTED:

1. Set up your owner account at SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada). Register by following the on-screen instructions, and then learn about the complimentary services that are available to you.
2. SYNC uses a wireless connection called Bluetooth® to communicate with your phone. Turn Bluetooth mode on in your phone's menu options. This lets your phone find SYNC. For more details on setting up your phone with SYNC, visit SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada), or your phone manufacturer's website.

PAIRING YOUR PHONE WITH SYNC:

Pair your phone to use the many of the features of SYNC:

1. Make sure that your vehicle is in (P) park and both your ignition and radio are turned on.
2. Press the phone button . When the display indicates no phone is paired, press **OK**.
3. When **Find SYNC** appears in the display, press **OK**.
4. Put your phone into Bluetooth discovery mode. Refer to your phone's user guide if necessary.
5. When prompted on your phone's display, enter the six-digit PIN provided by SYNC in the radio display.
6. The display indicates when the pairing is successful.

Note: The system may prompt you to:

- Set your phone as the primary/favorite (the primary phone will receive messages and voice mails).
- Download your phone book (this is required to use the full set of voice commands).
- Turn on 911 Assist®.



WHY DO I NEED A SYNC OWNER ACCOUNT?

A SYNC owner account is required for Vehicle Health Report activation and the ability to view your reports online. You'll also be able to take advantage of all of SYNC's Services and personalization features, such as saving your Favorites and Points of Interest (POI). You'll receive the latest software updates that add new places, directions and information; and if you have questions, you'll get free customer support. Visit the website or call the toll-free number to set up your account. See the inside front cover of this guide for more information.

COMMONLY USED VOICE COMMANDS SYNC... SAY THE WORD


Every time you want to give SYNC a voice command, you must first press the voice button  and when prompted, speak your voice command. For a list of voice commands, say **"What can I say?"**

USING MY PHONE WITH SYNC

Note: You can download your phone book to make phone calls with voice commands by name. Contacts listed in all caps will require you to spell them (i.e. JAKE will be J-A-K-E).

Making a phone call: Use SYNC to make a phone call to anyone in your phone book by pressing the voice button . When prompted, give a voice command.

For example, you could say, "Call Jake Smith at home". When the system confirms the number, say "Dial" to initiate the call automatically or say the phone number.



Answering incoming calls: Whenever you have an incoming call, you will be able to see the name and number of the person calling in your display. Press the phone button to answer an incoming call. You can hang up at any time by pressing and holding the phone button .

MEDIA HUB



USING SYNC TO ACCESS DIGITAL MEDIA

Your vehicle includes a concealed SYNC media hub. The multiple inputs allow you to plug in your USB media devices such as phones and MP3 players, and use SYNC to play all of your favorite music. In vehicles equipped with SYNC, the media hub is located in the center console. In vehicles equipped with MyFord Touch®, the media hub is located on top of the instrument panel (as shown above).

Note: SYNC indexes all of your music. The more music that is stored on your device, the longer it takes SYNC to index.

Using voice commands to play music:

1. Plug your media player into your USB port.
2. Press the voice button . When prompted, say **"USB"** and then follow up by saying a voice command.
3. You will hear the command repeated back to you and the selected item will play.

APPLINK

SYNC AppLink™ allows you voice access to select mobile applications that you already have or can download to your Android™, BlackBerry® or iPhone®. Current apps available include Pandora Internet Radio®, Stitcher Smart Radio™, Open Beak (BlackBerry exclusive), iHeartRadio, Slacker, NPR News, SYNC Destinations and more.

Note: AppLink is **not** available with MyFord Touch systems.



Using SYNC AppLink

1. Create your app account and personalize your app settings, if required.
2. Download the latest mobile app through your Smartphone's marketplace.
3. Turn on your ignition.
4. Pair the phone to a SYNC AppLink vehicle. If your phone is already paired to the vehicle, it connects automatically when you enter.
5. If you're an iPhone owner, you must also connect the Apple®-provided USB cable and start the application you want to use on your iPhone to access the apps through SYNC. Android and BlackBerry connect wirelessly using SYNC AppLink.
6. Now you're ready to voice-access the app by pressing the voice button and saying "mobile apps" and then the name of the app you want.

For more information on SYNC, please visit the website or use the toll-free number. See the inside front cover of this guide for details.

SYNC WITH MYFORD TOUCH[®]

Phone
Press this corner to access the phone functions.

Navigation
Press this corner to access Navigation maps or directions.

Entertainment
Press this corner to access all available music/media sources.

Climate
Press this corner to access all available climate functions, including one-touch access to heated seats (if equipped).

Information
Press this to access SYNC[®] Services, Sirius XM[®] Travel Link and Traffic.

Home
Press this to return to the home screen.

Settings
Press this to access personalized system settings.

A REVOLUTIONARY WAY TO CONNECT WITH YOUR TRUCK.

GET IN TOUCH USING YOUR FOUR-CORNER TOUCH SCREEN

GENERAL TIPS:

- Press the home icon at any time to return to your home screen. You can also use SYNC to go back by saying the voice command **"Go back"**.
- For additional support, refer to your *Owner's Manual*, visit the website or call the toll-free number. See the inside front cover of this guide for more information.
- The touch screen is sensitive, so make sure you press the desired icon accurately and firmly.



GETTING STARTED WITH YOUR SYNC SYSTEM

SYNC is a hands-free, voice recognition system used for entertainment, information and communication. SYNC...Say the word.

BEFORE YOU GET STARTED:

1. Set up your owner account at SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada). Register by following the on-screen instructions, and then learn about the complimentary services that are available to you.
2. SYNC uses a wireless connection called Bluetooth[®] to communicate with your phone. Turn Bluetooth mode on in your phone's menu options. This lets your phone find SYNC. For more details on setting up your phone with SYNC, visit SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada), or your phone manufacturer's website.

PAIRING YOUR PHONE WITH SYNC:

Pair your phone to use the many of the features of SYNC:

1. Make sure that your vehicle is in (P) park and both your ignition and radio are turned on.
2. Press the phone button . When the display indicates no phone is paired, press **OK**.
3. When **Find SYNC** appears in the display, press **OK**.
4. Put your phone into Bluetooth discovery mode. Refer to your phone's user guide if necessary.
5. When prompted on your phone's display, enter the six-digit PIN provided by SYNC in the radio display.
6. The display indicates when the pairing is successful.



Note: The system may prompt you to:

- Set your phone as the primary/favorite (the primary phone will receive messages and voice mails).
- Download your phone book (this is required to use the full set of voice commands).
- Turn on 911 Assist[®].

TIPS

- Make sure you accept SYNC's request to access your phone.
- To pair subsequent phones, please refer to *Pairing Subsequent Phones in the SYNC* chapter of your *Owner's Manual*.
- If you are experiencing pairing problems, refer to your *Owner's Manual*.

SYNC WITH MYFORD TOUCH®



PHONE

Voice-control your phone for hands-free calling with your phone securely put away. With SYNC, you won't even need to know the phone number. Just say the name of the person you want from your contacts.

Your phone connects you with many other features and SYNC Services:

- Connect to SYNC Services for traffic, directions, business searches and information favorites.

- Connect to Operator Assist to help locate a listing or destination.
- Call for a Vehicle Health Report.
- Automatically connects with a 911 Operator in the event of an accident (system must be turned on prior to event).
- Transfer calls seamlessly from SYNC to your phone as you get in or out of your vehicle.



SET UP YOUR IN-CASE-OF-EMERGENCY CONTACTS

You can add contacts from your phone book for simple one-touch access on the touch screen after a 911 Assist® event. You can save up to two contacts on the 911 Assist screen by scrolling through your menu choices and selecting the following information:

- Touch Settings, then Phone and 911 Assist.
- Touch Edit to add contacts from your phone book.

WIRELESS AND INTERNET

Your SYNC with MyFord Touch system has a Wi-Fi feature that creates a wireless network within your vehicle to use with a computer or other Internet-compatible device. From the Settings menu, select Wireless & Internet, and then Wi-Fi Settings.

From there:

- Turn the Wi-Fi network feature on.
- Choose a wireless network.
- Turn the Gateway Mode on to make SYNC an access point for a phone or computer. View and select or change your Gateway settings. Press *i* for more information.

Once the system is active, the local area network within the vehicle lets all passengers connect to the Internet. Refer to the *MyFord Touch* chapter of your *Owner's Manual* for complete details.



Get started with your navigation system by pressing the upper-right, green corner. The available, voice-activated navigation system includes:

- SiriusXM Traffic
- SiriusXM Travel Link
- Global positioning system (GPS) technology
- 3-D mapping
- Turn-by-turn navigation

Refer to the *MyFord Touch*® chapter of your *Owner's Manual* for complete details.

SET A DESTINATION

Set a destination through your touch screen by using a street address, a city center, a place on the map or a Point of Interest (POI). The easiest way, however, is by voice.

1. Push the voice button , then when prompted say **"Destination street address"**.
2. The system will ask you to say the full address and will display an example on-screen.
3. You can then speak the address naturally, such as: **"One two three Main Street, Anytown."**

You can also use the touch screen to enter a destination and narrow your choices by city or street as you type.

You can choose from up to three different types of routes:

- **Fastest:** Uses the fastest moving roads possible.
- **Shortest:** Uses the shortest distance possible.
- **Eco (EcoRoute):** Uses the most fuel-efficient route.



SAVE A FAVORITE

When you find a specific address or a Point of Interest (POI) that you'd like to store within the system, you can save it to your Favorites.

Using the touch screen, press *Save to Favorites*. When you want to view that destination again, you can press *Favorites* to retrieve your stored locations.

Note: Some features, such as Point of Interest (POI) ratings and the ability to type in a destination, are not available while the vehicle is moving. For more complete information, see the SYNC chapter in your *Owner's Manual*.

Tips:

- Save your favorite locations by touching *"Save to Favorites"*.
- Change your map views from Direction Headed, North Up or 3D.



SYNC WITH MYFORD TOUCH®



CLIMATE

SYNC® with MyFord Touch controls the temperature, airflow direction, fan speed, and activates other climate features like heated front seats for you and your passenger. To use voice commands to operate climate, say a voice command like **“Climate temperature 72 degrees”** and MyFord Touch will make that adjustment.

SET YOUR MYTEMP

- Touch the lower-right, blue Climate corner on the touch screen.
- Set your exact, desired temperature using the red or blue arrows.
- Press and hold the MyTemp button until the background goes solid.

SET YOUR PASSENGER'S TEMPERATURE




- Touch DUAL to turn on the passenger side temperature control.
- Touch + or - to adjust the temperature.

ADJUST HEATED OR COOLED FRONT SEATS*

- Touch the heated or cooled seat icon to control the seat temperature.
- More light bars indicate a higher setting.

To operate the heated feature, press  to cycle through the various heat settings and off.

To operate the cooled feature, press  to cycle through the various cooling settings and off.

ENTERTAINMENT

No matter how you store your music, SYNC makes it yours to enjoy when you're behind the wheel. Just press the lower-left, red corner of the touch screen. From here, you can easily go between AM/FM, Sirius, and other media sources.

Set your Radio Presets

- Touch the Entertainment corner on the touch screen.
- Touch *FM*.
- Touch *Direct Tune*.
- Enter the desired station and touch *Enter*.
- Touch *Presets* and then touch and hold one of the memory preset buttons to save it. You will hear a brief mute and the sound will return when the station is saved.

Bring in Your Own Music

Gain access to any audio source by voice and even control how each operates, like changing radio stations, CD tracks or music on one of the following devices:

- CD
- USB
- Bluetooth® Streaming
- SD Card
- A/V In

Refer to your *Owner's Manual*, visit the website or call the toll-free number. See the inside front cover of this guide for more information.



COMFORT & CONVENIENCE

MYKEY®

MyKey allows you to program certain driving restrictions in order to promote good driving habits. You can program things such as speed restrictions, limited volume levels. For complete information, refer to the *MyKey* chapter in your *Owner's Manual*.



MEMORY FEATURE*

The memory function allows a "one touch" recall of personalized memory features (i.e., the positions of the driver seat, power mirrors and power-adjustable foot pedals). Use the memory controls, located on the side of the driver's seat  , to program and then recall memory positions.

To program position 1, press and hold the 1 button  until you hear a chime. Use this same procedure to set the second position using the 2 button . You can now use these controls to recall the set memory positions.

REMOTE ENTRY SYSTEM WITH REMOTE START*

PRESS  **ONCE** to unlock the driver's door.

PRESS  **TWICE** to unlock the passenger and rear doors.

PRESS  **ONCE** to lock all the doors.

PRESS  **TWICE** to confirm all the doors are closed and locked.

PRESS  to activate the panic alarm. **PRESS**  **AGAIN** or turn the ignition on to deactivate the panic alarm.

CAR FINDER:

PRESS  **TWICE** within three seconds. The horn will chirp and the turn lamps will flash. It is recommended to use this method to locate your vehicle, rather than using the panic alarm.

REMOTE START:

PRESS  to lock all the doors.

PRESS  **TWICE**. The exterior lamps will flash twice. The horn will chirp if the system fails to start.



MOONROOF*

Your moonroof is equipped with a one-touch, express opening and closing feature. To open, press and release the SLIDE control, the sunscreen will open. To fully open the moonroof, press and release the SLIDE control again. To close, pull and release the SLIDE control. Press and release the TILT control to vent the moonroof. Pull and hold the TILT control to close the moonroof. The sliding shade can be manually opened or closed when the moonroof is closed. Pull the shade toward the front of the vehicle to close it.




HEATED REAR SEATS*

The rear seat heat controls are located on the rear door armrest. To operate the heated seats, push the indicated side of the control for maximum or minimum heat. Push again to deactivate.



ADJUSTABLE HEAD RESTRAINTS

The front head restraints can be adjusted to suit your needs. Simply pull up to raise the head restraint. To lower, press the head restraint down while pressing and holding the guide sleeve adjust/release button. You may also be able to tilt the head restraint forward or backward for additional comfort. Pivot the head restraint forward to the desired location. After the head restraint reaches the forward-most tilt position, pivot it forward again to return it to the standard position.



CENTER CONSOLE*

Your vehicle may be equipped with a variety of console features. These include:

- Locking storage compartment with hanging file folder supports and room for a laptop computer, binder or book; removable false bottom tray for accessing hidden storage compartment; and storage on the passenger side of the console bin.
- One 12-volt power point inside the storage compartment and one on the rear of the console; and a 110-volt AC power point outlet on the rear of the console.

ESSENTIAL INFORMATION



DIESEL FUEL RECOMMENDATIONS

Ford recommends that you use only the diesel fuels that meet either the ASTM D975 diesel or the ASTM D7467 B6-B20 biodiesel industry specifications. Outside of North America, use fuels meeting EN590 or equivalent local market standard.

Diesel fuel is adjusted seasonally for colder temperatures. For best results at temperatures below 20°F (-7°C), it is recommended to use a diesel fuel that has been seasonally adjusted for the weather.

DIESEL EXHAUST FLUID (DEF) LEVEL

To help reduce emission levels from the exhaust of the diesel engine, your vehicle is equipped with a selective catalytic reduction (SCR) system that relies upon diesel exhaust fluid (DEF) to operate properly. The SCR automatically injects DEF into the exhaust system to enable proper SCR function. Make sure that you check your vehicle's DEF level during the oil change service interval, but certain conditions or driving styles, such as trailer towing or fast rates of acceleration, will require the refilling of the DEF tank more often. See the scheduled maintenance information in your Diesel Supplement for more information.

FUEL TYPE/TANK CAPACITY/FLEX FUEL*

Depending on your vehicle, your fuel tank size varies based on body style and/or engine configuration. Refer to the *Capacities and Specifications* section in your *Owner's Manual* for more details.

Flex fuel vehicles have a yellow ring around the top of the fuel filler inlet (tube) and can use either regular unleaded fuel or E85 ethanol fuel.

It is best not to alternate repeatedly between gasoline and E85. If you do switch fuels, it is recommended that you add as much fuel as possible—at least half a tank. Do not add less than five gallons (18.9 liters) when refueling. You should drive the vehicle immediately after refueling for at least 5 miles (8 km) to allow the vehicle to adapt to the change in ethanol concentration. If you exclusively use E85 fuel, it is recommended to fill the fuel tank with regular unleaded gasoline at each scheduled oil change.

If you do not have a flex fuel vehicle, then only use "Regular" unleaded gasoline with an octane rating of 87. Do not use E85 fuels, because your vehicle was not designed to run on fuels with more than 15% ethanol.

FUEL-EFFICIENT TRANSMISSION*

Your vehicle has been designed to improve fuel economy by reducing fuel usage while coasting or decelerating. This may be perceived as a light to medium braking sensation when removing your foot from the accelerator pedal.

SOS POST-CRASH ALERT SYSTEM™

The SOS Post-Crash Alert System™ provides audible and visual alarms in the event of a crash which causes the deployment of airbags or the activation of the safety belt pretensioners. The turn signals will flash and the horn will sound. To deactivate the system, press the hazard flasher control, or you can press on your remote transmitter.

BRAKE OVER ACCELERATOR (BOA) FEATURE

In the event that the accelerator pedal becomes stuck or entrapped, BOA will reduce engine power when the brake pedal is applied. Drivers who rest a foot on the brake pedal while pressing the accelerator pedal may activate BOA. See your *Owner's Manual* for complete details.

TIRE PRESSURE MONITORING SYSTEM*

Your vehicle has been equipped with a **tire pressure monitoring system (TPMS)** that illuminates a low tire pressure warning light (⚠) when one or more of your tires is significantly under-inflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the *Wheels and Tires* chapter in your *Owner's Manual* for more information.

LOCATION OF SPARE TIRE AND TOOLS*

If your vehicle is equipped with a spare tire, jack and associated tools, refer to the following table for their locations:

Tool	Location
Spare tire (pick-up trucks only)	Under the vehicle, just forward of the rear bumper.
Jack	Regular cab and Crew Cab: fastened to the floor pan behind rear-most seat on passenger side; SuperCab: under the rear bench seat on the passenger side.
Jack handle, lug wrench, lug wrench extension (only available on Dual Rear Wheel [DRW] vehicles) and wheel chock (only available on Single Rear Wheel [SRW] vehicles equipped with a diesel engine)	Regular cab: fastened to the floor behind the driver seat SuperCab: under the passenger side rear bench seat Crew Cab: fastened to the floor behind the driver's side rear seat

For complete details on how to change your tire, refer to the *Roadside Emergencies* chapter in your *Owner's Manual*.

ROADSIDE ASSISTANCE

Your new Ford Super Duty® comes with the assurance and support of 24-hour emergency roadside assistance. To receive roadside assistance in the United States, call 1-800-241-3673. In Canada, call 1-800-665-2006.

FUNCTION

ADVANCETRAC® WITH ROLL STABILITY CONTROL™ (RSC®) STABILITY ENHANCEMENT SYSTEM*

The AdvanceTrac® stability system helps you to maintain stability and steer-ability of your vehicle during a variety of road conditions. If your vehicle becomes stuck in the snow, mud or sand, try turning off the AdvanceTrac® system to allow wheel spin and help increase momentum to dig the vehicle out. Press the control to turn the system off. Refer to your *Stability Control* chapter in your *Owner's Manual* for more details.



REAR VIEW CAMERA SYSTEM*

Located under the Ford oval badge on the tailgate, this camera provides a visual display of the area behind the vehicle. The display will automatically appear in the navigation system screen* or in the auto dimming rearview mirror whenever the vehicle is in R (Reverse) and uses colors (green, yellow and red) to alert you of your proximity to objects. If equipped with the navigation system, you can also press *Zoom* to zoom in or out.



Note: *Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your Owner's Manual for safety information, more detail and limitations.*

ONE-TOUCH UP OR DOWN (FRONT WINDOWS)

This feature automatically opens or closes the window. Press or lift the switch completely and release. The window will fully open or close. Press or lift it again to stop the window.

Note: *The window may be disabled for up to five minutes if it is cycled up and down repeatedly. This helps prevent damage to the motor. Normal operation will resume once the motor cools.*

REVERSE SENSING SYSTEM*

The sensing system, only active when the transmission is in R (Reverse), warns the driver of obstacles within a certain range of the rear bumper area. It sounds a warning tone if there is an object behind the vehicle. The tone will sound continuously when the object is less than 12 inches (30 centimeters) away. The system is not effective when the vehicle is traveling above 3 mph (5 km/h) and may not detect angular or moving objects.

Note: *Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your Owner's Manual for safety information, more detail and limitations.*

